

REVISION

LATEST REVISED PAGES SUPERSEDE THE SAME PAGES OF PREVIOUS DATE

Insert revised pages into basic publication. Destroy superseded pages.

11601A

Reproduction for non-military use of the information or illustrations contained in this publication is not permitted without specific approval of the issuing service (BuAer or USAF). The policy for use of Classified Publications is established for the Air Force in AFR 205-1 and for the Navy in Navy Regulations, Article 1509.

LIST OF EFFECTIVE PAGES

INSERT LATEST REVISED PAGES. DESTROY SUPERSEDED PAGES.

NOTE: The portion of the text affected by the current revision is indicated by a vertical line in the outer margins of the page.

This Publication Consists of the Following Pages:

| Title & A Page | 4-1 thru 4-44 | 8-1 thru 8-4 |
|----------------|---------------|--|
| i thru iv | 5-1 thru 5-12 | 9-1 thru 9-16 |
| 1-1 thru 1-56 | 6-1 thru 6-12 | A-1 thru A-78 |
| 2-1 thru 2-36 | 7-1 thru 7-4 | X-1 thru X-6 |
| 3_1 then 3_32 | | 20 10 4000000000000000000000000000000000 |

| Page | Date of Latest | Page | Date of Latest |
|--|----------------|------|----------------|
| No. | Revision | No. | Revision |
| iv | 2 January 1957 | 2–14 | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 May 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 May 1957 | | 2 May 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 May 1957 | | 2 January 1957 |
| | 2 May 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 May 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| The second secon | 2 January 1957 | | 2 May 1957 |
| | 2 January 1957 | | 2 May 1957 |
| | 2 January 1957 | | 2 May 1957 |
| | 2 January 1957 | 12 | 2 January 1957 |
| | 2 January 1957 | | 2 May 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 October 1956 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | 2 January 1957 | | 2 January 1957 |
| | | | |

* The asterisk indicates pages revised, added or deleted by the current revision.

ADDITIONAL COPIES OF THIS PUBLICATION MAY BE OBTAINED AS FOLLOWS:

USAF

USAF ACTIVITIES.—In accordance with Technical Order No. 00-5-2.

NAVY ACTIVITIES.—Submit request to nearest supply point listed below, using form NavAer-140; NASD, Philadelphia, Pa.; NAS, Alameda, Calif.; NAS, Jacksonville, Fla.; NAS, Norfolk, Va.; NAS, San Diego, Calif.; NAS, Seattle, Wash.; ASD, NSC, Guam.

TABLE OF CONTENTS

| Section I | DESCRIPTION1-1 |
|--------------|---|
| Section II | NORMAL PROCEDURES2-1 |
| Section III | EMERGENCY PROCEDURES3-1 |
| Section IV | DESCRIPTION AND OPERATION OF AUXILIARY EQUIPMENT4-1 |
| Section V | OPERATING LIMITATIONS5-1 |
| Section VI | FLIGHT CHARACTERISTICS6-1 |
| Section VII | SYSTEMS OPERATIONS |
| Section VIII | CREW DUTIES8-1 |
| Section IX | ALL WEATHER OPERATION9-1 |
| Appendix I | PERFORMANCE DATAA-1 |
| Index | X-1 |



SCOPE

This handbook contains all the information necessary for safe and efficient operation of the B-57B airplane. These instructions do not teach basic flight principles, but are designed to give a general knowledge of the airplane, its flight characteristics, and specific normal and emergency operating procedures. Your flying experience is recognized, and elementary instructions have been avoided.

SOUND JUDGMENT

The instructions in this handbook have been prepared to answer the needs of a crew with no experience in the operation of this airplane. Although this book provides the best possible operating instructions under most circumstances, it is a poor substitute for sound judgment. Multiple emergencies, adverse weather, and terrain may require modification of the procedures contained herein.

PERMISSIBLE OPERATIONS

The Flight Handbook is positive in approach and normally tells you only what you are permitted to do. Any unusual operation is prohibited unless specifically covered. Obtain clearance from ARDC before attempting any questionable operation not specifically covered in the Flight Handbook.

STANDARDIZATION


Once you have learned to use one Flight Handbook, you will know how to use them all. The scope and arrangement of all Flight Handbooks are the same.

ARRANGEMENT

To make the Flight Handbook easy to read and use as a reference, the information has been divided into ten sections, each having a table of contents. The first three sections present the minimum information needed to get the airplane off the ground and back down again safely. These sections must be read thoroughly and understood fully before a new airplane is to be flown. Section IV covers all equipment not essential to flight but which permits the airplane to perform special functions. The content of the remaining sections is obvious, except for Section VII, which contains detailed information on techniques and theory of operation. The experienced pilot need not study this section, but he should acquaint himself with any possible new information.

RESPONSIBILITY

These Flight Handbooks are kept up to date through an extremely active revision program. Frequent conferences with operating personnel and constant review of UR's, accident reports, and flight test reports assure inclusion of the latest data. In this regard, it is essential that you do your part! If you find anything you don't like about this book, let us know right away. We cannot correct an error we don't know about.






PERSONAL COPIES

All flight crew members, except those attached to an administrative base, are entitled to a personal copy of the Flight Handbook. Air Force Regulation 5-13 specifically makes that provision. Flexible loose-leaf tabs and binders are available to hold your personal copy of the Flight Handbook and to make it much easier for you to revise your handbook and keep it in good condition. These tabs and binders are secured through your local contracting officer.

HOW TO GET COPIES

To be sure of getting your handbook on time, order them before you need them. Early ordering will assure that enough copies are printed to cover your requirements. Technical Order 0-5-2 explain how to order Flight Handbooks so that you will automatically get all revisions, reissues, and Safety of Flight Supplements. Basically, all you have to do is order the required quantities in the Publication Requirements Table (T.O. 0-3-1). Talk to your base supply officer—it is his job to fulfill your Technical Order requests. Make sure to establish some system that will rapidly get the books to the flight crews once they are received on the base.




STATUS OF SAFETY OF FLIGHT SUPPLEMENTS

You can determine the status of Safety of Flight Supplements by referring to the Index of Technical Publications (T.O. 0-1-1) and the Weekly Supplemental Index (T.O. 0-1-1A). Also check the title page of the Flight Handbook and the title block of each new Safety of Flight Supplement to determine how these publications affect existing Safety of Flight Supplements.

WARNINGS, CAUTIONS AND NOTES

The warnings, cautions, and notes found throughout the handbook have these meanings:



Injury to personnel



Damage to equipment

Note:

Information requiring emphasis

COMMENTS AND QUESTIONS


Comments and questions regarding any phase of the Flight Handbook program are invited and should be addressed to the Directorate of Systems Management, Headquarters Air Research and Development Command, Wright-Patterson Air Force Base, Ohio, Attention: RDZSTH.

NOTE

Paragraphs covering major system and equipment differences in the B-57 series airplanes are identified by code letters appearing at the top right corner of the paragraph. Code letters and/or text will be removed or changed in subsequent revisions as field service changes are incorporated. Code letters are assigned as follows:

| Α | 52-1493 thru 52-1575 | 50 cal. guns |
|-------|------------------------------------|---|
| В | 52-1576 and up | 20 MM guns |
| С | 52-1493 thru 53-3930 | Fuel Panel |
| D | 53-3931 and up | Fuel Panel |
| E | 52-1493 thru 53-3865 | Ejection system |
| F | 53–3866 and up | Ejection system |
| G | 52-1493 thru 53-3904 | Radio compass |
| Н | 53-3905 and up | Radio compass |
| I STO | 52-1493 thru 53-3881 | Labs |
| 1 | 53—3882 and up | Labs |
| K | 52-1493 thru 53-3891 | Interim Warning System |
| L | 53-3892 and up | Interim Warning System |
| M | 52-1493 thru 53-3947 | Rocket Firing Order |
| N | 53-3948 and up | Rocket Firing Order |
| 0 | Before Modification (all Aircraft) | Elevator System and Stabilizer Trim System |
| P | After Modification (all Aircraft) | Elevator System and Stabilizer Trim System |
| Q | After Modification (all Aircraft) | Fuel Panel |

| Section I Description | This section describes the airplane and all systems and controls that contribute to the physical act of flying the airplane. Included in this section is a description of a emergency equipment that is not a part of an auxiliary system. |
|---|--|
| Section II Normal Procedures | This section contains the procedure to be followed from the time the flight is planne until the airplane is left parked on the ramp after one complete non-tactical missic under normal conditions has been made. |
| Section III Emergency Procedures | This section describes clearly and concisely the procedures to follow for any eme gency (except those in connection with the auxiliary equipment) that could reasonab be expected to be encountered. |
| Section IV Description and Operation of Auxiliary Equipment | This section includes the description, normal operation, and emergency operation all equipment not directly contributing to flight but which enables the airplane perform certain specialized functions. |
| Section V Operating Limitations | This section sets out the various ground and flight limitations which must be observe if the airplane is to be operated with safety and efficiency. |
| Section VI Flight Characteristics | This section familiarizes the pilot with the sort of control response and gener maneuverability that he may reasonably expect in flying this airplane. It emphasizes the characteristics that are different from other airplanes. |
| Section VII Systems Operation | This section gives additional information (to that covered in the other sections) abo the operation of the various airplane systems. |
| Section VIII Crew Duties | This section contains an explanation of the responsibilities of each crew memb toward the safe and efficient operation of the airplane. It lists the duties and resposibilities of these crew members. |
| Section IX All-Weather Operation | This section outlines the proper techniques and procedures to be used in unusual unique weather conditions. The instructions in this section supplement the procedure outlined in Section II, III, and VII. |
| Appendix I Performance Data | The appendix contains all performance data necessary for prefight and in-flig missions planning with explanatory text on the use of the data. |
| Alphabetical Index | This index facilitates locating subject material and illustrations contained in the |



Section I



DESCRIPTION

11608

TABLE OF CONTENTS


| | Page | | Page |
|------------------------------|------|------------------------|------|
| THE AIRPLANE | 1-1 | HYDRAULIC SYSTEM | 1-25 |
| ENGINES | 1-6 | FLIGHT CONTROL SYSTEMS | 1-29 |
| ENGINE FUEL SYSTEM | | LANDING GEAR SYSTEM | 1-35 |
| STARTING AND IGNITION SYSTEM | | BRAKE SYSTEM | 1-38 |
| OIL SYSTEM | | INSTRUMENTS | 1–38 |
| | | EMERGENCY EQUIPMENT | 1-39 |
| AIRPLANE FUEL SYSTEM | 1–12 | CANOPY | 1-39 |
| ENGINE INSTRUMENTS | 1-20 | EJECTION SEATS | 1-50 |
| ELECTRICAL SYSTEM | 1–20 | FIRE PROTECTION | 1-53 |

THE AIRPLANE.

The B-57B, manufactured by the Martin Company, is a light bombardment airplane. The mission of the B-57B is the destruction of surface military targets during night tactical operations. The B-57B is an all-metal, mid-wing, twin-engine, turbo-jet-propelled monoplane with retractable landing gear. Design

features include a variable-incidence stabilizer, wing and fuselage dive brakes, and a rotary bomb door. The fuselage is of semi-monocoque construction with a pressurized cabin for operation at altitudes above 10,000 feet. The outstanding recognition characteristic of the B-57 series of airplanes is the large chord of the wing between the root and the engine nacelle.

general arrangement




- 1. ANTENNA APG-31
- ACCESS HATCH APG-31 SPARE LAMPS STOWAGE
- WINDSHIELD WIPER
 PILOT'S MAP CASE

- 7. GLARE SHIELD 8. OBSERVER'S TABLE
- 6. PILOT'S EJECTION SEAT
- 9. OBSERVER'S EJECTION SEAT 10. OXYGEN CONVERTER 11. LOOP ANTENNA 12. GUN PORTS

- EXTERIOR LIGHTS
- 14. WING DIVE BRAKES
- 15. ANTENNA AN/APW-11A
- 16. LIGHT LENS STOWAGE

- 17. STARTER CARTRIDGE STOWAGE
- 18. MAST ANTENNA AN/ARN-6
 19. MOORING AND TIE DOWN LUGS,
 INITIATOR LOCK PIN, AND LANDING GEAR EXTENDER VALVE STOWAGE
- 20. TAIL WARNING ANTENNA 21. MARKER BEACON AN/ARN-12
- 22. SHORAN ANTENNA



- 23. FUSELAGE DIVE BRAKES

- 23. FUSELAGE DIVE BRAKES
 24. CANOPY SAFETY COLLAR STOWAGE
 25. AFT FUSELAGE DATA CASE
 26. AFT FUSELAGE ACCESS HATCH
 27. FRANGIBLE DOORS
 28. BOMB CARRIER DOOR
 29. BOMB HOIST DOOR ACCESS DOORS (8)
 30. BATTERY AND BATTERY ACCESS HATCH
 31. LEFT ELECTRICAL ACCESS HATCH
 32. IEFF ANTENINA AN/APX—6A

- 32. IFF ANTENNA AN/APX-6A 33. EQUIPMENT ACCESS HATCH

- 34. OBSERVER'S DATA CASE
 35. RIGHT ELECTRICAL ACCESS HATCH, EXTERNAL POWER
 RECEPTACLE, AND SPARE LAMPS STOWAGE
 36. OBSERVER'S RELIEF TUBE
 37. UHF ANTENNA AN/ARC-27

- 38. PILOT'S DATA CASE 39. SHORAN RECEIVING ANTENNA
- 40. PILOT'S RELIEF TUBE
- 41. GUNSIGHT
 42. STATIC PLATE
 43. PITOT TUBE

Figure 1-1 (Sheet 2 of 2)

MAIN DIFFERENCES TABLE

| MODEL | B-57A | RB-57A | B-57B | B-57C | RB-57D | B-57E |
|--------------------------------------|-----------------------|------------------------|--|--|---------------|---|
| CREW STATIONS | three | three | two | two | | two |
| CANOPY | pilot (fixed) | pilot (fixed) | pilot and observer (clam shell) | pilot and instructor pilot (clam shell) | | pilot and tow- target operator (clam shell) |
| JETTISONABLE HATCH | observer | observer | none | none | | none |
| ENTRANCE | access hatch | access hatch | canopy | canopy | | canopy |
| PHOTOGRAPHIC EQUIPMENT | none | day or night operation | none | none | CLA | none |
| DIVE BRAKES | wing (finger type) | wing (finger type) | wing (finger type) fuselage (flap type) | wing (finger type) fuselage (flap type) | CLASSIFIED IN | wing (finger type) fuselage (flap type) |
| FLIGHT AND PROPULSION CONTROLS | pilot | pilot | pilot | pilot and instructor pilot | INFORMATION | pilot and tow-target operator |
| NO. OF GENERATORS | two | three | four | four | LION | four |
| ARMAMENT AND BOMB DOOR | yes | bomb door only | yes | yes | | . provisions for |
| TOW TARGET EQUIPPED | по | no | no | 53-3844 and 53-3845 only | | yes |
| NOSE | transparent | transparent | opaque | opaque | | opaque |

- 1. AFT FUSELAGE COMPARTMENT
- 2. ELECTRONIC COMPARTMENT
- 3. BOMB BAY
- 4. L.H. GUN BAY, 50 CALIBER GUNS. (GROUP A)
- 5. OBSERVER'S EJECTION SEAT
- 6. PILOT'S EJECTION SEAT

- 7. FIRE CONTROL EQUIPMENT COMPARTMENT
- 8. R.H. ELECTRICAL ACCESS COMPARTMENT
- 9. EQUIPMENT COMPARTMENT
- 10. BATTERY COMPARTMENT
- 11. R.H. GUN BAY, 50 CALIBER GUNS. (GROUP A)
- 12. 20 MM GUNS (GROUP B)




Figure 1-3

FUSELAGE AND WING.

The nose section contains the pressurized cabin for the crew. The crew consists of a pilot and observer and the tandem seating arrangement places the observer to the rear of the pilot. A jettisonable canopy and ejection seats permit immediate escape for the crew. The center section of the fuselage contains the main fuel tanks, the rotary bomb door, the battery compartment, and electrical equipment. The aft fuselage section contains dive brakes, electronic equipment, and miscellaneous ground handling equipment. A skid on the underside of the tail section prevents damage to the tail during landings. The full-cantilever wing has dive brakes, inboard and outboard split

flaps, fuel tanks, fixed wing guns, and provisions for tip tanks and external stores.

AIRPLANE DIMENSIONS.

The overall dimensions of the airplane are:

| 1 | |
|-------------------------------------|-----------|
| Wing Span | 64.0 ft. |
| Length | 65.5 ft. |
| Horizontal Stabilizer Span | 27.8 ft. |
| Height (to top of fin) | |
| Ground clearance to bottom of fuse- | |
| lage for maximum gross weight | 19.2 in. |
| Ground clearance to bottom of tip | |
| tanks for maximum gross weight. | . 5.4 ft. |




Figure 1-4

AIRPLANE GROSS WEIGHT.

The approximate maximum gross weight of the airplane is 55,000 pounds. Refer to Section V for weight information.

ARMAMENT.

Airplane armament consists of fixed guns in the wings, a rotary bomb door; wing pylons for chemical tanks, bombs, and rockets; and special weapons equipment.

ENGINES.

Two J65-W-5 or J65-BW-5 turbo-jet engines (figure

1-4) power the airplane. Each engine has a rated sea-level static thrust of 7200 pounds for take-off and military power and 6350 pounds for normal continuous power. During operation, air enters the intake duct and flows through a 13-stage axial-flow compressor. The compressed air passes into a single annular combustion chamber where it mixes with fuel for combustion. Continuous ignition is sustained by the high combustion chamber temperature. Partial expansion of the gases through a two-stage turbine produces the mechanical power that drives the compressor. Progressive expansion of the exhaust gases in the exhaust duct produces a high-velocity jet that propels the airplane. There is no anti-icing equipment on the engines.

THROTTLES.

The throttles (figure 1–5) are on the pilot's left horizontal console. Throttle markings are OFF, IDLE, and FULL. Throttle movement out of OFF and from IDLE to OFF requires a vertical pull to disengage the stud on the throttle handle from detents in the quadrant. Throttle movement mechanically positions the governor in the fuel control unit. Placing the throttles in IDLE closes the warning horn, landing gear warning light, and engine start micro-switches. The dive brake switch (on later airplanes) and a microphone press-to-talk button are on the inboard throttle lever. An adjustable throttle friction knob is on the console below the throttles. The maximum force necessary to overcome the throttles with the friction lock engaged does not exceed 17 pounds.


ENGINE FUEL SYSTEM.

The engine fuel system (figure 1-6) consists of a pump assembly, a fuel control unit, a flow transmitter, six flow dividers, and two primers. The pump assembly has three engine-driven pumps: a centrifugal boost pump and two gear-type pumps. The centrifugal boost pump receives fuel from the airplane's fuel system and delivers it to the main, gear-type pumps. The main pumps supply the fuel control unit with fuel under pressure ranging from 175 psi (at IDLE) to 600 psi (at FULL). The main pumps are in parallel and each pump has a discharge check valve that permits continued operation of one pump if the other fails. Either pump supplies enough fuel to the engine for maximum speed and power. Failure of the centrifugal pump does not cause a loss of engine power unless the fuel tank boost pumps are inoperative also. The fuel control unit automatically regulates the flow of fuel to the engine for any throttle setting at any altitude. Regulated fuel from the control unit enters the flow dividers and the flow dividers direct fuel to the nozzles in the combustion chamber. For starting, fuel flows to the combustion chamber through the primer circuits. A flow measuring mechanism at the fuel control unit outlet has a transmitter that operates the fuel flow indicator on the pilot's instrument panel.

ENGINE FUEL CONTROL UNIT.

By regulating the amount of fuel, the fuel control unit governs the speed of the engine for a given throttle setting. The unit is a composite of several independently operated valves and each valve contributes to the regulation of the fuel. A filter at the control unit inlet protects the unit from any dirt in the fuel. If the filter becomes clogged, the filter relief valve opens and bypasses the fuel. A pressure relief valve relieves excessive pressure within the control unit. The regulator valve, operated by an engine-driven flyweight governor, works in conjunction with the

throttles



11613

Figure 1-5

bypass valve to regulate the fuel pressure within the control unit. The compensating devices give a fine adjustment to the pressure within the control unit. These devices compensate for altitude and engine air inlet temperature. The compressor discharge pressure limiter causes the fuel bypass valve to open when compressor discharge pressure exceeds a certain value. This results in a reduction in rpm to maintain compressor discharge pressure limits. Fuel leaves the control unit through the governor valve, which is the main metering unit. An engine-driven flyweight governor and the throttle position the governor valve. Metered fuel from the governor valve passes through a cut-off valve and a pressurizing check valve to the fuel distribution system of the engine. When the throttle is closed (OFF), the cut-off valve prevents any fuel from leaving the control unit. An engine speed of approximately 18 percent is necessary to supply the pressure necessary (100 psi) to open the pressurizing check valve. Since the pressurizing check valve restricts the flow of fuel during starting, fuel flowing through the primer circuit is the only fuel supply. The compressor pressure rise limiter causes the bypass valve to open when the compressor discharge pressure exceeds a certain value. The opening of the bypass valve causes a reduction of fuel flow from the control unit and a correspond-




Figure 1-6

ing reduction in rpm to maintain the compressor discharge pressure below the limit. An electrically controlled bypass within the unit directs fuel from the main pumps directly to the engine. Since this "emergency line" bypasses all of the regulating and governing devices within the control unit, an emergency throttle valve is the only control of the bypassed fuel. The electrical power for the emergency system comes from the 28-volt pilot's circuit breaker bus.

EMERGENCY FUEL CONTROL SWITCHES.

The switches that control the emergency bypass line in the fuel control unit are on the fuel control panel. (See figure 1–7.) The switch markings are OFF and EMERGENCY. When the switch is in OFF, the emergency fuel control is inoperative. Placing the switch in EMERGENCY actuates three solenoid-operated valves that close the normal fuel passage in the fuel control unit, open the emergency passage, and isolate the compressor limiter. Placing an emergency fuel control switch in EMERGENCY causes the indicater light above the switch to illuminate. There is no automatic changeover to the emergency system; the switch must be manually placed in the EMERGENCY position to activate the system.

Note

It is permissible to transfer to the emergency fuel system with the throttle in FULL up to an altitude of 6000 feet, provided the engine speed has not dropped below 85% at the time of the transfer. Under all other conditions, the throttle lever must be in IDLE prior to the transfer. Failure to do so will result in excessive exhaust gas temperatures and rich flame-out or compressor stall.

EMERGENCY FUEL CONTROL INDICATOR LIGHTS.

There are two amber press-to-test indicator lights on the fuel control panel above the emergency fuel control switches. (See figure 1–7.) When the emergency fuel control switch is placed in EMERGENCY, its respective indicator light illuminates. Power to operate the lights comes from the pilot's 28-volt d-c circuit breaker bus.

ENGINE COOLING SYSTEM.

During flight, ram air enters four screened circular openings and two flush airscoops on the inside surface of the engine air intake duct. (See figure 1-8.)

Air entering the screened openings cools the forward engine area and exhausts through flush slots forward of the firewall. Air entering the two airscoops cools the aft engine area. Aft engine cooling air exhausts

emergency fuel control switches and lights




Figure 1-7

through the area between the tail pipe and the nacelle. Ground engine operation creates low-pressure areas between the engine and cowling and between the tail pipe and nacelle, thus causing reverse air flow for ground engine cooling. Air entering the flush slots in the cowling flows forward around the engine and passes through the four screened openings in the nose cowl and exhausts through the engine. Extension of the landing gear opens the cowl doors allowing air to enter and cool the aft engine area. Part of this air flows forward through the ducts forward of the firewall and exhausts through the engine. The remaining air exhausts aft around the tailpipe.

Note

If either engine ground-cooling door remains open in flight, premature airframe buffet will generally occur considerably below the normal buffet limit, and a moderate yaw will be noticeable at about 350 knots or above.




Figure 1-8

STARTING AND IGNITION SYSTEM.

Each engine has its own starting and ignition system. The systems consist of two high-tension igniters, a timer-box assembly, two fuel-primer solenoids, and an explosive-cartridge starter. Placing the throttle in IDLE closes the throttle-actuated engine start microswitch. Placing the STARTING AND IGNITION switch in START completes the circuit to the timer, igniters, fuel primer solenoid, and the explosive cartridge in the starter breech (figure 1-9) starts the engine. After 15 ± 3 seconds, the timer automatically de-energizes the fuel primers and igniters. At the end of the timing cycle, engine temperature and acceleration are sufficiently high for continued operation; therefore, the engine no longer requires ignition and fuel priming. For ground testing, the engine may be motored without combustion. Retaining the throttle in OFF stops the flow of fuel to the engine. The cranking circuit bypasses the throttle microswitch and energizes the timer, the igniters, and the cartridge.

Note

Distinct clicks heard over the interphone system or from outside the airplane indicate proper functioning of the ignition system.

The 28-volt d-c circuit breaker bus supplies the power to operate the system through a 15-ampere circuit breaker.

STARTING AND IGNITION SWITCHES.

Two starting and ignition switches and a microswitch (figure 1-10) for each throttle control the starting and ignition systems. The starting and ignition switches are on the inverter control panel on the pilot's right vertical console. The switch positions




Figure 1-9

starting and ignition switches




Figure 1-10

are START (up), OFF (center), and CRANK ONLY (down). The switch is spring-loaded to the OFF position. Placing the throttle in IDLE and the starting switch in START completes the starting and ignition circuit. Placing the switch in the CRANK ONLY position bypasses the throttle microswitch to complete the starting and ignition circuit. Leaving the throttle in OFF prevents fuel flow to the engine. The CRANK ONLY position is for engine restarts in flight. By using CRANK ONLY, the ignition circuit operates prior to the introduction of fuel into the combustion chamber. Refer to ENGINE RESTART IN FLIGHT in Section III.

STARTER OVER-PRESSURE PROTECTION.

Although the starter is designed to withstand some excess pressure, a safety device guards against dangerously high pressures. The pressure-relief device is an integral part of the breech consisting of a blowout disc which ruptures at approximately 1½ times normal operating pressure. When the disc shears, the gas bypasses the starter turbine wheel and flows into the turbine ducting, and the indicator pin is released, detonating the sheared disc. The excessive pressure is then vented out the exhaust port. During a blowout disc rupture, little or no rpm indication appears on the tachometer.

OIL SYSTEM.

Each engine has an automatic integral oil system consisting of an oil tank, an oil pump assembly, and self-contained plumbing. The oil tank is on the upper left side of the engine compressor section. Oil from the tank is delivered to the pump assembly which consists of one pressure pump, a scavenger pump, and two oil metering pumps. A circulating oil system is used for the front bearing and accessory drives and a total-loss system for the center and rear bearing.

The oil tanks do not have dipsticks and require inspection and servicing following engine shutdown. The servicing diagram (figure 1–44) lists the oil grades and specifications. For oil capacities see figure 1–11. For operating oil pressure refer to figure 5–1. Oil consumption will normally run about one quart per hour. Although the oil system supplies oil during inverted flight, sudden negative G maneuvers may cause the oil pressure to drop to very low values, and several seconds may be required to recover normal pressures. For OIL-PRESSURE FAILURE procedure, refer to Section III.

AIRPLANE FUEL SYSTEM. (GROUP C AIRPLANES)

The airplane has four internal fuel tanks (figure 1-12), two in the fuselage and one in each wing. In addition wing-tip tanks supplement the normal fuel supply. The tip tanks are held on the wing by explosive bolts that explode to jettison the tanks in an emergency. If required, a ferry tank may be installed on the bomb door to carry additional fuel. The fuel system consists of fuel boost pumps, shut-off valves, a transfer valve, and a fuel-level shut-off valve. The knobs and switches on the fuel control panel control the fuel system. The fuselage lines and components are arranged for minimum vulnerability. The internal tanks have boost pumps at their outlets. A switch on the fuel control panel controls the No. 1 fuselage tank boost pumps. The No. 2 fuselage tank and wing tank boost pumps operate when their respective tank is selected. The tip tanks transfer fuel by means of compressed air from the engine compressors. Compressed air is supplied continuously when the engines are running. The pressure in the tip tank is controlled by a pressure-sensing check valve. If the pressure in the tanks exceeds five psi, the air is discharged overboard through a relief valve. Motor

oil quantity data




Figure 1-11

operated shut-off valves, located throughout the system, control fuel flow from the tanks to the engines. During normal operation of the fuel system, fuel flows from the No. 2 fuselage tank, the wing tanks, and the tip tanks through the auxiliary manifold (collector) to the No. 1 fuselage tank and then through the main manifold (collector) to the engines. If necessary, the No. 1 fuselage tank may be bypassed and fuel transferred from any tank directly to the engines.

A fuel-level shut-off valve in the No. 1 fuselage tank mechanically closes the tank inlet line from other tanks when fuel in the tank reaches a near full level. When fuel is transferred to the No. 1 fuselage tank the replenishment rate is sufficient to keep the No. 1 fuselage tank at least three-quarters full at all times during transfer. (See FUEL MANAGEMENT in Section VII.) There is a schematic flow diagram of the fuel system on the fuel control panel. The power to operate and control the system comes from the pilot's 28-volt d-c circuit breaker bus and the generator bus. There is a fuel-quantity indicator for each internal fuel tank. The tip tanks contain a low-level warning system. Each tank except the ferry tank has an access for ground refueling. Tank quantities are shown in figure 1-13.

AIRPLANE FUEL SYSTEM. (GROUP D AIRPLANES)

The fuel control panel comprises the only difference between the Group C and D airplane fuel systems. See figure 1-14 for panel layout.

(GROUP Q AIRPLANES)

The removal of the No. 1 fuselage tank boost pump indicator light from Group D airplanes and the installation of the No. 1 fuselage tank low-level warning light on Group Q airplanes comprises the only difference between Group D and Q airplanes. See figure 1–14 for panel layout.

FUEL SPECIFICATION.

Fuel specifications and grades, and fuel tank filler points are shown on the servicing diagram (figure 1-44).

FUEL CONTROLS. (See figure 1–14 for Group C, D, and Q panels.)

NO. 1 FUSELAGE TANK BOOST PUMPS

SWITCH. (GROUP C AIRPLANES)

The two boost pumps in the No. 1 fuselage tank are energized when the No. 1 fuselage tank booster pumps switch is on.

NO. 1 FUSELAGE TANK BOOST PUMP

INDICATOR LIGHT. (GROUP D AIRPLANES)
The red indicator light for the No. 1 fuselage tank
booster pumps illuminates when both No. 1 fuselage

tank boost pumps fail. The indicator light illuminates when the transfer and bypass valve knob is in the bypass position, when the No. 1 fuselage tank boost pump circuit breakers are in OFF, or when electrical malfunction causes both remote circuit breakers (power control for boost pumps and light relays) to trip off. The 28-volt d-c distribution bus supplies power to operate the indicator light and test circuits.

NO. 1 FUSELAGE TANK LOW-LEVEL WARNING LIGHT. (GROUP Q AIRPLANES)

A red low-level warning light on the fuel control panel illuminates when fuel quantity in the No. 1 fuselage tank decreases below 890 gallons (5800 pounds). The 28-volt distribution bus supplies the power to operate the warning and press-to-test circuits. ENGINE VALVE KNOBS.

(GROUP C AIRPLANES)

Two engine valve knobs control the fuel flow to the engines. Placing the No. 1 engine valve knob in the vertical (flow) position electrically opens the No. 1 engine shut-off valve in the main fuel manifold, permitting fuel to flow to the No. 1 engine. The No. 2 engine valve knob controls the No. 2 engine shut-off valve in a same manner. These valves are safetied to the flow position to prevent the pilot from turning the knobs OFF during flight. The knobs are painted with red and white stripes.

ENGINE VALVE SWITCHES.

(GROUP D AND Q AIRPLANES)

An engine valve switch controls the fuel flow to each engine. Switch markings are ON (up) and OFF (down). Placing the switches in ON opens the engine fuel shut-off valves. Placing the switches in OFF closes the engine fuel shut-off valves. The 28-volt d-c pilot's circuit breaker bus supplies power through a 5-ampere circuit breaker to operate the shut-off valves.

FUEL TRANSFER AND BYPASS VALVE KNOB. (GROUP C AIRPLANES)

The fuel transfer and bypass valve knob directs fuel flow to the No. 1 fuselage tank or directly to the engines. This knob is the fourth knob from the right on the fuel control panel. Aligning the transfer and bypass valve knob with the flow line leading into the No. 1 fuselage tank causes fuel in the auxiliary manifold to flow to the No. 1 fuselage tank. With the transfer and bypass valve knob set to the flow line leading directly to the engines, fuel in the auxiliary manifold bypasses the No. 1 fuselage tank. Placing the knob in OFF prevents fuel from entering the main fuel manifold. The 28-volt d-c pilot's circuit breaker bus supplies the power through a 5-ampere circuit breaker to operate the No. 1 fuselage tank transfer and bypass shut-off valves. The 28-volt d-c generator




Figure 1–12 (Sheet 1 of 2)




Figure 1–12 (Sheet 2 of 2)

fuel quantity data

IN U.S. GALLONS AND POUNDS

| TANKS | CONSTRUCTION | TOTAL | TOTAL FUEL | | TRAPPED FUEL | | TOTAL USABLE FUEL * | |
|----------------|--------------------------------|---------|------------|---------|--------------|---------|------------------------|--|
| TAI NO | CONSTRUCTION | GALLONS | POUNDS | GALLONS | POUNDS | GALLONS | POUNDS | |
| NO. 1 FUS TANK | SPLINTER PROOF SELF-SEALING | 1025.6 | 6667 | 15.6 | 102 | 1010 | 6565 | |
| NO. 2 FUS TANK | FLEXIBLE NON-SELF-SEALING | 666 | 4329 | 4 | 26 | 662 | 4303 | |
| R WING TANK | FLEXIBLE NON-SELF-SEALING | 291.5 | 1895 | 1.5 | 10 | 290 | 1885 | |
| L WING TANK | FLEXIBLE NON-SELF-SEALING | 291.5 | 1895 | 1.5 | 10 | 290 | 1885 | |
| R TIP TANK | METAL (ALU) | 320 | 2080 | o | o | 320 | 2080 | |
| L TIP TANK | METAL (ALU) | 320 | 2080 | 0 | 0 | 320 | 2080 | |
| BOMB METAL | METAL | 558 | 3627 | 10 | · 65 | 548 | 3562 | |
| | TOTAL | 3,472.6 | 22,571 | 32.6 | 213 | 3,440 | 22,360 | |

NOTE: NO EXPANSION SPACE IS PROVIDED AS EXPANSION SPACE IS ABOVE THE VENT OUTLET, THEREFORE, ANY EXPANSION WOULD DRAIN THROUGH THE VENT OUTLET. THE ABOVE FIGURES ARE FOR GROUND (STATIC) POSITION 0.9° NOSE UP.

*THESE QUANTITIES REPRESENT THE FUEL WHICH CAN ACTUALLY BE USED. QUANTITIES SHOWN ON THE FUEL CONTROL PANEL ARE SLIGHTLY LOWER TO AFFORD A SAFETY FACTOR.

ONE GALLON OF JP-4 FUEL IS EQUAL TO 6.5 LBS.

DATA BASIS FLIGHT TEST AS OF 9-30-55

116228

Figure 1-13

bus supplies the power to operate the No. 1 fuselage tank boost pumps.

FUEL TRANSFER AND BYPASS VALVE KNOB. (GROUP D AND Q AIRPLANES)

The fuel transfer and bypass valve directs fuel flow to the No. 1 fuselage tank or through the bypass line to the engines. Aligning the knob for flow to No. 1 tank directs all fuel to the No. 1 fuselage tank and turns on the No. 1 fuselage tank boost pumps. Aligning the knob to the bypass position turns off the No. 1 fuselage tank boost pumps, closes the valves to the No. 1 fuselage tank, and directs all fuel through the bypass line to the engines. Before the knob can be turned to a desired position, a pull is necessary to disengage the knob from detents.

FUEL PRESSURE WARNING LIGHT. (GROUP D AND Q AIRPLANES)


The red fuel pressure warning light indicates a reduction of fuel pressure in the main fuel manifold. When the pressure drops to $8.5\ (+1.5\ -0)$ psi, a pressure-sensing device causes the warning light to illuminate. A PRESS-TO-TEST circuit tests lamp operation. Power to operate the light is supplied by the 28-volt d-c distribution bus.

NO. 2 FUSELAGE TANK KNOB.

(GROUPS C, D, AND Q AIRPLANES)

The No. 2 fuselage tank knob controls the operation of the fuel shut-off valve and the two boost pumps for the No. 2 fuselage tank. With the knob in the flow position, the shut-off valve opens and the boost

fuel control panel



Group C Airplanes




Figure 1-14

pumps operate to supply fuel to the auxiliary manifold. With the knob in OFF, the boost pumps are de-energized and the shut-off valve is closed.

WING-TANK—TIP-TANK KNOBS. (GROUPS C, D, AND Q AIRPLANES)

Placing the left-wing-tank — left-tip-tank knob in line with the left-tip-tank flow lines, opens a valve that permits fuel to flow to the auxiliary manifold. When the knob is in this position, the wing-tank shut-off valve is closed and its boost pump is inoperative. Placing the knob in line with the left-wing-tank flow lines opens the left-wing-tank shut-off valve, energizes the tank boost pump and pumps fuel into the auxiliary manifold. With the knob in this position the left-tip-tank shut-off valve is closed. With the switch in OFF, both shut-off valves are closed and the boost pump is inoperative. The right-wing-tank — right-tip-tank knob selects fuel from the right-wing and wing-tip tanks in the same manner as the left-wing—left-tip-tank knob.

TIP-TANK LOW-LEVEL INDICATOR LIGHTS. (GROUPS C, D, AND Q AIRPLANES)

Two amber tip-tank low-level indicator lights, one for each tip tank, are on the fuel control panel. (See figure 1–14.) The fuel quantity gage does not indicate tip tank fuel quantity. The only indication of tip tank fuel quantity is the low-level indicator light that illuminates when the fuel quantity is below 195 pounds (30 gallons). The lights have a press-to-test circuit for testing lamp operation. Power for the light comes from the 28-volt d-c distribution bus.

Note

The tip-tank low-level indicator lights may come on during rapid descent or during negative G maneuvers. After a few seconds of level flight, the indicator lights will go out.

TIP-TANK JETTISON SWITCH.

Detonators explode the explosive bolts which secure the tip tanks to the wings to jettison the tip tanks. The guarded TIP TANK JETTISON switch controls tip tank jettisoning. Switch markings are TIP TANKS ONLY, NORMAL, and OFF. The switch is springloaded from TIP TANKS ONLY to NORMAL. The switch is on the pilot's left main control panel (panel 5, figure 1–39). Placing the switch in the momentary TIP TANKS ONLY position fires the explosive bolts and releases both tip tanks simultaneously. Depressing the master jettison switch, when the tip tank jettison switch is at NORMAL, causes the tip tanks to jettison. See MASTER JETTISON SWITCH in Section IV. Electrical power for firing the detonators comes from the 28-volt d-c distribution bus. A resistor is installed

in series with each detonator to prevent a short in any one detonator from affecting the other detonators.

FUEL QUANTITY INDICATOR.

The fuel quantity indicator (figure 1–31), on the pilot's main instrument panel, is a capacitance-type fuel gage which indicates the fuel quantity in each internal fuel tank individually or the total of all the internal tanks. The gage does not indicate the quantity of fuel in the tip tank. The indicator reflects the fuel quantity in pounds compensated for temperature, density, and airplane attitude so that the indication is a true indication of fuel quantity. The fuel quantity indicator shows the quantity of fuel in the tank selected by the fuel quantity selector switch. If the indicator is sticking, it can be checked with the fuel quantity test switch. Power for the indicator comes from the No. 1 inverter.

FUEL QUANTITY SELECTOR SWITCH.

The fuel quantity selector switch (figure 1-34), on the pilot's right horizontal console selects the tank or tanks whose fuel quantity is to appear on the fuel quantity indicator. By positioning the switch, the quantity of fuel in any internal tank or the total fuel in all the internal tanks is shown on the indicator.

FUEL QUANTITY TEST SWITCH.

The fuel quantity test switch, on the pilot's main instrument panel, is of the momentary type and checks any "sticking" condition of the fuel quantity indicator. (See figure 1-31.) Pressing the test switch causes the indicator pointer to rotate counterclockwise and thus relieve any sticking condition.

Note

The fuel quantity test switch acts slowly and must be held in FUEL QTY TEST for a few moments to ensure relieving any sticking condition.

FERRY TANK FILL SWITCH.

The ferry tank fill switch (figure 1–15) is on the pilot's right console. Switch markings are FILL VALVE OPEN and CLOSE. Placing the No. 2 fuselage tank selector knob to flow and the fill valve switch to OPEN turns on the No. 2 fuselage tank boost pumps and opens the fill valve, allowing fuel to be pumped from the No. 2 fuselage tank into the ferry tank. The 28-volt d-c pilot's circuit breaker bus supplies the power to operate the fill valve.

FERRY TANK BOOST PUMP SWITCH.

The ferry tank boost pump switch (figure 1–15) is on the pilot's right console. Switch markings are PUMP and OFF. Placing the switch in PUMP turns on the ferry tank boost pump, thereby pumping fuel from the ferry tank into the auxiliary fuel manifold. The 28-volt d-c pilot's circuit breaker bus supplies the power to operate the boost pump.

FERRY TANK FUEL LOW LEVEL INDICATOR LIGHT.

An amber PRESS-TO-TEST indicator light (figure 1–15) on the pilot's right console illuminates when the remaining fuel in the ferry tank reaches 65 pounds. Placing the ferry tank boost pump switch in OFF turns the low-level indicator light off. The 28-volt d-c pilot's circuit breaker bus supplies the power to operate the indicator light.

FUEL TANK VENT SYSTEM.

The fuel tank vent system maintains a regulated pressure within the fuel tanks to discharge combustible fuel vapors overboard and relieve excessive pressure within the tanks. When the difference between fuel tank pressure and ambient pressure reaches 0.5 psi, the corresponding vent-regulating valve opens and exhausts the vent pressure overboard through the vent masts. When the fuel tank pressure drops below 0.4 psi, the vent-regulating valve closes. The vent system services the fuselage tanks, the wing tanks, and the bomb door ferry tank when installed. The fuel tank vent system is electrically operated and automatically controlled whenever the fuel vent circuit breakers, on the pilot's circuit breaker panel, are pushed in. Power for the system comes from the 28-volt d-c pilot's circuit breaker bus.

Note

Venting of the fuel from the wing vent mast when the wing tanks are full is quite common during the early stages of a flight.

FUEL PURGE SYSTEM.

The fuel purge system adds nitrogen to the fuel tanks to keep the vapor concentration below a combustible level. The system is normally used for combat missions as a safety measure to forestall explosions or fire hazards in the fuel tanks in the event they should be damaged. The system contains six nitrogen bottles, two solenoid-operated shut-off valves, high and low pressure reducer valves, and thermal relief safety discs

with discharge indicators. The purge system operates in conjunction with the vent system, maintaining nitrogen pressure in the fuel tanks between 0.25 and 0.40 psi. Pressure in excess of 0.50 psi is vented overboard by normal vent system operation. The operation of the system is automatic and requires no further action by the pilot after the initial actuation. The system services all the tanks except the tip tanks and the ferry tank. Power to operate the system comes from the 28-volt d-c distribution bus.

ferry tank fuel control panel




Figure 1-15

FUEL PURGE SWITCH.

The fuel purge system is controlled by the fuel purge switch on the fuel control panel (figure 1–14). Placing the switch in FUEL PURGE prior to take-off allows nitrogen to flow into the fuel tanks as fuel is consumed. Power to control the system comes from the 28-volt d-c distribution bus.

FUEL PURGE DISCHARGE INDICATORS.

Three overboard discharge indicators containing red discs are mounted in the fuselage skin just forward of the bomb bay on the right side. When the pressure in the nitrogen cylinders becomes excessive, the nitro-

gen discharges overboard. The absence of the red discs in the discharge indicators shows that the nitrogen has discharged.

ENGINE INSTRUMENTS.

OIL PRESSURE INDICATOR.

The oil pressure indicators (figure 1–31) on the right side of the pilot's main instrument panel indicate the oil pressure delivered from the oil pumps. Pressure transmitters electrically transmit pressure information to the indicator. The 28-volt a-c bus supplies power through a 1-ampere fuse to energize the circuit.

FUEL FLOW INDICATOR.

The fuel-flow indicators (figure 1–31), one for each engine, indicate fuel consumption in pounds per hour. A flow-measuring device in the fuel line between the fuel control unit and the flow dividers has a transmitter that operates the fuel-flow indicator on the pilot's main instrument panel. Errors in density due to changes in altitude and temperature are negligible. The power to operate the circuit comes from the 28-volt a-c bus through a 1-ampere fuse.

Note

Rapid throttle movement causes fluctuation of the fuel flow indicator. However, the indicator will stabilize after a few minutes operation.

TACHOMETER.

Engine-driven tachometer generators electrically transmit the percentage of engine rpm to their respective tachometer. (See figure 1–31.) The indicators are on the pilot's main instrument panel. The tachometer circuit operates independently of the airplane's electrical system.

EXHAUST TEMPERATURE INDICATOR.

Two exhaust gas temperature indicators (one for each engine) are on the pilot's main instrument panel. (See figure 1–31.) Four thermocouples connected in parallel around the tail pipe transmit an average exhaust gas temperature to the indicators. Temperature readings are in degrees centrigrade. The temperature indicator circuits operate independently of the airplane's electrical system.

ELECTRICAL SYSTEM.

A 24-volt 36-ampere-hour battery and four enginedriven 300-ampere 28-volt generators supply the electrical power to operate the airplane's electrical equipment. (See figure 1-17.) Each engine drives two generators. For starting or ground service, an external power source can be connected to the system through an external power receptacle. Four inverters supply the power to operate the equipment requiring alternating current. The battery and main (No. 1) inverter are in the forward area of the fuselage center section. The electrical distribution center, below and to the left of the pilot, contains various power busses, relay panels, and fuse panels. The left electrical access compartment, in the lower left area of the nose section aft of the pressure bulkhead, contains the No. 2 inverter, the standby instrument inverter, the battery bus, and various relays and fuses. The right electrical access compartment, in the lower right area of the nose section aft of the pressure bulkhead, contains the normal instrument inverter, generator control panels, the external power receptacle, various relays, and fuses. A kit on the pilot's right console contains spare lamps. The right equipment compartment contains spare lamps and fuses. Circuit breaker panels are on the pilot's right and left vertical consoles and on the observers' left console.

D-C POWER SYSTEM.

The d-c power system is a 28-volt multiple distribution system using the airplane's structure for ground return. Its design permits single or parallel generator operation. Energizing the generator bus also energizes the distribution, the pilot's circuit breaker, the d-c radio, the armament, and the battery busses. The battery bus supplies power from the battery to the emergency circuits in the event of generator failure. Circuit breakers and fuses protect the bus supply lines and individual circuits.


EXTERNAL POWER RECEPTACLE.

The external power receptacle in the right electrical access compartment (figure 1–16) connects to the generator bus. An indication of voltage output of the external power source appears on the voltmeter when the voltage selector switch is in the DISTR BUS position.

BATTERY.

The battery is in the left forward section of the center fuselage. Battery rating is 36 ampere-hours at 24

external power receptacle



11626

Figure 1-16

volts. The battery connects directly to the battery bus and energizes the bus at all times. The battery bus voltage reading appears on the voltmeter when the voltmeter selector switch is placed in BATT BUS. A battery vent system allows boiling electrolyte to overflow into a jar in the battery compartment.

BATTERY SWITCH.

The battery switch, on the generator control panel (figure 1–18), is a three-position switch marked OFF (center position), and BATTERY (up position). The third position has no markings or function. The battery switch controls a battery contactor relay incorporated in the circuit between the battery bus and the 28-volt d-c generator bus. Placing the switch in BATTERY closes the battery contactor, completing the circuit between the battery bus and the generator bus.

Note

Closing the battery contactor requires a minimum battery voltage of 18 volts at one ampere. The battery contactor remains closed until battery voltage drops below seven volts.

The generators then energize the generator bus and the battery bus. Also, with the generators inoperative and the battery switch in BATTERY, the battery energizes the 28-volt d-c system.

GENERATOR REGULATOR PANELS.

Four generators regulator panels, two in the right electrical access compartment and two in the equipment compartment, regulate and protect the 28-volt d-c electrical system. The panels contain the various circuit breakers, fuses, and relays to regulate the system voltage, to control the load division between generators, and to prevent reverse current flow.

GENERATOR CONTROL PANEL.

The four generator control switches are on the generator control panel. (See figure 1–18.) Each switch is marked ON, OFF, and RESET. If the engine is operating and the generator voltage is approximately 28 volts, placing a generator switch in ON connects the generator to the generator bus and then to the battery, provided the battery switch is in BATTERY. Incorporated in the circuit between the generator and the generator bus is a reverse current relay. This relay prevents battery power from energizing the generator when the generator voltage is lower than battery voltage. Reverse-current relays also prevent the generators from cutting in when an external power source




Figure 1-17 (Sheet 1 of 2)




Figure 1-17 (Sheet 2 of 2)



is connected to the airplane. The generator field excitation circuit incorporates a trip relay (circuit breaker) which protects the circuit against overvoltage and shorting. Placing the generator switch in RESET closes the trip relay. If, upon placing the generator control switch in ON, there is no indication on the generator loadmeter, hold the switch in RESET

GENERATOR INDICATOR LIGHTS.

The generator indicator lights are on the generator control panel. The lights illuminate whenever the generators are inoperative or whenever generator voltage drops below battery voltage.

momentarily and then return the switch to ON.

LOADMETERS.

The generator loadmeters are on the generator control panel. The loadmeters measure the direct-current load of their respective generators. The loadmeter scale is from -0.1 to 1.25. When a generator delivers its maximum rating of 300 amperes, the loadmeter indicates 1.0 (100 percent). Loadmeters interpret the electrical load as a decimal part of the rated capacity. Thus, the pilot may determine whether a generator carries its share of the load. A loadmeter reading of 0.1 indicates a load of 30 amperes.

VOLTMETER.

The d-c voltmeter is on the generator control panel. Voltmeter calibration is in increments of 1 volt with a range from 0 to 30 volts.

VOLTMETER SELECTOR SWITCH.

The voltage of a generator or a bus appears on the

voltmeter when the voltmeter selector switch is turned to one of the following positions: RAD BUS, BAT BUS, DISTR BUS, GEN 1L, GEN 1R, GEN 2L, GEN 2R. A single voltmeter on the generator control panel indicates the voltage for all switch positions.

A-C POWER SYSTEM.

The a-c power for the airplane originates from four inverters: a 2500 VA (No. 1 main) inverter, a 2500 VA (No. 2 main) inverter, a 500 VA normal instrument inverter, and a 250 VA standby instrument inverter. The a-c power distribution system consists of two 115-volt single-phase a-c busses, two 115-volt three-phase a-c busses, one 28-volt single-phase a-c bus, and two 115-volt single-phase a-c radio busses. The radio busses are in the radio junction box and all other busses are in the electrical distribution center. The No. 1 inverter (2500 VA) energizes the 115-volt single phase bus. This bus in turn supplies power to the No. 1 radio bus, the fuel quantity indicating system, the 28-volt single-phase bus, the windshield anti-icing system, and the cabin temperature control system. The 115-volt bus energizes the 28-volt bus through a 28-volt step-down transformer. The 28-volt bus supplies power for fuel flow and oil pressure indication. The No. 1 radio bus supplies a-c power to various electronic equipment. The No. 2 inverter (2500 VA) energizes the No. 2 radio bus and the No. 2 radio bus supplies power to the IFF radar circuit. The normal instrument or standby inverters energize

the 115-volt three-phase a-c busses through a transfer relay. These busses supply power to the gyro co: pass, the flight attitude indicator, and the inverter failure indicator relay circuits.

NO. 1 AND NO. 2 INVERTER SWITCHES.

The No. 1 and No. 2 inverter switches (figure 1-19) on the inverter control panel control their respective inverters. Placing the switches in the up (ON) position closes a relay in the inverters. The closed relay allows power from the 28-volt d-c generator bus to operate the inverter. The No. 1 inverter energizes the No. 1 a-c 115-volt single-phase bus and the No. 2 115-volt single-phase bus and the No. 2 115-volt singlephase radio bus.

INSTRUMENT INVERTER SWITCH.

The instrument inverter switch (figure 1-19) on the inverter control panel controls the normal and standby instrument inverters. Placing the switch in NORMAL closes a relay in the inverter. The closed relay allows power from the 28-volt d-c pilot's circuit breaker bus to operate the normal instrument inverter. The inverter energizes the three-phase 115-volt a-c busses. Placing the switch in STANDBY closes a relay in the inverter allowing power from the 28-volt battery bus to operate the standby instrument inverter. The standby instrument inverter energizes the three-phase 115-volt a-c busses.

The instrument inverter switch controls the stay-alive relay and must be placed to OFF before you leave the airplane.

INVERTER FAILURE INDICATOR LIGHTS.

The inverter control panel contains the No. 1, No. 2, and instrument inverter failure lights. The lights illuminate whenever the respective inverters are inoperative or whenever the output drops below 90 volts. The 28-volt battery bus supplies power to operate the lights.

HYDRAULIC SYSTEM.

The hydraulic system (figure 1-20) supplies the hydraulic pressure necessary to operate the landing gear, landing gear doors, wing flaps, wheel brakes, canopy and canopy latches, wing and fuselage dive brakes, gun purge doors, and the bomb door. During engine operation, the power to pressurize the hydraulic system comes from independently operating pumps (one for each engine) which draw fluid from a single reservoir in the right inner wing and transmit hydraulic pressure through pressure lines to the various actuating cylinders. Fluid from the return side of the actuating cylinders replenishes the fluid in the reservoir. Compressed air from the engines pressurizes the reservoir to assure a supply of fluid to the enginedriven pumps. A reserve supply of hydraulic fluid

inverter switches and indicator lights



remains in the reservoir for emergency use. A relief valve limits system pressure to 3000 (+100 - 0) psi. The main accumulator is attached to the basic supply line, and an additional accumulator, smaller in volume than the main accumulator, is isolated from the system and retains pressure for emergency brake operation. Electrically controlled selector valves direct pressure to the up, close, or retract side of the actuating cylinders or to the down, open, or extend side of the cylinders, depending upon the position of the controls. Pressure exists in the actuating cylinders at all times during hydraulic pump operation, since the selector valves have no neutral position. A manually operated valve in the right wheel well bypasses hydraulic fluid, allowing the right main gear door to be closed during bomb loading. A bomb door shut-off valve in the




Figure 1-20 (Sheet 1 of 2)




Figure 1-20 (Sheet 2 of 2)

hydraulic hand pump




Figure 1-21

bomb bay prohibits bomb door operation while the airplane is on the ground. The valve is manually operated and must be opened before flight. A ground shut-off valve isolates the pilot's hand pump from the system. Emergency provisions within the hydraulic system are fuses, check valves, wheel brake accumulator, and a duplicate pressure circuit from the pilot's hand pump for landing gear and bomb door operation. There are two hydraulic pressure gages.

HYDRAULIC HAND PUMP.

The hydraulic hand pump, at the left-hand side of the pilot's seat, is used for emergency in-flight operation of the bomb door and landing gear and for ground operation by the ground crew. (See figure 1–21.) In rare cases, the hand pump may also be used for other sub-circuits in the system as described under BRAKE SYSTEM FAILURE in Section III. The hand pump obtains fluid directly from the reservoir. A branch line connects the hand pump to the main sys-

tem through a ground shut-off valve. An emergency branch line connects the hand pump to the landing gear control valve and then to the bomb door supply line. With the landing gear lever in UP, the emergency section of the control valve is connected to the emergency pressure line routed to the bomb door control valve. Approximately 30 to 50 strokes on the hand pump are necessary to open the bomb door, and 100 to 150 strokes or two to three minutes of steady pumping are needed to extend the landing gear. There is very light resistance when the gear is being pumped down.

EXTERNAL HAND PUMP.

The external hand pump (figure 1-22) is in the left electrical access compartment. The external hand pump uses the same supply line as the internal hand pump, but the pressure line goes directly to the main system pressure line. The external hand pump operates all of the airplane's hydraulic sub-circuits, depend-

canopy hand pump and control switch



11633

Figure 1-22

ing upon the position of the various hydraulic subcircuit selector valves. The canopy switch is adjacent to the pump. Actuation of the canopy switch positions valves allowing the operation of the pump to raise the canopy.

GROUND SHUT-OFF VALVE.

The ground shut-off valve is to the left of the pilot's seat on the compartment floor. This valve is manually operated and is safety-wired closed for flight. The shut-off valve is used to connect the hydraulic hand pump into the common pressure line so that pressure in the line may be built up for ground operation of the various sub-circuits. In the event of extreme emergencies, the pilot may open the valve and use the hand pump to put pressure on the hydraulic system while in flight as described under BRAKE SYSTEM FAILURE in Section III.

HYDRAULIC SYSTEM PRESSURE GAGE.

A gage (figure 1-37) on the pilot's left console indicates the pressure in the common line of the hydraulic

system. The indicating system consists of the gage and a pressure transmitter. If the engines are running, the gage should reflect readings which fall within the instrument range markings given in Section V.

FLIGHT CONTROL SYSTEMS.

The ailerons, elevator, rudder, and throttles control the airplane in flight. (See figures 1–23 and 1–24.) These primary controls receive assistance from the trim devices and the variable-incidence stabilizer. Additional controls in the form of high-drag devices are the flaps and dive brakes. The conventional elevator, rudder, and ailerons have unique mechanisms which relieve the pilot of heavy control loads. At high speeds, these mechanisms also prohibit excessive loads on the airplane's structure by indirectly restricting the travel of control surfaces. Rotation of the control wheel, or movement of the rudder pedals, or longitudinal movement of the control column moves push rods to actuate the control surfaces directly or indirectly. On the ground and at low speeds, the

flight control system




Figure 1-23

torque tube and blowback rod operation




Figure 1-24

push rods directly deflect the control surfaces, but as airspeed increases, the resulting load on the control surfaces resists the action of the push rod. The torque tube in the torque-tube-and-blow-back-rod assembly twists to absorb the movement of the push rod. Twising of the torque tube rotates the blow-back rod which deflects a spring tab. The spring tabs on the trailing edge of both ailerons, the rudder, and the port elevator give the elevator the effect of having a small aileron on the aileron or a small elevator on the elevator. The reaction resulting from moving the spring tabs into the airstream forces (flies) the surface to another position. The spring tabs operated by the torque-tube-and-blowback-rod assembly are powerful aerodynamic devices which reduce pilot effort and still maintain conventional control feel at all airspeeds. The displacement of the control surface is directly proportional to the displacement of the tab; however, the blowback rod, acting as a torsion spring, restricts tab movement. At high speeds, a large tab angle imposes high air loads on the tab, causing the blowback rod to twist in the opposite direction to the

torque tube. This increases the control load felt by the pilot, thereby utilizing the pilot's strength as a limiting factor to control surface movement.

CONTROL LOCKS.

External surface control locks placed on the elevator, rudder and ailerons are the only means of locking the controls. The control column has a stowage rod which holds the control column out of the way during exit or entrance but does not lock the controls.

TRIMMING.

Each flight control system has a different method of trimming. The variable-incidence stabilizer acts as elevator trim by raising and lowering the trailing edge of the horizontal stabilizer. Trimming the aileron varies the elongation of a spring (adding bias) at the base of the control column. In effect, this shifts the neutral position of the control wheel. Actuating the rudder trim switch operates an actuator in the vertical stabilizer. This actuator rotates the blowback rod which moves the combination spring tab-trim tab.

AILERON CONTROL SYSTEM.

Mechanical linkages connect the control wheel to torque-tube-and-blowback-rod assemblies in each ailer-on. One end of the torque tube anchors to the aileron spar. Rotation of the control wheel causes the other end of the torque tube to twist. The blowback rod, inside the torque tube and bolted to its free end, turns as the tube twists, thereby deflecting the spring tab. The aerodynamic force on the spring tab moves the aileron.

RUDDER CONTROL SYSTEM.

The rudder pedals connect to the torque-tube-andblowback-rod assembly inside the leading edge of the rudder. Movement of the pedals operates the rudder in the same manner that the control wheel operates the ailerons.

ELEVATOR CONTROL SYSTEM. (GROUP O AIRPLANES)

A common shaft joins the right and left elevator control surfaces, causing the surfaces to move simultaneously. Longitudinal movement of the control column deflects a spring tab to move the elevator. The elevator spring tab is identical in operation to the aileron spring tab. A balance tab on the trailing edge of the right elevator control surface aids the spring tab for elevator operation. The tab does not connect to any controls but operates solely as a function of elevator movement to further reduce pilot effort in the operation of the controls.

ELEVATOR CONTROL SYSTEM. (GROUP P AIRPLANES)

Installation of the elevator bungee and a more powerful torque tube and blow-back assembly in the left elevator comprise the only difference in the elevator systems between Group O and P airplanes. Operation of the elevator system bungee is automatic and requires only that the pilot be alert for the slight forward movement of the control column when the bungee actuates. Whenever the flaps are lowered, the flap system electrical circuit energizes the elevator system bungee which causes the bungee to apply a 25 pound push force (airplane nose down) to the elevator system to compensate for the airplane nose up attitude resulting from the lowering of the flaps. Replacement of the left elevator torque tube and blow-back rod assembly with a more powerful torque tube and blow-back rod assembly improves the maneuverability of the airplane because of the reduction of stick forces required to pull G's at lower altitudes.

CONTROL WHEEL AND COLUMN.

The control wheel and column (figure 1–25) controls the movement of the ailerons and elevator. The control wheel has a normal trim switch for the ailerons and horizontal stabilizer, a bomb release button, and a gun trigger on the right handgrip. The left grip has a microphone switch and a roger switch (used with the AN/APW-11A).

HORIZONTAL STABILIZER-AILERON TRIM SWITCH.

There is a five-position normal trim switch (figure 1-25) on the right handgrip of the control wheel. The switch is spring-loaded to the center (off) position. Moving the switch to the left (left wing down) or to the right (right wing down) causes the trim actuator to elongate a spring at the base of the forward control column. This shifts the neutral (noload) position of the control wheel down, thereby trimming the ailerons. Actuating the switch either forward (nose down) or aft (nose up) energizes the horizontal stabilizer actuator. The up-and-down movement of the trailing edge of the horizontal stabilizer gives the desired elevator trim. The stabilizer actuator has two speeds of travel. On group O airplanes only, during flight with the gear up, the stabilizer actuator operates at 60 to 70 percent of full speed. The actuator operates at full speed during trimming of the elevator with gear down. The pilot trims the airplane by positioning the controls for the desired flight altitude and operates the trim switch to relieve the control forces. On group O airplanes only, the normal trim switch is inoperative when the horizontal stabilizer override switch is in ALT. The d-c power to operate the aileron and stabilizer actuators is from the 28-volt d-c generator, distribution, and pilot's circuit breaker busses.

HORIZONTAL STABILIZER OVERRIDE SWITCHES. (GROUP O AIRPLANES)

Various trim control emergencies arise from faulty or sticking trim switches. The use of the horizontal stabilizer override switch and the stabilizer emergency control switch affords an alternate method of adjusting elevator trim. The override switch has two positions, NORM and ALT. (See figure 1–31.) When the switch is in NORM, the normal trim switch on the control wheel control the movement of the horizontal stabilizer. Placing the override switch in ALT renders the normal trim switch inoperative. The emergency control switch is spring-loaded to the center (off) position. Momentary operation to NOSE UP or NOSE DOWN adjusts the longitudinal trim in the same manner that the normal trim switch adjusts the trim.

horizontal stabilizer emergency switch (group P airplanes)



11791

Figure 1-24A

horizontal stabilizer position indicator (group P airplanes)



11792

Figure 1-24B





11673

Figure 1-25

HORIZONTAL STABILIZER EMERGENCY SWITCH. (GROUP P AIRPLANES)

The horizontal stabilizer emergency switch is on the pilot's glare shield. Switch positions are NORMAL and EMER OFF. (See figure 1–24A.) During all normal flight conditions, the switch should be in NORMAL. Whenever a stabilizer trim failure occurs, the horizontal stabilizer emergency switch when placed in EMER OFF causes the stabilizer actuator brake to be applied which locks the actuator and prevents further movement of the stabilizer surface.

STABILIZER POSITION INDICATOR. (GROUP O AIRPLANES)

The stabilizer position indicator on the pilot's left main control panel operates continuously when power is on the 28-volt d-c distribution bus. (See figure 1-39.) A device attached to the stabilizer actuator drive shaft follows the movement of the stabilizer. The device electrically operates the indicators to give

a visual indication of the position of the horizontal stabilizer. The indicator markings range from six divisions nose down to ten divisions nose up; however, the travel of the stabilizer and the needle is 2.5 divisions nose down and 1.5 divisions nose up. A division closely approximates a degree.

STABILIZER POSITION INDICATOR. (GROUP P AIRPLANES)

The stabilizer position indicator on the canopy control box (figure 1–24B) operates continuously when power is on the 28-volt distribution bus. A device attached to the stabilizer actuator drive shaft follows the movement of the horizontal stabilizer. The indicator pointer shows up and down movement of the stabilizer in tenths of a degree from 0° to 1.4°. Without electrical power or during electrical malfunction of the indicating system, the indicator pointer moves to the 3 o'clock position.

flap and trim control panel




Figure 1-26

RUDDER TRIM SWITCH.

The rudder trim switch is on the flap and trim control panel. (See figure 1–26.) Switch positions are NOSE LEFT and NOSE RIGHT. Placing the switch in NOSE LEFT or NOSE RIGHT causes the rudder trim tab actuator to change rudder trim. Movement of the ball in the turn-and-slip indicator indicates changes in rudder trim. The 28-volt d-c pilot's circuit breaker bus supplies the power to operate the trim circuits.

RUDDER TRIM INDICATOR LIGHT.

The green rudder trim light on the pilot's left main control panel illuminates when the rudder trim tab is within one-eighth of an inch of the neutral position. However, to supply power to light the lamp, the rudder trim switch must be moved to the right or left to close the light circuit. The 28-volt d-c pilot's circuit breaker bus supplies the power for lamp illumination.

AILERON TRIM INDICATOR LIGHT.

The green aileron trim light on the pilot's left main control panel, illuminates when the aileron trim tab is within one-eighth of an inch of the neutral position. However, to supply power to light the lamp, the normal trim switch must be moved to the right or left to close the light circuit. The 28-volt d-c pilot's circuit breaker bus supplies the power for lamp illuminations.

RUDDER PEDALS AND ADUSTMENT KNOB.

The rudder pedals are of the conventional type, incorporating integral toe-operated brake pedals. Rotating the adjustment knob between the pedals moves the pedals fore and aft to adjust for the desired leg length. (See figure 1–27.)

WING FLAPS.

The wing flaps are of the high-drag, low-lift type. The flap system consists of two inner and two outer split flaps hinged to the trailing edges of the wings, a hydraulic actuating cylinder for each flap section, an electrical control circuit, one control switch, and two flap-position indicators. The inner flaps are between the fuselage and the engine nacelle tail cones and the outer flaps are between the engine nacelle tail cones and the ailerons. Energizing the electrical control circuit causes a single control valve to position, allowing all four flap sections to move up or down simultaneously. The flaps have no intermediate position. The flaps must not be lowered above 170 knots IAS. The 28-volt d-c distribution bus supplies the power to operate the control circuit.

WING FLAP SWITCH.

The wing flap switch (figure 1-26) is on the pilot's flap and trim control panel aft of the pilot's throttles. The switch handle resembles an airfoil section. Switch markings are UP and DOWN. Placing the switch

rudder pedals and adjustment knob




Figure 1-27

UP or DOWN electrically positions the control valve to allow hydraulic pressure to go to the up or down sides of the four actuating cylinders of the wing flap sections. The maximum down travel is 60 degrees.

WING FLAP INDICATOR.

The wing flap indicator is on the pilot's left main control panel. Lowering the flaps causes microswitches to open the circuit to the indicator and a barber-pole design appears in the indicator. Upon reaching the full down position, the flaps close microswitches and cause the indicator to show a miniature flap in the down position. Raising the flaps causes the microswitches to open, and the barber-pole design again appears on the indicator. When the flaps are in the full up position, the indicator shows a miniature flap in the up position. Flap position indication is received from a micro-switch on the left inboard flap.

DIVE BRAKES.

The airplane is equipped with wing dive brakes and fuselage dive brakes to increase drag and reduce airspeed. (See figure 1-1.) The wing dive brakes are in a series of fingers in a straight line laterally along the upper and lower surface of both wings. When retracted, the wing dive brakes are flush with the wing surface. The wing dive brakes extend perpendicularly to the wing chord.

The fuselage dive brakes are two flaps on either side of the aft fuselage. When retracted, the brakes are flush with the fuselage and hinges at the forward part of the brakes to allow the brakes to open at the aft end into the slipstream. Both the wing and fuselage dive brakes are electrically controlled and hydraulically operated. A switch on the pilot's inboard throttle lever controls the operation of the fuselage brake. The opening and closing of the fuselage dive brakes open and close microswitches. These microswitches control the operation of the wing dive brakes. When fully opened, the fuselage brakes operate microswitches which cause the wing brakes to extend to the maximum travel. The initial movement of the fuselage brakes to the close position actuates microswitches to cause the wing brakes to retract. The wing brakes retract in advance of the fuselage brakes. There are no airspeed limitations for dive brake operation. The 28-volt d-c distribution bus supplies the power for dive brakes control.

DIVE BRAKE SWITCH.

The dive brake switch (figure 1-5) is on the pilot's inboard throttle lever. Switch markings are EXTEND and RETRACT. Placing the switch in EXTEND positions a solenoid valve to allow hydraulic pressure to go to the extend side of fuselage actuating cylinder. Placing the switch in RETRACT causes the valve to allow hydraulic pressure to go to the retract side of the actuating cylinder. The fuselage brakes cannot be stopped in an intermediate position. Extending the fuselage brakes also extends the wing brakes.

LANDING GEAR SYSTEM.

The electrically controlled, hydraulically operated tricycle landing gear fully retracts within the wing and fuselage contours. The main gear retracts inboard and up into wheel wells inboard of the engine, and the nose wheel retracts aft and up into the fuselage nosewheel well. When retracted, the landing gear is enclosed by fairing doors. Each main gear consists of an air-oil shock strut with a cantilevered axle, upand-down locks, position microswitches, an actuating cylinder, a wheel-and-brake assembly, and a gearoperated sequence valve. The nose gear consists of an air-oil shock strut with a self-centering device, dual wheels, a drag brace, an actuating cylinder, up-anddown locks, and gear-position microswitches. Sequence valves control the order of opening and closing of the gear and fairing doors. Hydraulic pressure and mechanical locks retain the gear in the desired position. When the airplane's weight is removed from the nose wheels strut, the self-centering device aligns the nose gear for retraction, and when the weight of the airplane compresses the nose wheel strut approximately two inches, the wheels are free to caster.

LANDING GEAR CONTROL LEVER.

A two-position landing gear control lever left of the landing gear control panel (figure 1–28) electrically controls gear operation. The lever handle is wheelshaped for distinctive identification, and is held in the DOWN position by a solenoid lock when the airplane is on the ground. When the landing gear control lever is placed in UP, a microswitch closes a circuit from the 28-volt d-c distribution bus to the single-acting solenoid of the landing gear control valve. The valve then allows hydraulic pressure to flow to the actuating cylinders of the gears and then to the doors in the retract direction. When retraction is completed, the actuating cylinder remains pressurized as long as the main hydraulic system is pressurized. Should the system pressure fail, the up lock

landing gear control panel



Figure 1-28

hooks will hold the gear in the retracted position. Placing the landing gear control lever in DOWN causes the solenoid valve to become de-energized, permitting hydraulic pressure to extend the doors, release the up locks, and extend the gears. Ground lock pins are provided for safety purposes and must be inserted before engine shutdown. (See figure 1–29.) Normal gear lever movement requires a force of 5 pounds (± 1 pound). An additional 25 pounds (± 5 pounds) pressure applied to the lever enables the pilot to override the solenoid for emergency gear retraction while the airplane is on the ground. Gear extension opens a nacelle cowl door to permit engine cooling. The 28-volt d-c distribution bus supplies the power to operate the landing gear controls.

EMERGENCY LANDING GEAR DOWN HANDLE.

The emergency landing gear down handle (figure

1-28) is to the left of the landing gear control lever. Using the T-handle enables the pilot to position the landing gear control valve if there is an electrical malfunction. Pulling the handle all the way out (approximately $2\frac{1}{2}$ inches) mechanically positions the control valve to the down position. Normal hydraulic system pressure or hydraulic hand pump pressure lowers the gear. A one-quarter turn to the right or left resets the handle and a spring returns it to the normal (in) position.

Note

When the emergency landing gear down handle has been used to lower the gear, the gear cannot be retracted if electrical power is not available.

LANDING GEAR WARNING HORN.

When the landing gear is in any position other than down and locked, retarding the throttles below mini-

ground lock pin




Figure 1-29

mum cruising speed (76 ± 3 percent rpm) energizes the landing gear warning horn. Electrical power to the horn comes from the pilot's 28-volt d-c circuit breaker bus through a 5-ampere circuit breaker.


LANDING GEAR WARNING HORN RELEASE.

The warning horn release button (figure 1-30) is aft of the parking brake lever and below the throttles. Momentarily depressing the release button silences the warning horn. Advancing the throttles above minimum cruise resets the warning horn microswitch.

LANDING GEAR WARNING LIGHT.

Placing the landing gear control lever in UP or DOWN completes circuits to the landing gear warning light in the landing gear lever handle. (See figure 1–28.) The light illuminates when the landing gear is in an intermediate position. Also, retarding the throttles below minimum cruise speed illuminates the light when the gear is in any position other than down and locked. Electrical power for the light comes from the 28-volt d-c pilor's circuit breaker bus through a 5-ampere circuit breaker.

parking brake lever and warning horn cut-out release



11682

Figure 1-30

LANDING GEAR WARNING LIGHT TEST SWITCH

The landing gear warning light test switch (figure 1-28) is on the landing gear control panel. Placing the switch in TEST illuminates the light in the landing gear control lever handle if the light is operative. The 28-volt d-c pilot's circuit breaker bus supplies the power to operate the circuit.

LANDING GEAR POSITION INDICATION.

A three-indication, three-position indicator on the pilot's landing gear control panel represent the position of the landing gear. (See figure 1–28.) The indications are: 1) cross-hatching if the gear is in an intermediate position, 2) the word UP if the gear is up and locked, and 3) a miniature wheel if the gear is down and locked. Position-indication microswitches on the gear energize their respective indicators. The 28-volt d-c pilot's circuit breaker bus supplies the power to operate the indicators.

BRAKE SYSTEM.

Operation of the brake pedals actuates separate hydraulic brake valves for each wheel brake. Toe pressure on the brake pedals meters hydraulic fluid under pressure to the brakes on the main gear. A check valve isolates a brake accumulator from the main hydraulic system, and during main hydraulic system failure the brake accumulator supplies pressure for two or three brake applications. Differential main gear braking steers the airplane when taxiing.

PARKING BRAKE LEVER.

The parking brake lever (figure 1-30) is on the pilot's left console forward of the throttle friction knob. The pilot sets the parking brake by depressing the brake pedals and placing the parking brake in ON and then releasing the brake pedals. He releases the parking brake by adding further pressure on the brake pedals.

Note

Release the parking brake after the wheel chocks are in place to avoid damage to the brakes.

BRAKE PRESSURE GAGE.

The brake pressure gage (figure 1-39) on the pilot's left horizontal console indicates hydraulic pressure in the wheel brake hydraulic system. Pressure is hydraulically transmitted from the brake system to the brake

pressure gage. The calibration of the gage is in increments of 500 psi. See Section V for instruments markings.

INSTRUMENTS.

The flight and engine instruments, which are on shock-mounted panels, are in full view of the pilot. The majority of the instruments are electrical and they receive their power from the a-c or d-c electrical systems. The electrical system supplies the power for the directional indicators, turn-and-slip indicator and the attitude indicator. The airspeed indicator, Machmeter, altimeters, and vertical velocity indicator operate by air pressure supplied from the pitot-static system. A vibrator on the pilot's and observer's main instrument panels prevents instrument lag or stick pointer indications. See Section IV for a discussion on lighting for the panels and instruments and Section V for instrument markings.

INSTRUMENT PANEL VIBRATORS.

Vibrators on the rear of the pilot's and observers main instrument panels prevent sticking or lagging of instrument pointers due to friction. There are no controls for the vibrators and they operate continuously when the 28-volt distribution bus is energized.

AIRSPEED INDICATOR.

The airspeed indicator on the pilot's and observers main instrument panels shows indicated airspeed and the maximum permissible indicated airspeed. The indicator has two pointers, a vernier drum, and a small triangular index. The indicator is marked from 50 to 650 knots in 100-knot increments. The narrow pointer registers indicated airspeed and the striped pointer registers maximum allowable indicated airspeed. The vernier drum permits the observer to read airspeed to the nearest knot. The small triangular index is preset on the ground and is set to a limiting Mach number on the face of the instrument and regulates the travel of the striped pointer. Assuming that the airplane is at sea level with a barometric pressure of 29.92 inches Hg, and the triangular index set at Mach 0.8, the striped pointer would indicate approximately 520 knots. As the airplane increases altitude, the striped pointer rotates counterclockwise, thereby indicating the maximum allowable indicated airspeed at any altitude.

MACHMETER.

The Machmeter (figure 1-31) on the pilot's main in-

strument panel is a primary flight instrument for indicating the speed of the airplane. Machmeter readings are more exact indications of airplane speed than indicated airspeed readings, particularly at higher altitudes. Indicator markings are in hundredths of Mach and are numbered every tenth of Mach from 0.3 to 1.0. The pitot-static system operates the indicator.

ACCELEROMETER.

During turns, loops, and similar maneuvers, the pull of centrifugal force on the airplane (and on the pilot) registers on the accelerometer. (See figure 1–31.) The calibration of the accelerometer is in terms of G, or multiples of the force of the pull of gravity. The meter has three pointers that indicate G-loads. In addition to the continuous pointer, two recording pointers (one for positive G and one for negative G) follow the continuous pointer to the maximum encountered G-load. The recording pointers return to the normal 1-G position when the knob on the lower left corner of the instrument is pressed.

FLIGHT ATTITUDE INDICATOR.

The B-1A flight attitude indicator visually indicates to the pilot, during flight, the attitude of the airplane with reference to the horizon. The B-1A gyro is noncaging, and incorporates a zero-pitch trim knob that positions both the sphere and the horizon bar to the zero position. The pitch trim knob has a triangular mark for zero-pitch trim, three dots corresponding to a one-half inch deflection in the downward direction, and six dots corresponding to a one-inch deflection in the upward direction. The gyro has a follow-up rate of 180 degrees-per-second in the pitch and bank axis. The gyro has a fast initial erection period, approximately two minutes ± 30 seconds, but if the gyro tumbles in flight, erection may take 15 minutes. Included in the gyro is an electrically-driven power warning flap that disappears from view when the gyro is up to full speed and the system is ready for operation. The flap appears when the power supplying the system is off. The instrument operates through 360 degrees of roll and through 164 degrees pitch. The instrument is compensated for turn-errors; however, the lower sensitivity limit of the turn-errors compensating mechanism is 40 degrees per minute. Any turn made below 40 degrees per minute will result in turn-errors common to other instruments. Turns made above 40 degrees per minute will be compensated for turn-errors. In level flight, the maximum error in the indication of the airplane's attitude is less than one-half degree. The 28-volt d-c radio bus supplies d-c power through a 5 ampere circuit breaker

B-1A
attitude
indicator
indicator

Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
Indicator
I

on the main radio circuit breaker panel. A-c power is supplied from the phase B and C busses.

EMERGENCY EQUIPMENT.

One bromochloromethane (CB) hand extinguisher and one crash axe constitute the items of portable emergency equipment in the airplane. (See figure 3–3.) The fire extinguisher is on the pressure bulkhead to the right of the observer's seat. The crash axe is on the right side of the cabin on the door of the main radio distribution box.


CANOPY.

The canopy is a laminated, transparent plastic bubble set in a metal frame. Its purpose is to enclose the cockpits and give the crew lateral and vertical visibility. Open hinges secure the canopy at the aft end, and a hydraulic actuating cylinder secures the canopy at the center. The canopy arcs upward for crew entrance or exit. Six hydraulically operated latches on the fuselage sill lock the canopy in the closed position. A rubber tube around the canopy inflates to form a seal for cabin pressurization. External or internal switches, handles, and hydraulic hand pumps operate the canopy to close, open, or jettison. Recirculated cabin air mixed with hot engine bleed-air defogs the canopy.

CANOPY JETTISON SYSTEM.

The canopy jettison system removes the canopy when the crew must abandon the airplane. The system is operated by three canopy emergency release handles (one external handle, one handle on the pilot's left horizontal console, and one handle on the observer's left horizontal console) and the right handgrips of the ejection seat. Cables connect the emergency release handles to a single M-3 initiator near the external release handle. The right handgrip of each ejection seat connects to the M-3 initiator in a similar manner; however, the use of the grip to jettison the canopy also initiates the elevator disconnect.

pilot's station — forward







Figure 1-32

pilot's right console 1. Marker Beacon-Radar Warning Switch 2. Radar Identification Set AN APX-6A 3. Radio Compass Selector Switch 4. Pilot's Lighting Control Panel

Figure 1-33

pilot's right console









- 1. Fuel Quantity Selector Switch
- 2. Oxygen Quantity Indicator
- 3. Cabin Conditioning Control Panel





- 5. Defogging Blower Knob
- 6. Radio Compass Control Panel







- 7. Radio Compass Tuning Panel
- 8. Windshield Control Panel
- 9. Radar Set APW-11A Control Panel

1-1687

pilot's right console







- 1. Helmet Defog Rheostat
- 2. Ferry Tank Fuel Control
- 3. AC-DC Circuit Breaker Panel





Figure 1-35

pilot's left console











Power Distribution Circuit Breaker Panel

11689

pilot's left console GROUP A AIRPLANES 1. Radar Warning Indicator AN APS-54 2. Hydraulic System Pressure Gage 3. Armament Control Panel

Figure 1-37




Figure 1-38




Figure 1-39

CANOPY EMERGENCY RELEASE HANDLES.

The two yellow internal canopy release handles are aft on the pilot's left console and on the observer's left console respectively. The external handle is on the left side of the fuselage in an access door above the electrical access hatch. The three handles connect to a single M-3 initiator. Pulling any one of the three handles fires the M-3 initiator. The force created by the expanding initiator gas moves the canopy locks to the open position. Also, the gas fires a second and larger M-5 initiator. The force created by this initiator disconnects the canopy from the canopy hydraulic actuating cylinder and fires the canopy thruster.

Note

When used, the canopy emergency release handles should be pulled straight out from the recess to prevent binding.

Note

The canopy thruster causes the canopy to jettison toward the aft fuselage. The six-foot cable extension is adequate to keep the person pulling the release handle clear of the falling canopy. However, the person pulling the release handle should observe the falling canopy and if necessary use the outer wing for protection in case high winds or abnormal jettisoning causes the canopy to fall too far to the left.

CANOPY SEAL.

The canopy seal is a rubber tube around the base of the canopy. (See figure 4–1.) When inflated, the canopy seal prevents loss of cabin pressure. Automatically controlled air from the air-conditioning system inflates the seal. With the canopy fully down, the movement of the canopy latches to lock the canopy actuates the canopy seal pressure regulator switch. The canopy seal pressure regulator switch turns on the regulator, allowing engine compressor air to inflate the canopy seal. As the canopy latches move to allow the canopy to open, the latches release the regulator switch, thereby turning off the regulator and deflating the canopy seal. The operation of at least one engine is needed to inflate the seal.

CANOPY ACTUATING SWITCH.

The three-position canopy actuating switch is on the pilor's left sill. (See figure 1-40.) Switch markings are OPEN (up) and CLOSE FOR FLIGHT (down). The switch has a center (off) position. Holding the switch in OPEN energizes the canopy latch solenoid to direct hydraulic pressure to the unlock side of the

canopy latch-actuating cylinder. The movement of the latches to the unlock position operates three microswitches. One microswitch completes a circuit to the CANOPY OPEN WARNING LIGHT, the second microswitch completes a circuit to the canopy actuating cylinder solenoid, which positions to allow hydraulic pressure to the up side of the canopy actuating cylinder, and the third microswitch completes a circuit to de-energize the canopy seal regulator. Placing the switch in CLOSE FOR FLIGHT reverses this sequence. The 28-volt d-c battery bus supplies the power to operate the circuit through a 5-ampere circuit breaker on the pilot's circuit breaker panel.

canopy actuating switch



11695

Figure 1-40

CANOPY CONTROL SWITCH, EXTERIOR.

The exterior canopy control switch (figure 1–22) is in the left electrical access compartment. Switch markings are UP and DOWN. Placing the switch in UP completes a circuit to the canopy latch solenoid valve, which positions to allow hydraulic pressure to the unlock side of the canopy latch actuating cylinder.

The movement of the latches operates three microswitches. One switch completes a circuit to the CAN-OPY OPEN WARNING LIGHT. The second microswitch completes a circuit to the canopy actuating cylinder solenoid valve which positions to allow hydraulic pressure to the up side of the canopy actuating cylinder. The third microswitch completes a circuit to de-energize the canopy seal regulator. Placing the switch in DOWN reverses this sequence. The 28-volt d-c battery bus supplies the power to operate the circuit through a 5-ampere circuit breaker on the pilot's circuit breaker panel.

CANOPY LOCK WARNING LAMP.

The red canopy lock warning lamp is on the canopy control box on the pilot's left sill. Movement of the canopy latches to the locked position opens the canopy lock warning lamp microswitch, thereby breaking the circuit to the warning lamp. The warning lamp illuminates when the canopy latches move to the unlocked position. The 28-volt d-c distribution bus supplies the power to operate the circuit.

CANOPY LOCK WARNING LAMP TEST SWITCH.

The canopy lock warning lamp test switch is on the pilot's left main control panel. Holding the switch in CANOPY LAMP TEST tests operation. The 28-volt d-c distribution bus supplies the power to operate the test circuit.

GLARE SHADE.

The ribbed pilot's and observer's canopy shades (figure 1–1) slide along a track on the lower surface of the canopy. The stowage position for the pilot's shade is behind the pilot's headrest. A loop grip in the wire stiffener along the forward edge of the shade enables the pilot to move the shade forward to the windshield. The stowage position for the observer's shade is forward of the observer above the glare shield. A strap retains the shade in the stowed position. To place the shade in position for use, loosen the strap and move the shade aft behind the observer's headrest.

EJECTION SEATS.

In an emergency, the pilot's and observer's ejection seat system (figure 1-41) catapults the seat and occupant clear of the airplane and releases the occupant from the seat approximately two seconds after ejection. Each seat consists of an outer frame and guide rail, a fixed headrest, inertia reel, a seat bucket, foot rests, an equipment quick-disconnect, catapult and safety belt initiators, right and left handgrips, and a vertical seat adjustment lever. The seat bucket accommodates a one-man life raft and a seat-type parachute. An inertia reel in the headrest holds the shoulder harness firmly against the occupant. The pilot's seat adjustment and equipment disconnect are on the right side of the seat; the observer's are on the left side of the seat. Spring clips on the armrests hold the handgrips in the stowed position. A force of approximately 20 pounds is necessary to move a handgrip out of the stowed position.

CONTROL COLUMN STOWAGE. (GROUP E AIRPLANES)

Raising the right grip on the pilot's ejection seat, energizes the elevator control rod detonator and the snatch unit solenoid. The detonator severs the elevator control rod and the snatch unit solenoid releases a spring which pulls the control column forward, leaving a clear path for seat ejection. Power to operate the system is supplied by the battery bus. However, a one-shot battery on the seat assembly assures power to energize the circuits, should battery failure occur.

Note

The electrical control columns stowage system in group E airplanes is being removed by a field service change. The system will be replaced by a gas-operated system described in the following paragraph.

CONTROL COLUMN STOWAGE. (GROUP F AIRPLANES)

The gas-operated control column stowage system consists of an elevator disconnect link, a control column snatch unit, an M-3 initiator, and two M-2 extractors. When the pilot pulls up the right-hand grip of the ejection seat to the locked position, the M-3 initiator is fired and the resultant gas pressure passes through tubing to the extractors at the elevator disconnect link and the control column snatch unit. The gas pressure withdraws the extractor rods from the disconnect link and the snatch unit spring-loaded latching mechanism. The release of this mechanism disconnects the elevator push-pull linkage from the control column and pulls the control column against the pilot's main instrument panel.

SHOULDER HARNESS.

The shoulder harness straps fasten to an inertia reel in the ejection seat headrest. The straps connect to the safety belt when in use. A lock control handle in the left armrest controls the inertia reel to lock or unlock the harness; however, an unlocked harness automatically restricts a forward movement of the occupant when there is an impact force of 2 to 3 G's.

SHOULDER HARNESS LOCK CONTROL.

The shoulder harness lock control is in the left arm rest of both ejection seats. To unlock the harness, the occupant depresses the lock control handle and moves the handle to the forward position. This allows the occupant freedom to bend forward. To lock the har-

ejection seat




Figure 1-41

ness, the occupant depresses the lock handle and moves the handle aft, allowing it to enter the LOCK position detent.

LEFT HANDGRIP.

Raising the left handgrip on both seats locks the respective shoulder harness. If, during seat ejection, the occupant fails to lock the shoulder harness by placing the lock control handle in the aft position or by raising the left handgrip, the inertia reel locks the shoulder harness to retain the occupant in the seat.

RIGHT HANDGRIP. (GROUP E AIRPLANES)

The right handgrip and trigger on the pilot's and observer's seats control canopy jettison and seat ejection. The pilot's right handgrip also actuates the control column disconnect and stowage mechanism. Raising the pilot's right handgrip actuates two microswitches, completing circuits from the battery bus and the one-shot battery to the snatch unit control relay. If battery power is available, the control column detonator fires, separating the control column from the elevator tube. The snatch unit solenoid then releases a spring, causing the control column to be stowed forward to the instrument panel. If the battery is dead, the snatch unit relay is de-energized and electrical power is received from the one-shot battery to stow the control column.


RIGHT HANDGRIP. (GROUP F AIRPLANES)

The right handgrip and the trigger within the loop of the handgrip on both seats control canopy jettison, and seat ejection. Raising the pilot's right handgrip fires two M-3 initiators simultaneously. The gas

created by one of the M-3 initiators removes pins that disconnect the elevator linkage and releases the control column snatch unit spring. The spring slams the column forward against the instrument panel. Only the pilot's right handgrip actuates the snatch unit, while the canopy jettisons when either of the right handgrips is actuated. Gas from the second M-3 initiator fires the lock thruster, thereby moving the canopy locks to the open position. The movement of the canopy thruster pulls a pin from a third M-3 initiator. Gas from the third M-3 initiator fires an M-5 initiator which in turn fires the canopy remover. Squeezing the trigger against the raised grip fires a fourth M-3 initiator and gas from this initiator explodes the seat catapult. Each occupant must raise his right grip to the locked position before squeezing the trigger for individual seat ejection.

SEAT ADJUSTMENT LEVER.

Manual operation of the seat lever vertically adjusts the seat to a desired position, and seat ejection can take place from any position of vertical adjustment. The pilot's seat adjustment lever is on the right side of the seat and the observer's lever is on the left side of the seat. To move the lever, it is necessary to depress the button on the end of the lever. Depressing the button releases a pin from one of several holes in a quadrant attached to the side of the seat. Moving the lever forward and down lowers the seat; moving the lever upward and aft raises the seat. When the vertical adjustment is satisfactory, the occupant releases the lever button. A slight vertical movement of the seat by the occupant permits the pin to drop into the nearest hole in the quadrant.



MA-3 or 4 automatic opening belt




Figure 1-42

MA-5 or 6 automatic opening belt LOCKED MANUALLY UNLOCKED PARACHUTE LANYARD AUTOMATIC RELEASE BUCKLE SWIVEL LINK RELEASE BUCKLE AUTOMATICALLY OPENED

Figure 1-42A

11788

MA-3 OR MA-4 AUTOMATIC SEAT BELT.

The MA-3 (or MA-4) automatic belt (figure 1-42) consists of two adjustable webbed belts, an eye buckle, a latch buckle, a latch buckle key, and a flexible hose. The occupant fastens the belt by inserting the eye buckle through the loops of the shoulder harness and placing the eye buckle on the stud of the latch buckle. The occupant then presses the key into the springloaded receptacle on the side of the latch buckle and depresses the latch lever. A finger moves into position to retain the eye buckle to the stud of the latch buckle. After ejection, gas pressure through the flexible hose moves the finger out of the locked position to free the occupant from the seat. The key remains in the receptacle of the latch buckle and as the occupant separates from the seat, the parachute lanyard actuates the aneroid-release device of the parachute. See AUTOMATIC OPENING SEAT BELT AND PARA-CHUTE in Section VII.

WARNING

Use the latch key attached to the lanyard of the automatically opening parachute. When using a manually opened parachute, insert the latch key attached to the MA-4 webbed belt.

For normal release, the occupant lifts the latch lever which causes the spring-loaded receptacle to move the finger out of the locked position and release the key.

MA-5 OR MA-6 AUTOMATIC SEAT BELT.

The MA-5 (or MA-6) automatic seat belt (figure 1-42A) consists of two adjustable webbed belts, a manual release buckle, a swivel link, an automatic release buckle, and a flexible hose. The occupant fastens the belt by inserting the swivel link through the loops of the shoulder harness and parachute lanyard. He then places the swivel link in the manual release buckle and locks the link in position with the manual release lever. After ejection, gas through the flexible hose moves a locking finger in the automatic release buckle to the unlocked position to free the occupant from the seat. A shoulder on the swivel link retains the loop of the parachute lanyard, and as the occupant separates from the seat, the parachute lanyard actuates the aneroid-release device of the parachute. See AUTO-MATIC OPENING SEAT BELT AND PARACHUTE in Section VII.

SEAT BELT AUTOMATIC RELEASE MECHANISM.

During ejection, as the seat rises along the guide rails, a telescopic tube fixed to the frame of the airplane pulls a pin to fire a slow-burning initiator. Gas from the initiator operates the release mechanism of the belt 2.5 seconds after the pin fires the initiator.

FIRE PROTECTION.

Each engine has a separate fire and overheat detection system. The system senses the presence of fire or an overheated condition in the engine area and electrically transmits this information to indicator lights on the pilot's instrument panel. Separate fire extinguishing systems for each engine route bromochloromethane from a bottle in the wings inboard of the engines to the nacelles.

Note

Repeated or prolonged exposure to high concentrations of Bromochloromethane (CB) or decomposition products should be avoided. CB is a narcotic agent of moderate intensity but of prolonged duration. It is considered to be less toxic than carbon tetrachloride, methyl bromide, or the usual products of combustion. Bromochloromethane is safer to use than previous fire-extinguishing agents. However, normal precautions should be taken, including the use of 100% oxygen when available.

FIRE AND OVERHEAT DETECTION SYSTEM.

Each engine contains two detector systems—one for fire detection and one to warn the pilot of an overheated condition. (See figure 1-43.) The fire detection system consists of nine fire detectors strategically placed in each engine nacelle area forward of the fire wall, an indicator light for each engine, a detector test switch, a lamp test switch, and an overheat blinker relay for each engine. The indicator lights and detector test switch are common to both systems. An excessive amount of heat causes the temperature-sensitive fire detectors and overheat detectors to complete a circuit to the indicator light on the pilot's main instrument panel. The blinker (flasher) relay in the overheat circuit causes the indicator light to flash. The fire detectors and overheat detectors cannot distinguish between an engine fire or an engine overheat condition. However, upon observing a flashing red light, the pilot may assume that an overheat condition exists in the aft engine nacelle area and when observing a steady red light the pilot must assume that a fire exists in the forward engine nacelle area. The 28-volt d-c distribution bus supplies the power to operate the system.




Figure 1-43

FIRE AND OVERHEAT DETECTION TEST SWITCH.

The three-position momentary fire and overheat detection test switch is on the pilot's left main control panel. Operation of the switch checks the continuity of the fire and overheat detection circuits. Holding the switch in the FIRE position completes the fire detection circuit to illuminate both lamps in the PULL-TO-ARM knobs. Placing the switch in the OVERHEAT position completes the overheat detection circuit through a flasher unit to illuminate both lamps in the PULL-TO-ARM knobs. The 28-volt dc distribution bus supplies the power to operate the test circuit.

FIRE AND OVERHEAT DETECTION LIGHTS.

A red warning light in each fire extinguisher PULL-TO-ARM knob warns the pilot of fire or an overheat condition in the engine nacelle area. (See figure 1-43.) A fire in the forward engine nacelle area causes the detectors to complete a circuit to illuminate their respective indicator light. An overheat condition in the aft engine nacelle area causes the detectors to complete a circuit through a flasher relay unit to illuminate their respective indicator light. The light goes out after the fire has been extinguished or the overheated condition alleviated. The 28-volt d-c dis-

tribution bus supplies the power to operate the light circuit.

FIRE AND OVERHEAT INDICATOR LAMP TEST SWITCH.

The fire and overheat indicator lamp test switch is on the pilot's left main control panel. Holding the switch in the LAMP position tests lamp operation. The 28volt d-c distribution bus supplies the power to operate the test circuit.

FIRE EXTINGUISHER SYSTEM.

The fire extinguisher system (figure 1-43) sprays bromochloromethane into the engine nacelle area. Bromochloromethane expands into a dense gas in the presence of high heat or flame. The system consists of a bottle of bromochloromethane in each wing inboard of the engines: hydraulic valves, fuel valves, and compressors air shut-off valves; an arming knob for each engine; and an agent discharge switch. One operation of the fire extinguisher system exhausts the supply of bromochloromethane. The bottles supply their respective engine nacelle areas only. The 28-volt d-c electrical system supplies the power to operate the extinguisher system.

FIRE EXTINGUISHER PULL-TO-ARM KNOBS.

The PULL-TO-ARM knobs (figure 1-43) on the main instrument panel energize the fire extinguisher system. Each knob contains a (red) warning light. Pulling the knobs out arms the AGENT DISCHARGE switch and causes the hydraulic, fuel, and compressor air shut-off valves to move to the closed position. The 28-volt d-c pilot's circuit breaker bus supplies the power to operate the circuit.

Pulling the PULL-TO-ARM knob closes the air conditioning shut-off valve. This eliminates the possibility of the toxic bromochloromethane fumes from entering the cabin through the air conditioning system. However, use 100 percent oxygen for added protection.


FIRE EXTINGUISHER AGENT DISCHARGE SWITCH.

The AGENT DISCHARGE switch is on the pilot's main instrument panel. (See figure 1-43.) The switch is not armed until one of the PULL-TO-ARM knobs is in the out position. When one of the PULL-TO-ARM knobs is in the out position, placing the agent discharge switch in the AGENT DISCHARGE position energizes a circuit to an explosive cartridge on the respective fire extinguisher bottle. The 28-volt d-c pilot's circuit breaker bus supplies the power to operate the circuit.

AUXILIARY EQUIPMENT.

Refer to Section IV for a discussion of the air-conditioning and pressurization system, the defogging and anti-icing systems, communication and electronic equipment, oxygen system, navigation equipment, armament equipment, and miscellaneous equipment.





- 1. WING TIP FUEL TANK
- 2. WING TIP FUEL TANK FILLER
- 3. PNEUMATIC GUN CHARGING BOTTLE (GROUP A)
- 4. FIRE EXTINGUISHER BOTTLE
- 5. NO. 1 FUSELAGE FUEL TANK FILLER
- 6. NO. 1 FUSELAGE FUEL TANK
- 7. NO. 2 FUSELAGE FUEL TANK
- 8. NO. 2 FUSELAGE FUEL TANK FILLER
- 9. NITROGEN PURGE BOTTLES
- 10. NITROGEN PURGE BOTTLE FILLER
- 11. SPARE STARTER CARTRIDGES
- 12. AFT FUSELAGE DATA CASE
- 13. LIGHT LENS STOWAGE
- 14. WING FUEL TANK
- 15. WING FUEL TANK FILLER
- 16. PNEUMATIC GUN CHARGING FILLER (GROUP A)
- 17. TIRES AIR FILLER STEM
- 18. ENGINE OIL TANK FILLER
- 19. ENGINE OIL TANK
- 20. OXYGEN CONVERTER
- 21. HYDRAULIC BRAKE ACCUMULATOR

22. BATTERY

16 15 14

- 23. SPARE LAMP AND FUSE STOWAGE
- 24. PORTABLE FIRE EXTINGUISHER
- 25. OXYGEN FILLER
- 26. MAIN HYDRAULIC ACCUMULATOR
- 27. HYDRAULIC RESERVOIR AND FILLER

SPECIFICATIONS

FUEL MIL-F-5624A

GRADE JP-4

ALTERNATE FUEL - JP-3

EMERGENCY

OXYGEN-

ALTERNATE FUEL - MIL-F-5572

HYDRAULIC FLUID - MIL-O-5606

AN-O-1c GRADE B

TYPE 2 (LIQUID)

FIRE EXTINGUISHER—BROMO-CHLORO-

METHANE (CB)

11680A

Section II



NORMAL PROCEDURES

11658

TABLE OF CONTENTS

| Po | age |
|----------------------------|-----|
| STATUS OF AIRPLANE | 2–1 |
| AIRPLANE ENTRANCE | 2–2 |
| BEFORE EXTERIOR INSPECTION | 2-3 |
| EXTERIOR INSPECTION | 2-5 |
| INTERIOR INSPECTION | 2–7 |
| BEFORE STARTING ENGINES | 2–8 |
| STARTING ENGINES 2 | -10 |
| BEFORE TAXIING 2 | -11 |
| TAXIING 2 | -12 |
| BEFORE TAKE-OFF 2 | -12 |
| TAKE-OFF 2 | -13 |
| AFTER TAKE-OFF 2 | -14 |

| | Page |
|---------------------------|------|
| CLIMB | 2-14 |
| TRANSFERRING FUEL CONTROL | 2-15 |
| CRUISE | 2-15 |
| FLIGHT CHARACTERISTICS | 2-15 |
| DESCENT | 2-15 |
| TRAFFIC PATTERN CHECK | 2-15 |
| TOUCH-AND-GO LANDING | 2-18 |
| LANDING | 2-18 |
| GO-AROUND | 2-18 |
| AFTER LANDING | 2-19 |
| STOPPING ENGINES | 2-19 |
| BEFORE LEAVING AIRPLANE | 2-19 |
| COMPENSED CHECK LICT | 2 20 |

STATUS OF THE AIRPLANE.

FLIGHT PLANNING.

 Accumulate the necessary weather data and flight equipment (maps, computer, pencil, flashlight, etc.) and check NOTAMS.

- Compute cruise control data (airspeeds, power settings, gross weights, etc.) from the operating data in Appendix I of this handbook.
- Check that the required fuel, oil, oxygen, armament, and all special equipment are suitable and in sufficient quantity for the mission to be performed.



11651

Figure 2-1

- Brief the observer on mission and emergency procedures.
- 5. Complete and file a clearance.

FLIGHT RESTRICTIONS.

Refer to Section V for flight and engine limitations.

WEIGHT AND BALANCE.

The airplane is stable if the center of gravity is within the published limits. The control-stick-force-per-G characteristics of the airplane vary over a wide range. The forces are high with the center of gravity at the forward limit and low with the center of gravity at the aft limit. The center of gravity is very close to the aft stability limit during take-off with maximum gross weight. You, the pilot, should be aware of this fact to insure that you do not inadvertently exceed the stability limits. Variation in the center of gravity of the airplane is primarily due to fuel consumption; therefore, use the correct fuel management procedures. Also, be careful when adding extra baggage or equipment to the aircraft. Refer to Section V for weight and balance limitations, to HANDBOOK OF

WEIGHT AND BALANCE, T.O. 1B-1-40, and to BASIC WEIGHT CHECK LIST AND LOADING DATA, T.O. 1B-57B-5, for loading information. Before each flight:


- Check take-off and anticipated landing gross weights.
- Check weight and balance clearance. DD Form 365F.
- 3. Compute the take-off performance data.
- Check the landing distance and final approach speed for the anticipated landing gross weight and pressure altitude.

AIRPLANE ENTRANCE. (See figure 2-1.)

For entrance:

- 1. Place the canopy external control switch (left electrical access compartment) in UP.
- Actuate the external hand pump (above the canopy external control switch) to build up sufficient hydraulic system pressure to open the canopy.
- 3. Place a portable ladder in position for entry.

seat safety pins



11652

Figure 2-2

BEFORE EXTERIOR INSPECTION.

Before making the exterior inspection, complete the following checks:

| 1. | Canopy | Condition and cleanliness | |
|----|--|---------------------------|--|
| 2. | Canopy safety pin | In place | |
| 3. | Seat safety pins, front and rear | In place | |
| | (See figure 2-2.) | | |
| 4. | DD Form 781 | Check | |
| | Determine the engineering status of the airplane and check for proper servicing. | | |
| 5. | Publications | In place | |
| | | | |

- Check the data case for the following:

 a. Radio Facility Charts (LF/MF Edition)
- b. Supplementary Flight Information Document
- c. Pilot's Handbooks-Jet, East and West
- d. Flight Handbook, T.O. 1B-57B-1
- All armament switches OFF or SAFE
 Place the following armament switches in the OFF or SAFE position: Master guns switch, select armament switch, gun charger switch, bomb.

arming switch, rocket fuzing switch, bomb bay station switches, and external station switches.

| 7. | Tip tank jettison switch | OFF |
|-----|----------------------------|----------------|
| 8. | Landing gear lever | Down |
| 9. | Emergency gear T-handle | In |
| 10. | Battery switch | OFF |
| 11. | Power distribution circuit | All circuit |
| | breaker panel | breakers ON or |
| | | IN |
| 12. | Seat quick-disconnect pins | In place |

- 13. All emergency equipment Stowed

 Check the following emergency equipment for
- proper stowage: Hydraulic hand pump handle, crash axe, and fire extinguisher.

 14. Main system hydraulic pres- Zero pressure

sure gage

SOLO FLIGHT INSPECTION.

Before a solo flight, secure the aft crew station.

- Fasten the seat belt, shoulder harness, oxygen hose, and radio cord.
- 2. Place the oxygen supply lever in the OFF position.
- 3. Check seat safety pins.




Figure 2-3

EXTERIOR INSPECTION. (See figure 2-3.)

At each of the following inspection points, check the condition of the airplane for miscellaneous damage, dents, etc. Also, check the security of all access doors and that all control surfaces locks and mooring lugs have been removed and stowed in the tail section.

1. LEFT NOSE SECTION.

| a. | domb | door | shut-off | valve | SAFE |
|----|------|------|----------|-------|------|
|----|------|------|----------|-------|------|

- b. Personnel safety switch SAFE
- c. Battery compartment Check Disconnect the battery and check the brake accumulator pressure gage for 850 psi min.
- d. Left electrical access com- Check partment Check for proper stowage of the external hand pump handle. Also, place the following circuit breakers to the IN position: standby instrument inverter, J-2 compass, APX-6A, and helmet defog.

| e. Shoran antenna | | Condition |
|-------------------|-----------------|----------------|
| f. | Static air vent | Open and clean |

g. Nose hatch Secure

2. RIGHT NOSE SECTION.

- a. Pitot cover Removed
- b. Static air vent Open and Clean
- c. UHF antenna Condition
- d. Pressure regulator static Open
- e. Right electrical access com- Check
 partment
 Inspect inverter for indication of overheating
 or scorching.
 Check security of fuses, electrical leads, and
 for loose equipment.
- f. Right upper equipment Check compartment
 Check the oxygen filler cap for security and that the build up lever is in the BUILD UP position. Be sure the cabin pressure regulator handle is in the FLIGHT position and safety wired. The UHF radio switches must be in the BOTH, REMOTE, and VOICE position.

3. NOSE WHEEL WELL.

- a. Gear lock safety pin In place
- b. Gear strut for correct in- 6 to 9 inches flation
- c. Condition of tires, wheels Check and fairing doors
 Check the tires and wheel assembly for slippage, and wheel lock nuts for security.

4. BOMB BAY (RIGHT SIDE).

| a. | Forward | bomb | door | actu- | Leakage |
|----|-----------|-------|------|-------|---------|
| | ating cyl | inder | | | |

- b. Fuel manifolds and lines Leakage
- c. Defueling valve Wired closed
- d. No. 1 and No. 2 fuselage Leakage and tank boost pumps and No. connection 2 probe
- e. Aileron crossover rods Possible distortion
- f. Aft bomb door actuating Leakage cylinder
- g. Hydraulic equipment and Leakage lines
- h. Boost pump drains Check for moisture

5. RIGHT WHEEL WELL.

- a. Gear lock safety pin In place
- b. Gear doors, linkage, and Condition pins
- c. Fuel strainer Security and leakage
- d. Main system hydraulic ac- 1000 psi cumulator
- e. Interphone switch NORMAL and cap in place
- f. Hydraulic fluid level Check
- g. Fire extinguisher bottle 450 psi
- h. Microswitches Condition
- i. Gear extender valve re- Check moved and port covered
- j. Gear strut for correction 1½ to 3 inches extension
 Strut extension varies with airplane gross

weight.

Note

The extension of both main gear struts should be equal.

| k. Tire and wheel | Condition and |
|-----------------------------|---------------|
| | slippage |
| 1. Brake assembly | Condition |
| m. Hydraulic and fuel lines | Leakage |
| n. Wheel chocks | In place |

6. RIGHT ENGINE.

- a. Cowling Secure
- b. Ground cooling door Secure and cable

taut

c. Starter breech lock and Secure dome

Note

Be sure that the clip is removed from the starter cartridge.

d. Front main bearing

Oil seepage

CAUTION

If oil seepage is excessive, check the front main bearing seal prior to flight.

e. Engine and generator air Clear intake ducts
Insure that the generator duct is free of moisture.

f. Compressor blades

Check for cracks

and breaks

g. Frangible doors

Condition

7. RIGHT WING.

a. Under surface of wing Check Inspect for fuel leaks, cracks, and security of all access doors. Check dive brakes and pylons for security and that mooring lugs are removed.

b. Fuel drain valve No leakage
With the right wing boost pump on, inspect
the fuel drain valve in the nacelle for leaks.

c. Fuel vent Check
Inspect vent mast for cracks and distortion.

d. Navigation and taxi lights Check

e. Tip tank Check

Check tip tank for security, dents, and leaks.

f. Aileron and tab Check
Remove locks and check aileron for binding
and full travel.

g. Wing flaps Condition

h. Tail pipe Check Check the tailpipe for cracks, dents, holes, and wrinkles and the condition of the turbine wheel. Also look for any accumulation of fuel or oil.

8. RIGHT REAR FUSELAGE.

a. Navigation lights Condition

b. Nitrogen purge indicator Check and filler cap

The nitrogen system gage should indicate 400 psi for airplanes in a non-combat status and 1000 psi for airplanes in a combat status.

c. Dive brake Condition

 d. Dive brake actuating cyl- Leakage inder

e. Aft fuselage entrance door Closed

f. Fuel vent mast Cracks and distortion

g. Tail skid Condition

9. EMPENNAGE.

a. Control locks Removed
 b. Stabilizer surfaces and Condition and tabs freedom of

movement

c. Variable - incidence stabi- Condition lizer

d. Navigation lights

Condition

10. LEFT REAR FUSELAGE.

a. Dive brake Condition

Dive brake actuating cyl- Leakage inder

c. Aft fuselage compartment Check Check for fuel and hydraulic leaks. Inspect control rods and hydraulic cylinders for condition and security. Check the stowage of spare starter cartridges, control locks, and loose articles.

d. Nitrogen purge blow-out Intact disk

11. LEFT WING.

a. Tail pipe Check Check the tailpipe for cracks, dents, holes, and wrinkles and the condition of the turbine wheel. Also look for any accumulation of fuel or oil.

b. Fuel drain valve

With the left wing tank boost pump on, inspect the fuel drain valve in the nacelle for leaks.

c. Wing flaps Condition

d. Aileron and tab Check
Remove locks and check aileron for binding
and full travel.

e. Tip tank Check
Check tip tank for security, dents, and leaks.

f. Fuel vent Check
Inspect vent mast for cracks and distortion.

g. Under surface of wing Check Inspect for fuel leaks, cracks and security of all access doors. Check landing light for condition. Check dive brakes and pylons for security and that mooring lugs are removed.

h. Navigation and taxi Check lights

12. LEFT ENGINE.

a. Engine and generator air Clear intake ducts
 Insure that the generator duct is free of moisture.

Starter breech lock and Secure dome

Note

Be sure that the clip is removed from the starter cartridge.

c. Front main bearing Oil seepage

CAUTION

If oil seepage is excessive, have the front main bearing seal checked prior to flight.

| d. | Cowling | Secure |
|----|--------------------------|--------------------------------|
| e. | Ground cooling door | Secure and cable |
| | | taut |
| f. | Cabin ram air inlet duct | Clear |
| g. | Frangible doors | Condition |
| h. | Compressor blades | Check for cracks and breaks |

13. LEFT WHEEL WELL.

| a. | Gear lock safety pin | In place |
|----|---|------------------|
| Ь. | Gear doors, linkage, and pins | Condition |
| c. | Fire extinguisher bottle | 450 psi |
| d. | Fuel strainer | Security and |
| | | leakage |
| e. | Microswitches | Condition |
| f. | Gear extender valve re- moved and port covered | Check |
| g. | Gear strut for correct ex- tension | 1½ to 3 inches |
| | Strut extension varies wit | h airplane gross |

weight. h. Tire and wheel Condition and slippage

Note

The extension of both main gear struts should be equal.

| i. | Brake assembly | Condition |
|----|--------------------------|-----------|
| j. | Hydraulic and fuel lines | Leakage |
| k. | Wheel chocks | In place |

14. BOMB BAY (LEFT SIDE).

| a. | Forward | bomb | door | actu- | Leakage |
|----|-----------|-------|------|-------|---------|
| | ating cyl | inder | | | |

| h | Hydrau | lic | valves | and | lines | Leakage |
|---|--------|-----|--------|-----|-------|---------|

| | Company of the second | | | | Contract Con |
|----|-----------------------|-------|-----------|-------|--|
| c. | No. 1 | and N | lo. 2 fus | elage | Leakage and |
| | tank | boost | pumps | and | connection |
| | probe | | | | |

| d. | Aileron | cross | over | and | Possible |
|----|---------|-------|------|-----|------------|
| | control | rods | | | distortion |

| e. | Aft bomb door actuating cylinder | Leakage |
|----|----------------------------------|-----------|
| f. | Boost pump drains | Check for |
| | | moisture |

15. LEFT NOSE SECTION.

| a. | Bomb door shut-off valve | FLIGHT |
|----|--|-----------|
| Ъ. | Personnel safety switch | FLIGHT |
| c. | Battery | Connected |
| d. | Emergency canopy initia- tor safety pin | Removed |
| e. | All hatches | Secure |

16. TOP SURFACE INSPECTION.

Fuel and oil tanks Check Check all fuel and oil tanks for quantity. Check all filler caps and doors for security. Inspect the top surface of the wings for dents, cracks, etc., and the wing dive brakes for condition.

| INT | ERIOR INSPECTION. | |
|-----|--|------------------------|
| 1. | Parachute, shoulder harness, and seat belt | Adjusted |
| 2. | Inertia reel | Unlocked |
| 3. | Oxygen hose, bail-out bottle, and radio cord | Connected |
| 4. | Seat and rudder pedals | Adjusted |
| 5. | Parking brake | Set |
| 6. | External power | Connected |
| 7. | Star valve | Closed (safetied) |
| 8. | Electrical distribution panel circuit breakers | All ON or IN |
| 9. | Emergency canopy release Thandle | In |
| 10. | UHF radio | OFF |
| 11. | Wing flaps switch | UP |
| 12. | Throttles | OFF |
| 13. | Dive brakes switch | Retract |
| 14. | Taxi and landing lights switch | OFF |
| 15. | Fire extinguisher agent discharge switch | OFF |
| 16. | Altimeter | Set to field elevation |
| 17. | Clock | Set and operating |
| 18. | Fuel panel (Group C air- | Set for start |

Place the emergency fuel control switches and the wing tank-tip tank selector knobs in OFF. Insure that safety wire retains the No. 1 boost

pump switch, the No. 1 and No. 2 engine valve knobs, and the No. 1 fuselage tank transfer and bypass valve knob in ON or FLOW. Place the No. 2 fuselage tank selector knob in the flow position.

Fuel panel (Group D air- Set for start planes only)

Place the fuel control switches and knobs in the following positions: Emergency fuel control switches, OFF; NO. 2 fuselage tank selector knob, flow; Wing tank tip tank selector knobs, OFF; NO. 1 and NO. 2 engine valve switches, ON; and the NO. 1 fuselage tank transfer and bypass valve knob in the flow to NO. 1 tank position.

| 19. | Inverter switches | All OFF |
|-----|-------------------|---------|
| 20 | | OFF |

20. Starting and ignition switches OFF

21. Voltmeter selector switch to Check voltage.

BAT BUS (18 volts minimum)

22. Generator switches ON

23. Oxygen quantity gage 4.0 to 4.5 liters

24. Air conditioning control Check panel

Place the air conditioning controls and switches

in the following positions:

Dump valve guard DOWN
Cabin pressure selector RAM
Temperature control AUTO
Set the temperature rheostat as desired.

25. Interphone control panel As desired

26. Radio compass OFF

27. APW-11A radar set OFF

28. Windshield control panel All switches
OFF

29. Defog air knob As desired

30. A-c and d-c circuit breakers All in except GPI

31. Lighting control panel As desired switches

32. IFF OFF

33. AIC filter switch BOTH
34. Oxygen system Checked

- a. Place the diluter lever in NORMAL OXY-GEN and blow gently into the oxygen regulator hose. (A resistance to blowing indicates satisfactory operation of the demand diaphragm.)
- b. Place the diluter lever in 100% OXYGEN and blow gently into the oxygen regulator hose. (A resistance to blowing indicates satis-

- factory operation of the demand diaphragm and diluter air valve.)
- c. Don the mask and connect the mask to the regulator hose. (Breathe normally and note operation of the blinker dial.)
- d. Hold breath and place the EMERGENCY pressure lever to the right or left. (A positive pressure felt within the mask indicates proper emergency oxygen flow.)
- e. Depress the EMERGENCY pressure lever while holding the breath to test the mask for leakage. (A properly fitted mask will retain the EMERGENCY oxygen pressure until normal breathing is resumed.)
- f. Mask hose fittings are properly seated and secure.
- g. The mask hose attachment to the parachute harness is as required.
- 35. All indicator and warning PRESS TO lights TEST

INTERIOR INSPECTION (NIGHT FLIGHT)

For night operation, perform all of the preceding checks, and add the following:

1. Navigation lights ON

2. All other lights Checked

Note

Spare lamps are in a kit on the pilot's right console. Fuses and additional spare lamps are in the right electrical access compartment and are inaccessible in flight.

BEFORE STARTING ENGINES.

When available, use an external source for starting the engines. When using battery power to start the engines, turn off all unnecessary electrical equipment.

Note

A battery contactor joins the battery to the 28-volt d-c generator bus. Placing the battery switch on completes a circuit from the battery to the battery contactor. The battery must be of sufficient voltage (approximately 18 volts) to close the contactor and join the battery to the 28-volt generator bus. Since the starting and fuel systems receive their power from the generator bus, you will be unable to start the engines if the battery voltage is low. To determine battery voltage, place the voltmeter selector switch in BAT BUS and observe the voltmeter.




Figure 2-4

WARNING

Insure that the starting and ignition switch is OFF before placing a cartridge in the starter breech. All ground personnel must be at least 25 feet from the plane of rotation of the starter turbine wheel before starting the engines. See DANGER AREAS, figure 2-4.

STARTING ENGINES.

When practicable, head the airplane into the wind when starting the engines to keep fumes out of the cabin and to aid engine cooling.

To avoid carbon-monoxide poisoning, follow this procedure during engine start, taxiing, run-up, and takeoff:

- 1. Use 100 percent oxygen.
- Place the cabin pressure selector switch in RAM.
- 3. Place the cabin pressure selector switch and oxygen diluter lever to NORMAL after take-off.

STARTING ENGINES WITH EXTERNAL POWER.

Use the following procedure when starting the engines with external power:

1. Ground crew Clear 2. Fire detection system Check Check the operation of the fire and overheat detection system and lights by placing the fire detector test switch first in FIRE, then in OVER-HEAT, observing that the lights in the pull-toarm knobs illuminate steadily in the FIRE position and blink in the OVERHEAT position.

3. Interphone

On

Note

Distinct clicks over the interphone or from outside the airplane indicates proper functioning of the timer and ignition circuit.

4. NO. 2 engine throttle

IDLE

5. NO. 2 start and ignition START switch

Note

A faulty throttle microswitch can prevent detonation of the cartridge. If the cartridge does not detonate, attempt the start by placing the starting and ignition switch in the CRANK ONLY position.

 The voltage regulators do not effectively control the generators at idle rpm; therefore, the low output voltage of the generator causes illumination of the failure warning light. Under this condition, placing the generator switch in RESET does not put the generator "on the line". To put the generator on the line, increase the generator rpm by advancing the throttle slightly or increase the load on the electrical system.

The expanding gas from the starter cartridge causes the engine to accelerate to 18 to 22 percent rpm. A timer automatically stops ignition and fuel priming after 15 ± 3 seconds. After the "light-up", the engine accelerates to 36 to 42 percent rpm (idling speed) and the oil pressure is 10 to 20 psi, the fuel flow is 1000 pph, and the exhaust gas temperature is approximately 550 degrees C. Refer to ENGINE LIMITA-TIONS in Section V.

6. Engine instruments

Check

7. Hydraulic system pressure Check

8. Canopy

Close

Repeat steps 4 through 6 for the NO. 1 engine.

9. Landing gear ground lock In sight, then pins

stowed

10. External power source

Disconnected

11. Battery switch

BATTERY

12. Inverters

On

STARTING ENGINES WITH BATTERY.

Because you must conserve the battery for the engine start, do not use battery power to check electrical or electronic equipment before starting the engines. Use this procedure to start the engines without external power:

1. Voltmeter selector switch

BAT BUS

Note

If the battery voltage is 18 volts or more, you may assume that the battery contactor will close. Refer to BEFORE STARTING EN-GINES in this section.

2. Ground crew

Clear

3. Battery switch

BATTERY

4. Fire detection system

Check

Check the operation of the fire and overheat detection system and lights by placing the fire detector test switch first in FIRE, then in OVER-

HEAT, observing that the lights in the pull-toarm knobs illuminate steadily in the FIRE position and blink in the OVERHEAT position.

5. Interphone

ON

Note

Distinct clicks over the interphone or from outside the airplane indicate proper functioning of the timer and ignition circuit.

6. NO. 2 engine throttle

IDLE

7. NO. 2 start and ignition START

The expanding gas from the starter cartridge causes the engine to accelerate to 18 to 22 percent rpm. A timer automatically stops ignition and fuel priming after 15 ± 3 seconds. After the engine "light-up", the engine accelerates to 36 to 42 percent rpm (idling speed) and the oil pressure is 10 to 20 psi, the fuel flow is 1000 pph, and the exhaust gas temperature is approximately 550 degrees C. Refer to ENGINE LIMITATIONS in Section V.

Note

Do not turn off the battery switch if the engine fails to start. Instead immediately attempt to start the other engine.

8. Engine instruments

Check

9. Hydraulic system pressure Check

gage 10. Canopy

Close

Repeat steps 6 through 8 for the NO. 1 engine.

11. Gear lock safety pins

In sight, then stowed

12. Inverters

On

HOT START.

A faulty starter cartridge, timer, or primer can cause a hot start. The maximum permissible exhaust temperature during starting is 800 degrees C. If the exhaust gas exceeds this temperature:

- 1. Immediately place the throttle OFF.
- Determine the cause of the excessive temperature.
- Attempt a second start after eliminating the cause of the overtemperature and allowing the fuel to drain from the combustion chamber.
- Record in DD Form 781 all starting temperatures that reach or exceed the limit. The engine requires an inspection after five hot starts.

FALSE START.

If the exhaust gas temperature does not rise before the engine accelerates to 17 percent rpm:

- 1. Move the throttle to OFF.
- 2. Eliminate the cause of the false start before making further starting attempts.
- Be sure that surplus fuel is completely drained from the combustion chamber before attempting another start.

CAUTION

Because of the excessive heat generated by the ignition coils during the starting cycle, make only two consecutive starting attempts. A 20-minute cooling period is required before making a third attempt. After 40 minutes or longer, this cycle may be repeated.

BEFORE TAXIING.

Refer to Section V for the exhaust gas temperature allowed for steady-state operation. If the exhaust temperature exceeds the maximum limit, shut down the engine immediately. Complete the following checks before taxiing.

| | 0 | |
|----|---------------------------|---------------|
| 1. | Generators | Check output |
| 2. | Voltmeter selector switch | Check all |
| | | positions |
| 3. | Aileron trim | Neutral |
| | | (green light) |
| 4. | Rudder trim | Neutral |
| | | (green light) |
| | | |

Note

Prior to checking rudder trim, neutralize the rudder.

 Horizontal stabilizer override NOR switch (Group O Airplanes)

5a. Horizontal stabilizer NORMAL emergency switch (Group P Airplanes)

6. Horizontal stabilizer 1/4 division nose (Group O Airplanes) down

Actuate the horizontal stabilizer through a complete cycle in the normal system. Then use the override switches to actuate the stabilizer through a complete cycle and return the system to normal. Have the ground crew observe the

stabilizer travel during check.

6a. Horizontal stabilizer 0°
(Group P Airplanes)

Actuate the stabilizer through a complete cycle. Have the ground crew observe the stabilizer travel during the check.

7. UHF radio
 8. J2 COMP SLAVE switch
 IN

CAUTION

The main system hydraulic pressure gage is a good indication of the proper functioning of the hydraulic system. Normally, the gage will show an imperceptible amount of movement and will indicate only an occasional recharge of the system at about 2-1/2 minute intervals. When no hydraulic component is being operated and the main system gage shows a continual oscillation, or a constant value of approximately 3,500 psi, these are indications of a malfunction of the hydraulic system. It is good pilot practice to check this after the gear has been retracted during the initial climb out after take-off. Discovery of a hydraulic malfunction at this stage of the flight may make possible a normal immediate landing without recourse to emergency procedures. Rapid continued fluctuation of this gage will indicate a malfunctioning or bypassing control valve which will generate excessive heat in the hydraulic lines. Rapid continued fluctuation of the gage will also indicate hydraulic leak in a pressure line or certain failures of the accumulator.

| 9. | Flight and engine instruments | Check |
|------|-------------------------------|-------------------|
| 10. | Fuel quantity | Check |
| | | (all tanks) |
| 11. | Fuel quantity indicator | Test |
| 12. | IFF | As desired |
| 13. | Radio compass function | ANT |
| | control | |
| 14. | GPI circuit breakers | In |
| 15. | Bomb door, dive brakes, and | Close and retract |
| | flaps (Group O and P air- | |
| | planes) | |
| 15a. | Elevator system bungee | Check operation |

Check the operation of the elevator system bungee by cycling the wing flap system. As the wing flaps extend and retract, a slight movement of the control column should occur indicating operation of the bungee.

(Group P airplanes)

Note

Check with the ground crew for the position of the bomb door, dive brakes, and flaps.

| ini- |
|------|
| |
| |
| |
| |
| |

TAXIING.

Steer the airplane by applying differential pressure to the brake pedals. The engines consume approximately 8 gallons (52) pounds of fuel a minute during taxiing under normal conditions. Complete the following checks while taxiing:

| 1. | Brakes | Check |
|----|-------------------------|-------|
| 2. | Turn and slip indicator | Check |

CAUTION

Stop taxiing and request a tow to the parking area if a loss of air charge in the nose oleo strut causes excessive noise, bottoming, or hard riding. Turning the nose wheel more than 20 degrees without air in the oleo will cause damage to the nose wheel and airplane structure.

Note

During night ground operation, the landing light should be used when necessary to supplement the taxi lights.

Figure 2-5 is deleted.

BEFORE TAKE-OFF.

PREFLIGHT AIRPLANE CHECK.

After taxiing to the take-off area, hold the brakes and check the following:

| 1. | Trim | Checked |
|----|--------------------------------|-------------------|
| 2. | Cabin pressure selector switch | RAM |
| 3. | Pitot heater switch | As desired |
| 4. | Canopy | Closed, light our |
| 5. | Wing flaps switch | UP |
| 6. | Seat belt and shoulder harness | Adjusted |
| 7. | Inertia reel | Unlocked |
| 8. | Flight controls | Check travel, |
| | | free and correct |
| | | movement |




Figure 2-6

Note

Prior to checking rudder movement, neutralize the rudder trim.

PREFLIGHT ENGINE CHECK.

1. Check that the fuel controls are in the following positions:

Engine valve knobs

Flow

No. 1 fuselage tank boost

Wired ON

pumps switch (Group C air-

planes only)

Flow to No. 1

Fuel transfer and bypass valve

fuselage tank

knob

Flow

No. 2 fuselage tank knob

Assure that the NO. 2 fuselage tank is feeding into the NO. 1 fuselage tank.

- 2. Advance the throttle for No. 1 engine to 90 percent rpm.
- 3. Place the emergency fuel control switch for No. 1 engine in EMERGENCY. The emergency fuel control warning light should come on.

Note

The engine rpm will increase or decrease immediately if the ambient conditions differ from those of a standard day. If the ambient conditions are near standard, no apparent change will occur.

4. Advance the throttle for No. 1 engine to FULL and check the rpm against figure 2-6.

CAUTION

If the results obtained in step 4 are not \pm 2 percent of the value specified in figure 2-6, maintenance will be required.

- 5. If the results are satisfactory, retard the throttle slowly to IDLE, and place the emergency fuel control switch in OFF when the rpm drops to 60 percent during deceleration. This will return the engine to the normal fuel control system.
- Repeat the above procedure for No. 2 engine.
- 7. Check the engine instruments for satisfactory readings.

TAKE-OFF.

- 1. Align the airplane with the runway and check the heading indication.
- 2. Depress the brakes.
- 3. Advance throttles to FULL and check engine instruments for normal readings.
- 4. Partially tighten the throttle friction knob to prevent "creepback" during take-off.

- All warning lights Out
- Release the brakes and commence the take-off.
 Use the brakes for directional control until there
 is positive rudder response (approximately 60 knots).

Note

When the brakes are released, hold the control column well forward of neutral to prevent the airplane from assuming the take-off attitude before it has reached the optimum take-off speed of approximately 110 knots IAS for an approximate gross weight of 45,000 pounds. If the take-off attitude is assumed before the optimum take-off speed, the increased drag appreciably lengthens the take-off run. If operating at maximum gross weight, the optimum take-off speed is approximately 120 knots IAS.

7. When the airplane attains optimum take-off speed, relax the forward pressure on the controls to allow the nose to rise slightly. A slight pull is necessary for the airplane to fly off the ground.

Note

A compressor discharge pressure limiter in the fuel control unit automatically reduces the fuel flow to the engine whenever the compressor discharge pressure exceeds a certain value. This excess pressure occurs at high speeds, low altitudes, and on cold days. Learn to recognize this condition to avoid unnecessary concern regarding the proper functioning of the engine fuel system.

CROSS-WIND TAKE-OFF.

In addition to the normal take-off procedure:

- Increase the nose wheel lift-off speed approximately 10 to 15 knots IAS by holding the nose wheel down a little longer during ground run.
- 2. Anticipate drift when the airplane lifts off; then lower a wing or "crab" into the wind.

NIGHT TAKE-OFF.

Night take-off procedure is the same as daylight operation; however, a thorough knowledge of switch and light location is essential. Follow this additional procedure:

- Adjust the cabin and instrument lights to the desired brilliance.
- 2. Use the runway lights for reference to maintain alignment with the runway on take-off run.

MINIMUM-RUN TAKE-OFF.

Refer to the take-off distance chart in APPENDIX I for the minimum distance required. To make a short take-off:

- If necessary, reduce gross weight by reducing fuel load.
- 2. Use all the available runway.
- Depress the brake pedals and advance the throttles to full.
- 4. Pull the airplane off the runway at a lower than normal airspeed (130 to 140 knots IAS).
- Retract the gear and start climbing at 340 knots IAS.

AFTER TAKE-OFF.

When the airplane is definitely airborne:

- Apply brakes lightly to stop the wheels from spinning.
- 2. Place landing gear lever in UP.

Note

Retraction time for the landing gear is approximately eight seconds.

CAUTION

When take-off is made with light gross weights, a high initial rate of climb or a reduction in power is necessary to avoid exceeding the 200 knots IAS maximum speed, for extended landing gear.

- Accelerate to the safe single engine speed by maintaining the take-off attitude.
- Check the landing gear warning light and position indicators for an "up" indication.
- Place the cabin pressure selector switch in NOR-MAL.
- Position the cabin temperature selector as desired.
- 7. Place the oxygen selector lever to NORMAL.

CLIMB.

Refer to the Performance Data Charts in Appendix I for best climb speeds and approximate time to attain a desired altitude with varied gross weights and configurations. Establish the initial climb at 340 knots IAS.

CAUTION

The maximum time allowed for use of maximum or military thrust is 30 minutes. Reduce power to 96.5 percent rpm for maximum continuous power as soon after take-off as practicable.

TRANSFERRING FUEL CONTROL.

To transfer from emergency fuel control to normal fuel control during flight, use the following procedure:

- 1. Set the throttle at 90% rpm.
- 2. Retard the throttle slowly to IDLE and place the emergency fuel switch to OFF at 60% rpm or less during the deceleration.
- 3. Accelerate slowly to the desired rpm.

CRUISE.

Refer to Appendix I for cruise data and to Section VII for fuel management procedure.

FLIGHT CHARACTERISTICS.

Refer to Section VI for information on flight characteristics.

DESCENT.

Refer to the descent charts in Appendix I. Before descent, complete the following checks:

1. Place the windshield anti-icing switch in ANTI-ICING position.

Note

Whenever possible, turn on the windshield anti-icing switch thirty minutes before a descent.

- 2. Pull the defog air knob up.
- 3. Turn on the defog hot air switch.
- 4. Adjust the defog air rheostat as desired.
- 5. Turn on the pitot heater.
- 6. Retard the throttles as necessary to avoid excessive airspeed.
- 7. If necessary, place the dive brake switch in EXTEND.

TRAFFIC PATTERN CHECK.

1. Alert the observer for landing

CAUTION

When landing with the emergency fuel control switches in EMER-GENCY, move the throttles slowly and smoothly to avoid engine compressor stall or overspeed.

2. All armament switches

OFF or SAFE

3. Fuel transfer and bypass valve Flow to NO. 1 knob

tank

- 4. NO. 1 fuselage tank boost ON pump switch (group C airplanes only)
- 5. Applicable fuel tank (con- Flow taining fuel) knob

Note

If the NO. 2 fuselage tank contains fuel, assure the NO. 2 fuselage tank selector knob is in the flow position and that the NO. 2 tank is feeding the NO.1 fuselage tank.

- 100% Oxygen
- 7. Safety belt and shoulder har-Adjusted and ness tight
- Unlocked 8. Inertia reel

The remaining operations, the places at which they are to be performed, and the safe approach speeds are shown on the Typical Landing Pattern Diagram. (See figure 2-7.)

9. Landing gear handle

DOWN

Down

CAUTION

Do not lower the gear above 200 knots IAS.

Note

The landing gear extension time is approximately six seconds. Operation of two or more hydraulic sub-circuits at the same time will not lengthen the normal operating time.

- 10. Landing gear position indi-Down
- 11. Landing gear warning light Out
- 12. Dive brakes As desired
- 13. Flaps

2500 psi mini-14. Main hydraulic system pressure gage mum


1000 psi mini-15. Brake pressure gage mum

CAUTION

Do not check brake operation by depressing the pedals after an emergency landing gear extension.

Note

Lowering the flaps causes the airplane to pitch up. On rare occasions the flaps may operate slightly out of unison. You will notice it because of a moderate rolling tendency. This condition lasts for one or two seconds, and is easily controlled.



normal partial power approach gross weight 37,500 pounds

11656




Figure 2-7 (Sheet 2 of 2)

LANDING.

Land on the main landing gear and hold the nose wheel off the runway by maintaining back pressure on the control column. Avoid an extreme tail-low attitude. After touchdown, intermittently apply pressure to the brake pedals.

CAUTION

Allow a ten-minute brake cooling period with the gear extended when making a series of full-stop landings. Allow thirty minutes if the gear is retracted.

If a condition of aft center of gravity due to fuel system malfunction or improper fuel management is suspected, perform a landing-characteristic stall at altitude. Refer to STICK FORCES in Section VI.

HEAVY WEIGHT LANDING.

Normal landing techniques apply to heavy weight landings except for the necessary increase in airspeed on final approach.

NIGHT LANDINGS.

The same technique and procedure used in a normal landing apply for night landings. If there is fog, smoke, or haze, avoid using the landing light. Reflection from the light impedes vision and may distort depth perception. Be alert when the landing light is on to avoid following the light beam into the ground. Extend the landing light below 200 knots IAS.

CROSS-WIND LANDING.

Use the standard wing-low-into-the-wind technique for cross-wind landings.

MINIMUM RUN LANDING.

A minimum run landing requires at least a 3000 foot runway. Make a wider-than-normal landing pattern and approach the end of the runway in a flat glide with sufficient power to maintain an airspeed 10 knots above stalling speed. Use flaps on approach and, after touchdown, lower the nose and brake immediately. Stall speeds vary with gross weight; therefore, if necessary, perform a characteristic power on, flaps-and-gear-down stall at approximately 5000 feet to determine the airspeed on final approach.

TOUCH-AND-GO LANDINGS.

Use normal approach and landing speeds when making touch-and-go landings. Use the following procedure after touchdown.

- 1. Throttles IDLE at touchdown.
- 2. Retract flaps immediately following touchdown.
- 3. Advance throttles smoothly to 70 to 75% rpm.

CAUTION

Advance throttles smoothly to prevent yawing due to asymetrical engine acceleration.

The throttles may be advanced as rapidly as required after the engines have stabilized at 70 to 75% rpm.

4. Proceed as in normal take-off.

GO-AROUND.

Make the decision to go around as soon as possible, and keep in mind that a jet-powered airplane does not accelerate nearly as rapidly as a propeller-driven airplane.

1. Advance throttles smoothly to 70 to 75 percent.

CAUTION

Advance throttles smoothly to prevent yawing due to asymmetrical engine acceleration.

Advance throttles to FULL as rapidly as necessary after the engines stabilize.

Note

Under standard sea-level conditions, the engines take eleven to fourteen seconds to accelerate from idle to maximum thrust.

3. Place the flaps switch in UP.

CAUTION

To prevent structural damage to the airplane, retract the flaps before attaining a speed of 170 knots IAS.

 Place the landing gear control in UP when a definite rate of climb has been established and contact with the ground will not be made.

Note

During the go-around it may be necessary to touchdown momentarily; therefore, establish a climb before raising the gear.

CAUTION

To prevent structural damage to the airplane, retract the landing gear before attaining a speed of 200 knots IAS.

- Place the dive brakes switch in RETRACT to retract the brakes.
- 6. Make trim changes as necessary.

AFTER LANDING.

| 1. | Wing flaps | UP |
|----|-----------------|----------------|
| 2. | Dive brakes | RETRACT |
| 3. | Trim indicators | Neutral |
| | | (green lights) |
| 4. | Canopy | As desired |

Note

If practicable, park the airplane headed into the wind and wait at least 15 minutes before putting on the engine covers or moving the airplane into the hangar. This is to disperse fuel fumes which might be present and which could cause an explosion.

STOPPING ENGINES.

Note

If the engines are being shut down from 95 percent rpm or above, pause for at least one minute at IDLE power to allow temperature conditions in the engines to stabilize, and then place the throttles in OFF. If engines are being shut down from below 95 percent rpm, throttles may be moved immediately to OFF.

1. Parking brake Set

2. Throttle NO. 2

Off

Note

Shut down the No. 2 engine first and check the hydraulic pump operation of the No. 1 engine.


| 3. | Hydraulic pressure NO. 1 en- | Checked |
|-----|--|---|
| | gine | |
| 4. | All radios and IFF | OFF |
| 5. | Inverters | OFF |
| 6. | Oxygen supply lever | OFF |
| 7. | Throttle NO. 1 | OFF |
| 8. | Fuel panel knobs (Group C airplanes only) | All OFF except those which are safetied |
| | Fuel panel knobs and switches (Group D airplanes only) | All OFF |
| 9. | Battery switch | OFF |
| 10. | Wheel chocks | In place |
| 11. | Parking brake | OFF |
| 12. | Armrest and canopy safety pins | Installed |
| 13. | All electrical switches | OFF |
| 14. | Control column | Secured |
| 15. | Canopy safety collar | In place |

BEFORE LEAVING AIRPLANE.

WARNING

Be sure that the seat safety pins are in place before leaving the airplane. Personnel might fire one of the explosive charges and it could result in serious injury or death.

| 1. | Gear lock safety pins | In place |
|----|------------------------------|--------------|
| 2. | Battery | Disconnected |
| 3. | Personnel safety switch | SAFE |
| 4. | Bomb bay door shut-off valve | SAFE |
| 5. | Complete DD Form 781 | Check |



B-57B

CONDENSED CHECK
LIST

2 July 1956 Revised 2 January 1957

B-57B CONDENSED CHECK LIST

BEFORE ENTERING THE AIRPLANE.

Flight Restrictions

Checked

FLIGHT PLANNING.

1. Flight data and equipment Available and checked

2. Cruise control data Checked

3. Fuel, oil, oxygen, armament Checked and special equipment

 Observer briefed on mission Checked and emergency procedures

5. Clearance filed Checked

BEFORE EXTERIOR INSPECTION.

1. Canopy Condition

Canopy safety pin In place
 Seat armrest safety pins, front In

and rear

4. DD Form 781 Check5. Publications In place

6. All armament switches OFF or SAFE

7. Tip tank jettison switch OFF

8. Landing gear lever Down

9. Emergency gear T-handle In
10. Battery switch OFF

11. Power distribution circuit All circuit breakers in

breaker panel

12. Seat quick-disconnect pins In place

13. All emergency equipment Stowed

14. Main system hydraulic pressure Zero pressure gage

Revised 2 October 1956

1

| 7 | Leakage | actuating cylinder b. Fuel manifolds and lines | |
|---|----------------|--|----------------|
| | Leakage | a. Forward bomb door | |
| | | BOMB BAY (RIGHT SIDE). | · þ |
| | | doors | |
| | Check | inflation c. Tires, wheels, fairing, and | |
| | sedoni 6 ot 0 | b. Gear strut for correct | |
| | In place | a. Gear lock safety pin | |
| | | NOSE MHEET METT | .٤ |
| | | compartment | |
| | Check | f. Right upper equipment | |
| | Check | e. Right electrical access compartment | |
| | 10040 | vent | |
| | Open | d. Pressure regulator static | |
| | Condition | c. UHF antenna | |
| | Open and clean | b. Static air vent | |
| | Removed | a. Pitot cover | |
| | | KICHL NOSE SECLION | 7. |
| | Secure | g. Nose hatch | |
| | Open and clean | f. Static air vent | |
| | Condition | compartment e. Shoran antenna | |
| | Check | d. Left electrical access | |
| | Check | c. Battery compartment | |
| | SAFE | b. Personnel safety switch | |
| | SAFE | a. Bomb door shut-off valve | |
| | | TELL NOSE SECTION | ī. |
| | | RIOR INSPECTION. | ILX: |

| | c. Defueling valve | Wired closed |
|----|--|-------------------------|
| | d. No. 1 and No. 2 fuselage boost pumps and No. 2 | Leakage and connection |
| | probe | - |
| | e. Aileron crossover rods | Possible distortion |
| | f. Aft bomb door actuating cylinder | Leakage |
| | g. Hydraulic lines | Leakage |
| | h. Boost pump drains | Check for moisture |
| 5. | RIGHT WHEEL WELL. | |
| | a. Gear lock safety pin | In place |
| | b. Gear doors, linkage and pins | Condition |
| | c. Fuel strainer | Security and leakage |
| | d. Main system hydraulic accumulator | 1000 psi |
| | e. Interphone switch | NORMAL and cap in place |
| | f. Hydraulic fluid level | Check |
| | g. Fire extinguisher bottle | 450 psi |
| | h. Microswitches | Condition |
| | i. Gear extender valve | Check |
| | removed and port covered | |
| | j. Gear strut for correct extension | 1½ to 3 inches |
| | k. Tire and wheel | Condition and slippage |
| | 1. Brake assembly | Condition and slippage |
| | m. Hydraulic and fuel lines | Leakage |
| | n. Wheel chocks | In place |
| 6. | RIGHT ENGINE | |
| | a. Cowling | Secure |
| | b. Ground cooling door | Secure and cable taut |
| | c. Starter breech lock and | Secure |
| | | |

| 7 Installation | Fired 2 January 1957 |
|--------------------------------|---|
| | disk |
| Intact | d. Nitrogen purge blow-out |
| Сћеск | cylinder c. Aft fuselage compartment |
| Leakage | b. Dive brake actuating |
| Condition | a, Dive brake |
| | 10. LEFT REAR FUSELAGE. |
| Condition | d. Navigation lights |
| Condition | c. Variable incidence stabilizer |
| ment | |
| Condition and freedom of move- | b. Stabilizer surfaces and tabs |
| Removed | a. Control locks |
| | 9. EMPENNAGE. |
| Condition | g. Tail skid |
| Cracks and distortion | f. Fuel vent mast |
| Closed | e. Aft fuselage entrance door |
| | cylinder |
| Leakage | d. Dive brake actuating |
| Condition | c. Dive brakes |
| | and filler cap |
| Check | b. Nitrogen purge indicator |
| Condition | a. Navigation lights |
| O I | 8. RIGHT REAR FUSELAGE. |
| Condition and warpage | h. Tail pipe |
| Condition | edsh gniW .g |
| Check | f. Aileron |
| Check | e. Tip tanks |
| Check | d. Navigation and taxi lights |
| Speck | c. Fuel vent |
| No leakage | b. Nacelle fuel drain valve |
| Check | a. Under surface of wing |
| HOLLDHOO | 7. RIGHT WING. |
| Condition | g. Frangible doors |
| Checked for cracks and breaks | france duces f. Compressor blades |
| VIPAYO | intake ducts |
| Oil seepage Clean | e. Engine and generator air |
| apertage liO | d. Front main bearing |

| 11. | LEFT WING. | Contract |
|-----|--|------------------------|
| | a. Tail pipe | Condition and warpage |
| | b. Nacelle fuel drain valve | No leakage |
| | c. Wing flaps | Condition |
| | d. Aileron | Check |
| | e. Tip tanks | Check |
| | f. Fuel vent | Check |
| | g. Under surface of wing | Check |
| | h. Navigation and taxi lights | Check |
| 2. | LEFT ENGINE. | |
| | a. Engine and generator air | Clear |
| | intake ducts | |
| | b. Starter breech lock and dome | Secure |
| | c. Front main bearing | Oil seepage |
| | d. Cowling | Secure |
| | e. Ground cooling door | Secure and cable taut |
| | f. Cabin ram air inlet duct | Clear |
| | g. Frangible doors | Condition |
| | h. Compressor blades | Condition |
| 13. | LEFT WHEEL WELL. | |
| | a. Gear lock safety pin | In place |
| | b. Gear doors, linkage and pins | Condition |
| | c. Fire extinguisher bottle | 450 psi |
| | d. Fuel strainer | Security and leakage |
| | e. Micro switches | Condition |
| | f. Gear extender valve removed and port covered | Check |
| | g. Gear strut for correct extension | 1½ to 3 inches |
| | h. Tire and wheel | Condition and slippage |
| | i. Brake assembly | Condition and slippage |
| | j. Hydraulic and fuel lines | Leakage |
| | k. Wheel chocks | In place |

| 9 | Connected | External power | .9 |
|---|------------------------|--|-----|
| , | 198 | Parking brake | ٠, |
| | Adjusted | Seat and rudder pedals | .₽ |
| | | and radio cord | |
| | Connected | Oxygen hose, bail-out bottle | ٠٤ |
| | Unlocked | Inertia reel | 7. |
| | | pelt | |
| | Adjusted | Parachute, harness, and seat | .I |
| | | BIOB CHECK. | HTE |
| | Caps and doors secure | | |
| | Checked and full | a. Fuel and oil tanks | |
| | | TOP SURFACE INSPECTION. | .91 |
| | Secure | e. All hatches | |
| | | safety pin | |
| | Removed | d. Emergency canopy initiator | |
| | Connected | c. Battery | |
| | FLIGHT | b. Personnel safety switch | |
| | FLIGHT | a. Bomb door shut-off valve | |
| | | LEFT NOSE SECTION. | SI |
| | Check for moisture | cylinder f. Boost pump drains | |
| | Гезкаде | control rods e. Aft bomb door actuating | |
| | Possible distortion | tank booster pumps and probe d. Aileron cross over and | |
| | Leakage and connection | c. No. I and No. 2 fuselage | |
| | Leakage | b. Hydraulic valves and lines | |
| | Condition and distance | actuating cylinder | |
| | Гезкаде | a. Forward bomb door | |
| | | BOMB BAY (LEFT SIDE). | .FI |

| 7. | Star valve | Closed (safetied) | |
|-----|--|----------------------------------|--|
| 8. | Electrical distribution panel circuit breakers | All in or ON | |
| 9. | Emergency canopy release T-handle | In | |
| 10. | UHF radio | OFF | |
| 11. | Wing flaps switch | UP | |
| 12. | Throttles | OFF | |
| 13. | Dive brakes switch | RETRACT | |
| 14. | Taxi and landing lights | OFF | |
| | Fire extinguisher agent discharge switch | OFF | |
| 16. | Altimeter | Set to field elevation | |
| 17. | Clock | Set and operating | |
| 18. | Fuel panel | Set for start | |
| 19. | Inverter switches | ALL OFF | |
| 20. | Starting and ignition switches | OFF | |
| 21. | Voltmeter selector switch to BATT | Check voltage (18 volts min.) | |
| 22. | Generators switches | ON | |
| 23. | Oxygen quantity gage | 4.0 to 4.5 liters | |
| | Air conditioning control panel | Check | |
| | Interphone control panel | As desired | |
| | Radio compass | OFF | |
| | APW-11A radar set | OFF | |
| | Windshield control panel | All switches OFF | |
| | Defog knob A-c and d-c circuit breakers | As desired | |
| | Lighting control panel | All in except GPI As desired | |
| | IFF | OFF | |
| | AIC filter switch | BOTH | |
| | Oxygen system | Checked | |
| | All indicator and warning | PRESS TO TEST | |

2-30

8

3. Battery switch BATTERY Clear 2. Ground crew I. Voltmeter selector switch BAT BUS STARTING ENGINES WITH BATTERY. 12. Inverters nO 11. Battery switch BATTERY Disconnected 10. External power source 9. Landing gear ground lock pins In sight then stowed Repeat steps 4 through 6 for the NO. 1 engine. Close 8. Canopy 7. Hydraulic system pressure gage Check 6. Engine instruments Check 5. NO. 2 start and ignition switch START IDFE 4. NO. 2 engine throttle nO 3. Interphone 2. Fire detection system Check Clear I. Ground crew STARTING ENGINES WITH EXTERNAL POWER. STARTING ENGINES. 3. Use 100% oxygen Check Clear 2. Ground personnel I. Voltmeter selector switch BAT and check voltage BEFORE STARTING ENGINES. 2. All other lights Checked NO I. Navigation lights INTERIOR INSPECTION (NIGHT FLIGHT)

CUT ON BLACK LINE

4. Fire detection system

Check

| 5. | Interphone | ON | |
|------|---|------------------------|--|
| | NO. 2 engine throttle | IDLE | |
| | NO. 2 start and ignition switch | START | |
| | Engine instruments | Check | |
| | Hydraulic system pressure gage | Check | |
| | Сапору | Close | |
| | at steps 6 through 8 for the NO. 1 | engine. | |
| | Landing gear pins | In sight; then stowed | |
| | Inverters | On | |
| BEFC | ORE TAXIING. | | |
| 1. | Generator | Check output | |
| | Voltmeter selector switch | Check all positions | |
| 3. | Aileron trim | Neutral (green light) | |
| 4. | Rudder trim | Neutral (green light) | |
| 5. | Horizontal stabilizer override | NOR | |
| 50 | switch (Group O Airplanes) | NODWAL | |
| Ja. | Horizontal stabilizer emergen- cy switch (Group P Airplanes) | NORMAL | |
| 6. | Horizontal stabilizer (Group O | 1/4 division nose down | |
| | Airplanes) | ya division nose down | |
| 6a. | Horizontal stabilizer (Group P | 0° | |
| | Airplanes) | T.ID | |
| 7. | UHF radio | On | |
| 8. | J2 COMP SLAVE switch | IN | |
| | Flight and engine instruments | Check | |
| 10. | | Check (all tanks) | |
| 11. | Fuel quantity indicator | Test | |
| 12. | IFF | As desired | |
| 13. | Radio compass function control | ANT | |
| 14. | GPI circuit breakers | In | |
| 15. | Bomb door, dive brakes and | Close and Retract | |
| | flaps (Group O and P airplanes) | Check operation | |
| 15a. | Elevator system bungee | | |
| | (Group P airplanes) | | |
| | Seat safety pins | Remove and stow | |
| | Brake pressure | 1000 psi minimum | |
| 18. | Chocks | Remove | |

| | Revised 2 May 1957 |
|--------------------------------|---|
| | |
| Среск | 9. Instruments |
| | switches 8. Repeat procedure for No. 2 engine |
| OFF (60% rpm or less) | 7. No. I emergency fuel control |
| FULL (check rpm) | 6. No. I engine throttle |
| (check light) | control switch |
| Emergency | 5. No. I engine emergency fuel |
| mq1 %06 | 4. Advance No. I engine throttle |
| Feeding | 3. No. 2 fuselage tank |
| | knob |
| Flow | 2. No. 2 fuselage tank valve |
| Check | I. Fuel controls |
| | PREFLIGHT ENGINE CHECK. |
| movement | |
| Check travel, free and correct | 8. Flight controls |
| Unlocked | 7. Inertia reel |
| bətsujbA | 6. Seat belt and shoulder harness |
| ďΩ | 5. Wing flaps switch |
| Closed, light out | 4. Canopy |
| As desired | 3. Pitot heater switch |
| KAM | 2. Cabin pressure selector switch |
| Check | 1. Trim devices |
| | PREFLIGHT AIRPLANE CHECK. |
| | SEFORE TAKE-OFF. |
| Check | 2. Turn-and-slip indicator |
| Check | l. Brakes |
| | PXIING. |
| | |
| OFF | 19. Parking brake |
| | terbed 2 January 1937 |

TAKE-OFF.

- Align the airplane with the runway and check the heading indication.
- 2. Depress the brakes

Throttles
 Throttle friction knob
 All warning lights
 Out

6. Release brakes

AFTER TAKE-OFF.

Brakes Applied
 Landing gear lever UP
 Safe single engine speed 155 knots
 Landing gear position indication cators

Cabin pressure selector switch
 Cabin temperature selector switch
 As desired

7. Oxygen selector lever Normal

DESCENT.

Windshield anti-icing switch
 Defog air knob
 Defog hot air switch
 Defog hot air switch
 Defog air rheostat
 Pitot heater switch
 Throttles
 Dive brakes

ANTI-ICING
ON
As desired
ON
As required
As required
As required

TRAFFIC PATTERN CHECK LIST.

1. Alert observer for landing

2. All armament switches OFF or SAFE

11

4. Canopy As desired 71 3. Trim indicators Neutral 2. Dive brakes RETRACT I. Wing flaps dn AFTER LANDING. Airspeed 130 knots minimum 3. Final Airspeed 155 knots minimum 2. Base Dive brakes as desired I. Downwind LANDING. muminim isq 000,1 15. Brake pressure gage gage 14. Main hydraulic system pressure muminim isq 002,5 13. Flaps DOWN As desired 12. Dive brakes 11. Landing gear warning light JuO indicators 10. Landing gear position DOWN 9. Landing gear handle DOWN and locked 8. Inertia reel Unlocked harness 7. Safety belt and shoulder Adjusted and tight 6. Oxygen %00I (containing fuel) knob 5. Applicable fuel tank Flow airplanes only) D quord) davirch (Group C 4. NO. I fuselage tank boost NO кпор 3. Fuel transfer and bypass valve Flow to NO. I tank

STOPPING ENGINES.

| 1. | Parking brake | Set |
|-----|---------------------------------|-----------|
| 2. | Throttle NO. 2 | Off |
| 3. | Hydraulic pressure No. 1 engine | Checked |
| 4. | All radios and IFF | OFF |
| 5. | Inverters | OFF |
| 6. | Oxygen supply lever | OFF |
| 7. | Throttle NO. 1 | OFF |
| 8. | Fuel panel knobs and switches | All OFF |
| 9. | Battery switch | OFF |
| 10. | Wheel chocks | In place |
| 11. | Parking brake | OFF |
| 12. | Armrest and canopy safety pins | Installed |
| 13. | All electrical switches | OFF |
| 14. | Control column | Secured |
| 15. | Canopy safety collar | In place |
| | | |

BEFORE LEAVING AIRPLANE.

| 1. | Gear lock safety pins | In place |
|----|------------------------------|--------------|
| 2. | Battery | Disconnected |
| 3. | Personnel safety switch | SAFE |
| 4. | Bomb bay door shut-off valve | SAFE |
| 5. | Complete DD Form 781 | |

End Condensed Check List

13

THIS PAGE LEFT BLANK INTENTIONALLY

14

Section III



EMERGENCY PROCEDURES

11659

TABLE OF CONTENTS

| Contract marks the policy of | age | | Page |
|--------------------------------|------|--|------|
| ENGINE FAILURE | 3-2 | ENGINE FUEL CONTROL SYSTEM | |
| ENGINE AIR START | 3-3 | MALFUNCTION | |
| FIRE | 3–8 | AIRPLANE FUEL SYSTEM FAILURE TIP TANK JETTISON | |
| ELIMINATION OF SMOKE AND FUMES | 3–9 | BOMBS AND EXTERNAL STORES | 5-17 |
| BAIL-OUT | 3-12 | JETTISON | 3-18 |
| PILOT'S SEAT EJECTION | 3-12 | ENGINE OIL PRESSURE FAILURE | 3–18 |
| OBSERVER'S SEAT EJECTION | | FAILURE SYSTEM | 3–18 |
| LANDING EMERGENCIES | | HYDRAULIC SYSTEM FAILURE | |
| EMERGENCY ENTRANCE | 3–15 | LANDING GEAR SYSTEM FAILURE | |
| EMERGENCY EXIT | 3–15 | BRAKE SYSTEM FAILURE | 3-23 |
| DITCHING | 3-15 | CHECK LIST OF EMERGENCY PROCEDURES | 3-25 |
| | | | |

INTRODUCTION.

To minimize the degree of emergencies created by the failure or malfunction of one or more components, the crew is advised to follow the procedures outlined in this section. The emergencies described are those more likely to occur, and complete understanding of the airplane and its systems is invaluable in coping with emergencies. Section IV of the handbook describes the normal and emergency operation of the auxiliary systems and equipment.

ENGINE FAILURE.

Most jet-engine failures are the result of improper fuel flow caused by malfunction of the fuel control system or by incorrect operating techniques. In this airplane, the pilot receives warnings of engine failure from engine instruments and warning lights before actual engine stoppage. In the event of stoppage and where there are no obvious mechanical failures, the pilot should have no difficulty in making air starts.



ENGINE FLAME-OUT.

Prolonged maneuvers involving negative G's disrupt the normal fuel flow to the engines, thereby causing flame-outs. Since the engines receive fuel from a common manifold, dual flame-outs are entirely possible, and simultaneous dual flame-outs are almost always the result of improper fuel management. With sufficient battery power, altitude, and fuel, the pilot can feasibly start one and then the other engine.

FLIGHT CHARACTERISTICS WITH ONE ENGINE INOPERATIVE.

When one engine is inoperative, the normal cruise characteristics present no difficulties and the airplane may be trimmed to fly "hands-off" at normal cruising power. However, single-engine control speed is governed by maximum rudder force in relation to rudder deflection. Below the airspeed established as the

single-engine control speed, the pilot cannot exert enough effort on the rudder to hold the necessary rudder deflection when excessive thrust is applied to the operating engine. Although one engine is capable of providing sufficient hydraulic and electrical power for all basic flight requirements, the pilot must monitor all electrical loads.

WARNING

Minimum single engine control speed is 155 knots IAS.

During take-off, accelerate the aircraft to a speed above the minimum control speed (155 knots IAS) as quickly as possible to insure that adequate directional control is available in the event of an engine failure.

WARNING

Should an engine fail on take-off, exercise the utmost care in the manipulation of the throttle controlling the operating engine. Rapid advancement of the throttle may result in an uncontrollable yaw force at any speed, particularly when below the minimum single engine control speed of 155 knots IAS. (Refer to ENGINE FAILURE ON TAKE-OFF in this Section.)

PROCEDURES WHEN ENCOUNTERING ENGINE FAILURE.

If a rapid drop in fuel flow occurs, place the emergency fuel control switch for the malfunctioning engine in EMERGENCY. If one engine fails in flight, do this immediately:

- 1. Adjust the throttle on the operating engine to maintain airspeed and directional control.
- 2. Retard the throttle of the malfunctioning engine to OFF to prevent flooding the engine with fuel.
- 3. Retrim the airplane for flight.
- Place the engine valve knob for the inoperative engine in OFF.
- 5. Check for possible engine fire.
- 6. Reset the cabin pressure selector switch to the operating engine.
- Turn off the generators on the inoperative engine.

 If extended operation is required, adjust the operating engine to give the desired airspeed. (Refer to Appendix I for single-engine performance data.)

ENGINE FAILURE DURING TAKE-OFF.

ENGINE FAILURE DURING TAKE-OFF BEFORE LEAVING GROUND.

If an engine should fail before leaving the ground, do this:

- 1. Retard both throttles immediately to IDLE.
- 2. Apply full braking to stop.

If the landing gear must be retracted because of insufficient remaining clearance, do this:

- Actuate the wing tip tanks jettison switch if the tip tanks contain fuel.
- Pull the canopy emergency release handle switch to jettison the canopy.
- 3. Place the landing gear lever in UP.

Note

A force of 25 pounds is necessary to override the solenoid lock which holds the control lever in the DOWN position.

4. Place the battery switch in OFF.

ENGINE FAILURE DURING TAKE-OFF AFTER LEAVING GROUND.

If an engine fails after the airplane is airborne, do this:

- Reduce power on operating engine to counteract yaw while accelerating to 155 knots.
- 2. Place the landing gear lever in UP.
- 3. Place the throttle for the malfunctioning engine in OFF.
- Place the engine valve knob for the inoperating engine in OFF.
- 5. Check that the fire warning lights are out.
- Gain sufficient altitude before attempting to restart the malfunctioning engine. Refer to ENGINE RE-START IN FLIGHT in this section.

If a rapid drop in fuel flow occurs during take-off, place the emergency fuel control switch for the malfunctioning engine in EMERGENCY.

CAUTION

If the engine fuel system fails on take-off or up to an altitude of 6000 feet, it is permissible to transfer to the emergency fuel system with the throttle in the FULL position provided that the engine rpm has not dropped below 85% at the time of transfer. Under all other conditions the throttle level must be retarded to IDLE prior to the transfer; failure to do so results in excessive exhaust gas temperatures and rich flame-out (blow-out) and/or compressor stall.

If the engine rpm returns to the approximate take-off setting, continue to operate in the emergency system and observe normal precaution for emergency fuel control procedures.

ENGINE FAILURE DURING FLIGHT.

To determine the cruise control conditions for single-engine operation, see the Single Engine Cruise Control Charts in Appendix I. Refer to PROCEDURE WHEN ENCOUNTERING ENGINE FAILURE in this section for shutting down an engine. Also, for information concerning engine oil pressure failure and engine noise and roughness, refer to ENGINE OIL PRESSURE FAILURE in this section and ENGINE NOISE AND ROUGHNESS in Section VII.

ENGINE AIR START. (NORMAL)

Air starts can be made consistently up to 16,000 feet if you follow the normal restart procedures.

CAUTION

Do not attempt to restart the inoperative engine until you are sure that it will be reasonably safe to do so.

- Place the throttle in OFF and descend below 20,000 feet.
- Check that the FUEL SYSTEM VALVES and FUEL SYSTEM PUMPS circuit breakers are all in ON.

 Place the airplane in a nose-high attitude for 15 seconds to drain any excess fuel from the combustion chamber.

Note

A nose-high attitude held for 15 seconds will dissipate G forces and allow fuel to drain freely.

- Adjust the attitude of the airplane to attain a speed between 155 knots and 220 IAS or from 14 to 22 percent rpm.
- Place the engine valve knob in the flow position.
- 6. Check that the battery switch is in BATTERY.
- Momentarily place the start and ignition switch in CRANK ONLY.
- Immediately move the throttle to IDLE or slightly above. This opens the fuel shut-off valve and the throttle valve. An increase in exhaust gas temperature and rpm indicates the engine has started.

Note

Any delay in moving the throttle wastes a portion of the 15 ± 3 seconds ignition cycle. The ignition timer cannot be recycled until the 15 ± 3 second period has run out.

 If the exhaust gas temperature does not increase within five to ten seconds after the throttle is open, immediately place the throttle in OFF to prevent flooding the engine with fuel.

ENGINE AIR START. (ALTERNATE)

Although air starts can be obtained above 20,000 feet, the chances of a successful air start increase at lower altitudes. Occasionally, when normal air start methods fail, it is possible to obtain a start by placing the emergency fuel control switch in EMERGENCY and following the normal air start procedure. Monitor the start carefully under these circumstances. After the start has been obtained and the engine is idling normally, continue to operate on the emergency system and make a landing as soon as possible.

DUAL ENGINE FAILURE.

The two most prominent reasons for engine stoppage are mechanical failure and fuel starvation. Because the fuel system is common to both engines, the majority of dual engine flame-outs occuring simultaneously or at short intervals result from fuel starvation. The causes of fuel starvation are improper fuel management or failure within the fuel system. During electrical system failure at high altitudes, the fuel tank boost pumps do not receive power for operation and a dual engine flame-out is possible. Below 25,000 feet, the engine-driven pumps draw enough fuel from the tanks for normal engine operation. Since the engine run-down time is approximately 30 seconds, the generators supply sufficient power to operate the flight instruments, inverters, canopy and windshield anti-icing for this period of time. At altitudes above 42,000 feet, heat and pressurization can be retained in the cabin by placing the cabin pressure selector switch in OFF. As the engines decelerate, the generators trip off the line; therefore, the battery is the only source of electrical power. When descending from 43,000 feet, place the cabin pressure selector switch in RAM to avoid canopy and windshield fogging. If dual engine flame-out occurs, do this:

- 1. Place the battery switch in OFF.
- 2. Turn off all electrical equipment.
- If flame-out occurred at an altitude above 43,000 feet, turn the battery switch to ON and reposition the cabin pressure selector switch to OFF.
 Make a rapid descent to below 30,000 feet if the glide distance of an airfield is not critical.
 - a. If the flame-out occurred at an altitude below 43,000 feet, turn the battery switch to ON and reposition the cabin pressure selector switch to RAM. Descend to a safe relight altitude.
- Refer to procedures listed under DUAL EN-GINE AID START PROCEDURE.

DUAL ENGINE AIR START PROCEDURE.

- 1. Place the battery switch in ON.
- 2. Place the No. 1 inverter switch in ON.
- Check the fuel quantity and realign the fuel selector switches to the fullest tank.
- Turn off the battery switch and the NO. 1 inverter switch.
- Follow the procedures as outlined under EN-GINE RESTART IN FLIGHT in this section.

Note

Start one engine at a time. If the first starting attempt is unsuccessful, try to start the second engine before making a second attempt to start the first engine.

MAXIMUM GLIDE.

The maximum glide ranges for various altitudes are given in figure 3-1. To obtain maximum range during descent without engine power, fly at the speeds given in figure 3-1.

Note

To obtain maximum glide distance, keep gear and flaps up and the dive brakes retracted.

PARTIAL POWER.

Partial power of these engines can be caused by icing, or malfunction of the engine, the engine fuel system, or the airplane fuel system. For failure due to icing, refer to ICE, SNOW, AND RAIN in Section IX. A partial power failure due to improper fuel flow is indicated by a drop in fuel flow and should be cor-

rected as follows after checking all fuel switches and fuel knobs on the fuel control panel and all circuit breakers placarded FUEL SYSTEM VALVES and FUEL SYSTEM PUMPS.

- Check all fuel switches and fuel knobs on the fuel control panel for proper setting.
- Check circuit breakers placarded FUEL SYSTEM VALVES and FUEL SYSTEM PUMPS and reset if necessary.
- Place the emergency fuel control switch of the malfunctioning engine in EMERGENCY.
- 4. If power is not recovered when the emergency fuel control switch is placed in EMERGENCY, the malfunction is in a part of the engine or the airplane fuel system that affects both normal and emergency fuel flow, or in the engine itself.
- If the cause of a partial power failure cannot be definitely established, check the fuel flow to the




Figure 3-1

malfunctioning engine against the existing power setting to determine if excessive fuel is being lost. If the fuel flow is consistent with the existing power setting and the engine is otherwise operating within normal limits, you may continue to operate the engine. If the fuel flow is excessive for the power setting and/or there is a fluctuation in rpm, shut the malfunctioning engine down to avoid further damage and eliminate the possibilities of fire in the engine.

6. Trim the airplane for single-engine operation and adjust the power of the operating engine for desired crusing conditions. Refer to FLIGHT CHARACTERISTICS WITH ONE ENGINE INOPERATIVE in this section.

LANDING WITH ONE ENGINE INOPERATIVE.

If a landing is to be made with one engine inoperative, do not allow airspeed to decrease below 155 knots IAS until on final approach. The landing gear may be lowered on the downwind or base leg if 155 knots IAS airspeed can be maintained and should always be lowered in time to insure that gear will be down and locked prior to touchdown. After completing the turn on final approach, decrease the airspeed to 130 knots IAS but do not use flaps or dive brakes until a landing is assured. After the flaps are down, do not attempt a go-around unless the airplane is above 500 feet altitude.

WARNING

You are committed to land when making a single-engine approach at less than 500 feet altitude with the gear and flaps extended. Under these conditions do not attempt a go-around.

LANDING WITH BOTH ENGINES INOPERATIVE. (See figure 3-2.)

Landing with both engines inoperative is mechanically feasible. All flight control systems operate normally, although trim may not be available because of the loss of electrical power. The engine windmilling rpm at normal glide speeds is below rpm required to produce electrical power from the generators. Therefore, because only battery power remains, plan to land without the use of trim, wing flaps, or dive brakes. However, sufficient hydraulic pressure will probably be available to permit extremely slow operation of all hydraulically operated units. Thus the units desired may be used if they can be electrically actuated by remaining battery power.

In preparing for a landing with both engines inoperative, do this:

- Establish a glide speed of approximately 160 knots.
- At approximately 10,000 feet above the terrain, place the landing gear lever DOWN and pull emergency landing gear down handle. (Use of the emergency landing gear down handle conserves battery power.)
- 3. Select a high key point to the right of the runway, approximately 5,000 feet above the terrain.
- 4. Proceeding through 360° approach, select a low key point approximately 1500 feet above the terrain. This point should be at the turn from downwind to base leg, 1 mile to the side of the runway, and 1 mile downwind from the end of the runway.

Note


This pattern is for a normal landing weight of 37,500 pounds. For higher gross weights, use proportionally higher key points.

This pattern is recommended for headwinds under 10 knots. For headwinds of greater velocity, reduce the turning radius between the high and low key point so that the low key point is closer to the runway.

- 5. Turn base leg and establish an airspeed between 140 and 150 knots.
- Turn on final approach, establish an airspeed between 120 and 130 knots, and S-turn, fishtail, or sideslip to lose excessive altitude.
- When positive of correct position relative to the runway, lower the flaps for the landing, provided that enough battery power remains to actuate the flap system.

Note

If the flap system can be electrically actuated with remaining battery power, flap operation will be extremely slow as hydraulic pressure is being produced only by the windmilling engines at low rpm.



dual flame-out landing pattern




Figure 3-2

SINGLE ENGINE GO-AROUND.

WARNING

You are committed to land when making single-engine approaches at less than 500 feet with flaps and gear extended. Under these conditions, do not attempt a go-around and make the decision to go around before the flaps are extended.

If it is necessary to make a go-around, perform these operations:

Apply power gradually to maintain positive control.

WARNING

Advance the throttle slowly or an uncontrollable yaw can result.

- Place the flaps switch in UP before 170 knots IAS is reached.
- When establishing that contact with the runway will not be made, place the landing gear control lever in UP.
- 4. Retract dive brakes.

WARNING

This airplane has a minimum singleengine control speed of 155 knots IAS. Practice single-engine maneuvers only at safe altitudes and be careful with low speeds and high engine power.

FIRE.

ENGINE FIRE.

A flashing or steady red light in the PULL-TO-ARM knobs indicates a fire or an overheat condition in the engine area. In most cases, retarding the throttle alleviates the overheat condition. However, if the flashing or steady light persists, you must institute corrective action for an engine fire.

ENGINE FIRE ON GROUND.

If a fire detection light illuminates (flashing or steady) to indicate an abnormal condition in the engine, retard the throttle and observe the indicator light. If the light persists:

- 1. Place both throttles in OFF.
- Signal the ground crew to use carbon dioxide fire extinguishing equipment.

Note

Each nacelle has two frangible wooden doors for the insertion of hand fire extinguishers.

If there is a tailpipe fire during engine shutdown, have the ground crew use a CO₂ fire extinguisher. If ground equipment is not available:

 Pull the PULL-TO-ARM knob for the applicable engine.

Note

Pulling out the pull-to-arm knob stops the flow of fuel and hydraulic fluid to the engines, closes the air bleed shut-off valves to the air-conditioning system, and arms the agent discharge switch.

- Place the agent discharge switch in AGENT DISCHARGE.
- 3. Leave the airplane as quickly as possible.

ENGINE FIRE IN FLIGHT.

If the fire detection lights illuminate (flashing or steady) to indicate an abnormal condition in the engine, retard the throttle and observe the indicator light. If the light persists:

- 1. Move the throttle to OFF.
- Pull the PULL-TO-ARM knob for the applicable engine.
- Place the agent discharge switch in AGENT DISCHARGE.

Note

This is a one-shot system, and actuating the agent release switch exhausts the fire extinguishing supply for the affected engine. Therefore, do not actuate the AGENT DISCHARGE switch unless it is necessary.

- Move the oxygen diluter lever to 100% OXY-GEN.
- Insure that the cabin pressure selector switch is in the proper position (NORMAL or in position for the operating engine).

 Follow the procedure outlined under PROCE-DURE WHEN ENCOUNTERING ENGINE FAILURE in this section.

CAUTION

Do not attempt to restart the engine after extinguishing the fire.

ENGINE OVERHEAT CONDITION.

A flashing red light in the PULL-TO-ARM knob indicates an overheat condition, but the overheat detectors cannot distinguish between a fire and an overheat condition.

- Correct the overheat condition by reducing the power of the affected engine.
- If the light persists, follow the procedures outlined under ENGINE FIRE IN FLIGHT in this section.

WING OR FUSELAGE FIRE.

A fire in the fuselage or the wing cannot be extinguished in flight.

- 1. If a system is afire, shut it off immediately.
- If the fire gets out of control, abandon the airplane.

FIRE IN FLIGHT COMPARTMENT.

In the event of a fire in the flight compartment:

- 1. Connect the oxygen masks.
- Set the oxygen regulator diluter lever to 100% OXYGEN.
- 3. Use the hand fire extinguisher.
- 4. Place the cabin pressure selector switch in RAM.
- If the fire gets out of control, abandon the airplane.

ELECTRICAL FIRE.

Circuit breakers and fuses protect most of the circuits and tend to isolate an electrical fire. However, if the source of the fire cannot be determined, turn off all electrical equipment not absolutely essential for flight in order to isolate the fire. If you can locate the source of the fire by this procedure, gradually restore all circuits to operation except those causing or affected by the fire. If smoke or fumes are present during or after the fire proceed as follows:

CAUTION

Above an altitude of 26,000 feet, engine flame-out will almost cerly occur if there is not at least one fuel tank boost pump feeding fuel directly to the engine. Therefore, if the boost pumps must be turned off, you must descend to below 26,000 feet.

1. Cabin Pressure Selector Switch

As required

2. Oxygen Mask

Connected

3. Oxygen Diluter Lever

100% OXYGEN

4. Hand Fire Extinguisher

As necessary

Note

To prevent rapid blow-off of cabin air at high altitude, place the cabin pressure selector switch in OFF.

Gradually restore electrical power to determine the source of fire.

CAUTION

Make sure that the electrical circuit involved is isolated before restoring complete power.

If the source of the electrical fire is not determined, land as soon as possible, or if the fire is serious enough, abandon the airplane.

ELIMINATION OF SMOKE OR FUMES.

In the event of heavy smoke or toxic fume concentration in the flight compartment, do this:

- Determine which engine might be causing the smoke or fumes by placing the cabin pressure selector switch in the NO. 1 ENG and then in the NO. 2 ENG position. If this reveals that the engines are the source of the smoke or fumes, then proceed with step 2 or 3.
- 2. If below 42,000 feet cabin altitude:

Oxygen Mask

Connected

Oxygen Regulator Diluter Lever 100% OXYGEN

Cabin Pressure Selector Switch RAM

3. If above 42,000 feet cabin altitude, make a rapid descent to below 42,000 feet and purge the cabin

ejection procedures RAISE RIGHT AND LEFT GRIP TO JETTISON CAN-OPY, STOW COLUMN AND LOCK SHOULDER PLACE FEET FIRMLY IN IF AT HIGH ALTITUDE PULL PLUG PLACE ARMS IN RESTS. ON BAILOUT BOTTLE.

Figure 3-3 (Sheet 1 of 2)




Figure 3-3 (Sheet 2 of 2)

air by placing the cabin pressure selector switch in RAM.

Oxygen Mask

Connected

Oxygen Regulator Diluter

100% OXYGEN

Lever

Cabin Pressure Selector Switch RAM

Note

Ram air at high altitudes may be extremely cold. Do not leave the cabin pressure selector switch in RAM too long.

If the source of smoke is not due to malfunctioning of the air conditioning system, retain heat in the cabin by placing the cabin dump switch in the on position and leaving the cabin pressure selector switch in NORMAL.

BAIL-OUT.

In all cases of emergency exit in flight, use the ejection seat system. This is the safest method of escape in either high or low speed flight since it avoids the possibility of colliding with the empennage. If the ejection seat system should malfunction, use the following procedure to bail out:

- 1. Stow all loose equipment.
- Jettison the canopy by pulling the canopy emergency release handle.
- Disconnect the microphone headset and oxygen hose.
- 4. Pull the plug on the oxygen bail-out bottle if at high altitude.
- 5. Trim the stabilizer full nose down; then roll the airplane over.
- Unfasten the seat safety belt and fall out of the airplane.

PILOT'S SEAT EJECTION.

When immediate escape from the airplane is necessary follow the procedures shown on figure 3-3.

WARNING

The minimum safe ejection altitude for upward ejection seat with automatic belt and manual chute is 1000 feet. The minimum safe ejection altitude with an automatic seat safety belt and automatic parachute is 500 feet, provided the parachute lanyard is attached to the seat belt.

If immediate escape from the airplane is not necessary and time permits, the following procedures are recommended and are to be coordinated between the pilot and observer. The observer will eject from the airplane before the pilot.

- 1. Follow the radio distress procedure.
- 2. Place the IFF master switch in EMERGENCY.
- 3. Stow all loose equipment.
- Disconnect the microphone headset lead, oxygen hose, and helmet defogging lead if they are connected.
- 5. The observer will check that his table is stowed.
- If at high altitude, pull the plug on the oxygen bail-out bottle.
- 7. Jettison the canopy, using the controls in the following sequence until the canopy jettisons:
 - a. Observer's canopy emergency release handle.
 - b. Observer's right grip.
 - c. Pilot's canopy control switch.

Note

All available means of jettisoning the canopy should be tried before using the pilot's right grip. This procedure allows the pilot to maintain longitudinal control of the airplane until he is ready to eject.

- 8. Raise the left grip to lock the shoulder harness.
- Sit erect, head against the head rest, chin in, and feet and arms in the rests.
- Raise right grip to the up-and-locked position; then squeeze the trigger to eject from the airplane.

WARNING

Normal longitudinal control of the airplane will be lost after raising the pilot's right grip because of the operation of the control column stowage system. Under these conditions you will have only very limited longitudinal control of the airplane by using the stabilizer trim switch.

11. After ejecting and after release of the automatic seat belt, kick free of the seat and delay opening the parachute as long as altitude will permit. This procedure will prolong the duration of the oxygen in the bail-out battle.

OBSERVER'S SEAT EJECTION.

Ejection of the observer's seat is identical to that for the pilot except that the observer's right grip will not stow the control column. Therefore, the observer must use the procedures shown on figure 3–3. If the seat fails to eject, follow the procedures required under BAIL-OUT.

LANDING EMERGENCIES.

LANDING WITH GEAR RETRACTED.

WARNING

Whenever the terrain is unknown or unsuited for forced landing, use the ejection seat to escape from the airplane rather than attempt a forced landing. The probability of receiving severe injuries from a forced landing under adverse conditions is very high. The minimum safe ejection altitude in level flight for upward ejection seats with automatic seat belt and manual chute is 1,000 feet. The minimum safe ejection altitude with an automatic seat belt and an automatic parachute is 500 feet, provided the parachute lanyard is attached to the seat belt.

If it should be necessary to land with the landing gear retracted, proceed as follows:

- Notify the observer to prepare for a crash landing.
- Advise the control tower of the existing emergency and request an application of foam to the runway when the time of landing has been determined.
- 3. Reduce the fuel load but retain empty or nearly empty tip tanks.

Note

If wing tip tanks are installed and they are full of fuel, actuate the tip tank jettison switch. If the tip tanks are empty, or nearly empty retain them; they will act as skids and will prevent a wing tip from digging in, especially on soft surfaces, and causing the airplane to cartwheel.

 Jettison all internal and external stores and close the bomb door.

- Unfasten the parachute harness buckles and readjust safety belt and shoulder harness (pilot and observer).
- 6. Turn off all unneeded electrical equipment.
- Set up landing pattern using a flat, power-on approach.
- 8. Jettison the canopy when airspeed reduces to 180 knots IAS or below.

WARNING

Before pulling the canopy emergency release handle, bottom the ejection seat to avoid any possibility of being struck by the canopy.

- 9. Just before touchdown perform the following:
 - a. Place the throttle in OFF.
 - b. Pull the pull-to-arm knobs and place the agent discharge switch in the AGENT DIS-CHARGE position.
 - c. Lock the shoulder harness (pilot and observer).

CAUTION

You cannot bend forward when the inertia reel is locked; therefore, before locking the reel, cut all switches not accessible from the locked position.

- d. Disconnect the radio cord and oxygen hose (pilot and navigator).
- e. Place the battery and generator switches in OFF.
- f. Make contact with the ground in a normallanding attitude at the lowest possible airspeed and rate of descent consistent with safe control of the airplane. Do not stall in. If necessary "stick" the airplane on the ground.
- After the airplane comes to a complete stop, get out as soon as possible.

LANDING WITH ONE MAIN GEAR UP OR UNLOCKED.

If one main gear remains in the up position or does not lock in the down position, retract the gear and make a wheels-up landing in accordance with the instructions under LANDING WITH GEAR RETRACTED.



Figure 3-4

LANDING WITH MAIN GEAR EXTENDED AND NOSE GEAR UP OR UNLOCKED.

Touch down on main gear and hold the nose off the runway as long as possible.

LANDING WITH FLAPS UP.

When landing without the use of wing flaps, add approximately 10 knots to speeds used during a normal landing.

EMERGENCY ENTRANCE.

To gain emergency entrance to the airplane on the ground, follow the procedures shown in figure 3-4.

EMERGENCY EXIT.

Two methods of emergency exit from the airplane are available. In flight, use the ejection seat system. (See PILOT'S SEAT EJECTION and OBSERVER'S SEAT EJECTION in this section.) If the airplane is on the ground and emergency exit is necessary, do this:

- 1. Insert seat safety pins.
- 2. Actuate the canopy control switch to OPEN.
- If the canopy control switch fails to open the canopy, pull the canopy emergency release handle (pilot's or observer's) to jettison the canopy.



Watch out for the jettisoned canopy.

4. If the canopy cannot be opened according to the procedures in 2 and 3, use the crash ax to chop through the canopy.

DITCHING.

Ditching is a last resort. Since all survival equipment is carried by the crew on their persons, there is no advantage to be gained in riding the airplane down. However, if altitude is not sufficient for bail-out and ditching is unavoidable, do this:

- 1. Notify the observer to prepare for ditching.
- 2. Place the IFF switch in EMERGENCY.
- Actuate the master jettison switch if it is desirable to jettison stores and tip tanks.

Note

The construction of the rotary bomb door is such that the presence of bombs on the closed door may tend to reduce the cave-in of the door. If the tip tanks are empty and the sea is calm, do not jettison the tanks as they will provide additional buoyancy.

- 4. If stores are jettisoned, place the bomb door switch in CLOSE.
- 5. Check that the landing gear lever is in UP.

CAUTION

The landing gear must be retracted. If the gear is extended, the airplane will dive into the water upon contract.

- 6. Place the dive brakes switch in EXTEND.
- 7. Place the wing flaps switch in DOWN.
- Disconnect all personal equipment except the oxygen hose.
- 9. Unbuckle the parachute harness.
- 10. When the airspeed has dropped to 180 knots IAS or less, jettison the canopy by pulling the canopy emergency release handle.
- Check that the seat belt and shoulder harness are secure and lock the inertia reel.

CAUTION

The pilot cannot bend forward when the inertia reel is locked. Therefore, cut all switches not accessible before locking the inertia reel.

- 12. Insert the seat safety pins.
- 13. Make the landing into the wind. If the sea is rough, land in a direction parallel to the waves and on top of a wave crest if possible.
- 14. Place the throttles in OFF.
- 15. Make the touchdown as slowly as possible with a slightly nose-high attitude.
- 16. After the airplane has stopped, abandon it immediately; the airplane may sink rapidly.

Note

In the event of ditching and sinking in water where you find yourself unable to immediately escape due to any number of factors, it is possible for you to survive under water with your oxygen equipment until you can free yourself and escape. The diluter-demand-type oxygen regulator is a suitable underwater breathing device when the regulator is set at 100% OXYGEN. The mask must be in place and tightly strapped, and that the regulator must be set at 100% OXYGEN, but remember the bail-out bottle cannot be used under water.

ENGINE FUEL CONTROL SYSTEM MALFUNCTION.

If an engine fuel control system malfunctions, as indicated by a loss of power and drop in fuel flow indication, attempt to correct the condition in this manner:

- Check all circuit breakers placarded FUEL SYS-TEM VALVES and FUEL SYSTEM PUMPS for proper setting and reset if necessary. If this does not correct the condition proceed with step No. 2.
- Place the emergency fuel control switch of the malfunctioning engine in EMERGENCY.

CAUTION

If the engine fuel control system fails on take-off or up to 6,000 feet, you can transfer to the emergency fuel system at FULL throttle, if the engine has not dropped below 85% at the time of transfer. Under all other conditions retard the throttle to IDLE prior to the transfer. Failure to do this causes excessive exhaust gas temperatures, rich flame-out and/or compressor stall. The emergency fuel control does not incorporate the compensatory features of the normal fuel control. Therefore, rpm and exhaust temperature limits may be exceeded if you do not make accelerations slowly and smoothly.

 If the use of emergency fuel control does not correct the condition and the engine is still operating, refer to PARTIAL POWER FAILURE in this section. 4. If the use of emergency fuel control does not correct the condition and the engine has flamedout, attempt to start the engine as described under ENGINE RE-START IN FLIGHT in this section.

ENGINE-DRIVEN FUEL PUMP FAILURE.

If both main pumps of the engine-driven fuel pump assembly fail completely, engine flame-out results and the engine cannot be restarted. Normal engine operation will not be affected, however, by the loss of one main (gear) pump or by the loss of one main (gear) pump and the boost pump (centrifugal), provided that the boost pumps of the airplane fuel system are operating.

AIRPLANE FUEL SYSTEM FAILURE.

CAUTION

Above an altitude of about 26,000 feet, engine flame-out will almost certainly occur if there is not at least one fuel tank boost pump feeding fuel directly to the engines. Since fuel is normally fed from the No. 1 tank to the engines, this means that if both the boost pumps in that tank are inoperative, normal flight above approximately 26,000 feet is not possible. Under these conditions and just prior to flame-out, a rapid fluctuation of the fuel flow will be evident.

NO. 1 OR NO. 2 FUSELAGE TANK BOOST PUMP FAILURE.

The No. 1 and No. 2 fuselage tanks each have two boost pumps and it is unlikely that all four pumps would fail simultaneously. In the event of boost pump failure, do this:

- Check that all fuel system circuit breakers are on or in.
- 2. In the event of failure of both boost pumps in the No. 1 fuselage tank, position the fuel transfer and bypass valve knob to feed fuel directly to the engines from the No. 2 fuselage tank, the wing tanks, or the wing tip tanks. Turn the No. 1 fuselage booster pumps switch to OFF on Group C airplanes. If necessary, fuel may may be recovered from the No. 1 tank even though the boost pumps have failed but continued flight is limited to altitudes below 26,000

feet due to the limited suction action of the engine-driven fuel pumps. Recover the fuel in the No. 1 fuselage tank only if the other tanks have been exhausted.

CAUTION

When drawing fuel from the No. 2 fuselage tank or the wing tanks directly to the engines, observe the fuel quantity indicator to avoid flame-out. Delivery rates from the tip tanks are sufficient for satisfactory engine operation only at low power and at low altitudes.

3. If both No. 2 fuselage tank boost pumps fail below 26,000 feet, fuel may be recovered by positioning the fuel transfer and bypass valve knob to the flow to engines position and by placing the No. 2 fuselage tank knob in the flow position. Under these conditions, the No. 1 fuselage tank boost pumps should be off on Group C Airplanes.

NO. 1 FUSELAGE TANK FUEL LEVEL SHUT-OFF VALVE FAILURE.

Malfunctioning of the No. 1 tank fuel level shut-off valve will cause large quantities of fuel to be dumped overboard out of the fuselage vent mast. This will generally be noticeable prior to take-off. However, during flight, if the airplane is apparently consuming abnormally large amounts of fuel, temporarily halt the transfer of fuel to the No. 1 tank and check to see that all fuel vent circuit breakers are in and that the fuel consumption is normal from the No. 1 tank to the engines and from all other tanks to the No. 1 fuselage tank. If fuel consumption is abnormally high from the No. 1 fuselage tank, the valve is malfunctioning. Transfer fuel intermittently to the No. 1 tank as needed without relying on the No. 1 fuselage tank fuel level shut-off valve.

WING TANK BOOST PUMP FAILURE.

Failure of a wing tank boost pump prevents the flow of fuel from that tank. Trim change and fuel quantity indication enable the pilot to determine the operation of the wing tank boost pump. If a wing tank boost pump is inoperative, check the applicable circuit breaker before turning off the wing-tank—tiptank selector switch. If fuel fails to flow from any one

of the wing or tip tanks causing extensive lateral trim correction, draw fuel from the opposite tank in the same wing to decrease the necessary lateral trim correction. For example, if the left tip tank fails to supply fuel while the right tip tank supplies fuel normally, and an out-of-lateral trim condition occurs, discontinue drawing fuel from the right and left tip tanks and draw fuel from the left wing tank until the lateral trim to neutral. Continue drawing fuel from the tanks in any manner that maintains lateral trim. Refer to procedures under TIP TANK FUEL SYSTEM FAILURE in this section.

TIP TANK FUEL SYSTEM FAILURE.

Excessive use of aileron trim may indicate uneven feeding from a tip tank. Maneuver the airplane in an attempt to start the flow of the fuel from the tip tank by inducing positive and negative G loads. If these maneuvers fail to start the fuel flow, check the aileron control above 10,000 feet with the aircraft in landing configuration. After establishing the amount of aileron control required to maintain level flight, jettison the heavy tank, if necessary. (See TIP TANK JETTISON in this section). If the heavy tip tank cannot be emptied or jettisoned, empty the wing tank on the heavy side and leave the wing tank on the light side full to create the best landing situation. Although landings have been made with one tip tank empty and the other full, do not attempt them unless it is absolutely necessary and then only under the best conditions. Make your "touchdown" at approximately 130 knots to maintain lateral control with full aileron.

BOMB DOOR FERRY TANK BOOST PUMP FAILURE.

If the boost pump in the bomb door ferry tank fails, place the ferry tank boost pump selector switch in OFF and select the next tank to be used. Fuel in the ferry tanks cannot be recovered nor can the tank be jettisoned.

TIP TANK JETTISON.

To jettison the tip tanks, place the tip tank jettison switch in TIP TANK ONLY. The tip tanks will also jettison if the master jettison switch is actuated and the tip tank jettison switch is in NORMAL. It is not necessary to turn the wing tip tank fuel selector knob to OFF when jettisoning, because a flapper valve closes the line. Do not jettison empty tip tanks above 365 knots; full tip tanks under 160 knots.

BOMBS AND EXTERNAL STORES JETTISON.

During an emergency, all bombs and external stores can be jettisoned in an unarmed condition by momentarily actuating the master jettison switch.

Note

If the wing tip tanks are to be retained the tip tank jettison switch must be OFF. If the tip tank switch is in NORMAL when the master jettison switch is actuated, the wing tip tanks will be jettisoned as well as the stores.

ENGINE OIL PRESSURE FAILURE.

GROUND OPERATION.

Normal operating oil pressure is between 20 and 35 psi. Oil pressure between 10 and 20 psi and between 35 and 40 psi is undesirable; however, it is possible to operate the engines extensively within these pressure areas. Retard the throttle to reduce oil pressure in excess of 40 psi. Stop the engine and land as soon as possible when the oil pressure falls below 10 psi. One minute of continuous engine operation with zero oil pressure is satisfactory for continued service. Over one minute but less than two and one-half minutes is satisfactory for continued service, provided:

- 1. No abnormal engine noise exists.
- The oil pressure pump strainer and the oil scavenge pump are checked and found free of metallic particles.
- No indication of damage or metallization exists.
 No oil pressure for a period exceeding two and one half minutes is cause for engine removal.

IN FLIGHT.

One minute of continuous engine operation with zero oil pressure is permissible. Over one minute but less than two and one-half minutes engine operation may be continued at the pilot's discretion; after landing, inspection should be made as in items No. 1 and No. 3 of ENGINE OIL PRESSURE FAILURE, GROUND OPERATION, this section.

ELECTRICAL POWER SUPPLY SYSTEM FAILURE.

GENERATOR FAILURE.

1. If a generator fails, as indicated by voltage read-

ing of zero, a loadmeter reading of zero, the generator indicator light being on, and normal indications of the remaining three generators, place the indicated generator switch in OFF. No monitoring of the electrical load is required. (See figure 3–6.)

- If a generator fails, as indicated by a loadmeter reading of zero and the generator indicator light being on, but with a normal voltage reading and the remaining three generators indicating normal, do this:
 - Place the indicated generator switch momentarily in RESET and return it to ON.
 - b. If the generator indicator light is out and the loadmeter indication is normal, leave the generator switch in ON.
 - c. If the generator indicator light remains on and the loadmeter indicates a zero reading, place the generator switch in OFF.
 - d. No monitoring of the electrical load is required.
- If a generator fails, as indicated by a low voltage reading and a high loadmeter reading:
 - Place the generator switch for the indicated generator in OFF.
 - b. Check the loadmeters of the remaining generators for indications that the electrical load is approximately in balance.
 - No monitoring of the electrical load is required.
- 4. If any two generators fail (assuming both engines are operating) and either or both cannot be reconnected to the electrical system by following the procedures given in 1, 2, and 3 above, place both indicated generator switches in OFF.

CAUTION

For two-generator operation at 50,000 feet altitude and cruise-combat speeds, the amount of monitoring required is high and the type of equipment that must be shut off may reduce the effectiveness of some missions and may even preclude the completion of others. Two operating generators have a system capacity of 396 amperes (0.65 per load meter, 1.3 total), while the predicted maximum continuous amperes required

for this flight condition is 542 amperes (0.9 per load meter, 1.8 total) or 146 amperes (0.25 per loadmeter, 0.5 total) more than two-generator output. Therefore, it is extremely important that the electrical loads be monitored to prevent overloading the generators.

Note

One way to obtain the required amount of monitoring is to limit the use of fuel pumps to two at a time and to turn off both the S-4 Shoran and the APG-31 Gun Ranging Radar. The electrical system loading will then be below the system's two-generator capacity and will operate safely.

For two-generator operation at altitudes of 36,500 feet and below, no monitoring is required.

- 5. If two generators are lost because of engine failure:
 - Place both generator switches for the malfunctioning engine in OFF.
 - b. No monitoring of electrical load is required.

- Note

The capacity of the two operating generators at the airplane's single engine service ceiling is sufficient to supply the electrical system without monitoring.

- 6. If two generators are lost because of engine failure and one of the remaining generators fails, as indicated by any of the conditions in paragraphs 1 through 3:
 - Place the generator switches for the inoperative generators in OFF.

Note

As a result of an engine failure, the mission will probably have to be aborted. The system's electrical loads should be monitored, commensurate with the gross weight of the airplane and the altitude at which it is flying. The electrical load must not exceed the electrical system's capacity for single-engine, single-generator operation so that the effectiveness of the airplane will be maintained on the return flight to base. The generator rating for maximum operational altitude of 36,500 feet, for light gross weight is 294 amperes 0.95 loadmeter reading.

- b. Monitor electrical loads by turning off power for special weapons, bomb control, gun ranging radar, gun charging, gun heaters, recirculating blower, Radar Beacon APW-11A, inverters, and by limiting the use of fuel boost pumps to two at a time.
- 7. If all four generators indicate failure:
 - Immediately place the battery switch in OFF if the airplane is below 26,000 feet altitude.

CAUTION

Above an altitude of about 26,000 feet, engine flame-out occurs if there is not at least one fuel tank boost pump feeding fuel directly to the engines.

- b. Turn off all non-essential electrical loads.
- c. Place the battery switch in ON and, one at a time, place each generator switch in RE-SET, note the voltage, and place the switch in OFF.
- After checking all the generators, place the battery switch in OFF.
- e. If normal voltage is indicated by any or all generators, place the switch for the generators that indicated normal voltage in ON one at a time.
- f. If the electrical system is functioning properly, place the battery switch in ON and turn on needed electrical equipment.

CAUTION

Be careful not to overload the generator or generators now supplying the electrical system.

8. If none of the generators can be returned to the electrical system, leave the generators switches in OFF, leave the battery switch in OFF, and land as soon as possible.

Note

If it is necessary and sufficient battery power remains, the battery will operate the canopy control circuit, control column stowage system (Group E Airplanes), master jettison circuit, standby inverter circuits, and the C-4A lights. These circuits operate regardless of the position of the battery switch.

ELECTRICAL FAILURE

| NO. OF GENERATORS OPERATING | NO. OF ENGINES OPERATING | BATTERY POWER | MAXIMUM ALLOW- ABLE LOADMETER READING PER GENERATOR | GENERATING SYSTEM OUT- PUT (AMPERES) | REMARKS |
|-----------------------------------|--------------------------------|------------------|--|--|---|
| 4 | 2 | Yes | .7* | 792 | Normal operation, 50,000 ft. altitude no monitoring required. |
| 3 | 2 | Yes | .7* | 594 | Normal operation, 50,000 ft. altitude. No monitoring required. |
| 2 | 2 | Yes | .7* | 396 | Unnecessary loads must be monitored. Maximum loadmeter reading at 50,000 ft. altitude is .7. |
| 1 | 2 | Yes | .7* | 220 | Unnecessary loads must be monitored. Maximum loadmeter reading at 50,000 ft. altitude is .7. |
| 0 | 2 | Yes | 0 | Depends upon conditions of battery† | Since fuel booster pumps are necessary at altitudes above 26,000 ft. the battery can be used to operate necessary fuel booster pumps during let down to 26,000 ft. It is imperative that all loads except necessary fuel booster pumps and standby instrument inverter be turned off. |
| 0 | 2 | No | 0 | 0 | No power available for flight instruments or for relite in case of flame-out. Engines will probably flame-out when operating above 26,000 ft. with no power for the fuel booster pumps. The center of gravity cannot be controlled without fuel booster pumps. |
| 2 | 1 | Yes | .95 | 540 | The altitude for single-engine operation is limited to 36,500 ft. Tactical mission considered aborted. No monitoring of loads required for all other remaining operating conditions. |
| 1 | 1 | Yes | .95* | 300 | Altitudes limited to 36,500 ft. Loads (all but 2 fuel pumps) shall be monitored so that loadmeter reading of remaining generator does not exceed 1.0. |
| 0 | 1 | Yes | 0 | Depends upon condition of battery† | Altitude limited to approximately 26,000 ft. Supply loads on battery bus only. Preserve battery for relite attempts in case of flame-out. (Battery switch in OFF position.) |
| 0 | 1 | No | 0. | 0 | Altitude limited to approximately 26,000 ft. No electrical power available. |
| 0 | 0 | Yes | 0 = | Depends upon condition of battery† | Only battery bus should be energized. (Battery switch in OFF position.) Engine relight is possible depending upon the condition of the battery. |
| 0 | 0 | No | 0 | 0 | Refer to glide distance in this section. No electrical power available. |

† Life expectancy of battery depends upon the state of charge, its temperature, and rate of discharge.

| ALT. FEET | | dmeter readings at different altitudes. VABLE LOAD PER GENERATOR |
|---------------------|---------|--|
| | Amperes | Aircraft loadmeter reading |
| Ground Operation | 110 | .35 |
| S.L. to 35,000 | 300 | 1.0 |
| 40,000 | 280 | .9 |
| 45,000 | 245 | 8. |
| 50,000 | 220 | 7 |

.

CIRCUIT BREAKERS.

If a circuit breaker opens disconnecting power to any circuit, it indicates an overload or short in that circuit. If the circuit breaker reopens after being reset, do not use that circuit.

NO. 1 AND NO. 2 INVERTER FAILURE.

If the No. 1 or No. 2 inverter fails during flight, the No. 1 and No. 2 inverter failure indicator light illuminates. If one of these light should illuminate, place its respective inverter switch in OFF. Because there is no alternate source of power for the a-c circuits if the No. 1 or No. 2 inverter fails, all circuits supplied by the inoperative inverter will be out.

Note

When the No. 1 inverter fails during flight, the following instruments probably will retain the same readings as were indicated immediately prior to the No. 1 inverter failure: the fuel quantity gauge, No. 1 and No. 2 engine oil pressure indicators, the No. 1 and No. 2 engine fuel flow indicators, and the main system hydraulic pressure indicator.

INSTRUMENT INVERTER FAILURE.

If the instrument inverter fails in flight, as indicated by the inverter failure light, place the instrument inverter switch in STANDBY. In this position, the standby instrument operates the flight attitude indicator and the J-2 compass.

Note

When the instrument inverter fails during flight, J-2 compass will retain the same reading as was indicated immediately before the inverter failed. The vertical gyro indicator will assume an erratic position.

COMPLETE ELECTRICAL FAILURE.

Note

During complete electrical failure, all a-c instruments retain the same readings as were indicated immediately before the electrical failure occurred. All d-c instruments will assume an off-scale position or revert to zero. If the entire electrical system fails or if it becomes necessary to turn off the battery and generators, much of the auxiliary equipment and many controls will be inoperative. Flight without electrical power is limited and should be conducted as follows:

- If it is possible, reduce airspeed and adjust trim before turning off the electrical power. Trim control is not available without electrical power and the trim devices will continue to assume the positions they had at the time of electrical failure.
- 2. The fuel system will not continue to operate if electrical power is not available. All fuel boost pumps, except the engine-driven fuel boost pump, will cease operation. Therefore, a reduction in altitude and rpm may be necessary for satisfactory engine operation.

CAUTION

Loss of boost pump pressure may cause erratic engine operation above an altitude of 26,000 feet. Engine flame-out will almost certainly occur if there is not at least one fuel tank boost pump feeding fuel directly to the engines. Since fuel is normally fed from the No. 1 fuselage tank to the engines. this means that if both the boost pumps in that tank are inoperative, normal flight above 26,000 feet is not possible. Under these conditions and just prior to flameout, a rapid fluctuation of the fuel flow will be evident.

CAUTION

When electrical power has been lost, the emergency fuel control system cannot be put into operation.

3. If possible, check that the fuel transfer and bypass valve knob is in the flow from No. 1 tank position, before turning off electrical power. The No. 1 fuselage tank is the main service tank to which fuel from all other tanks is normally transferred. (This procedure is recommended since more fuel is in the No. 1 tank than in any other tank all times during flight.)

CAUTION

If all electrical power is lost, the fuel quantity indicator is inoperative. However, the pointer remains in position and gives a false reading.

4. Land as soon as possible. The landing gear and bomb door will operate satisfactorily, but the flaps and dive brakes will be inoperative.

CAUTION

The external stores, internal stores, and wing tip tanks cannot be released without electrical power.

HORIZONTAL STABILIZER MALFUNCTION. (GROUP O AIRPLANES)

The maximum speed at which a runway stabilizer can be safely controlled is 250 knots IAS. If stabilizer failure occurs at full nose-up trim, you can still make a flaps-up landing safely. If stabilizer failure occurs at full nose-down trim, a full flaps landing can be made safely. If failure of the stabilizer normal control system should occur, do this:

- Place the horizontal stabilizer control switch in ALT.
- 2. Actuate the stabilizer emergency control switch to position the stabilizer.

Note

When the horizontal stabilizer control override switch is in ALT, the aileron trim control system is inoperative.

HORIZONTAL STABILIZER MALFUNCTION. (GROUP P AIRPLANES)

Full nose-down trim failure can be controlled at maximum airspeeds using about 80 pounds of stick force for an airplane with an aft cg condition. With a forward cg condition, full nose-down trim failure can be controlled at maximum airspeeds using about 135 pounds stick force. Full nose-up trim failure cannot be overcome at maximum airspeeds. Under this condition the airplane will climb, the airspeed will decrease, and at about 350 knots IAS the trim can be overpowered to attain level flight. If failure of the stabilizer trim system occurs:

- Place the stabilizer emergency switch in EMERG OFF.
- Place the stabilizer POWER circuit breaker in OFF.

HYDRAULIC SYSTEM FAILURE.

If the hydraulic system fails, a wheel brake accumulator which is isolated from the main system by a check valve provides fluid for emergency operation of the wheel brakes. Emergency operation of the landing gear and bomb door is possible by the use of the pilot's hydraulic hand pump which supplies pressure to a duplicate pressure line to the control valves for the landing gear and bomb systems. There is enough fluid in the emergency portion of the hydraulic reservoir for opening the door and extending the landing gear. If the bomb door is closed at the time of hydraulic system failure, and it is necessary to open the door before landing in order to release the bomb load, the landing should be made with the door open. If, after approximately 50 strokes of the hand pump, there is no indication of pressure buildup or bomb door operation, make no further attempt to operate the bomb door. For other hydraulic system failures, see BRAKE SYSTEM FAILURE and LAND-ING GEAR EMERGENCY EXTENSION in this sec-

EXCESSIVE HYDRAULIC FLUID TEMPERATURES.

Loss of accumulator precharge pressure is a major factor in attaining a high frequency of pressure oscillation and excessive hydraulic fluid temperatures. The temperature of the hydraulic fluid becomes excessive when a high pressure drop is combined with high fluid flow over an extended period of time. This condition can also be the result of pressure regulator failure in the cut-in position, requiring the output of both pumps to be passed through the main relief valve. It will be evident by a continuous 3500 psi indication on the main hydraulic system pressure gage. High temperatures will occur in approximately 20 minutes. This may cause hydraulic system failure due to pump failure or loss of fluid through leakage induced by the high temperatures. The emergency procedures described in this section must then be followed for bomb door and landing gear operation. Excessive fluid temperatures can also be caused by very rapid continuous oscillation of system pressure, when the subcircuits are not being operated, between the nor-

mal cut-in pressure of 2600 $^{+100}_{-0}$ psi and the normal

cut-out pressure of 3000 $^{+100}_{-0}$ psi. Rapid fluctuation of system pressure is the result of considerable increase in the internal leakage rate. Fluctuation of system pressure is indicated by the main hydraulic system pressure gage. Operation of each subcircuit may stop the internal leakage and fluctuation. The operation of one subcircuit should be completed before actuating another. This will assist in determining the circuit in which internal leakage existed.

LANDING GEAR SYSTEM FAILURE.

MAIN LANDING GEAR EMERGENCY EXTENSION.

If the landing gear fails to extend in the normal manner, do this:

- 1. Place the landing gear lever in DOWN.
- Pull the emergency landing gear down handle all the way out.
- 3. Operate the hydraulic hand pump.

Note

The hand pump requires approximately 100 to 150 strokes to extend the landing gear, and landing gear extension may require as much as three minutes.

CAUTION

If the bomb door is closed at the time of the hydraulic system failure and it is necessary to open the door before landing to release the bomb load, land with the door open. The emergency portion of the hydraulic reservoir contains only enough fluid for opening the bomb door and extending the landing gear.

NOSE LANDING GEAR EMERGENCY EXTENSION.

If the nose gear fails to extend normally, it can be the result of damage to the nose gear door locking mechanism. Reduce the airspeed well below the 200-knot limitation and apply sufficient engine power while attempting to extend the gear. If repeated cycling fails to obtain extension of the nose gear, operate the hand pump with the gear in the extended position. The forces on the hand pump will be exceedingly high but in some cases it will be possible to obtain slightly more pressure on the nose gear lock mechanism than by the normal system.

CAUTION

If the main hydraulic system fails, do not depress the pedals while in flight, since all brake system pressure will be lost. Save the brake pressure for landing. Although the brake circuit contains enough fluid for two or three applications of the brakes, after touchdown is made, apply the brakes gradually and do not let up until stopped. After the airplane has been brought to a complete stop on the runway, do not attempt taxiing under any conditions because total brake failure will occur in a very short period of time.

BRAKE SYSTEM FAILURE.

In the event the main hydraulic system fails, the wheel brake accumulator has sufficient pressure for two or three applications of the brakes. However, only one continued application is recommended when the main hydraulic system has failed.

Note

In the event pressure has been lost in the brake system and the landing gear is down and locked, open the ground shut-off valve and use the hydraulic hand pump to charge the brake accumulator. Do not use this method to lower the flaps or operate any other system. If the flaps are lowered by this means, it is entirely possible that they could not be raised. The possibility of both hydraulic pumps malfunctioning at the same time is highly improbable. However, if this should happen, the valve and hand pump may be used as a last resort to lower the flaps.

If the brake system has failed and pressure cannot be built-up by emergency means, do this:

- If there are at least 10,000 feet of landing clearance, including the runway and clear area beyond, make the landing with the landing gear extended.
- 2. If there is less than 10,000 feet landing clearance, land with the gear extended and retract the gear when it becomes apparent that insufficient rollout distance remains. Raising the nose-wheel and leaving the flaps down after touchdown decreases the landing roll distance.

Note

See LANDING WITH GEAR RETRACTED in this section.




Figure 3-6

11. HAND FIRE EXTINGUISHER (C.B.)

12. OBSERVER'S SEAT

CONTROL

5. PILOT'S INERTIA REEL LOCK CONTROL

11661A

17. HYDRAULIC HAND PUMP

CHECK LIST OF EMERGENCY PROCEDURES

ENGINE FAILURE DURING TAKE-OFF.

With sufficient runway remaining.

1. Throttles OFF 2. Brakes Apply

With insufficient runway remaining.

1. Throttles OFF 2. Brakes Apply 3. Wing tip tanks Jettison 4. Canopy emergency release han-Pull

dle

5. Landing gear UP 6. Battery switch OFF

After becoming airborne

1. Throttle on operating engine Reduce to maintain directional

control while accelerating to safe single-engine speed of 155 knots

2. Landing gear UP 3. Throttle on dead engine OFF

4. Engine valve knob for dead OFF engine

5. Fire warning lights Check OUT to eliminate possibility of fire

ENGINE FAILURE IN FLIGHT.

1. Throttle on operating engine Adjust to maintain airspeed and directional control

2. Throttle on dead engine OFF

Retrim to maintain level flight

4. Engine valve knob for dead engine

3. Trim system

OFF

| Fullest tank | Fuel selector switches | |
|---|--------------------------------|-------|
| NO | No. 1 inverter switch | |
| BATTERY | Battery switch | I. |
| SOCEDNKE. | AY TAATS AIA BUIDNE JA | AUG |
| | | |
| КАМ | b. Below 43,000 feet | |
| OFF | a. Above 43,000 feet | |
| OFF | | ·Þ |
| BATTERY | HILD MAKES | ·ć |
| OFF | All electrical equipment | 7 |
| OEE | Battery switch | |
| 413 | L ENGINE FAILURE. | |
| | THE PARTIES EATHING | A 114 |
| | | |
| IDLE or slightly above | Throttle | .8 |
| tarily | 8 | |
| To CRANK ONLY momen- | Ignition switch | |
| BATTERY | Battery switch | |
| Flow position | Engine valve knob | 5 |
| Air speed 155 to 220 knots IAS: 14 to 22% tpm | onigne Ilimbni₩ | ·Þ |
| Nose-high attitude for 15 seconds | Drain fuel from engine | ·c |
| (NO) uI | Fuel system circuit breakers | |
| OFF | Throttle | |
| PROCEDURE. | SLE ENGINE AIR START | |
| | | |
| OFF | Generators on dead engine | ٠.٢ |
| Reset to operative engine | Cabin pressure selector switch | .9 |
| Check OUT to eliminate possibility of fite | Fire warning lights | ٠ς |
| | | |

| IAS; |
|------|
| |
| |
| 1- |
| |
| |

SINGLE ENGINE LANDING.

 Maintain safe single engine control speed (155 knots) until on final approach.

DOWN in time to insure down and locked prior to touchdown
 130 knots IAS

4. Flaps DOWN when landing assured

LANDING WITH BOTH ENGINES INOPERATIVE.

1. Glide speed

2. Landing gear

3. High key point

4. Low key point

5. Base leg

6. Final approach

Approximately 160 knots

DOWN, 10,000 feet above terrain

Select 5,000 feet above terrain

Select 1,500 feet over the terrain

Turn with IAS 140 to 150 knots

IAS 120 to 130 knots. Side-slip and "S" turn to lose excessive altitude

LANDING WITH GEAR RETRACTED.

- I. Notify observer to prepare for crash landing.
- just prior to landing. 2. Advise control tower of emergency and request foam on runway
- 3. Reduce fuel load but retain empty or nearly empty tanks.
- 4. Jettison all internal and external stores and close bomb door,
- 5. Unfasten parachute harness and readjust lap belt and shoulder har-
- 6. All unneeded electrical equip- OFF
- 7. Landing pattern Set up flat with power on
- 8. Canopy Jettison with IAS 180 knots or
- DOMN below.
- 105 knots maximum 10. Touchdown 9. Flaps
- (After Touchdown)
- OFF OEE II. Throttle
- Abandon airplane as soon as possible.

DITCHING.

12. Battery switch

- I. Notify observer to prepare for ditching.
- **EWERGENCY** 2. IFF switch
- 3. Actuate master jettison switch if it is desirable to jettison stores.
- 4. Bomb door switch CLOSE
- EXLEND 6. Dive brakes 5. Landing gear dΩ
- 7. Flaps DOMN

CUT ON BLACK LINE

- 8. Disconnect all personal equipment except oxygen hose.
- 9. Unbuckle parachute harness.
- 10. Airspeed 180 knots or less Jettison canopy
- 11. Check seat belt and shoulder harness secure and locked.
- 12. Insert seat safety pins.
- 13. Make landing into wind. If sea is rough, land parallel to waves, on top of wave crest.
- 14. Throttles OFF
- 15. Make touchdown as slowly as possible with slightly hose-high attitude.
- 16. After airplane has stopped, abandon it immediately.

SINGLE ENGINE GO-AROUND.

1. Throttle of operative engine Advance gradually as airspeed

increases to maintain directional

- control
- 2. Dive brakes RETRACT
- 3. Flaps UP
- 4. Landing gear UP as soon as climb is estab-

blished

ENGINE FIRE.

- 1. Fire extinguisher PULL-TO-Pull ARM knob
- 2. Agent discharge switch AGENT DISCHARGE
- 3. Throttle OFF 4. Oxygen 100%

ENGINE FIRE ON GROUND.

- 1. Throttles OFF
- 2. Carbon dioxide fire extinguish-Signal for use by ground crew ing equipment
 - (If ground crew not available.)
- 1. Fire extinguisher PULL-TO-Pull ARM knob

| bosziple | | |
|--------------------------|------------------------|----|
| Leave airplane as soon a | Pilot | ·Þ |
| OFF | Throttle | .ć |
| VGENT DISCHARGE | Agent discharge switch | 7 |
| | | |
| | | |

WING OR FUSELAGE FIRE.

| 3. | If fire is uncontrollable | Bail out |
|----|-----------------------------|-------------------------------|
| .2 | If system fire | Shut down system feeding fire |
| •1 | Cabin pressure selector swi | KYM |

FIRE IN FLIGHT COMPARTMENT.

| Bail out | If fire uncontrollable | ·Þ | |
|------------------|--------------------------------|----|--|
| RAM | Cabin pressure selector switch | ٠٤ | |
| Use as necessary | Hand fire extinguisher | 7. | |
| %00I | Oxygen regulator | ī. | |
| | | | |

ELECTRICAL FIRE.

| 2 | Flectrical equipment | ot ullenbigibni stinn anotsa & |
|---|--------------------------------|--------------------------------|
| 7 | Hand fire extinguisher | Use as necessary |
| 3 | Oxygen regulator | %001 |
| 7 | Cabin pressure selector switch | As required |
| | ednipment | |
| I | All non-essential electrical | OFF |

| determine faulty circuit | | |
|-------------------------------|----------------------|----|
| Restore units individually to | Electrical equipment | .6 |

ELIMINATION OF SMOKE OR FUMES.

| | | detern | os ənim | onice | ous jo | oke or | |
|----|--------------------------------|--------|---------|-------|--------|--------|---|
| ·I | Cabin pressure selector switch | NO' | I ENC | and | 7 'ON | ENC 40 | 0 |
| | (Below 42,000 feet) | | | | | | |

CUT ON BLACK LINE

2. Oxygen regulator 100% RAM

3. Cabin pressure selector switch (Above 42,000 feet)

1. Cabin pressure selector switch

NO. 1 ENG and NO. 2 ENG to determine source of smoke or

fumes

100% 2. Oxygen regulator

3. Cabin pressure selector switch RAM after rapid descent to below 42,000 feet

LANDING GEAR SYSTEM FAILURE.

1. Landing gear lever

2. Emergency landing gear handle OUT, all the way

3. Hydraulic hand pump Operate manually as required

DOWN and locked 4. Landing gear

HORIZONTAL STABILIZER SYSTEM FAILURE. (GROUP O AIRPLANES)

1. Stabilizer control switch ALT

Actuate to position stabilizer as 2. Stabilizer emergency control desired switch

HORIZONTAL STABILIZER SYSTEM FAILURE. (GROUP P AIRPLANES)

EMERG OFF 1. Stabilizer emergency switch

2. Stabilizer POWER circuit OFF breaker

SEAT EJECTION.


Raise to jettison canopy, lock 1. Right and left grips shoulder harness, and stow con-

trol column

Revised 2 January 1957

77 Revised 2 January 1956 End Check List of Emergency Procedures Trigger on right grip Squeeze Erect, head against rest, chin in 4. Body Place in rests smiA .ć Place in rests 2. Feet

Section IV



DESCRIPTION AND OPERATION OF

AUXILIARY EQUIPMENT

11699

TABLE OF CONTENTS

| Pag | Page |
|--|---|
| AIR-CONDITIONING AND PRESSURIZATION SYSTEM 4—WINDSHIELD- AND CANOPY-DEFOGGING 4—PITOT STATIC SYSTEM 4— | LIGHTING EQUIPMENT 4-15 OXYGEN SYSTEM 4-2 NAVIGATION EQUIPMENT 4-25 |
| COMMUNICATIONS AND ASSOCIATED ELECTRONIC EQUIPMENT 4- | ARMAMENT EQUIPMENT 4-27 8 MISCELLANEOUS EQUIPMENT 4-47 |

AIR-CONDITIONING AND PRESSURIZATION SYSTEM.

The air-conditioning and pressurization system (figure 4–1) heats, ventilates, and pressurizes the cabin. The system also supplies air for canopy and windshield defogging, windshield anti-icing, and for pressure in the canopy seal.

CABIN PRESSURIZATION AND HEATING.

A shut-off valve in the ducts from each engine permits one or both engines to supply hot pressurized

air to the cabin. One engine supplies enough air to the system for normal operation. Air pressure from the engines varies with engine rpm; therefore, an automatic venturi airflow regulator incorporated in the system maintains a constant system pressure. Hot air from the thirteenth stage of the engine compressor(s) passes through a refrigeration unit for cooling, an electrically controlled hot-air modulating valve regulates the mixing of refrigerated air with hot engine compressor air to give the selected cabin temperature. Air enters the cabin through the canopy




Figure 4-1 (Sheet 1 of 2)




Figure 4-1 (Sheet 2 of 2)




Figure 4-2

defogging nozzles or through the pilot's and observer's air outlets, and a cabin pressure regulator automatically opens and closes to regulate the cabin pressure. Opening the ram-air shut-off valve and the cabin safety valve permits unrestricted cabin ventilation; however, ventilating the cabin with ram air causes a rapid loss of cabin pressure and heat. Cabin pressurization is effective above 10,000 feet. From 10,000 to 20,500 feet, cabin pressure is equivalent to an atmospheric pressure of 10,000 feet. Above 20,500 feet the differential pressure is constant at 3.5 psi. See cabin pressure schedule, figure 4–2.

CABIN PRESSURIZATION AND HEATING SWITCHES. (See figure 4-3.)

CABIN PRESSURE SELECTOR SWITCH.

The rotary CABIN PRESSURE selector switch is on the air-conditioning control panel. Switch markings are OFF, NO. 1 ENG., NORMAL, NO. 2 ENG. and RAM. The switch controls the right and left engine compressor air shut-off valves, the ram-air shut-off valve, and the cabin safety valve. Placing the switch in OFF closes the right and left engine shut-off valves.

Placing the switch in the NO. 1 ENG or NO. 2 ENG position opens the respective shut-off valve and closes the opposite valve. The NORMAL position allows air to flow through both shut-off valves. Placing the switch in RAM closes the two compressor air shut-off valves and opens the ram-air shut-off valve and the cabin safety valve. The 28-volt d-c distribution bus supplies the power to operate the valves.

CABIN TEMPERATURE CONTROL SWITCH.

The cabin temperature control switch is on the air-conditioning control panel. Switch markings are AUTO (up), OFF (center), WARM (lower right), and COOL (lower left). Placing the switch in AUTO arms the cabin temperature rheostat. Manual control of cabin temperature is possible by momentary operation of the switch from OFF to COOL or WARM. This bypasses the cabin temperature control box to directly adjust the hot-air modulating valve. The 28-volt d-c distribution bus supplies the power to operate the circuit.

CABIN AIR TEMPERATURE RHEOSTAT.

The cabin air temperature rheostat is on the air-conditioning control panel. The markings for the rheostat

are COOL and WARM. Placing the cabin temperature control switch in AUTO and rotating the rheostat cause the hot air modulating valve to move to a desired position between fully opened and fully closed, depending on the direction of rheostat rotation. A thermostat and a temperature control box regulate the modulating valve to maintain the selected temperature. The 28-volt d-c distribution bus supplies the power to operate the circuit.

CABIN DUMP SWITCH.

The guarded two-position CABIN DUMP switch on the cabin air-conditioning panel controls the cabin safety valve. Raising the guard and placing the switch in the up position open the cabin safety valve. The 28-volt d-c distribution bus supplies the power to operate the circuit.

CABIN PRESSURE ALTITUDE INDICATOR.

The cabin pressure altitude indicator on the generator control panel indicates cabin pressure. Comparing the cabin pressure altitude indication with the altimeter enables the pilot to evaluate cabin pressurization.

CABIN PRESSURIZATION AND HEATING, NORMAL OPERATION.

- After starting the engines, place the cabin pressure selector switch in RAM for taxiing and take-off.
- After take-off, place the selector switch in NOR-MAL and place the cabin temperature control switch in AUTO.
- Position the cabin pressure temperature rheostat to select a desired temperature.
- Before leaving the airplane and de-energizing the 28-volt system, place the selector switch in OFF.

CABIN PRESSURIZATION AND HEATING, EMERGENCY OPERATION.

ENGINE FAILURE.

- 1. Place the cabin pressure switch in the operating engine position.
- 2. Compare the cabin pressure altitude indicator with the altimeter to evaluate system operation.




Figure 4-3

HEATING SYSTEM MALFUNCTION.

To regulate cabin temperature during heating system malfunction:

- Momentarily move the cabin temperature control switch to COOL or WARM and then to OFF.
- Reduce altitude and place the cabin pressure selector switch in RAM if heat becomes excessive.

Note

Electrically operated valves control the temperature. During electrical failure, the valves remain in the position held at the time of the electrical failure.

ENGINE BLEED-AIR-DUCT RUPTURE.

- Place the selector switch in NO. 1 ENG position and check system operation by observing the cabin pressure indicator.
- If the cabin pressure decreases after the switch is in the NO. 1 ENG position, place the selector switch in the NO. 2 ENG position and check system operation by observing the cabin pressure indicator.
- If cabin pressure decreases after the selector switch is in NO. 1 ENG and NO. 2 ENG, place the selector switch in OFF and if necessary reduce altitude or land.

ENGINE BLEED-AIR CONTAMINATION.

- 1. Place the oxygen selector to 100 percent.
- 2. Place the cabin pressure selector switch in the NO. 1 ENG position.
- If contamination persists with the selector switch in the NO. 1 ENG position, place the selector switch in NO. 2 ENG position.
- If contamination persists with the selector switch in the NO. 1 ENG and NO. 2 ENG positions, reduce altitude if above 18,000 feet and place the selector switch in RAM.
- If desired, after clearing the cabin by ram ventilation, repeat steps 1 through 4.

WINDSHIELD AND CANOPY DEFOGGING.

Air from the air-conditioning and pressurization system plus hot engine compressor air defogs the windshield and canopy. During the heating and pressurization not requiring windshield and canopy defogging, air enters the cabin through the CANOPY NOZZLES and not through the pilot's and observer's air outlets. During heating and pressurization requiring windshield and canopy defogging, shut-off valves divert the

air from the canopy nozzles to the pilot's and observer's air outlets. The defogging and recirculating blower forces the cabin air through a separate duct to the windshield and canopy. A defogging airmodulating valve permits a desired amount of hot engine compressor air to mix with the air from the blower.

DEFOGGING BLOWER KNOB.

The defogging blower knob on the pilot's right console controls the canopy and windshield defogging and air circulation within the cabin. Pulling the defogging blower knob all the way out (on) mechanically positions a damper that closes the cabin conditioned air inlet and opens the recirculating and defogging air inlet. The final 1/8 inch of travel (out) actuates a microswitch which energizes the recirculating blower and the defogging control circuits. The 28-volt d-c pilot's circuit breaker bus supplies the power to operate the circuits.

DEFOG HOT AIR SWITCH.

The windshield and canopy DEFOG HOT AIR switch (figure 4-4) is on the windshield control panel. It is marked DEFOG HOT AIR and OFF. The switch circuit is operative only after the DEFOGGING BLOW-ER KNOB on the right console is pulled all the way out. Placing the switch in DEFOG HOT AIR arms the defog air rheostat. The 28-volt auxiliary distribution bus supplies the power to the control circuit through the DEFOG AIR switch.

DEFOG AIR RHEOSTAT.

The DEFOG AIR rheostat, marked COOL and WARM, is on the windshield control panel. Rotating the rheostat clockwise causes a heating coil to raise the mercury level in a thermostat. When the mercury rises sufficiently, it completes a circuit to the "more heat" relay. Closing the "more heat" relay completes a circuit to open the hot-air modulating valve, thereby raising the temperature of the air delivered to the windshield and canopy. Rotating the rheostat counterclockwise reduces the mercury level. When the mercury lowers sufficiently, it completes a circuit to the "less heat" relay. Closing of the "less heat" relay causes the hot-air modulating valve to close, thereby lowering the temperature of the air delivered to the windshield and canopy. The 28-volt d-c distribution bus supplies the power to operate the circuits.

WINDSHIELD ANTI-ICING SYSTEM.

The windshield anti-icing system (figure 4-1) distributes a stream of hot air to the outside surface of

windshield control panel



11703

Figure 4-4

the windshield through an external nozzle. The air-conditioning and pressurization system supplies the hot air for the windshield anti-icing system; therefore, the air-conditioning and pressurization system must be operating to de-ice the windshield. A grid of tungsten wire embedded in the windshield glass senses windshield temperature. Since the electrical resistance of the sensing element varies with the windshield temperature, the variation of resistance causes the shut-off valve to adjust the amount of hot air flowing to the windshield.

WINDSHIELD ANTI-ICING SWITCH.

The two-position WINDSHIELD ANTI-ICING switch (figure 4-4) is on the windshield control panel. Placing the switch in ANTI-ICING energizes relays in the windshield anti-icing temperature control box and completes a circuit to the shut-off valve. Placing the switch in OFF de-energizes the relays and closes the shut-off valve. The 28-volt d-c distribution bus supplies the power to operate the system.

WINDSHIELD ANTI-ICING SYSTEM, NORMAL OPERATION.

 Place the cabin pressure switch in the NOR-MAL, NO. 1 ENG, or NO. 2 ENG positions. Place the windshield anti-icing switch in WIND-SHIELD ANTI-ICING.

PITOT STATIC SYSTEM.

The pitot static system supplies dynamic and static air pressure to the airspeed indicator, Machmeter, and the vertical velociter indicator. Static plates are on both sides of the nose section and the pitot head is on the under surface of the nose.

PITOT HEATER SWITCH.

The two-position PITOT HEATER switch on the windshield control panel controls the heating element in the pitot head. Switch markings are PITOT HEATER and OFF. Placing the switch in PITOT HEATER energizes the heating element. There are no devices in the circuit to limit the heating of the element, therefore, turn the pitot heater switch off during ground operation. The 28-volt d-c pilot's distribution bus supplies the power to operate the circuit.

HELMET DEFOGGING RHEOSTAT.

Helmet defogging rheostats control the electrical power to the heating element in the pilot's and observer's helmet face piece. Rheostat markings are OFF and HEAT. The pilot's rheostat is on his right console, and the observer's rheostat is on his left console. To operate the system, move the rheostat clockwise, out of OFF until desired heat is obtained. The 28-volt d-c battery bus supplies the power to operate the system.

Note


The helmet defog circuit breakers are in the left electrical access compartment. These circuit breakers are inaccessible during flight, and must be placed IN during the exterior inspection.

COMMUNICATIONS AND ASSOCIATED ELECTRONICS EQUIPMENT.

All electronic and communication equipment controls are at the pilot's and observer's stations. (See figure 4–5 for equipment and range data.) The airplane has nine antennas for the operation of the existing equipment. See figure 1–1 for antenna locations. The 28-volt d-c radio bus and the NO. 1 and NO. 2 a-c radio busses supply the power to operate the communications and electronics equipment.

INTERCOMMUNICATION SET AN/AIC-10.

The intercommunication set receives signals from all communications equipment on the airplane. Manipulation of the switch on the pilot's interphone control



communications

and associated electronic equipment

| TYPE | DESIGNATION | FUNCTION | OPERATOR | RANGE | CONTROL LOCATION |
|------------------------------------|---|---|--|------------------|--|
| IHF COMMAND ECEIVER TRANSMITTER | RADIO SET AN/ARC-27 | RADIO TELEPHONE COMMUNICATION ON PRESELECTED UHF CHANNELS | PILOT | LINE OF SIGHT | PILOT'S LEFT CONSOLE |
| RADIO COMPASS | RADIO COMPASS AN/ARN-6 | RECEIVER COMMUNICATIONS FOR AUTOMATIC DIRECTION FINDING AND GENERAL RECEPTION OF L-F AND M-F, C-W AND A-M, SIGNALS | PILOT OBSERVER | 200 MILES | PILOT'S AND OBSERVER'S RIGHT CONSOLE |
| MARKER BEACON ECEIVER | MARKER BEACON RECEIVING SET AN/ARN 12 | AURAL AND VISUAL INDICATIONS OF COURSE AND CONE OF SILENCE MARKERS | PILOT | ALL ALTITUDES | PILOT'S RIGHT CONSOLE |
| nterphone | INTERCOMMUNICA- TION SET AN/AIC 10 | TALKING AND LISTENING CONTROL BETWEEN AIRPLANE STATIONS AND OTHER COMMUNICATIONS EQUIPMENT | PILOT OBSERVER MAINTE- NANCE PERSONNEL | CABIN | PILOT'S RIGHT CONSOLE OBSERVER'S LEFT CONSOLE RIGHT WHEEL WELL |
| ff | RADAR IDENTIFI CATION SET AN/APX-6A | AUTOMATICALLY IDENTIFIES AIRPLANE AS FRIENDLY WHEN CHALLENGED BY PROPERLY EQUIPPED RADARS | PILOT | LINE OF SIGHT | PILOT'S RIGHT CONSOLE |
| PADAR BEACON | RADAR SET AN/APW-11A WITH INDICATING GROUP AN/APA-90 | NAVIGATIONAL AND BOMBING AID RADAR GUIDANCE SYSTEM | PILOT | 200 MILES | PILOT'S RIGHT CONSOLE |
| HORAN | S-4 | NAVIGATIONAL RADAR SYSTEM | OBSERVER | LINE OF SIGHT | OBSERVER'S RIGHT CONSOLE |
| YRO COMPASS | TYPE J-2 SLAVED — GYRO MAGNETIC COMPASS | PROVIDES STABILIZED MAGNETIC HEADING OF AIRPLANE | PILOT | | PILOT'S INSTRUMENT PANEL |
| PADAR WARNING | RADAR RECEIVING SET AN/APS-54 | VISUAL AND AURAL WARNING OF AIRBORNE INTERCEPTION OF AIRBORNE GUN LAYING RADAR | OBSERVER (VISUAL) PILOT (AURAL) | 75 MILES | PILOT'S RIGHT CONSOLE PILOT'S LEFT CONSOLE |

Figure 4-5

panel (right horizontal console) or the observer's interphone control panel (left console) enables the user to receive a single signal or to mix two or more signals. The equipment used by the pilot or observer are the control panels, headsets, microphones, and press-to-talk switches on the control wheel and inboard throttles. The observer's microphone switch (figure 4-6) is below the observer's instrument panel

on the floor. Three features of the set insure high intelligibility at all altitudes: 1) the air-damped headphones that enable the vibrations of the diaphragm to become more vigorous as the air becomes thinner due to increases in altitude, 2) the barometric switches that automatically adjust sound volume during changes in altitude, and 3) the automatic volume control. A control box in the right wheel well enables the crew to talk to ground personnel.

observer's microphone switch



Figure 4-6

INTERCOMMUNICATION SET AN/AIC-10 CONTROL PANEL.

The pilot's interphone control panel (figure 4–7) is on the pilot's right horizontal console, and the observer's interphone control panel is on the observer's left console. The control panels contain a rotary function-selector switch, a volume control knob, a NORMAL-AUX LISTEN switch, and a row of audio mixing switches along the top of the control panel. The 28-volt d-c radio bus supplies the power to operate the intercommunication set.

FUNCTION SELECTOR SWITCH.

A rotary function selector switch is on the pilot's and observer's intercommunication set control panel. The position of the switch determines the equipment used for transmission and reception. Switch markings are CALL, INTER, HOT-MIC, COMM, and ADF. Rotating the function selector switch to CALL and depressing a microphone switch enables the user to communicate with the other crew member regardless

intercommunication set

AN/AIC-10 control panel



11710

of the position of the latter's function selector switch or mixing switches. Placing the switch in INTER and depressing a microphone switch enables the user to talk to the other occupant if the latter also has his function selector switch in INTER or has his INTER mixing switch in the up position. However, a conversation cannot take place unless both rotary function selector switches are in INTER or HOT-MIC. Rotating the function selector switch to COMM enables the user to transmit and receive with the uhf set. Placing the function selector switch in HOT-MIC enables the user to converse with the other crew member without depressing a microphone switch, provided the latter also has his function selector switch in HOT-MIC. The HOT-MIC function enables the crew to use the interphone while monitoring the uhf radio. Depressing a microphone switch with the function selector switch in HOT-MIC energizes the AN/ARC-27 transmitter. Placing the function selector switch to ADF permits the user to monitor the radio compass exclusively.

MALFUNCTION OF CONTROL UNIT.

In the event of intercommunication set malfunction, it is possible to listen (but not transmit) by placing the NORMAL-AUX LISTEN switch in AUX LIS-TEN. In this position, both headsets are in parallel, thereby permitting reception from the other control panel. Operation in this function reduces the strength of the signal to the headsets with a consequent reduction in volume. During individual panel operation in AUX LISTEN, there is a definite switching priority of the audio mixing switches and the function selector switch. The INTER switch has first priority. While the INTER switch is in the up (on) position no other circuit is connected, regardless of the position of the other switches. Placing the INTER switch in the down position passes priority to the switch immediately to the right of the INTER switch. Priority continues to pass to the right in this manner along the line of audio mixing switches. All switches to the left of the desired switch must be down. Placing all audio mixing switches off (down), enables the function selector switch to control the selection of the equipment.

AUDIO MIXING SWITCHES.

The audio mixing switches are along the top of the control panel. Individual switch markings are, from left to right, INTER, COMM, MARKER WARNING, ADF, and BEACON. Placing the NORMAL-AUX LISTEN switch in NORMAL enables the user to monitor one or all of the available facilities by placing one or all of the audio-mixing switches in the up position.

AIC FILTER.

The AIC filters, one on the pilot's right vertical console and one on the observer's right console, enable the pilot or observer to separate the simultaneous voice-range broadcast from the radio range stations. Switch markings are VOICE, RANGE, BOTH, RANGE, and VOICE in that order from the top to the bottom of the panel. The first two (top) VOICE-RANGE positions are for one ADF system and the last two (bottom) RANGE-VOICE positions are for a second ADF system. Since the airplane has only one ADF system, the last two (bottom) positions are inoperative. The BOTH position is common to ADF-1, ADF-2. Placing the switch in VOICE enables the listener to hear only the voice transmission from the radio range station. Placing the switch in RANGE enables the listener to hear only the range transmission, and placing the switch in BOTH enables the listener to hear the range and voice transmissions simultaneously.

RADIO SET AN/ARC-27.


The radio set AN/ARC-27 provides air-to-air or air-to-ground communication in the uhf spectra from 225.0 to 399.9 megacycles. The set includes a stub antenna on the bottom right side of the nose section, a transmitter and two receivers (guard and main) in the equipment compartment, and a control panel on the pilot's left console. There are 1750 frequencies available in 100 kilocycle steps. Eighteen frequencies can be preset in any order within the operating range of the equipment. Rotating the preset channel-selector knob selects the desired channel and tunes the main receiver and transmitter to the same frequency. The guard receiver is tuned to a predetermined frequency and does not change. The 28-volt d-c radio bus supplies the power to operate the radio set.

AN/ARC-27 CONTROL PANEL.

The control panel (figure 4-7) is on the pilot's left console. Controls are a volume control, a channel-selector knob and a four-position rotary switch. The channel-selector knob is marked for 19 positions, 1 thru 18 and G. The four-position rotary switch is marked OFF, T/R, T/R + G REC, and ADF.

AN/ARC-27, NORMAL OPERATION.

To turn on the radio, put the uhf circuit breaker to IN and rotate the four-position rotary switch out of OFF to the mode of operation desired. Select the channel desired and depress the microphone button. Place the four-position rotary switch to OFF to deenergize the equipment.



uhf radio control panel AN/ARC-27

11704

Figure 4-8

AN/ARC-27 EMERGENCY OPERATION.

In-flight emergency operation is not possible with this installation,

RADIO COMPASS AN/ARN-6.

The radio compass AN/ARN-6 (figure 4-8) is an airborne navigational aid and a general communications receiver. The components of the set are a sense antenna mounted on top of the center fuselage, a loop antenna behind the observer's headrest, a receiver in the electrical equipment compartment, the pilot's and observer's control panels and ADF tuners on the right horizontal consoles, and the pilot's and observer's radio compass indicator on the main instrument panels. By individual or combined use of the loop and sense antennas, the compass can be used for weather report reception, position-finding, and homing. Many radio range stations do not have uhf transmitters, but all have uhf receivers. Transmission on uhf and reception on radio compass establish two-way radio communications with range stations for position reports, weather requests, etc. The 28-volt d-c radio bus supplies the power through a 10-ampere circuit breaker to operate the radio compass.

RADIO COMPASS CONTROLS.

The control unit on the pilot's and observer's right horizontal console contains all the controls for operating the AN/ARN-6 radio compass. The various knobs and switches on the unit for control of the radio compass are a function-control knob, a frequency TUNING crank, a VOLUME control, a CW-VOICE switch, a frequency-band selector, and a LOOP rotator switch.

RADIO COMPASS FUNCTION CONTROL.

Knob position markings for the function control are OFF, ADF, ANT, LOOP and CONT. Rotating the knob from OFF to any one of the other positions turns the set on. Placing the knob in ADF combines the functions of the sense and loop antennas for homing and automatic direction finding. With the knob in ANT, only the sense antenna receives signals for set operation. The LOOP position allows the operator to use the loop antenna for aural-null operation. To transfer control of the set from the observer to the pilot or from the pilot to the observer, momentarily place the knob in CONT.

RADIO COMPASS TUNING CRANK.

Rotation of the TUNING crank permits selection of a desired frequency shown on the calibrated dial at the top of the control unit.

RADIO COMPASS BAND SELECTOR KNOB.

Rotation of the band-selector knob permits selection of any one of four bands of receiver frequencies. Band ranges are 100 to 200 kcs, 200 to 410 kcs, 410




Figure 4-9

to 850 kcs, and 850 to 1750 kcs. Rotating the bandselector knob changes the band's calibrated range scale in the window above the knob.

RADIO COMPASS VOLUME CONTROL.

The VOLUME control enables the operator to adjust the audio level to the interphone system.

RADIO COMPASS CW-VOICE SWITCH.

To obtain greater accuracy in tuning, place the CW-VOICE switch in CW. When the switch is in ADF, you can hear a 900-cycle tone along with station modulation. Tune to a zero beat in the ANT or LOOP position.

RADIO COMPASS LOOP ROTATOR SWITCH.

Switch position markings are L and R. Turning the switch to L rotates the loop antenna to the left. Turning the switch to R rotates the loop antenna to the right. When released, the switch springs back to the neutral position. The amount of deflection of the switch governs the speed of the loop rotation. To attain maximum speed of loop rotation, turn the switch to the maximum L or R position.

ADF TUNER.

The TUNE TO MAX (ADF Tuner) is on the pilot's and observer's right horizontal console immediately forward of the pilot's and observer's AN/ARN-6 control panel. Maximum needle deflection to the right indicates proper tuning of a desired signal.

RADIO COMPASS INDICATOR.


The radio compass indicator for the pilot and observer is on the main instrument panels. The radio compass needle indicates the direction of a tuned station relative to the airplane's heading.

RADIO COMPASS OPERATION.

To turn on the radio compass, rotate the functioncontrol knob to the LOOP position and operate the L-R switch to determine proper loop operation and to determine which panel has control. If there is no pointer rotation, place the function control switch momentarily in CONT to gain control. After gaining control of the set, place the function control switch in ANT: then:

- Place the ADF audio mixer switch on intercommunication control panel in the up position.
- 2. Place the CW-VOICE switch in CW.
- Rotate the band-selector knob to the band scale containing the desired frequency.
- 4. Adjust the volume control as necessary.
- Rotate the TUNING crank to the desired frequency and tune to the maximum needle deflection on the ADF tuner.
- 6. Place the CW-VOICE switch in VOICE.

To operate the set for automatic direction finding, place the function control knob in ADF. To operate the set for aural-null operation, place the function



radar

identification set AN/APX-6A control panel

Figure 4-10

11727

control knob in LOOP and use the loop rotator knob for loop rotation.

MARKER BEACON AN/ARN-12.

Applying power to the electrical system causes the marker beacon to operate continuously. The set receives 75 megacycle transmissions from the ground. An indicator light on the pilot's and observer's main instrument panel flashes as the airplane passes over a marker transmitter, thereby giving a navigational fix. Also, placing the BEACON switch on the interphone control panel in the BEACON position and the marker beacon radar warning switch in MARKER BEACON enables the pilot or observer to hear the coded marker identification. Pressing the lamp case completes a circuit to test the lamp operation. The 28-volt d-c radio bus supplies the power for marker beacon receiver operation.

MARKER BEACON-RADAR WARNING SWITCH. The MARKER BEACON-RADAR WARNING switch is on the pilor's right console. Placing the switch in MARKER BEACON enables the crew to listen to the aural code transmitted from a marker beacon. However, the MARKER BEACON audio mixing switch on the interphone control panel must be in the UP position. (Refer to RADAR RECEIVING SET AN/

APS-54 for switch function at the RADAR WARN-ING positions.)

IFF RADAR SET AN/APX-6A.

The IFF radar set AN/APX-6A enables an aircraft to identify itself automatically when challenged by suitably equipped friendly surface radar or airborne radar. The radar set is a transponder rather than a transmitter since it does not originate signals. The set receives signals from a remote radar station and amplifies these signals. The originating radar station picks up the amplified signal and reproduces it visually on its radar scope. The 28-volt d-c radio bus and the 115-volt a-c No. 2 radio bus supply the power to operate the set.

IFF CONTROL PANEL.

The control panel (figure 4-10) on the pilot's right vertical console enables the pilot to select all operational conditions of the transponder by means of the following switches:

- Master switch. This control is a five-position rotary switch. The five positions are: OFF, STDBY, LOW, NORM, and EMERGENCY.
- 2. MODE 2 switch.
- 3. MODE 3 switch.
- 4. L/P MIC switch.

4-13

IFF MASTER SWITCH.

Rotating the MASTER switch from OFF to any other position turns on the equipment. Operation of the master switch does not turn on panel illumination. The pilot must run a "parrot" check with ground or airborne radar to assure the proper functioning of the equipment. Placing the master switch in STDBY energizes the set so that it is ready for immediate use but no replies from a challenging radar are answered. Placing the master switch in LOW causes the set to reply in mode 1. The reply is of low intensity. This is particularly useful to the interrogating radar when the airplane is flying nearby. Placing the switch in NORM causes the set to reply in mode 1 and the reply is of normal intensity. Placing the switch in EMERGENCY causes the set to transpond a distinctive emergency reply of normal intensity. To rotate the switch to EMERGENCY, depress the button at the lower left corner of the control panel.

MODE SELECTOR SWITCHES.

The two mode-selector switches to the right of the master switch are the controls for transponder operation in MODE 2 and MODE 3. Switch markings are MODE 2—OUT and MODE 3—OUT. Placing either switch in the mode position causes the set to reply in the selected mode. The master switch and the mode selector switches operate independently; therefore, an individual reply or any combination of replies is possible. However, the master switch must be in LOW or NORMAL for set operation.

Note

Placing the master switch in EMERGENCY causes the set to transpond an emergency reply regardless of the position of mode selector switches.

I/P-MIC SWITCH.

The three-position I/P-MIC switch is at the right of the control panel. Switch markings are I/P (up), OUT (center), and MIC (down). The switch enables the pilot to identify his position to interrogating radar by momentarily changing the transponder to a different mode. To identify his position, the pilot places the switch momentarily in the I/P position. An observer using the interrogating radar notes the change in modes to determine on the radar scope the position of the airplane. An alternate method of identifying position is to place the switch in the MIC position and to use the microphone button on the control wheel or on the inboard throttle. When the MIC position is in use, the airplane's uhf radio must be on. The mode change remains in effect for thirty seconds after releasing the switch or microphone button. The transponder then replies in the mode originally selected.

RADAR SET AN/APW-11A WITH INDICATING GROUP AN/APA-90.

Radar Set AN/APW-11A, (figure 4-11) used in conjunction with the Indicating Group AN/APA-90, serves as a navigational and bombing-aid radar guidance system. In navigational operations, intelligence obtained from a ground station can help determine aircraft speed, heading, and altitude. In bombing-aid operations, the pilot receives tactical instructions visually. The pilot controls the radar set AN/APW-11A. Actuate the BEACON mixing switch on the pilot's interphone control panel, for radar beacon reception. Tactical instructions for the pilot are indicated by the flight command indicator. A roger switch, located in the left handgrip of the control wheel, is connected in parallel with the roger switch on the AN/ APW-11A control panel. This switch cancels all previous indications on the flight command indicator and acknowledges receipt of all indications. The 28-volt d-c radio bus supplies the power to operate the equipment.

RADAR SET AN/APW-11A WITH INDICATING GROUP AN/APA-90, NORMAL OPERATION.

The radar set AN/APW-11A control panel is on the pilot's right console. The control is a four-position switch marked OFF, BEACON ONLY, ON, and LIGHT CHECK, and a ROGER button. To energize the equipment place the four position switch to ON. Place the switch to OFF to de-energize the equipment.

RADAR RECEIVING SET AN/APS-54.

Radar Receiving Set AN/APS-54 transmits visible and audible warning to the pilot when an airborne interception or an airborne gun-laying radar system is in position to offer a potential threat to the airplane. The visible warning is displayed by indicator lights on the pilot's indicator panel and the observer's AN/ APS-54 control panel (figure 4-12). The red lights illuminate when radar signals arrive from the direction of the nose, the tail, or both. The green light (observer's panel only) illuminates during an absence of signals. The audible warning is an audio tone in the headset and corresponds to the pulse rate frequency (high pulse rate for airborne radar and medium or low pulse rate for gun-laying or ground radar) of the intercepted signals. The audible tones are monitored through the AN/AIC-10 Intercommunication set. A test switch on the observer's control panel tests operation of the visible and audible warning systems. The 28-volt d-c radio bus and the No. 1 a-c radio bus supplies the power to operate the equipment.

radar set
APW-11
control
panel




Figure 4-11

radar receiving set AN/APS-54

control panel




Figure 4-12

4-15

1,110

11716

NORMAL OPERATION.

Place the AN/APS-54 power switch to ON. Place the pilot's interphone marker warning switch ON and the marker beacon-radar warning switch to RADAR WARNING. Set the panel controls as follows: delay switch OUT, audio switch BOTH, and audio-gain maximum (fully clockwise). Place the test switch to UP. An audio tone in the headset, illumination of both red nose and tail warning lights, and extinguishing of the green light, indicator proper system operation. The audio switch selects tones from the nose, tail, or both positions. The audio gain control governs the amplitude of the signals. Place the delay switch IN to delay signal indication. Delay time is two seconds. Place the delay switch OUT for instant signal indication.

S-4 SHORAN SYSTEM.

The S-4 shoran system is a highly accurate, short-range, navigational and bombing radar device. In navigational function, the equipment aids in computing a fix on the airplane's position. In bombing functions, the equipment automatically compensates for the variables of flight that affect the accuracy of bombing and provides data which enable flight to the true release point. At the release point, the bombs are automatically dropped whether the target is visible or not. The equipment is operated by the observer, but both the pilot and the observer receive indications from the system. Power for the system comes from the No. 1 radio bus and the 28-volt d-c radio bus through three circuit breakers on the main radio circuit breaker panel.

SHORAN COMPUTER UNIT.

The computer unit is on the observer's right console. (See figure 4–13.) Flight variables automatically feed into the computer as the airplane approaches the release point. The computer determines the release point and the instant of release. At a predetermined distance from the bomb-release point, power is automatically supplied to the bomb carrier door control circuit to open the door. At the release point, power is automatically supplied to the bomb release circuits to release the bombs.

SHORAN RANGE INDICATOR.

The shoran range indicator is on the observer's right console. (See figure 4-12.) A transmitter in the airplane sends out radar signals which are received by two shoran ground stations and retransmitted. The range indicator receives these retransmitted signals and indicates them visually on the range indicator scope. The observer then superimposes the returned video

signals upon reference marker pulses on the scope to reveal the distances to each station. Distances are indicated on station-miles dials and vernier counters. This locates the point on the earth's surface directly below the airplane. Prior to receiving video pulses, preset the indicator by means of the various controls and indicators on its panel.

SHORAN COMPARATOR.

The shoran comparator (figure 4-31), located to the right of the observer's feet, receives timing signals and the returned drift station video from the shoran range indicator. Deviations of returning video pulses are visually indicated to the pilot and observer.

SHORAN POSITION DEVIATION INDICATOR.

Two shoran position deviation indicators, one on the pilot's main instrument panel and the other on the observer's instrument panel give instantaneous rate-of-approach and displacement-from-track data. This enables the pilot to fly the airplane precisely along a predetermined flight path.

SHORAN MILES-TO-RELEASE INDICATOR.

The shoran miles-to-release indicator on the observer's instrument panel indicates the miles remaining to the release point. The indicator is calibrated in one-mile increments from zero to nine. One revolution of the indicator needle represents ten miles; therefore, the needle recycles every ten miles.

AN/ALE-2 CHAFF DISPENSER.


The AN/ALE-2 Chaff Dispenser equipment is for protection and evasion from hostile radar. The system consists of two control panels on the observer's left console, and two dispenser pads. The pads are on the left and right wing inboard pylons. The 28-volt d-c radio bus supplies the power to operate the equipment.

C-1282/ALE-1 CONTROL PANELS.

Two C-1282/ALE-1 control panels (figure 4-29) are on the observer's left console. Each panel controls the operation of its respective chaff dispenser pod. Controls are an ON-OFF power switch, CHAFF RESERVE subtractive counters, a SIGNAL lamp, and a speed selector switch placarded INTERVALOMETER-CONTINUOUS FPM.

The chaff reserve counter indicates the number of chaff packages available for dispensing. The speed-selector switch selects variable-speed or intervalometer-controlled chaff dispensing. For variable-speed control, the selector speed is marked numerically in feet-perminute positions: 2.5, 5, 10, 20, 40, and 80. For intervalometer-controlled dispensing, there is a choice of

shoran computer and indicator



11715

four timed intervals between chaff package release: A (5 sec. off), B (10 sec. off), C (15 sec. off), and D (20 sec. off). E and F positions dispense single packages. Select position E for packages with 35% inches to 4 inches between centers and position F for packages having 2½ inches between centers.

The SIGNAL light indicates the operation of the stripper unit. With numerical selections, the light goes out as each chaff package is stripped and relights ready for the next package. With alphabetical selections the SIGNAL light remains out, illuminating only during the stripping of each package.

AN/ALE-2 NORMAL OPERATION.

- Set the CHAFF RESERVE counter to correspond with the number of chaff packages in the respective pod.
- Place the speed selector switch to the desired position.
- 3. Place the power switch in ON.
- 4. Monitor the SIGNAL light for proper operation of equipment.

LIGHTING EQUIPMENT.

NAVIGATION LIGHTS.

The navigation lights (figure 1-1) consist of two clear lights on top of the fuselage center section, two clear lights on the bottom of the fuselage center section, a yellow light and a white light on the top and bottom of the tail cone, a red light in the left wing tip, a red light on the left tip tank, a green light in the right wing tip, and a green light on the right tip tank. Two switches on the pilot's lighting control panel control the lights and the 28-volt d-c distribution bus supplies the power to operate them.

NAVIGATION LIGHTS SWITCHES.

The two navigation lights switches are on the pilot's lighting control panel. (See figure 4-14.) Switch position markings for one of the switches are FLASH, OFF, and STEADY. Switch position markings for the second switch are BRIGHT and DIM. Placing the first switch from OFF to STEADY turns on the navigation lights and causes the lights to glow steadily.




Figure 4-14

Placing the switch from OFF to FLASH turns on the lights and causes the lights to flash. The clear lights at the top and bottom of the fuselage glow steadily in either switch position. Operating the DIM-BRIGHT switch controls light intensity.

PILOT'S CONSOLE AND INSTRUMENT LIGHTS.

The pilot's console and instrument lights furnish red illumination for the pilot's station. The lights are divided into four groups: engine instruments, flight instruments, left console and right console lights, and include both lucite panel and instrument ring lights. Each group is controlled by a rheostat. The rheostat varies light intensity and is placarded OFF and BRT. The rheostats are on the pilot's lighting control panel. (See figure 4–14.) The 28-volt d-c pilot's circuit breaker bus supplies the power to operate the system.

PILOT'S RED AND WHITE FLOODLIGHTS.

The pilot's station has red floodlights for general illumination and white floodlights to provide a color contrast to reduce visual distortion. The floodlight system is controlled by two rheostats on the pilot's lighting control panel. The rheostats control the intensity of all the floodlights from dim to bright and also have an OFF position. The 28-volt d-c pilot's circuit breaker bus supplies the power to operate the system.

OBSERVER'S CONSOLE AND INSTRUMENT LIGHTS.

The observer's console and instrument lights furnish red illumination for the observer's station. The lights are divided into two groups and include both lucite panel and instrument mask lights. Each group is controlled by a rheostat. The rheostat varies light intensity and is placarded OFF BRT. The rheostats are on the observer's lighting control panel. (See figure 4-15.) The 28-volt d-c circuit breaker bus supplies the power to operate the system.

OBSERVER'S RED AND WHITE FLOODLIGHTS.

The observer's station is equipped with red and white floodlights for general illumination of the consoles and the instrument panel. The floodlights are controlled by two rheostats on the observer's lighting control panel. (See figure 4–15.) The rheostats control light intensity from dim to bright and also have

observer's lighting control panel



Figure 4-15

an OFF position. The 28-volt d-c distribution bus supplies the power to operate the system.

OBSERVER'S SPOTLIGHT.

The observer's spotlight is on the aft glare shield. The observer's spotlight switch is on the observer's main instrument panel. Placing the switch from the center position to the ON (up) position causes the spotlight to illuminate. Placing the switch from ON to the center position turns the light off.

C-4A LIGHTS.

Two C-4A lights, one on the pilot's right circuit

pilot's auxiliary lighting control panel



11729

Figure 4-16

breaker panel and one on the pressure bulkhead to the right of the observer's seat, are convenient portable lights for map reading and general illumination. The light assemblies consist of a stowage rod, a coiled electrical wire, a metal case housing the lamp, and a detachable red lens. Appearing on the lamp casing are a button switch and a rotary switch. The button switch and the rotary knob switch control lamp operation. The 28-volt d-c battery bus supplies power to operate the lamp.

C-4A LIGHT CONTROLS.

A spring-loaded button switch on the lamp casing is the control for momentary lamp operation. Depressing the button causes the lamp to illuminate; releasing the button causes the lamp to go out. Rotating the rotary switch from one of the extreme positions causes the light to illuminate and remain illuminated. Light intensity depends on the amount of switch rotation. Depressing two clips on the sides of the red lens enables the operator to remove the red lens. To use the light for illuminating a specific object in the cabin, remove the lamp from its stowed position.

Note

To avoid discharging the battery, turn off the C-4A lamps before leaving the airplane.

COMPARTMENT DOME LIGHTS.

Compartment dome lights are in the right electrical access compartment, the bomb door area, the electronic compartment, the equipment compartment, the electrical distribution center, and the gun bays. The right electrical access compartment light and switch are on the same bracket, located over the access door. The bomb door area has two lights, one at each end, controlled by a switch at the forward end of the bomb door area on the right side. The electronic compartment lights are controlled by a switch in the electronic compartment above the aft fuselage access door. Each gun bay has two lights, one over the inboard guns and one over the outboard guns. The gun bay lights are controlled by a switch on the forward side of the spar, inside the gun bay access door. The equipment compartment has one light and two switches. Each switch is in the equipment compartment inside and aft of each hatch. The electrical distribution center light is controlled by a switch inside and forward of the access door on the lower right side of the forward fuselage. Electric power for the dome lights comes from the 28-volt generator bus.

TAXI LIGHTS.

Two taxi lights, one mounted in the leading edge of

each wing tip, furnish limited illumination for night ground operation. The taxi lights switch on the landing gear control panel controls this circuit. The 28volt d-c distribution bus supplies power for operation.

TAXI LIGHTS SWITCH.

Placing the tax lights switch, on the pilot's auxiliary switch panel, to TAXI LIGHTS turns the lights on. (See figure 1-28.) Placing the switch in OFF turns the lights off.

WARNING LIGHTS.

There are warning lights of variable brilliance for the emergency fuel control indicator, the landing gear indicator, and the inverter indicator.

WARNING LIGHTS SWITCH.

A warning lights switch, on the pilot's auxiliary lighting control panel, controls the intensity of the warning lights. (See figure 4-16.) The switch has two positions: BRIGHT AND DIM.

THUNDERSTORM LIGHTS SWITCH.

The pilot's thunderstorm lights, under the glare-shield and above the consoles, are controlled by a three-position switch on the pilot's auxiliary lighting control panel. Place the switch in the up position for steady illumination and hold the switch in the down position for momentary illumination. Placing the switch in OFF (center) turns the lights off.

LANDING LIGHT.

A high-intensity lamp within the lower surface of the left wing supplies the illumination for night landings. The light fully retracts within a recess in the wing. The airspeed limitation for light extension is 200 knots IAS.

LANDING LIGHT SWITCHES.

Two switches on the landing gear control panel control landing light operation. (See figure 1–28.) The markings for one switch are EXTEND and RETRACT. The markings for the second switch are ON and OFF. The EXTEND-RETRACT switch controls the light motor to raise or lower the light and the OFF-ON switch controls lamp operation. The EXTEND-RETRACT switch has a neutral position. The switch must be in the neutral position when the light is fully up or down. The 28-volt generator bus supplies the power to operate the motor and illuminate the lamp.

OXYGEN SYSTEM.

A five-liter high-flow oxygen converter supplies oxygen to the low-pressure (70 psi) system. The converter in the equipment compartment delivers oxygen to two automatic pressure-demand regulators. The regulators (at the pilot's and observer's station) combine the functions of an oxygen flow indicator, pressure gage, and regulator. The converter is serviced through a quick-disconnect filler valve. During servicing, the converter vents to the atmosphere through the buildup-and-vent valve. Both valves are in the right equipment compartment. Placing the build-up-and-vent valve in the build-up position closes the system to atmospheric pressure and a relief valve prevents system pressure from exceeding 100 psi. A bracket on the compartment door prevents the door from closing until the build-up-and-vent valve handle is in the build-up position. An oxygen duration table is shown in figure 4-17. Refer to figure 1-44 for the location of the filler valve and converter and for oxygen specification.

WARNING

Keep oxygen equipment clean. Oil or grease in contact with oxygen under pressure causes fire or explosion.

PRESSURE-DEMAND OXYGEN REGULATORS.

A Type D-2 automatic pressure-demand oxygen regulator (figure 4-18) at each crew station control oxygen flow from the converter to the mask. The regulator automatically mixes the correct ratio of cabin air and 100% oxygen. A diluter air valve in the regulator controls the flow of cabin air into the regulator. As cabin altitude increases, the diluter air valve closes, permitting less cabin air to mix with the 100% oxygen. A demand diaphragm in the regulator operates a demand valve. Inhalation causes the diaphragm to open the demand valve to permit the flow of diluted oxygen to the mask. A faulty demand diaphragm or a faulty diluter air valve allows oxygen to leak out of the regulator during exhalation. Perform a blow-back test as described under OXYGEN SYSTEM BLOW BACK TEST in this section before flight to detect regulator malfunction. The regulator controls are an oxygen supply lever, an oxygen-diluter lever, and an EMERGENCY PRESSURE lever. While in use, the oxygen system stabilizes at 70 psi as long as there is liquid oxygen in the converter. Check DD Form 781 to insure that the system has been serviced before flight.




Figure 4-17

OXYGEN-REGULATOR DILUTER LEVER.


The oxygen-diluter lever on the oxygen regulator is a manual control for selecting 100% oxygen or diluted oxygen. Placing the lever in NORMAL OXYGEN causes the regulator to mix a proper ratio of cabin air to oxygen; however, above 30,000 feet cabin altitude the user receives 100% oxygen in the NORMAL OXY-

GEN position. Placing the lever in 100% OXYGEN causes the user to receive 100% oxygen at any altitude.

OXYGEN-REGULATOR SUPPLY LEVER.

The oxygen-regulator supply lever on the oxygen regulator controls the oxygen supply shut-off valve. Placing the lever in ON opens the shut-off valve. The opened shut-off valve releases oxygen under pressure

oxygen regulator



11725

Figure 4-18

from the converter to the regulator at 70 to 100 psi. Placing the lever in OFF shuts off the valve.

EMERGENCY PRESSURE LEVER.

The EMERGENCY pressure lever is on the oxygen regulator. Placing the lever to the right or left increases the oxygen pressure from the regulator to the mask for additional pressure. Returning the lever to the center position restores normal operation. Depress the lever to obtain maximum oxygen pressure to the mask for a preflight check of mask.

OXYGEN PRESSURE GAGE AND FLOW INDICATOR.

The combination pressure gage and flow indicator is on the exygen regulator. As long as there is liquid oxygen in the converter, the pressure gage indicates a pressure between 70 to 100 psi. Gage markings are from 0 to 500 in 100 psi increments. Since the airplane has a low-pressure system, the needle normally does not exceed the 1 on the face of the gage. The flow indicator blinker dial exposes four luminescent

painted segments in tear-shaped windows every time the user inhales.

OXYGEN QUANTITY GAGE.

The oxygen quantity gage is on the pilot's right console. It indicates the quantity of liquid oxygen in the converter. The gage indicates the quantity in one-liter increments from 0 to 5 liters. The liquid oxygen contents indicators should read between four and four and one-half liters when the system is fully charged. Do not be alarmed if the indicator does not read five liters since it is impossible to charge the liquid oxygen converter to five liters. Use the oxygen duration chart (figure 4–34) to determine oxygen duration for the indicated supply.

OXYGEN SYSTEM BLOW-BACK TEST.

The oxygen regulator contains a demand diaphragm and diluter air valve. The diaphragm operates a demand valve and controls the flow of oxygen according to the suction created in the regulator by the user. The diluter air valve controls the flow of air into the regulator, decreasing the flow with increases in altitude so that the suction in the regulator creates a greater load on the diaphragm, thus giving more oxygen. A damaged diaphragm will allow air to enter the regulator during inhalation, thus decreasing the oxygen-air ratio. Therefore, a damaged diaphragm or faulty diluter air valve will allow oxygen to leak out of the regulator at all times during positive pressure breathing. To check the operation of the regulator before take-off on each flight, conduct a blow-back test as follows:

- Place the diluter lever in NORMAL OXYGEN and blow gently into the oxygen regulator hose.
 A resistance indicates satisfactory operation of the demand diaphragm and diluter air valve.
- Place the diluter lever in 100% OXYGEN and blow gently into the oxygen regulator hose. A resistance indicates satisfactory operation of the demand diaphragm and diluter air valve.
- Don the mask and connect the mask to the regulator hose. Breathe normally and note operation of blinker dial.
- 4. Hold breath and place the EMERGENCY pressure lever to the right or left. A positive pressure felt within the mask indicates proper emergency oxygen flow. This positive pressure is approximately 0.07 psi more than cabin altitude.
- To test the mask for leakage, depress the EMER-GENCY pressure lever while holding the breath. Oxygen pressure from the regulator enters the

- mask at approximately 0.5 psi above cabin altitude. A properly fitted mask retains this pressure until normal respiration continues.
- Check that the mask hose fittings are properly seated are secure.
- Check the mask hose attachment to the parachute harness in accordance with the instructions on figure 4-19.

Note

Depress the PUSH-TO-TEST-MASK lever only for preflight mask and helmet testing. Depressing the lever during flight causes discomfort and could cause maladjustment of an otherwise properly fitted mask.

OXYGEN SYSTEM, NORMAL OPERATION.

For normal operation, place the OXYGEN SUPPLY LEVER in ON and place the oxygen diluter lever in NORMAL OXYGEN. The user receives a diluted supply of oxygen up to approximately 30,000 feet cabin altitude and receives 100 percent oxygen under pressure above approximately 30,000 feet cabin altitude.

OXYGEN SYSTEM, EMERGENCY OPERATION.

With symptoms of the onset of the hypoxia, or if smoke or fuel fumes should enter the cabin, set the diluter lever of the oxygen regulator at 100% OXY-GEN. In event of accidental loss of cabin pressure, set the diluter lever to 100% OXYGEN and actuate the oxygen regulator emergency toggle switch to the right or left.

Note

When the emergency is over, set the oxygen regulator diluter lever to NORMAL OXYGEN.

WARNING

The presence of carbon monoxide in the flight compartment of jet aircraft has been suspected in numerous instances. There are various ways which carbon monoxide may enter these compartments during ground operation, but as yet, neither the exact concentration nor the exact sources have been determined.

If the airplane is to be operated on the ground under possible conditions of carbon monoxide contamina-

oxygen hose hookup




Figure 4-19

tion, such as during runup or taxiing directly behind another operating jet aircraft, or during runup with its tail into the wind, the following procedure shall be used:

- Before starting engines, all crew members must don oxygen masks, connect hoses to oxygen regulator, and place diluter lever at the 100% OXY-GEN position.
- Whenever contamination is suspected, 100 percent oxygen must be used during ground operation and take-off.
- After contamination is no longer suspected, place the diluter lever of the oxygen regulator in NORMAL OXYGEN.

WARNING

Return the oxygen diluter lever to NORMAL OXYGEN as soon as possible because the use of 100 percent oxygen throughout a long mission will so deplete the oxygen supply as to be hazardous to the flight crew.

NAVIGATION EQUIPMENT.

J-2 COMPASS SYSTEM.

The J-2 compass system indicates the airplane's heading. The direction-seeking characteristics of the magnetic compass combined with the stability of a gyro give headings without northerly turning error, oscillation, or swinging. Operating within 85 degrees from level flight (climbs, dives, and banks), the gyro strikes mechanical stops at 85 degrees, causing subsequent heading indications to be inaccurate within ± 5°. After five minutes or less of level flight, the gyro recovers and automatically begins to give correct heading indications. The compass system receives its heading information from a compass transmitter remotely installed in the right horizontal stabilizer. An amplifier receives a relatively weak signal from the compass transmitter, increases the strength of the signal, and directs this information to torque motors which slave the gyro. The transmitter is accurate between the latitudes of 78 degrees north and 69 degrees south. An out-of-slave function permits the compass to operate as a directional gyro in polar areas. The compass requires both a-c and d-c power. The a-c power is supplied from 115-volt phase B and phase C busses and from the No. 2 radio bus. The d-c power is supplied from the 28-volt d-c battery bus. A one-ampere circuit breaker in the left electrical access compartment controls operation of the J-2 compass system.

Note

The J-2 compass circuit breaker is in the left electrical access compartment. This circuit breaker is not accessible during flight and must be placed in during the exterior inspection.

J-2 COMPASS SWITCH.

The J-2 COMP switch (figure 1-37) is on the pilor's left horizontal console. The switch is marked IN and SLAVE OUT. Placing the switch in the IN position completes the slaving circuits from the remote compass transmitter to the gyro torque motors. Placing the switch in SLAVE OUT de-energizes the circuit from the transmitter to the motors. While out of slave, the gyro acts as an independent directional gyro.

J-2 COMPASS SLAVE REINITIATE BUTTON.

The SLAVE REINITIATE button (figure 1-37) is on the pilot's left horizontal console. Depressing the button closes a circuit to supply high voltage for two to three minutes to the gyro torque motors, thereby accelerating the gyro erection and alignment. Allow a ten-minute interval before again depressing the button, to allow a thermal time switch to cool.

J-2 COMPASS INDICATOR.

The compass indicators (one on the pilot's main instrument panel and one on the observer's main instrument panel) furnish the crew magnetic heading indications without a northerly turning error, oscillation, or swinging. (See figures 1–31 and 4–30.) A settable dial knob enables the user to rotate the dial index to the desired heading. A selsyn unit transmits heading information from the gyro to the compass indicator. The 115-volt a-c 400-cycle B and C phase bus supplies the power to operate the compass.

J-2 COMPASS NORMAL OPERATION.

The compass will operate if the engines are running and the instrument inverter switch is in NORMAL or STANDBY, if the engines are shut-down and the instrument inverter switch is in STANDBY, or if external power is supplied and the instrument inverter switch is in NORMAL. After turning on the equipment, allow three minutes to elapse so that the gyro in the directional gyro control comes up to operating speed, levels, and aligns the indication on the slaved gyro compass indicator with the remote control compass transmitter.

J-2 COMPASS EMERGENCY OPERATION.

If any one of the three inverters should fail, the J-2

compass will continue to operate only as a directional gyro. During an inverter failure, the J-2 compass system will not supply data to the S-4 shoran system or to the AN/ASN-6 system. Complete failure of either the a-c or d-c electrical systems causes the J-2 compass system to be inoperative.

STANDBY COMPASS.

A conventional magnetic compass is on the windshield frame directly in front of the pilot. (See figure 1–31.) During electrical system failure or malfunctioning of the J–2 compass, use the standby compass as a navigational aid. The standby compass correction card is on the pilot's glare shield.

STANDBY COMPASS LIGHT SWITCH.

The STANDBY COMPASS LIGHT switch (figure 4–16) is on the pilot's auxiliary lighting control panel. The switch is marked STANDBY COMPASS LIGHT and OFF. Placing the switch from OFF to STANDBY COMPASS LIGHT causes illumination of the standby compass. The flight instrument light rheostat must be on to energize the circuit. The 28-volt d-c pilot's circuit breaker bus supplies the power to operate the lamp.

SHORAN EQUIPMENT.

Refer to COMMUNICATION AND ASSOCIATED ELECTRONIC EQUIPMENT in this section.

RADIO COMPASS.

Refer to COMMUNICATION AND ASSOCIATED ELECTRONIC EQUIPMENT in this section.

LATITUDE AND LONGITUDE COMPUTER SET AN/ASN-6.

(AIRPLANES AF No. 52-1510 and up.)

Latitude and Longitude Computer Set AN/ASN-6 (Ground Position Indicator) is a dead-reckoning navigation system. The system continuously solves for and indicates the ground position of the airplane in degrees and minutes of latitude and longitude, regardless of the speed of the airplane. Both manual and automatic inputs are fed to the system. The automatic inputs are provided by the J-2 compass for magnetic heading and by the pitot-static system through a transmitter for true airspeed. The observer manually sets the figures for wind force, wind direction, and magnetic variation through the use of computer controls. A-c power for the system is supplied by the No. 2 radio bus, and d-c power by the 28-volt d-c radio

bus. The system is operable whenever these busses are energized and no power switch is provided.

COMPUTER CONTROLS.

The computer controls, on the observer's left console, permit the manual adjustment of wind force, wind heading, and magnetic variation to be transmitted to the computer. Located on the panel are three knobs labeled WF, WD, and VAR. These knobs control three indicators also located on the panel and labeled WIND FORCE, WIND DIRECTION, and VARI-ATION. These knobs are connected to the indicators, and turning one of them causes its respective indicator to turn. In the case of the wind direction and wind force knobs, turning the knobs in a clockwise direction causes their respective indicators to show an increase in the reading. In the case of the variation knob, turning it in a clockwise direction will show a decrease in westerly variation or an increase in easterly variation, whichever may be the presetting.

DEPARTURE SWITCH.

A departure switch on the observer's console, permits the retention of the airplane's point of departure position data on the latitude and longitude counters until the airplane is airborne and generating change of position. The switch is labeled LAT-DEPART and has two positions: ON and OFF. Placing the switch in OFF applies 28-volt d-c power to a locking relay in the computer. This relay then opens the circuits to the latitude and longitude counters and causes them to remain at the positions they had when the switch was actuated. Placing the switch in ON causes the locking relay to close the circuits to the counters and they will then begin indicating a change of position.

GROUND POSITION INDICATOR.

The ground position indicator, on the observer's instrument panel, continuously indicates the ground position of the airplane. In addition to indicating the position visually, the indicator also transmits this information to the latitude and longitude computing system. The ground position is indicated by a latitude counter and a longitude counter on the face of the indicator. The counters automatically indicate whether the latitude is north or south and whether the longitude is east or west.

GROUND POSITION INDICATOR COUNTER RESET SWITCHES.

Two counter reset switches are on the front of the ground position indicator. These switches permit setting the initial co-ordinates of the point of departure or any other point desired. Each switch controls a motor, and the direction of rotation depends on the

displacement of the switch. The reset switches may also be used to reset the counters while the system is in operation.

LATITUDE AND LONGITUDE COMPUTER SET AN/ASN-6, NORMAL OPERATION.

- Check that both GPI circuit breakers on the a-c, d-c circuit breaker panel are pushed in.
- Position the wind force, wind direction, and variation knobs so that their respective indicators reflect a zero reading.
- Actuate the counter reset switches until the counters reflect the correct co-ordinates on the indicator.
- 4. Place the departure switch in OFF.
- 5. Before take-off, place the mean wind direction, wind force, and magnetic variation for climb on the computer control indicators. As soon as practicable after take-off, determine the actual wind conditions and adjust the indicators as necessary. If leaving a check point, place the actual wind conditions and magnetic variation on the indicators.
- Place the departure switch in ON during take-off or when leaving a check point.

ARMAMENT EQUIPMENT.

The basic armament equipment in the airplane consists of fixed wing guns, internal stores carried on the rotary bomb carrier door, and rockets or external stores carried on pylons under the wings. A Mark 8 Mod 8 (modified) Gunsight, mounted on the pilot's glare shield, is the sight for the guns, the rockets and low-level bombing.


GUNNERY EQUIPMENT.

(GROUP A)

The gunnery equipment consists of eight M3 50-caliber machine guns. Four guns are mounted in a horizontal bank in a gun bay outboard of the engine nacelle in each wing. Each gun can fire 300 rounds of ammunition for a total of 2,400 rounds for the airplane. In addition, each gun is electrically heated and pneumatically charged. All controls for the guns are electrical.

WARNING

To prevent inadvertent firing of the M3 50-caliber guns while the airplane is on the ground, make absolutely sure that the master guns switch is OFF.



armament control panel

11705

Figure 4-20

PNEUMATIC GUN-CHARGING SYSTEM.

(GROUP A)

Each M3 50-caliber gun is equipped with a pneumatic gun charger. Pressure is maintained by an air compressor and two air storage bottles. A relief valve at each bottle protects the bottle and system from excessive pressures. A fuse in each gun line prevents loss of the entire system should a line fail. A line tapped into the engine compressor bleed line augments the pneumatic compressor at altitudes above 35,000 feet. The system is controlled by a gun charger switch on the armament control panel. (See figure 4-20.) The operation of the compressor is controlled by two pres-

sure switches in the system; one completes the circuit to energize the compressor when system pressure is low, and the other breaks the circuit to de-energize the compressor when the pressure in the system is normal. Power for the system comes from the pilot's 28-volt d-c circuit breaker bus. A pressure gage is located in the outlet line of the compressor before it branches off to the air bottle in each wing. A ground charging valve adjacent to the pressure gage is used for charging the system before flight rather than using the compressor in the airplane.

GUN-CHARGERS SWITCH.

(GROUP A)

The gun-chargers switch, on the armament control

panel, permits clearing the guns if a misfire should occur. The switch is of the momentary type and has three positions: RELEASE, RETRACT, and OFF. When the switch is placed momentarily in RETRACT, and chargers place the guns in a hold-back condition. Held momentarily in the RELEASE position, the switch causes the gun chargers to return the guns to the battery position.

MASTER GUNS SWITCH. (GROUP A)

The master guns switch, marked GUNS, is on the armament control panel. (See figure 4–25.) The switch has three positions: GUNS, SIGHT AND RADAR, and OFF. When guns are to be fired, the switch must be in the GUNS position. When the switch is in this position, circuit will be completed from the 28-volt d-c distribution bus to the gun firing switch and the gunsight light switch. When rockets are to be fired or bombs dropped, and the gunsight is to be used, the master guns switch must be in SIGHT AND RADAR. When the switch is in this position, the circuit will be completed from the distribution bus to the gunsight light switch, but the circuit to the gun firing switch will be open. When the switch is in the OFF position, both circuits are broken.

GUN-FIRING TRIGGER. (GROUP A)

The gun-firing switch, in the right handgrip of the control wheel, is the trigger for the gun. (See figure 1–25.) When the master guns switch is in the GUNS position, the gun-firing switch is energized. Depressing this switch closes the circuit to the gun controls in the wings, causing the guns to fire. The switch supplies power from the 28-volt d-c distribution bus.

GUN-HEATERS SWITCH. (GROUP A)

The gun-heaters switch, located on the armament control panel, controls the heaters for each 50-caliber gun. During extreme cold or icing conditions placing the switch in HEATERS keeps the guns from freezing. When the switch is placed in this position, a circuit to the heaters is energized and the heaters warm up the guns. Power for the heaters comes from the 28-volt d-c distribution bus.

GUNNERY EQUIPMENT. (GROUP B)

The gunnery equipment consists of four M39 20-millimeter guns. Two guns are mounted in a horizontal bank in a gun bay outboard of the engine nacelle in each wing. The guns are fixed to fire downward at 3 degrees 36 minutes from the flight path and converge at a point 3,250 feet in front of the airplane. Each gun can fire 290 rounds of ammunition, totaling 1,160 rounds for the airplane. The guns have a rate

of fire in excess of 1,500 rounds per minute. All controls for the guns are electrical, with the exception of the manual chargers.

GROUND CHARGER CABLES. (GROUP B)

Each M39 20-millimeter gun is equipped with a manual gun charger. To ready the guns for firing, the armorer must charge each gun separately three times prior to flight. The guns cannot be charged in flight.

MASTER GUNS SWITCH. (GROUP B)
Refer to MASTER GUNS SWITCH (GROUP A) in
this section.

GUN-FIRING TRIGGER. (GROUP B)

The gun-firing switch, located in the right handgrip of the control wheel, is the trigger for the guns. (See figure 1-25.) When the master guns switch is in the GUNS position, the gun-firing switch is energized. When the trigger is depressed, a circuit is completed to the open side of the air purge control valve solenoid. When this valve opens, hydraulic pressure opens the two air-purge intake doors, one of which is located in the leading edge of each wing. After the intake doors open, outside air pressure passes through airpurge exhaust openings under the guns to purge the gun bay areas of all gases. When these doors have fully opened, microswitches complete circuits to fire the guns. The guns cease firing immediately after release of the trigger, but the purge doors remain open for a two-minute period to ensure the expulsion of all gases.

GROUND FIRING SWITCH. (GROUP B)

A ground-firing switch, mounted on the left canopy sill, permits the guns to be fired while the airplane is on the ground by bypassing the landing gear gun cutout relay. The gun-firing switch is placarded OFF and GROUND FIRING. The guns fire when the switch is held in the momentary GROUND FIRING position and the gun-firing trigger is squeezed.

GUNSIGHT.

An illuminated Mark 8 Mod 8 (Modified) Gunsight, mounted on the pilot's glare shield on the centerline of the airplane, is the sight for the guns and rockets and for low-level bombing. (See figure 4–21.)

Note

The Mark 8 Mod 8 (Modified) Gunsight is an interim sight. When available, a computing gunsight will be installed to be used with the MA-1 Fire Control System.

The sight is of the collimator type, and the pilot observes the reticle image on an adjustable reflecting

gun sight




Figure 4-21

glass plate through which the target is also visible. and for low-level bombing. (See figure 4–21.)

A soft rubber crash pad is on the rear of the sight. The adjustable reflector plate can be tilted to allow 4 degrees elevation and at least 8½ degrees depression of th reticle image with respect to the detent lock position of the reflector plate. An index plate placarded B (bombs), O (reflector position at 45 degrees), R (rockets), and G (guns) permits the sight to be adjusted for use when firing the guns or rockets or when bombing at low levels.

GUNSIGHT TILTING KNOB.

The knurled tilting knob, on the left side of the gunsight, elevates or depresses the reticle image. The tilting knob is turned up or down to align the index pointer with one of the four modes of operation, B (bombs), O (reflector position at 45 degrees), R (rockets) and G (guns).

GUNSIGHT LIGHT SWITCH.

The gunsight light switch, on the left side of the fuel

control panel (figure 1-14), controls the lamp for the reticle image in the sight. The switch has three positions: GUNSIGHT ON, ALTERNATE ON, and off (neutral). The lamp is of the dual-filament type, so that, if the filament which is controlled by the GUNSIGHT ON position should burn out, the other filament will light when the switch is placed in the ALTERNATE ON position. Power for the light comes from the 28-volt d-c distribution bus. The master guns switch on the armament control panel must be in the guns or SIGHT & RADAR position for the circuit to be completed to the gunsight light switch. See MASTER GUNS SWITCH in this section.

GUNSIGHT LIGHT RHEOSTAT.

The gunsight light rheostat, on the left side of the fuel control panel (figure 1-14), controls the brilliance of the reticle image. When the gunsight light is lit, the brilliance of the image may be adjusted as desired by positioning the rheostat to any position between the BRT and DIM markings on the panel. The rheo-

position setting unit



Figure 4-22

stat controls voltage from the 28-volt d-c distribution bus through the master guns switch and the gunsight light switch.

FIRING M3 50-CALIBER GUNS. (GROUP A) To fire the M3 50-caliber guns, proceed as follows:

- Check that the gun compressor circuit breaker is ON.
- If extreme cold or icing conditions exist, place the gun heaters switch in the HEATERS position.
- Place the master guns switch in the GUNS position.
- Set the gunsight tilting knob to the GUNS position.
- Place the gunsight light switch in the GUN-SIGHT ON or ALTERNATE ON position.
- Adjust the gunsight light rheostat to desired reticle brilliance.
- 7. Actuate the gun-firing trigger.

Note

If the guns fail to fire after actuating the gunfiring switch, place the chargers switch in the RETRACT and RELEASE positions alternately a few times to clear the guns.

CAUTION

After firing has been completed, place the master guns switch in OFF to safety the guns.

FIRING M39 20-MILLIMETER GUNS. (GROUP B) To fire the M39 20-millimeter guns, proceed as follows:

Note

Before take-off, make sure that all the guns have been charged, as there are no provisions for charging the guns in flight.

- Place the master guns switch in the GUNS position.
- Set the gunsight tilting knob to the GUNS position.
- Place the gunsight light switch to the GUN-SIGHT ON or ALTERNATE ON position.
- Adjust the gunsight light rheostat to desired reticle brilliance.
- 5. Actuate the gun firing trigger.

CAUTION

After firing has been completed, place the master guns switch in OFF to safety the guns.

INTERIM WARNING SYSTEM.

The interim warning system is an automatic range and warning system, used for air-to-ground gunnery only. The radar portion of an MA-1 fire control system supplies automatic range information, which is transmitted to the pilot's headset as audible signals. Preselected firing data is set in the equipment prior to take off. The system uses a non-computing gunsight.

POSITION SETTING UNIT.

The position-setting unit (figure 4–22) is on the right side of the pilot's compartment above the generator control panel and is the only control necessary for operation of the interim warning system. Controls are a SLANT RANGE dial and a FIRING RANGE dial. Both dials are calibrated in hundreds of feet. A removable pull-up range computer is mounted on the position-setting unit. The 28-volt d-c radio bus and the 115-volt No. 2 a-c bus supply the power to operate the system.

NORMAL OPERATION.

 Determine the value for the following air-toground gunnery conditions:

Dive angle of 10, 20, or 30 degrees Pull-up acceleration of 2, 3, or 4 G's True air speed of 200, 300, or 400 knots Terrain clearance of 500, 1000, or 1500 feet

Note

Always use true air speed when computing slant range.

- Rotate the inner disk of the pull-up range computer until the predetermined values appear at
 the appropriate part of the open window. When
 inserting values into the computer, follow the
 order listed in step 1.
- Read the slant range value appearing at the appropriate part of the open window.
- 4. Set the SLANT RANGE control on the position setting unit to the computed value of slant range obtained in step 3. The slant range value obtained from the computer represents the slant range at the time of pull-up and not the vertical terrain clearance.
- Determine a value for the firing range and set the FIRING RANGE control on the positionsetting unit to that value. This setting determines the radar target range at which the firing range signal is transmitted to the pilot's headset.

WARNING

The preselected terrain clearance will be reduced if the following precautions are not adhered to: Never increase or decrease the dive angle during attack. Never increase the true air speed. Start pull-up immediately after receiving the pull-up signal. Do not decrease pull-up acceleration.

6. Place the guns switch to the GUNS or SIGHT-RADAR position to energize the system. The pilot receives two operational signals: An interrupted tone indicates that the airplane is within firing range of the target, and a siren tone indicates the point of pull-up.

Note

Depressing the mike button or placing the AIC-10 control switch to CALL during a gunnery run prevents the pilot from receiving the firing range and pull-up signals.

After firing is completed, place the guns switch to OFF to de-energize the system.

BOMBING EQUIPMENT.

The airplane is equipped with a horizontal, rotarytype bomb-carrier door for carrying various sized bombs in varied configurations. Pylons, two under each wing, carry the external stores. Both the internal and external stores may be released by the normal bomb release system, the jettison bomb release system, or the shoran bomb release. For buffet and release speed limitations, refer to EXTERNAL STORES in Section V. All controls for the bombing system are at the pilot's station, except the shoran controls, which are located in the observer's station. During normal release or shoran release, all stores may be dropped singly or in train. During jettison bomb release, all stores will be released simultaneously. If it is desired, the wing tip fuel tanks may be jettisoned simultaneously. If it is desired, the wing tip fuel tanks may be jettisoned simultaneously with the stores. There are provisions for carrying special weapons.

BOMB DOOR.

The removable bomb-carrier door is in the center fuselage section and can carry various sized bombs in varied configurations. (See figure 4-23.) The door is electrically controlled and hydraulically actuated to pivot 180 degrees on its horizontal axis to expose the bombs for release. At the same time, the lower surface of the door seals the cavity of the bomb door area. The door is divided into three armament bays: forward bay, middle bay, and rear bay, each having seven bomb stations. These stations are so arranged and electrically interconnected that any number of bomb racks, up to a total of 21, may be installed to accommodate various bomb loadings. Two alternate bomb racks are installed between the middle and rear bays to accommodate large stores. All stores are retained by S2A or MA-4 bomb racks, chocks, and a second layer suspension assembly of racks and chocks. Controls for the bomb door are the bomb door switch (for normal bomb release), the shoran bomb release system, or the jettison bomb release system.

BOMB DOOR SWITCH. The bomb door switch, located on the armament control panel, is of the momentary type and has three positions: OFF, OPEN, and CLOSE. (See figure 4-20.) The switch is springloaded to the OFF position. When the switch is placed in OPEN, power passes to a double-acting solenoid valve, energizing the open side of the valve. When the valve opens, hydraulic pressure passes to two double-acting actuating cylinders which rotate the door 180 degrees clockwise in four seconds. When the bomb door switch is placed in CLOSE, the door rotates counterclockwise 180 degrees in six seconds to the close position. With the door fully opened or closed, the respective double-acting solenoid valve remains energized. The door has no mechanical locks since the actuating cylinder lines are pressurized in either direction. Loss of hydraulic fluid in these lines normally causes the door to move to a position near full open.




Figure 4-23

personnel safety switch




Figure 4-24

PERSONNEL SAFETY SWITCH. The personnel safety switch, at the left forward corner of the bomb door area adjacent to the bomb door ground shut-off valve, is a ground handling safety feature used to open the bomb bay circuits as a precaution against inadvertent operation of the bombing equipment when personnel are working in the bomb door area. (See figure 4–24.) This switch prevents power from being supplied from the armament bus to the bombing equipment when the switch is in the SAFE position. Before flight the switch must be in the FLIGHT position.

EMERGENCY BOMB DOOR OPEN HANDLE. The emergency bomb door open handle, over the observer's left console, is used in the event the bomb door fails to open normally. (See figure 4–29.) When this handle is lifted, turned one-quarter turn clockwise, and pulled all the way out (four inches), a cable attached to the handle will manually override the bomb door control valve solenoid and position the valve so that hydraulic pressure from an emergency selector valve will be routed to the open side of the bomb door actuating cylinders. Pressure is routed to the emergency selector valve from the emergency pressure line of the hydraulic system by the hydraulic system hand pump.

Note

After the emergency bomb door open handle has been pulled all the way out, it will remain in that position to keep the manual override on the bomb door control valve solenoid in the correct position. The valve cannot be returned to the door-closed position until the airplane is on the ground. To return the valve to the door-closed position, pull out the lanyard in the upper left forward bomb hoist access door a distance of about four inches.

CAUTION

Before pulling out the emergency bomb door open handle, make sure that the emergency landing gear down handle is in the normal (in) position. The emergency selector valve is spring-loaded to route pressure to the bomb door control valve; however, when the emergency landing gear down handle is in the emergency (out) position, the handle overrides the spring and the emergency selector valve is positioned to route pressure to the landing gear.

BOMB-DOOR GROUND SHUT-OFF VALVE. A manually operated bomb door ground shut-off valve, located at the left forward end of the bomb door area adjacent to the personnel safety switch, positions and locks the door during servicing operations. The valve is mechanically connected with the hinged access door which covers the personnel safety switch. When the access door is pulled out, the valve is in the off (safe) position. When the access door is pushed in, the valve is in the open (flight) position. The valve must be in the flight position prior to all flights.

BOMB-DOOR POSITION INDICATOR. The bomb-door position indicator, on the armament control panel, indicates the position of the bomb door. (See figure 4–25.) When the door is fully closed, the word closed appears on the indicator. When the door is fully opened, seven dots appear on the indicator. The dots are arranged in two horizontal rows, four on the top and three on the bottom, representing the position of the stores as they are ready for release. When the door is in any position other than fully open or fully closed, diagonal lines like those on a barber pole appear on the indicator.

Note

The bomb-door position indicator will not function unless the select armament switch is in any position other than OFF.

EMERGENCY BOMB DOOR OPERATION.

If the bomb door system fails, proceed as follows to open the door:

 Check that the emergency landing gear down handle is in the normal (in) position.

CAUTION

The emergency selector valve is spring-loaded to route pressure to the bomb door control valve, but when the emergency landing gear down handle is in the out position, it overrides the spring and the valve will be positioned to route pressure to the landing gear control valve.

- Have the observer pull the emergency bomb door open handle all the way out.
- 3. Operate the hydraulic hand pump.

Note

Approximately 30 to 50 light strokes of the hand pump are needed to open the door. Once the door has been opened it cannot be closed again until the airplane is on the ground.

WARNING

If after approximately 50 strokes of the hand pump there is no indication of pressure build-up or bomb door operation, make no further attempt to open the door.

BOMBING CONTROLS.

BOMB-AND-ROCKET RELEASE BUTTON. The bomb-and-rocket release button, located in the right handgrip of the pilot's control wheel, energizes the various stores and rocket release circuits. (See figure 1-25.) When the stores or rockets and their manner of release have been selected by their respective controls, depressing the release button energizes the respective circuit.

Note

Internal bomb stores will not release unless the bomb door is in the full open position.

The release button supplies power from the 28-volt d-c armament bus.

WARNING

Before pressing the bomb and rocket release button, make sure that all bomb and rocket controls are in the correct positions for the desired release to avoid accidental bomb or rocket release.

SELECT ARMAMENT SWITCH. The select armament ment switch, located on the select armament control panel next to the armament control panel, permits the selection of stores to be released. (See figure 4–25.) When this switch is in OFF, the armament bus is deenergized. When the switch is in any position other than OFF, the armament bus is energized and the stores may be selected for release as follows: internal, external, or both, or smoke may be selected when external chemical tanks are carried. The rockets may be released either singly or automatically by positioning the switch in either the ROCKETS SINGLE or in the ROCKETS AUTO position.

BOMB STATION SWITCHES. Three bomb station switches, located on the armament control panel, are

select armament control panel





Figure 4-25

bomb intervalometer



11722

Figure 4-26

marked FWD BAY, MID BAY, and REAR BAY. (See figure 4-25.) Each switch is located adjacent to the indicator lights for its respective bay. These switches enable the pilot to select the bay to be released. When any or all of the switches are placed in their respective BAY position, the bombs in the respective bays are released in ascending numerical order, either singly or in train, depending upon the position of the intervalometer train-select switch. When the intervalometer is set for train and the select armament switch is in the BOMB EXT & INT position, the internal stores will be released after the external stores.

EXTERNAL STORES SWITCHES. Four external stores switches, located on the armament control panel, select any or all of the external stores to be dropped by the normal bomb release system. (See figure 4–25.) There is one switch for each external store carried, as follows: STA L2 controls the power circuit to the left outboard pylon bomb rack; STA L1; the left inboard rack; STA R3, the right inboard racks; and STA R2, the right outboard rack. The external stores may be dropped in train or individually, depending upon the setting of the switches and the intervalometer. If both the external stores and internal stores are to be dropped in train, the external stores will be dropped first in the following order: STA L2, STA R2, STA R1, STA L1.

BOMB-ARMING SWITCH. The bomb-arming switch located on the armament control panel, is used to

arm both the internal and external stores. (See figure 4-25.) The switch has three positions: NOSE & TAIL, TAIL ONLY, and SAFE. The bombs are set to explode instantly upon impact when the arming switch is set at the NOSE & TAIL position. Setting the arming switch at the TAIL ONLY position arms the bombs for delayed detonation. The bombs will be released unarmed if the switch is in the SAFE position. When the select armament switch is in the SMOKE position, placing the bomb arming switch in the NOSE & TAIL position energizes the chemical tank smoke release unit thereby causing the release of smoke. When the jettison bomb system is operating, a relay opens the arming circuit so that the bombs will be released in an unarmed condition.

BOMB INTERVALOMETER. The bomb intervalometer located on the pilot's left console, enables the pilot to release the internal and external bombs individually or in train. (See figure 4-26.) The select-train switch on the intervalometer selects the method of release. Placing the switch in the SEL position releases the bombs singly. When train release is desired, the switch must be in the TRAIN position, the ground spacing knob must be set for the interval desired, and the bomb counter must be set for the number of bombs to be released. With either method of release, the internal bombs are dropped in ascending numerical order from the bomb stations which are loaded and selected. When the select armament switch is in the BOMBS EXT & INT position, the

external stores are released before the internal stores. MASTER JETTISON SWITCH. The master jettison switch is located on the pilot's left main control panel (figure 1-35). When this switch is pressed, the bomb door opens, and all stores, including external stores or rockets, are released. In addition, when the switch is actuated, a relay opens the bomb arming circuit so that the bombs will be released unarmed. Power for the jettison system comes from the battery bus.

CAUTION

The wing tip tanks will be jettisoned with the bombs and external stores or rockets if the tip tanks jettison switch is in NORMAL when the master jettison switch is actuated.

BOMB INDICATOR LIGHTS. Twenty-one bomb in-

BOMBING INDICATORS.

dicator lights are mounted on the armament control panel. (See figure 4-25.) Each light corresponds to a bomb station. The lights are arranged in three groups of seven to correspond to the three bomb bays of the bomb carrier door. When bombs are loaded at any or all of the stations and the respective racks are cocked, the lights operate, provided the armament bus is energized and the bomb station and bomb indicator lights switches are on. When a bomb is released, its corresponding indicator light goes out. BOMB INDICATOR LIGHTS SWITCH. The bomb indicator lights switch is located on the armament control panel. (See figure 4-25.) When bombs are loaded at any or all stations, the respective racks cocked, and the bomb station switches placed in the BAY position, actuating the bomb indicator lights switch causes the bomb indicator lights to operate if their respective station is loaded. Power for the switch comes from the armament bus.

EXTERNAL STORES INDICATOR LIGHTS. Four external stores indicator lights are mounted on the armament control panel. (See figure 4-25.) Each light corresponds to one of the external stores stations. When external stores are loaded at any or all of the stations and the respective racks are cocked, the lights operate, provided the arament bus is energized and the external stores and bomb indicator lights switches are on. When an external store is released, its corresponding indicator light goes out.

BOMB-RELEASED INDICATOR LIGHT. A bombreleased indicator light (figure 1-31) is mounted on the pilot's main instrument panel and another is mounted on the observer's instrument panel. (See figure 4-30.) When stores are being released, the pulse from the intervalometer which energizes the bomb racks also energizes a circuit to the bomb-released indicator light. Therefore, every time a store is released, the indicator light will light for the time the signal is transmitted for bomb release. Power is supplied to the bomb-released light through the intervalometer from the 28-volt d-c armament bus.

Note

When a bomb is released, the corresponding bomb station indicator light on the armament control panel will go out.

BOMB RELEASE.

NORMAL BOMB RELEASE. The normal bomb release system permits selected release or train release of the internal and external stores as follows:

Note

If the gunsight is used for low-level bombing, place the master guns switch in the SIGHT & RADAR position, place the gunsight light switch in the GUNSIGHT ON or ALTERNATE ON position, adjust the gunsight light rheostat for the desired brilliance, and set the gunsight tilting knob to the B (bombs) position.

- Position the select armament switch to the BOMBS INT, BOMBS EXT, or BOMBS EXT & INT position.
- Place the bomb arming switch in the desired postion.
- Set the bomb intervalometer select-train switch in the SEL or TRAIN position, and if TRAIN is selected also set the ground spacing knob for the interval desired and the bomb counter for the number of bomb stations to be released.

Note

If external stores are to drop at the same time as the internal bombs, the external stores will be released first.

4. Place the bomb stations switches in the up position for the stations to be released, and if external bombs are being released, check that the external stores switches are in the ON position.

CAUTION

If the external stores switches are in the STA position, all external stores selected will be released together.

- 5. Place the bomb indicator lights switch in LIGHTS.
- 6. Place the bomb door switch in OPEN and check that the bomb door reaches the full open position by observing that the bomb door position indicator shows seven dots (representing the bombs on the bomb door).
- Press the bomb and rocket release button in the right handgrip of the control wheel.
- If all the selected internal bomb station indicator lights have gone out (all selected bombs released), place the bomb door switch in CLOSE.

BOMB JETTISON RELEASE. All internal and external stores can be jettisoned by actuating the master jettison switch. This action will jettison all internal bombs, external stores, and rockets.

CAUTION

Actuating the master jettison switch also jettisons the wing tip tanks, if the tip tanks jettison switch is in the NORMAL position. Therefore the tip tank jettison switch should be in the OFF position if the tanks are not to be jettisoned.

NORMAL EXTERNAL STORES RELEASE. The external stores may be released with the internal stores as described under NORMAL BOMB RELEASE in this section, or they may be released separately as follows:

Note

If the gunsight is used for low-level bombing, place the master guns switch in the SIGHT & RADAR position, place the gunsight light switch in the GUNSIGHT ON or ALTERNATE ON position, adjust the gunsight light rheostat for the desired brilliance, and set the gunsight tilting knob to the R or B position.

- 1. Position the select armament switch in the BOMBS EXT position.
- Set the bomb arming switch in the desired position.
- Place the external stores switches in STA for the stores to be released.
- Place the bomb indicator lights switch in LIGHTS.
- Press the bomb and rocket release button in the right handgrip of the control wheel.

SMOKE RELEASE.

When any or all of the external bomb pylons are loaded with an E-26 chemical tank, a smoke release may be made by proceeding as follows:

- 1. Place the select armament switch to SMOKE.
- 2. Place the external stores switches for the desired tanks in the STA position.
- Actuate the bomb arming switch to the NOSE
 TAIL position to release the smoke.

SHORAN BOMB RELEASE. To release bombs by means of the shoran system, follow the procedure given under NORMAL BOMB RELEASE or NORMAL EXTERNAL STORES RELEASE in this section, with the following exceptions:

- Do not open the bomb door because shoran control of the door is automatic.
- Do not depress the bomb and rocket release button because release power is initiated by the shoran computer.
- If all the selected internal bomb station indicator lights have gone out (all selected bombs released), place the bomb door switch in CLOSE.

ROCKET EQUIPMENT.

There are fittings for the installation of eight rocket pylons, four under each wing. Four of these pylons are alternates to the four external stores pylons. Two 5-inch HVAR rockets, one mounted directly below the other, hang from each pylon. The Mk Mod 8 (Modified) Gunsight aims the rockets. Controls for normal firing and emergency release of the rockets are at the pilot's station. During normal firing, rocket can be fired singly or in salvo. The firing order is illustrated in figure 4–27.

ROCKET CONTROLS.

SELECT ARMAMENT SWITCH. Refer to BOMB-ING CONTROLS in this section.

ROCKET FUZING (ARMING) SWITCH. The rocket fuzing switch on the armament control panel controls the arming of the nose fuzes of rockets to be released normally. (See figure 4–25.) When the switch is set in INSTANT, the nose fuze is armed upon release to detonate upon impact. The nose fuze is unarmed if the switch is set at DELAY or OFF. However, an internal fuze will cause delayed detonation after impact on a normal release. During jettison, the nose fuze is automatically unarmed and the internal fuze is inoperative.

ROCKET INTERVALOMETER (PROJECTOR RE-LEASE CONTROL). The rocket intervalometer on the armament control panel controls the sequence of




Figure 4-27

firing in both single firing or salvo. (See figure 4-25.) When the select armament switch has been set at the ROCKETS SINGLE position, one rocket is released each time the pilot depresses the bomb and rocket release button, and the intervalometer automatically maintains the correct firing sequence for each successive release. When the selector switch is set at the ROCKETS AUTO position and the bomb and rocket release button is depressed, the intervalometer causes the rockets to be fired in the proper salvo sequence at approximately 1/10-second intervals as long as the button is depressed. A numbered dial, visible through a window in the intervalometer housing, indicates the rocket to be fired. The dial is set at the time of rocket loading and should be set at 1 when a normal complement of rockets is carried. The reset knob on the intervalometer selects release of any particular rocket in case of misfire or other malfunction during a "single" release.

Note

If one of the lower rockets misfires, the corresponding upper rocket may be fired. However, both rockets will dive upon release and the airplane may receive superficial damage consisting of a scratched and scorched wing.

BOMB-AND-ROCKET RELEASE BUTTON. Refer to BOMBING CONTROLS in this section.

MASTER JETTISON SWITCH. Refer to BOMBING CONTROLS in this section.

FIRING ROCKETS.

To launch rockets, proceed as follows:

- Place the master guns switch in SIGHT & RADAR.
- Place the gunsight light switch in the GUN-SIGHT ON or ALTERNATE ON position.
- Set the gunsight light rheostat to the desired reticle brilliance.

- Set the degrees dial on the gunsight tilting knob to 1.9 degrees on the white portion of the dial.
- Position the select armament switch to the ROCKETS SINGLE or ROCKETS AUTO position, as desired.
- Set the rocket fuzing switch at INSTANT or DELAY, as desired.
- 7. Check that the number appearing in the window of the rocket intervalometer is 1 (one), if carrying a normal complement of rockets. If a different complement of rockets is being carried, reset the dial accordingly.
- 8. Press the bomb-and-release button.

ROCKET JETTISON RELEASE.

All rockets may be jettisoned in the same manner as the bombs, that is, by actuating the master jettison switch. This action will also jettison all internal and external stores.

CAUTION

Actuating the master jettison switch will also jettison the wing tip tanks if the tip tanks jettison switch is in NORMAL. Therefore, the tip tank jettison switch should be OFF if the tanks are not to be jettisoned.

M-1 BOMBING SYSTEM.

At the present time, there are only provisions for the

installation of the M-1 bombing equipment. The text on this system will be expanded when the information is available.

MA-2 LOW ALTITUDE BOMBING SYSTEM.

The MA-2 LABS COMPUTER SET, when used with other associated equipment, permits precision low-altitude, automatic bomb release. The 28-volt d-c armament bus and the No. 2 a-c bus supply the power to operate the system.

LOW ALTITUDE BOMBING SYSTEM CONTROL PANEL.

The LABS CONTROL PANEL is on the pilot's left console. (See figure 4–28.) The panel controls consist of a labs selector switch with positions OFF, DIVE \(\neq \text{IND, LABS NORM and LABS ALT, and a labs start switch with OFF and START positions.

LABS INDICATOR.

The LABS INDICATOR is on the pilot's main instrument panel. (See figure 1-31.) The indicator is a dual-movement meter which indicates roll-and-pitch-attitude information during bomb run-in, and yaw-roll and acceleration information during pull up. The indicator markings are nine divisions left (9 degrees), and nine divisions right (9 degrees) for the vertical needle. Indicator markings are HI G, LO G, nine divisions up (90 degrees) and nine divisions down (90 degrees) for the horizontal needle. Dive angle indication can be obtained by positioning the labs selector switch in the DIVE \angle IND position.

labs control panel




Figure 4-28

NORMAL OPERATION.

- 1. Place the select armament switch in the desired position.
- 2. Place the labs selector switch in LABS NORM.
- Place the labs start switch in START no sooner than two minutes after positioning the labs selector switch. The sight reticle light will illuminate, and airplane pitch-and-roll movement is indicated by the labs indicator.
- Depress the bomb release button when the airplane passes over the proper point. (The bomb release button must remain depressed until runin, pull-up, and release are completed.)

Note

To abort a low-angle (normal) delivery, rapidly switch to LABS ALT any time during the run-in and perform a high-angle (alternate) release.

- 5. When the sight reticle light goes out (completion of the timing cycle), start the pull-up. The labs instrument automatically transfers from pitch to acceleration indication. Transfer from roll to yaw-roll indication occurs either when the wings are level or within ± 4 seconds after the completion of the timing cycle.
- When the airplane has maneuvered through the selected angle, the sight reticle light will illuminate, indicating bomb release.
- Release the bomb release button after the bomb delivery. This transfers the labs instrument indication from acceleration to pitch-attitude information, and turns the sight reticle light off.
- 8. Depressing the bomb release button after completion of step 6 causes the labs instrument to retain yaw-roll indication and transfer from pitch to acceleration. The sight reticle light remains off. Repeat this cycle after bomb release, and prior to recycling the labs system.
- Place the labs start switch in OFF for a minimum of 10 seconds, and then ON when the airplane is in position to commence another run.

CAUTION

Never operate the labs start switch unless the airplane is in a relatively static state about its roll axis. Operation of the switch will cause serious damage to the equipment gyros.

10. Place the labs start switch in OFF to de-energize the system.

ALTERNATE OPERATION.

- Place the select armament switch in the desired position.
- 2. Place the labs selector in LABS ALT.
- Place the labs start switch in START no sooner than two minutes after positioning the labs selector switch.

Note

Disregard the operation of the sight reticle light while the labs selector switch is in LABS ALT. All operations normally started at the completion of the timing cycle start when the bomb release button is depressed.

- 4. When the airplane passes over the target, start the pull-up. Depress the bomb release button and hold until the selected release angle is reached. Labs instrument will transfer from pitch to acceleration and roll to yaw-roll indication when the wings are level. The remaining operations are the same as for normal operation.
- 5. To stop the labs system at any time during operation, release the bomb release button.

MISCELLANEOUS EQUIPMENT.

Miscellaneous equipment such as data cases, relief tubes, stowage bags, etc. are shown on the general arrangement diagram (figure 1-1).

WINDSHIELD WIPER.

A motor-operated variable-speed windshield wiper, controlled by the pilot, is installed below the windshield. Power to operate the wiper comes from the pilot's circuit breaker bus through a circuit breaker on the pilot's power distribution circuit breaker panel.

WINDSHIELD WIPER SWITCH.

The windshield wiper switch, located on the windshield control panel, is marked PARK, OFF, HIGH, MED, and LOW. (See figure 4-4.) The FAST position and any intermediate positions between FAST and OFF control the speed of the motor which drives the wiper. The OFF position de-energizes the motor. The wiper can be stopped on the right side of the windshield by rotating the switch from OFF to the PARK position momentarily, and then back to OFF.

observer's left console 2. Chaff Dispenser Control Panel 3. Special Weapon Control Panel 7. ASN-6 Computor Control 4. APS-54 Control Panel 8. Latitude Departure Switch

Figure 4–29




Figure 4-30




Figure 4-31

Section V



OPERATING LIMITATIONS

11643

TABLE OF CONTENTS

| | Page | | Page |
|---------------------------|------|-------------------------------|-------|
| INTRODUCTION | 5-1 | PROHIBITED MANEUVERS | 5-7 |
| MINIMUM CREW REQUIREMENTS | 5-1 | ACCELERATION LIMITATIONS | |
| ENGINE LIMITATIONS | 5-1 | ACCELERATION EINITATIONS | .)-/ |
| AIRSPEED LIMITATIONS | 5-4 | CENTER-OF-GRAVITY LIMITATIONS | 5-7 |
| LANDING DESCENT | 5-7 | GROSS WEIGHT LIMITATIONS | 5-7 |

INTRODUCTION.

This section contains the engine and aircraft limitations that must be observed during normal operations. For instrument markings, refer to figure 5-1 because these limitations are not necessarily repeated in the text of this or other sections.

MINIMUM CREW REQUIREMENTS.


The minimum crew required for this airplane is the pilot. Additional crew members can be added at the discretion of the Commanding Officer.

ENGINE LIMITATIONS.


GENERAL.

All normal limitations are shown in figure 5-2. If the limits for steady-state operation, acceleration, or starting are reached or exceeded, make an entry in form DD787 of the magnitude and duration of the operation at or above the limitations. During steady state operation, note only the indications above the limitations. When shutting down the engine from 95% or above, idle the engine for at least one minute to allow temperature conditions to stabilize, and then

instrument markings



BRAKE PRESSURE




AIRSPEED

170 KNOTS IAS-FLAP EXTENSION 200 KNOTS IAS-LANDING GEAR EXTENSION 444 KNOTS IAS-AIRSPEED LIMIT

WITH TIP TANKS

513 KNOTS IAS-AIRSPEED LIMIT WITHOUT TIP TANKS







Figure 5-1 (Sheet 1 of 2)






Figure 5-2

place the throttles in OFF. If the engines are being shut down from below 95% rpm, you can close the throttles immediately.

CAUTION

Operating the engines without a nose cowl or bellmouth and without a starter fairing installed causes compressor failure because of improper airflow distribution.

TEMPERATURE AND POWER LIMITS.

The steady-state exhaust gas temperature should never exceed 620°C except during starting or acceleration. If necessary, throttle back the engine to keep within this limit. If the temperature cannot be controlled by this method, stop the engine and do not attempt a restart until an inspection can be made. If you have made five starts in which the exhaust gas temperature is 800° to 900°C, or one start exceeding 900°C, stop the engine and perform an immediate inspection. If airborne and unable to determine the cause of the malfunction, stop the engine and do not attempt a restart. Never operate the engine if the engine air inlet tem-

perature reaches 93°C. Should the engine rpm exceed 105.5% rpm during acceleration or 102.5% rpm during steady state flight, retard the throttle and keep below these limits. If the engine continues to overspeed, shut it down immediately. If the engine overspeeds to 106% rpm, an inspection is required before restarting.

CAUTION

Do not attempt to restart the engine after exceeding a starting exhaust gas temperature of 900°C, or an rpm limit of 106% without first performing an inspection.

AIRSPEED LIMITATIONS.

LANDING GEAR EXTENSION SPEED.

The limiting airspeed for extending the landing gear is 200 knots IAS. If the gear is lowered at speeds in excess of this value, the fairing, doors, or operating mechanism may be damaged.

WING FLAP LOWERING SPEED.

The limiting airspeed for lowering the wing flaps is 170 knots IAS. Flap distortion or damage to the operating mechanism may result at speeds in excess of this limiting value.

DIVE BRAKES.

There is no limitation for the operation of the dive

CAUTION

Do not extend the dive brakes when the airplane is equipped with external wing stores. This results in severe buffeting.

BOMB DOOR.

There is no airspeed limitation imposed on the operation of the bomb door.

LANDING LIGHT EXTENSION.

The limitation airspeed for extending the landing

light is 200 knots IAS. Damage to the light support and buffet may occur in excess of this speed.

MAXIMUM ALLOWABLE AIRSPEEDS WITH WING TIP TANKS.

When tip tanks are carried, the maximum allowable airspeed at any altitude is 444 knots IAS or 0.78 Mach, whichever is less. (See figure 5-3.)

MAXIMUM ALLOWABLE AIRSPEEDS WITHOUT WING TIP TANKS.

Without tip tanks the maximum allowable airspeed up to 5,000 feet is 513 knots IAS. (See figure 5–4.) From 5,000 to 20,000 feet the limit is 0.82 Mach. From 20,000 feet up the buffet limit is encountered between 0.83 and 0.85 Mach. The airspeed limitations for normal control are shown in figures 5–3 and 5–4. If you exceed these values, the result will be extremely heavy buffeting at low altitudes and in severe longitudinal trim changes at high altitudes.




Figure 5-3




Figure 5-4

RELEASE AND JETTISON AIRSPEEDS FOR EXTERNAL STORES.

There is danger of external stores striking and damaging the airplane when dropped at excessive speeds. The maximum allowable airspeed at which empty wing tip tanks can be jettisoned is 365 knots IAS. Do not drop completely filled E-74 series 750pound napalm tanks at speeds in excess of 200 knots IAS. If partly filled or empty, these tanks should not be dropped at any speed except in case of emergency. Do not drop externally mounted T-54 series 750pound bombs at speeds in excess of 350 knots IAS. This restriction does not apply to those bombs carried internally. Do not jettison five-inch, high-velocity aerial rockets at speeds greater than 200 knots IAS, except in emergency. This restriction does not include 2.75 FFAR rockets and rocket pods for which there are no jettison restrictions. The speed restrictions for dropping other external stores will be included when flight-test data are available.

RELEASE AND JETTISON AIRSPEEDS OF INTERNAL STORES.

As with external stores, the release of internal stores

at excessive speeds can cause damage to the aircraft. Do not jettison five-hundred-pound box-fin, general-purpose bombs at speeds in excess of 400 knots IAS, except in emergency. The M-26 paraflare may be released from the bomb door up to 350 knots IAS, provided inert stores are loaded on bomb stations 18 and 21 on a "no-release" basis. Tests show that these two stores are the only ones that "hang-up" or damage the airplane on separation up to the 350 limit. Tests have also shown that flares are more reliable when released at speeds of 300 knots IAS or less. E-53 cluster adapters may be released from the bomb door at any IAS up to the airspeed limit of the airplane, provided that inert stores are loaded on stations 18 and 21 and carried on a "no-release" basis.

M-39 GUN LIMITATIONS.

To insure adequate purging of gun gas, do not fire the M-39 guns at less than 190 knots IAS from sea level to 5,000 feet. Test firing the guns above 20,000 feet is not recommended, but if test firing at this altitude is necessary, the airspeed should be at least 300 knots IAS.

LANDING DESCENT.

540 fpm with a gross weight of 37,600 pounds. 438 fpm with a gross weight of 44,000 pounds. 300 fpm with a gross weight of 53,400 pounds.

PROHIBITED MANEUVERS.

Do not perform the following maneuvers:

- 1. Intentional spins.
- 2. Snap rolls or any other snap maneuver.
- Inverted flying or any maneuvers resulting in extended negative acceleration.
- Abrupt rudder-induced maneuvers.

CAUTION

Inverted flying or any maneuver resulting in extended negative acceleration may result in engine flame-out, since there are no means of insuring a continuous flow of fuel in this attitude.

Do not make maneuvers solely by use of trim devices. Trim devices increase the pilot's apparent strength by reducing the required stick forces. The high stick forces experienced during maneuvers without the use of trim serve to protect the crew and the airplane. Use trim devices only to reduce the maneuvering stick forces to tolerable limits, and not to zero. The use of trim in anticipation of a maneuver, or to reduce maneuvering stick forces to very small values, may result in airloads strong enough to cause complete structural failure of the airplane.

ACCELERATION LIMITATIONS.

The maximum allowable G for different conditions is illustrated in the operating flight strength diagrams. (See figures 5-5 and 5-6.) These flight strength (V-G) diagrams define the flight speed and load factor limits at various altitudes for a given airplane gross weight. The speeds quoted are indicated readings exactly as observed during flight.

MAXIMUM ACCELERATION.

NO EXTERNAL LOAD.

The maximum allowable positive acceleration for the airplane with no external load is 5G and the maximum negative limits is 2.5G. (See figure 5–5.)

WING TIP TANKS INSTALLED.

The maximum allowable positive 4G acceleration is

4G's for an airplane with tip tanks. (See figure 5-6.) This acceleration limit is for both the full or empty tip tanks. The negative limit varies with full or empty tip tanks. The maximum negative limit with tip tanks is 1.33G, while a 2.05G acceleration is allowable with the tip tanks empty.

CENTER OF GRAVITY LIMITATIONS.

The CG limitations of the airplane are: forward 21.0% MAC, with or without tip tanks; aft 28.3% MAC, with tip tanks; and aft 28.8% MAC without tip tanks. The location of all equipment (see figures 5–7, 5–8, and 5–9) has been carefully controlled to provide satisfactory center-of-gravity position at all times. The greatest single cause of CG travel is the distribution of the fuel load. The normal sequence of fuel distribution to the engines, as outlined in Section VII, keeps the airplane well within the CG limits.

GROSS WEIGHT LIMITATIONS.

no wind.

The maximum gross weight of the B-57B is 57,000 pounds, provided that cargo and stores are loaded as specified in T.O. 1-1B-40. This gross-weight limitation is not imposed by the structural limits of the airplane, but by the facilities available for the loading of internal and external stores. There are certain limitations associated with gross weight that affect the service life, strength, and performance of the airplane. A tabulation of these limitations follows.

Gross Weight

Pounds 55,000

49,000

| 57,000 | Requires at least 10,000-foot take-off roll to clear 50-foot take-off obstacle with 100% rpm; sea level, hot day, no wind. |
|------------------|--|
| 57,000 | Maximum gross weight based on available capacity. |
| 53,400 | Limit of 300 fpm sinking speed imposed at time of landing contact with runway. |
| 49,000 to 53,400 | Load factor limited to $+4G$ and $-1.33G$ constant with tip tanks installed. |
| | |

Requires at least 5,400-foot take-off roll

at 100% rpm; standard day at sea level,

37,500 Load factor limited to +5G and -2.3G constant without tip tanks installed. Sinking speed limited to 540 fpm at

44,000 to Load factor limited to +4G and -2G

constant without tip tanks installed.

landing contact with runway.


operating flight strength diagrams

HOW TO USE CHART


- 1. Select your indicated airspeed.
- 2. Trace vertically your flight altitude.
 3. Move horizontally to the left and find the maximum G you can pull at that airspeed and altitude before stalling.

 NOTE: Any G in excess of 5G is prohibited.

SYMETRICAL FLIGHT WITH WING-TIP TANKS GROSS WEIGHT - 53,400 LB



SYMETRICAL FLIGHT WITHOUT WING-TIP TANKS GROSS WEIGHT - 48,600 LB



SYMETRICAL FLIGHT WITHOUT WING-TIP TANKS GROSS WEIGHT - 37,600 LB





Figure 5-5

center of gravity maximum range condition

C. G. LIMITS ARE BASED UPON LANDING GEAR RETRACTED CONDITION




C.G. PERCENT M.A.C.

GROSS WEIGHT — IN THOUSANDS OF POUNDS

center of gravity limits maximum stores condition

C. G. LIMITS ARE BASED UPON LANDING GEAR RETRACTED CONDITION



C.G. PERCENT M.A.C.

center of gravity limits ferry condition

C. G. LIMITS ARE BASED UPON LANDING GEAR RETRACTED CONDITION




Figure 5-8





Figure 5-9

Section VI



FLIGHT CHARACTERISTICS

11667

TABLE OF CONTENTS

| nation the supplement of the continue of | Page | | Page |
|--|------|--|--------|
| GENERAL FLIGHT CHARACTERISTICS | 6-1 | SPINS | . 6-6 |
| TAKE-OFF | | LOW-SPEED CHARACTERISTICS | 6-7 |
| CRUISE PERFORMANCE | 6-2 | | |
| STICK FORCES | 6-3 | STALLS | . 6–7 |
| MANEUVERING FLIGHT | 6-3 | DIVES | . 6–10 |
| HIGH-SPEED CHARACTERISTICS | 6-5 | LANDING | . 6–10 |
| | | The state of the s | |

GENERAL FLIGHT CHARACTERISTICS.

The B-57B is a high-performance airplane that combines the simplicity of operation of a fighter with the load-carrying capabilities and the safety of a twinengine bomber. It has unusually good speed acceleration for a jet-powered aircraft. Unlike an airplane with reciprocating engines, it does not decelerate rapidly when the engines are throttled. Therefore, the airplane is equipped with dive brakes to aid deceleration from high speeds. The B-57B has a relatively low wing loading and a high load-factor strength. As a result, it is unusually maneuverable for a bomber

and the comparatively low thrust loading results in a service ceiling of over 50,000 feet.

The B-57B is stable about all axes throughout its speed and center-of-gravity range. As with all high-speed, high-altitude aircraft, the longitudinal stability starts to deteriorate at the Mach number where the effects of compressibility begin. At extremely high altitudes, the airplane has a certain amount of lateral-directional oscillation known as Dutch-roll. Dutch-roll is a characteristic of most aircraft at these altitudes, and while annoying, it is controllable. You can stop it for short periods to maintain a stable platform for bombing or photography.

TAKE-OFF.

The take-off characteristics are slightly different from those of other airplanes with tricycle landing gear. On the take-off roll, differential braking maintains directional control until the rudder becomes effective at approximately 60 knots IAS. Since the nose has a tendency to rise prematurely, the pilot must exert a push force of approximately 30 pounds on the control column. At approximately 100 knots IAS, relaxation of the push force allows the nose wheel to lift off the runway. The main gear oleos absorb the vibrations of the wheels and the pilot may experience a false sense of flying due to the smooth ground roll. A slight pull on the control column is necessary for the airplane to fly off the ground (approximately 110 to 130 knots). For take-off distances refer to Appendix I. Restriction of the rate of climb immediately after take-off permits the airplane to accelerate beyond the safe single-engine speed and to attain the best climb as soon as possible.

CLIMB.

A vibration that shakes the entire airplane may develop during climbs to altitude. This condition is not dangerous and can be eliminated by reducing power. The vibration is caused by the nose or "beak" of the aileron contacting the surrounding wing structure and transmitting engine vibration throughout the airplane. The clearance between the aileron and the surrounding structure is very close to obtain the lowest possible aileron forces. Temperature changes cause the various metal parts to expand and contract, thus producing the vibration contact.

CAUTION

If vibration through aileron contact occurs during climb, inspect the aileron and surrounding structure after completing the flight for possible damage.

CRUISE PERFORMANCE.

The range and endurance performance of turbo-jet airplanes differs from that of aircraft with reciprocating engines in one important respect. The reciprocating engine operates most efficiently at low power outputs, whereas the gas turbine operates most efficiently at, or near, maximum power output. Because of this characteristic, the maximum range and maximum

mum endurance procedures for jet-powered aircraft are quite different. To better understand the way the airplane is affected by maximum range and maximum endurance flying, it is best to study the airframe and the engine separately.

If the airframe is considered separately from the engine, it can be shown aerodynamically that at one indicated airspeed with a constant gross weight the airframe can be flown at its maximum efficiency. Flying at this airspeed will result in the most miles per pound of applied effort. There is also one indicated airspeed, a few knots lower, at which the airframe can be flown for the most hours per pound of applied effort. These airspeeds, which are relatively low (about 180 and 160 knots IAS for the B-57) and which change very little with altitude, are the maximum range and maximum endurance speeds. The airframe is flown at the greatest ratio of velocity to thrust at the maximum range airspeed, and at the minimumthrust-required point at the maximum endurance speed.

When considered separately from an airframe, the gas turbine engine operates most efficiently and produces the most thrust per pound of fuel per hour at 95% to 100% rpm. This is true regardless of altitude, but the total amount of thrust produced at a constant rpm is greater at low altitudes and falls off appreciably at high altitudes. Mount the turbo-jet engine on the airframe, and at low altitudes the most efficient engine operation, 95% to 100% rpm, will produce far more thrust than the airframe requires to be propelled at its most efficient speed. If the airplane is climbed to high altitudes, there will be one altitude at which the engine can be operated at its most efficient rpm, and produce just enough thrust to propel the airframe at its most efficient indicated airspeed (180 knots IAS). Flying at this altitude, near the airplane's service ceiling, will result in a maximum of miles per pound of fuel used. At lower altitudes both the engine and the airframe compromise their efficiency. The engine must be operated below its most efficient power setting, and the airframe must be flown faster than its most efficient indicated airspeed. Consult the Operating Data in Appendix I for specific range figures.

An additional advantage in cruising at high altitude is the increase in true airspeed. Two hundred knots indicated airspeed at sea level is about two hundred knots true airspeed. An indicated airspeed of 200 knots at 40,000 feet is approximately 400 knots true airspeed. This discussion is reference to an airplane at a constant gross weight. An increase in gross weight requires a slight increase in the recommended cruising speeds.

To obtain maximum range with a full load of fuel, climb the B-57B to maximum altitude as rapidly as possible and cruise at maximum continuous power at the recommended Mach number. Make a normal descent (RPM-IDLE, Dive Brakes-EXTENDED, IAS-250 knots) when reaching the precomputed descent distance from your destination. You can obtain maximum endurance by flying at the minimum-thrustrequired speed, approximately 160 knots indicated, depending on weight. Because it is difficult to stabilize at this speed, a speed of 10 to 15 knots faster is recommended. The difference in endurance is negligible, and some excess thrust is available for turns and other maneuvering.

At low altitudes, engine rpm is reduced to considerably less than its most efficient setting. Therefore, more time per pound of fuel is gained by flying at a high altitude where the engine can be operated at maximum continuous power, and where this power setting is just sufficient to maintain maximum endurance speed. When deciding whether or not to climb, give consideration to the fuel required to climb and descend. If you have less than 2,000 pounds of fuel remaining in the fuel supply, it is to your advantage to reduce power and remain at the same altitude.

In cases of emergency and when it may be impractical to climb to a high altitude, one engine may be shut down and the other engine operated at a higher rpm. If at an altitude where one engine will provide sufficient thrust, it is more economical to operate one engine at full or near full rpm than two engines, each at a reduced rpm.

STICK FORCES.

The airplane is longitudinally stable through a cg range of 21% MAC to 28.3% MAC with tip tanks, 28.8% MAC without tip tanks. Under certain loading conditions when all fuel except that in the No. 1 fuselage tank is used, the forward cg limit may be exceeded by approximately three-fourths of one percent. This presents no operational problem because stick forces at the forward cg are normally high and this slight additional forward movement has little effect. The airplane will not fully stall in this condition, but the airspeed can be reduced to near actual stall speed. At high speed with a forward cg the stick forces per G are such that the load factor that can be applied to the plane is limited by pilot strength. For example, at 21% cg and 450 knots it takes about 150 pounds of effort to pull about 2 G. This fact is important during aerobatics. Refer to Stick Forces Chart, figure 6-1.

It is important to keep in mind that the B-57B nor-


mally operates close to its aft cg limit when fully loaded with fuel. The basic longitudinal stability is reduced as the center of gravity approaches the aft limit, and less pilot effort on the control column is required to change the airspeed from a given trim point. The plane's cg can easily move beyond its aft limit if fuel and equipment are improperly loaded, or the fuel system is mismanaged in flight, particularly if the No. 2 fuselage tank is allowed to remain full while utilizing fuel only from the No. 1 fuselage tank. Progressively less pilot effort is required for control as the cg moves aft of its limit and after a shift of approximately 3%, the plane reaches its so-called neutral point. Here there is little feel in the elevator control system and the control column can be moved back and forth with little effort. The elevator remains effective, however, and movement of the control results in normal aircraft response. The pilot can apply destructive load factors to the plane in this condition with absolutely no effort. The B-57B becomes essentially unmanageable past this neutral point and if it begins a pitching motion in either direction, it has a tendency to continue the pitching motion by itself.

These characteristics are basic to any plane and should not be considered peculiar to the B-57. You should know of them, however, since it is possible to create such conditions on the B-57B through carelessness in fuel management, and/or equipment loading. If the plane seems unusually light on the control column or if the longitudinal control seems spongy while flying, you should check your loading condition and handle the plane with extreme care. Reduce airspeed to between 200 and 250 knots and make all control motions as smoothly and gently as possible. Do not attempt steep turns or any other maneuvers that apply a load factor to the plane and be especially cautious of handling the plane roughly in turbulent air. Try to move the cg forward bxy fuel management, particularly before trying to land.


MANEUVERING FLIGHT.

The maneuverability of the B-57B is aided by springtab assists on the control surfaces. The ailerons are designed to be fully deflected only at low indicated airspeeds and are limited to an 80-pound effort on the control wheel. The elevator also has a spring tab assist but several other factors affect elevator effectiveness. The most important of these factors is the position of the center of gravity. The plane is more maneuverable at the aft cg position and requires more pilot effort at the forward cg positions. Altitude also affects maneuverability or the ease with which G acceleration can be produced during turns, pull-outs, loops, and

stick forces - group O airplanes




40,000 FT ELEVATOR FORCE POUNDS PULL




LOAD FACTOR - G

25,000 FT ELEVATOR FORCE POUNDS PULL



LOAD FACTOR - G

10,000 FT ELEVATOR FORCE POUNDS PULL



11669A

Figure 6-1 (Sheet 1 of 2)

CG = 21 %


CAS = 250 KNOTS CG = 28.8 %

stick forces - group P airplanes

40

20

0



35.000 FT **ELEVATOR** FORCE POUNDS PULL

LOAD FACTOR-G

3

2

CAS = 228 KNOTS CG = 28.8 %

CAS = 200 KNOTS CG = 28.8 %

4





Figure 6-1 (Sheet 2 of 2)

FORCE



other G-producing maneuvers. At the same cg, it requires less pilot effort to pull G at high altitudes than at low altitudes. On the other hand, while it requires less pilot effort to maneuver at high altitudes, less G can be produced because of lowering buffet limits. Therefore, practice aerobatic maneuvers at low to medium altitudes, 5,000 to 15,000 feet. Practice loops at 5000 to 10,000 feet with entry speeds ranging from 375 to 425 knots IAS. Use full power during the climb portion of the loop and hold a constant 3 to 31/2 positive G through the maneuver. Practice aileron rolls at 5000 to 10,000 feet and become proficient in performing aileron rolls before attempting an Immelmann. The aileron roll can be performed between 225 and 300 knots IAS (optimum 250 knots IAS) with power settings from IDLE to FULL. If performing the aileron roll at low power settings, keep a nose low attitude to maintain the optimum indicated airspeed; if performing the maneuver at high power settings, climb steeply to avoid excessive airspeed. Enter the roll with the nose of the airplane above the horizon to produce and stabilize and indicated airspeed that is compatible with your power setting. Apply full aileron in the desired direction of the roll with rudder in the same direction as necessary for coordination. Apply slight back pressure on the control column to produce a positive load factor and hold the controls fixed in this position until the roll is completed. A positive load factor held throughout the maneuver avoids a possible flame-out. Enter an Immelmann at 425 knots IAS, FULL power, and pull a constant 3 positive G. Immediately after reaching the vertical climb position, look directly back over your head to locate the horizon as soon as possible. After locating the horizon, continue the maneuver until you reach an inverted dive angle of approximately 40 degrees; then execute the scond half of an aileron roll. The altitude gained from the point of entry to the roll-out point is approximately 6000 to 7000 feet.

CAUTION

The airplane has not been tested for spin characteristics. Therefore, it is important to follow the recommended aerobatic procedures to avoid stalls.

HIGH-SPEED CHARACTERISTICS.

All pilots flying moderate- to high-performance aircraft should have a thorough understanding of the high speed characteristics of the aircraft. Jet airplanes in general are capable of level flight cruise speeds that are very close to the flight limitations of the aircraft, whether these limitations are structural or aerodynamic. The B-57 is no exception.

WITH TIP TANKS.

With tip tanks (figure 5-3) the limiting speed is 444 knots IAS or 0.78 Mach, whichever is lower. It is possible to exceed this structural limit speed at lower altitudes without any particular aerodynamic effects. Above 10,000 feet the limiting speed is 0.78 Mach. This is primarily an aerodynamic limitation but it also approaches the structural limits with tip tanks installed. Between 7,500 feet and 15,000 feet considerable airframe buffet and aileron shake occur at Mach numbers above 0.75. Even though the airspeed at which this occurs is within the placard limitations, sustained cruising at this speed may possibly result in loosening rivets in the ailerons. Above 20,000 feet, the placard speed of 0.78 Mach can be attained with little or no aerodynamic effects. The last few hundredths of the Mach number may be accompanied by light airframe buffet, aileron shake, and occasionally by light. intermittent wing dropping. Actually, the structural limitation on the tip tanks at altitudes above approximately 10,500 feet is 0.79 Mach. Very few airplanes will reach this limitation without excessive aerodynamic effects in the form of buffet, aileron shake, or wing drop.

WITHOUT TIP TANKS.

Without tip tanks (figure 5-4) the airspeed limit below 5000 feet is 513 knots IAS or 0.82 Mach, whichever is less. The airplane can be flown to the structural limit airspeed of 513 knots IAS at all altitudes below 5000 feet without any aerodynamic effects occurring. From 5,000 feet to 20,000 feet, the Mach limit of 0.82 is attained with little aerodynamic effect, although a slight airframe buffet may occur at approximately 0.81 Mach below 5,000 feet. If the speed is advanced beyond this limitation, buffet will usually increase. The Mach limit of 0.82 is established for this altitude range because of the aerodynamic tendencies encountered above it. At approximately 0.83 Mach the aircraft has a light "tucking" tendency, and an increase in speed to 0.85 Mach requires a pull force of three to eight pounds, instead of a push force, to maintain the initial attitude. At airspeeds between 0.86 and 0.87 Mach the airplane pitches up sharply with the amount of pitch-up directly proportional to the entry rate at which you encounter the pitch-up area. If the airplane reaches this area with even small amounts of acceleration in speed, uncontrollable pitch-up occurs, resulting in a high-speed stall at high altitudes. If the stall is

penetrated deeply enough, it generally results in loss of control and entry into a spin. At lower altitudes, the pitch-up may be sufficient magnitude to cause structural failure before the stall is reached. Above 30,000 feet the Mach limitation is 0.83. The characteristics of the airplane are similar to those just discussed, although aerodynamic buffet may not be present at a Mach reading as high as 0.85. However, above 0.85 Mach, wing dropping may occur and a strong pitch-up may result in a high-speed accelerated stall.

ACCELERATION AND DECELERATION.

With Mach readings of 0.82 and 0.85 there is at least a 0.003 Mach margin before any serious aerodynamic effects occur. However, the B-57, like most jet airplanes, is very clean and accelerates extremely fast. Always remain conscious of your airspeed in dives and maneuvers and maintain a margin to regulate your speed within safe limits. The airplane has effective dive brakes which can be used at all speeds to aid in speed regulation. These dive brakes are much more effective at altitudes below 30,000 feet and will not immediately affect speed above that altitude. Decreasing power also helps to decelerate, especially at lower altitudes. Always remember that a standard Machmeter has a rather large speed tolerance. An error of 0.02 and 0.03 is not uncommon at high altitudes. Develop a feel for the aerodynamic characteristics of your plane so that you can correlate the response characteristics of the airplane with the indicated Mach number, and not be totally reliant on the Machmeter. If buffet occurs before the Mach limitation is reached, be very cautious until the Machmeter can be checked for accuracy.

DIVE BRAKES.

The extension of the dive brakes is effective at high speeds and is accompanied by an increase in buffet. There is a very slight nose-down trim change with the extension of the dive brakes.

HORIZONTAL STABILIZER.

Varying the incidence of the horizontal stabilizer trims the airplane longitudinally. Using the entire surface of the horizontal stabilizer requires only small changes in the angle of incidence to make a large trim correction, either nose up or nose down. Therefore, at high indicated airspeeds, it is difficult to make small trim corrections without overtrimming.

ROTARY BOMB CARRIER.

The rotary bomb carrier can be operated with or without stores at any speed. (Refer to Section V for

stores drop speeds.) During the transition movement of the rotary bomb carrier, a moderate pitch-up of the airplane occurs, and when the carrier is fully open, a certain amount of nose-up pitching remains. This may be readily "trimmed-out" with a small amount of nose-down trim. Also, during the transition movement of the bomb carrier, there is some buffeting of the airplane. However, with the carrier fully open, only very moderate amounts of buffeting will be noticed. At an extremely high indicated airspeed, (about 400 to 425 knots) the amount of pitch-up during the transition movement is fairly large and elevator push-force in the neighborhood of 30 to 40 pounds is necessary during operation of the carrier to maintain level flight.

Following the completion of the opening cycle, the push-force will decrease to approximately 20 pounds. During the closing cycle the reverse of the pitching tendency will occur. At high altitudes (even at the limiting Mach number) there is practically no noticeable trim change and practically no buffeting.

SPINS.

WARNING

Intentional spins are prohibited. The procedures given below are merely recommendations since this airplane has not been flight tested for spins.

To recover from an inadvertent spin, use the following spin recovery procedure. Fuel in the tip tanks has an adverse affect on spins and spin recovery. If there is no response to recovery, jettison the tip tanks.

The recovery procedure for erect and inverted spins is the same. The G forces on the pilot indicate the type of spin: You are pressed against the seat during an erect spin, and pressed against the seat-belt during an inverted spin. The recovery procedure is:

- 1. Gear and flaps-UP.
- 2. Throttle-IDLE.
- 3. Ailerons-Neutral.
- 4. Control column-Aft.
- Rudder—Against the spin until rotation stops, then neutralize.
- Back pressure on the control column—Release after rotation stops. If oscillation accompanies the spin, apply rudder against the rotation when the nose is well below the horizon.

stall speed KNOTS IAS

| ANGLE OF BANK | | 0° | 30° | 45° | 60° |
|---|------------------------|------|------|------|------|
| LOAD FACTOR | | 1.0G | 1.2G | 1.4G | 2.0G |
| CRUISING CONFIGURATION OR TAKE-OFF WITH GEAR DOWN | GROSS WT—LBS 28,000 | 93 | 99 | 110 | 131 |
| | 35,000 | 104 | 111 | 123 | 146 |
| | 45,000 | 119 | 126 | 139 | 166 |
| | 55,000 | 130 | 140 | 155 | 183 |
| FLAPS AT 60° OR LANDING FLAPS AT 60° | GROSS WT-LBS 28,000 | 81 | 88 | 97 | 115 |
| | 35,000 | 91 | 98 | 108 | 129 |
| | 45,000 | 103 | 111 | 123 | 146 |
| GEAR DOWN | 55,000 | 114 | 122 | 136 | 161 |

DATAESTIMATED 4-1-56

. 11670

Figure 6-2

Note

Wind tunnel tests of spins and spin characteristics are being made at the present time. Results of these tests will be included in the handbook when the tests are completed.

LOW-SPEED CHARACTERISTICS.

The B-57B has good handling characteristics at low speeds. Controls are effective down to the stall and response is good. Sufficient horizontal stabilizer trim is available for all normal conditions. Should horizontal stabilizer trim failure occur with the trim setting anywhere between full nose-up or full nose-down, there is sufficient control to override the trim system at speeds below 250 knots. (Refer to HORIZONTAL STABILIZER SYSTEM FAILURE, Section III.) High rudder-pedal forces result in a minimum single-engine control speed of 155 knots. These forces cannot be eliminated by use of trim.

STALLS.

The airplane has extremely safe stall characteristics although normal pre-stall buffet is hard to detect with the gear and flaps extended. Power-off and power-on stalls have like characteristics. (See figure 6-2.)

STALLS WITH GEAR AND FLAPS RETRACTED.

Stall warning in the form of general airframe roughness occurs 10 to 15 knots above the stalling speed. As the speed is reduced, the roughness increases and near the stall the control column oscillates slightly. At the stall a mild aileron snatch occurs. Aileron snatching characteristics are aggravated by a sideslip allowed to occur during the approach to the stall. There is sufficient rudder control to control any sideslips that might occur. The airplane pitches mildly nose down at the stall and may roll slightly either way. Recovery is easily made with or without power and sufficient aileron control is available throughout the stall.

dive recovery

4G ALTITUDE LOSS CONSTANT RECOVERY

40,000 ◀ ALTITUDE 30,000 ◀ AT START OF 20,000 ◀ RECOVERY (FEET) 10,000 ◀ 0 4 2,000 ◀ **ALTITUDE** 4,000 ◀ LOSS DURING RECOVERY 70° 6,000 ◀ (FEET) 8,000 ◀ 90 10,000 ◀

HOW TO USE CHART



Enter chart at altitude line nearest actual altitude at start of pull-out. (For example, 10,000 ft.)



On scale along altitude line, select point nearest the IAS at which pull-out is started (400 knots IAS).



Sight vertically down to point on curve of dive angle (90°) directly below airspeed.



Sight back horizontally to scale at left to read altitude lost during pull-out, (Constant 4G pull-out-6000 ft.)



DATA ESTIMATED 4-1-56

Figure 6-3 (Sheet 1 of 2)

dive recovery




Figure 6-3 (Sheet 2 of 2)

STALL WITH GEAR AND FLAPS EXTENDED.

Stall characteristics are generally the same as with gear and flaps retracted. The warning buffet is less noticeable because of general airframe roughness with the flaps and gear extended. Stall speeds are approximately 10 knots lower with the gear and flaps extended. See figure 6–2 for stall speeds at various gross weights and configurations.

Note

Pre-stalled buffet is hard to detect with the gear and flaps extended.

ACCELERATED STALLS.

Accelerated stall characteristics are the same as those previously mentioned and sufficient warning is present to prevent inadvertent entry into such a condition. Recovery from such a stall is made simply by relieving the load. The maximum accelerations attainable decrease with altitude and speed; the stick forces also decrease with altitude.

PRACTICE STALLS.

In performing practice stalls, trim the airplane to approach speed, approximately 130 knots, and complete the stall without further use of the trim. Trimming into the stall is similar to holding the stick back after the stall occurs and makes stall recovery difficult. Perform practice stalls at altitudes sufficient to provide a safe recovery distance. In general, 10,000 feet above the terrain is considered satisfactory.

DIVES.

Control forces during dives are reasonable and handling characteristics are good. Be careful not to exceed the airspeed and acceleration limitations stated in Section V. Figure 6–3 shows the altitude and acceleration required to recover from dives at various altitudes. Retard throttles and extend dive and speed brakes if airspeed approaches the limit. Stick forces will be highest at high airspeeds and with a forward cg condition. Use longitudinal trim cautiously during recovery because overtrimming can produce G forces in excess of the airplane's limitations.

LANDING.

The B-57 lands in a conventional manner and you

may follow a normal pattern. (See figure 2–7.) Extend the flaps at any speed below 170 knots IAS with approximately 15 pounds of push-force on the control column to prevent nose pitch-up. A slight buffet may accompany flap extension.

Make a conventional nose-high landing. There is little or no danger of striking the tail skid. At normal landing weights, the airplane can be stopped in less than 3,000 feet, and even for landings at high gross weights, a 5,000-foot runway is adequate. For landing distances see Appendix I.

Below gross weights of 38,000 pounds, be careful when applying the brakes to keep the tires from skidding. Above 40,000 pounds, the braking effect is noticeably less than at low gross weights. Pilots who have made most of their landings at low gross weights should remember this when undertaking heavy-weight landings.

Landing with large amounts of asymmetric loading in the tip tanks requires caution. Never attempt a landing with one tip tank full and the other empty unless it is impossible to jettison the tanks. If a landing is necessary in this configuration, make your "touchdown" at a speed of approximately 130 knots to maintain lateral control with full aileron. To repeat, attempt such a landing only under the best of circumstances. If possible, at least half the fuel in the full tank should be transferred or used.

When landing without the use of flaps, add approximately ten knots to speeds used during normal landing.


For a go-around, make your decision as soon as possible and keep in mind that a jet engine does not accelerate as rapidly as a reciprocating engine. Advance the throttles to FULL smoothly and be alert for asymmetrical engine acceleration which produces varying amounts of yaw. Retract the flaps before reaching 170 knots IAS and retract the landing gear after establishing that contact with the ground will definitely not be made. The landing gear should be retracted before reaching 200 knots IAS and dive brakes can be retracted after completing the procedures just mentioned. Rapid trim adjustment is necessary to aid control.


ANGLE OF ATTACK RELATIONSHIP CURVE.

Figure 6-4 is provided to aid in familiarization with the flight characteristics of the airplane. This angle of attack relationship curve indicates the angle of attack of the airplane at sea level for various airspeeds and attitudes. Included on the chart is an example of its use.


angle of attack relationship curve

GLIDES OR DIVES





Section VII



SYSTEMS OPERATION

11/70

TABLE OF CONTENTS

| | Page | | Page |
|--------|------|-----------------|------|
| ENCINE | 7_1 | FUEL MANAGEMENT | 7-3 |

ENGINE.

ENGINE ACCELERATION.

The maximum permissible exhaust gas temperature during an acceleration appears in Section V under ENGINE LIMITATIONS. If any of these limitations are exceeded during an acceleration, retard the throttle until the temperature has dropped below the steady-state limit. Then accelerate the engine slowly by advancing the throttle gradually so that you do not exceed the acceleration temperature limit.

COMPRESSOR STALL.

The possibility of compressor stall is practically eliminated when the normal engine fuel control system is in operation. Compressor stall may occur after any rapid advancement of the throttle if either of the following conditions prevails: a malfunction develops in the normal engine fuel control system, or the emergency fuel control system is set in operation. If the emergency fuel control system is in manual operation, rapid throttle advancements inject more fuel into the combustion chamber than the engine can utilize for acceleration at the existing rpm. As this additional fuel burns, the combustion pressures increase. Because of these increases in pressure, there is a corresponding increase in the pressure against the compressor discharge air. This increase of compressor discharge air pressure results in a breakdown of the airflow through the last stages of the compressor. This condition is known as compressor stall. As a result of this stall, the mass airflow through the compressor is reduced and causes a reduction in airflow through the turbine, thereby decreasing the energy available to the turbine wheel. If the engine is allowed to continue operating in this stalled condition, the temperatures of the burning gases increases until engine failure occurs as a result of damage to the turbine. Compressor stall is accompanied by a roaring, pulsating noise and may occur before any engine instrument reflects the existing conditions. In addition to the roaring, pulsating noise, other indications of a compressor stall are a rapidly rising exhaust temperature, steady or decreasing rpm, a long flame from the tail pipe, loss of thrust, and a heavy engine vibration. Immediately upon hearing the roaring noise, check to see that the emergency fuel control switches are OFF. If they are OFF, retard the throttle, since there may be malfunctioning of the normal fuel control system. If, after the throttle is retarded, the exhaust gas temperatures stabilize at a normal value, readvance the throttle. The exhaust temperature rise should be normal during the throttle advancement. If it is not, retard the throttle again and place the emergency fuel control switch to ON. If, after retarding the throttle and switching to the emergency fuel control system, the exhaust temperature stabilizes at the normal value, slowly advance the throttle. If the exhaust temperature continues to drop after retarding the throttle, you have a flame-out and should try an air start.

FLAME-OUT.

Flame-out is exactly what the name implies and it can occur during acceleration or deceleration of the engine. Acceleration flame-out, like compressor stall, results when more fuel is injected into the combustion chamber than the engine can utilize for acceleration at the existing rpm. The difference is that the mixture which is injected into the combustion chamber is so rich that it cannot burn and it extinguishes the flame. Flame-out may also occur during rapid engine decelerations when the amount of fuel injected into the combustion chamber may be too lean to sustain combustion at the existing rpm. Flame-out is indicated by loss of thrust, drop in exhaust temperature, and possibly by a loud noise similar to engine torching. If flame-out occurs, place the throttles in OFF and try an air start.

ENGINE NOISE AND ROUGHNESS.

In flight, any unusual noise or roughness that can be attributed to the engine and cannot be eliminated by variations in engine speed or altitude indicates that some mechanical failure is present. Operate all hydraulically operated equipment to determine if chatter in the hydraulic system is the cause. Placing the gun compressor circuit breaker in OFF will eliminate compressor vibration. If incipient failure of the main bearing or a loose engine stabilizing mount is indicated or if excessive engine noise or roughness persists, shut down the faulty engine and land as soon as possible.

ENGINE EXHAUST TEMPERATURE VARIATION.

Turbo-jet engines equipped with fixed-area exhaust nozzles do not provide for direct control of exhaust temperature. Therefore, you must be familiar with certain engine characteristics to obtain maximum airplane performance. This airplane has a fixed-area engine-exhaust nozzle. The only direct control over exhaust temperature is adjusting the engine rpm. The exhaust temperature will vary with changes in the temperature and density of the engine inlet air, as well as with changing thermal conditions within the engine. Generally, an increase in outside air temperature or an increase in altitude causes an increase in the exhaust temperature, while an increase in airspeed decreases the exhaust temperature. Since all three factors can change singly or together, their effect on exhaust temperature will not be consistent for any given rpm. You can expect the exhaust temperature to be relatively high at 100% rpm when the airplane is not moving, but as the airspeed increases during a take-off run, the exhaust temperature will drop well below the maximum operating limit. Since take-offs are made with unstabilized engines, the exhaust temperatures will remain below the maximum limit until it stabilizes at steady-state operation. If the exhaust temperature rises above the maximum limitation after the engine has stabilized, you will have to retard the throttle to bring the temperature down to normal.

SMOKE FROM TURBINES DURING SHUTDOWN.

During engine shutdown, fuel may accumulate in the turbine housing where heat from the turbine section may cause it to boil. Although there are drains for this accumulated fuel, some fuel may still remain. The presence of this residual fuel in the engine is indicated by the emission of fuel vapor or smoke from the tailpipe of the intake duct, depending on the

ground wind condition. Boiling fuel, which is indicated by the presence of white fuel vapor, is not injurious to the engine but does create a hazard to personnel. The vapor may ignite with explosive violence if allowed to accumulate. The appearance of black smoke coming out of the tailpipe indicates that fuel is burning. Extinguish the burning with a CO₂ extinguisher or serious damage to the engine may result.

WARNING

An accumulation of fuel in the tailpipe may explode with serious injury to personnel. All personnel should keep clear of the tailpipe for at least three minutes after shutting down the engine and should keep away at all times when fuel vapor or smoke issues from the engine.

FUEL MANAGEMENT.

The No. 1 fuselage tanks is the main service tank. The normal fuel management procedure consists of transferring fuel from all other tanks to the No. 1 fuselage tank. Since the fuel system is controlled manually, the pilot must constantly check the fuel quantity. The change in weight distribution due to fuel consumption is the most important factor affecting the center of gravity. The consumption of all fuel from the No. 2 fuselage tank, before using the fuel from the other tanks, eliminates the center of gravity problem.

NORMAL FUEL MANAGEMENT PROCEDURE.

To transfer fuel to the No. 1 fuselage tank:

- 1. Align the No. 2 fuselage tank selector switch to allow fuel to flow to the No. 1 fuselage tank.
- 2. Allow the No. 2 fuselage tank to empty and turn off the No. 2 fuselage tank selector switch.
- For airplane using a ferry tank, place the ferry tank pump switch in the PUMP position. When the ferry tank empties (light indication), return the switch to the OFF position.
- Align the tip tank-wing tank selector switches to allow fuel to flow from the tip tanks to the No. 1 fuselage tank and allow the tip tanks to empty.
- Align the tip tank-wing tank selector switches to allow fuel to flow from the wing tanks to the No. 1 fuselage tank. After emptying the

- wing tanks, rotate the tip tank-wing tank selector switches to OFF.
- Use the fuel in the No. 1 fuselage tank for the remainder of the mission.

Note

To consume all fuel in the tanks and to compensate for any asymmetrical fuel feeding from the wing and tip tanks, delay switching tanks for a few minutes after noting empty tank indications (indicator light or quantity gage). Fuel in the No. 1 fuselage to maintains engine operation for this period.

ALTERNATE FUEL MANAGEMENT PROCEDURE.

During operations using the NORMAL FUEL MAN-AGEMENT PROCEDURE, approximately 70 gallons of fuel siphon out of the wing tanks through the fuel vents during take-off and climb. To avoid loss of this fuel, use alternate procedure for fuel management. For starting, taxiing, take-off, and climb:

- Align the tip tank-wing tank selector switches to allow fuel to flow from the wing tanks to the No. 1 fuselage tank.
- After ten minutes of flying, turn the tip tankwing tank selector switches OFF and follow the NORMAL FUEL MANAGEMENT PROCE-DURE.

EMERGENCY FUEL MANAGEMENT.

Under emergency conditions, fuel may be transferred from the No. 2 fuselage tank, the tip tanks, or the wing tanks directly to the engines by placing the desired tank knobs in the flow position, placing the fuel transfer valve knob in the flow-to-engines position.

When fuel is transferred from No. 2 fuselage tank, the tip tanks, or the wing tanks directly to the engines, closely observe the quantity of fuel remaining in the tanks selected (light indication of fuel quantity indicator) to avoid a flame-out when the tanks empty.

The maximum rate of fuel consumption for both engines at sea level with standard day temperature and both engines operating at 100% rpm is 17,000 pounds per hour. The rate of transfer of fuel from the No. 2 fuselage tank or the wing tanks is 18,000 to 19,000 pounds per hour which is sufficient for normal engine operation when bypassing the No. 1 fuselage tank. However, the rate of transfer of fuel from both tip tanks is approximately 7,000 pounds per hour which will not sustain normal engine oaperation under all conditions. If the No. 1 fuselage tank is bypassed because the boost pumps in that tank are inoperative

above 25,000 feet, fuel flow from the tip tanks will sustain normal engine operation with the aid of the fuel that is normally drawn from the No. 1 fuselage tank by the engine-driven fuel pump without the No. 1 fuselage tank boost pumps operating. In discussing this emergency it is assumed that the tip tank pressurization system is operating normally. If no fuel is available from the No. 1 fuselage tank fuel flow from the tip tanks sustain engine operation only at high altitudes where fuel consumption is at a minimum. In this condition, fuel flow from the wing tanks is selected immediately after the tip tank low-level indicator illuminates to avoid a flame-out when the tip tank fuel supply is exhausted.

AUTOMATICALLY OPENING SEAT BELT AND PARACHUTE.

The automatically opening seat belt and parachute extend the maximum and minimum altitudes for successful escape with the ejection seat. In a low-altitude ejection, the use of the automatic belt reduces the time required for separation from the seat and the opening of an automatically opening parachute. In a high-altitude ejection, using the automatic belt and parachute avoids the opening of the parachute at an altitude where the lack of oxygen would reduce the possibility of a safe descent. Also, the automatic belt retains the occupant in the seat for a sufficient length of time (2.5 seconds) to take advantage of the slower rate of deceleration caused by the combined weight of the seat and occupant.

WARNING

Never release the belt manually prior to ejection, since this causes immediate separation of the seat and occupant. At high speed without the protection of the seat, the parachute could open inadvertently and the opening shock of the parachute may cause fatal injuries. If the belt fails to open automatically after ejection, the occupant can manually release the belt and under these circumstances, the occupant must open the parachute manually.

There may be a tendency for the user to distrust the automatic equipment; however, the automatic belt and parachute have been tested thoroughly and are completely reliable. The best human reaction is slower than the operation of the automatic belt. Also, the user may not be conscious after an actual emergency ejection. It is possible to release the belt manually anytime during or after ejection. Likewise, the user may open the parachute manually anytime before the operation of the aneroid-release device.



Section VIII



CREW DUTIES

11679

TABLE OF CONTENTS

| | | Page | | P | age |
|--------------|---|-------|--------------------------|---|-----|
| INTRODUCTION | *************************************** | 8-1 | PILOT'S RESPONSIBILITIES | | 8-1 |
| | OBSERVER'S RESE | ONSIB | ILITIES 8–2 | | |

INTRODUCTION.

Each crew member has primary duties and additional duties. The primary duties of the crew member are explained by his title, for example, pilot and observer. The additional duties are those which must be performed to insure proper flight of the airplane and to support crew safety during ground operation and flight. It is the responsibility of each crew member to be familiar with each item of equipment and to be able to inspect it thoroughly for any irregularities. Do not let this inspection become so routine that you check it off as completed without doing a thorough job. Remember, it is not just your life that is at stake but also the life of your crew member and the success of your mission.

PILOT'S RESPONSIBILITIES.

The pilot is responsible for the issuance of all instructions governing flight operation. His duties and functions are given in NORMAL PROCEDURES, Section II. His responsibilities with regard to formal crew briefing are discussed in the following paragraphs.

CREW BRIEFING.

The pilot should conduct a formal crew briefing as soon as possible after detailed mission planning. The first item he should cover in his briefing is a recapitulation of the mission plan to insure that the ob-

server is completely familiar with the purpose of the mission. If any phase of the mission seems unclear to the observer, the pilot should completely review that phase. Before dismissing the observer, he should discuss personal equipment to be carried and make certain that the observer is aware of the schedule for reporting to the airplane and of take-off time. If the pilot has paid close attention to the premission planning and has conducted his briefing well, he will have successfully surmounted one of the most difficult phases of flying a mission.

PERSONAL EQUIPMENT REQUIREMENTS.

Personal equipment plays such an important part in the safety and comfort of the crew that the pilot must never assume that the observer is adequately equipped. It is his responsibility to make certain that the observer knows what equipment he must carry and to hold a formal inspection before boarding the plane. In the briefing that will be conducted prior to flight, either the operations officer or the pilot will specify the equipment needed for the flight.

Common sense will tell you that if you are scheduled for any high-altitude work you will need heavy clothing, oxygen equipment, and bail-out bottles, plus your normal gear. Keep the cabin heat down when flying over cold regions so that the crew may wear their heavy clothing in comfort. Thus, if an emergency occurs, the crew will be properly clothed for survival.

OBSERVER'S RESPONSIBILITIES.

The primary duty of the observer is, naturally, navigation. The navigation equipment includes shoran equipment, compasses, and a latitude and longitude computer, all of which are located in the observer's station. In addition to his primary duties, the navigator has the duties listed below.

BEFORE EXTERIOR INSPECTION.

Enter the airplane and perform the following inspection at the aft crew station.

| Installed in arm- rest |
|---------------------------|
| rest |
| In |
| OFF |
| In |
| |
| |
| Adjusted and |
| |

connected

| Seat and rudder pedals | Adjusted |
|-------------------------------------|--------------|
| Inertia reel | Unlocked |
| Interphone function selector switch | HOT-MIC |
| Interphone audio-mixing | As necessary |

OXYGEN SYSTEM.

- a. Place the diluter lever in NORMAL OXYGEN and blow gently into the oxygen regulator hose.
 (A resistance to blowing indicates satisfactory operation of the demand diaphragm.)
- b. Place the diluter lever in 100% OXYGEN and blow gently into the oxygen regulator hose. (A resistance to blowing indicates satisfactory operation of the demand diaphragm and diluter air valve.)
- c. Don the mask and connect the mask to the regulator hose. (Breathe normally and note operation of the blinker dial.)
- d. Hold breath and place the EMERGENCY pressure lever to the right or left. (A positive pressure felt within the mask indicates proper emergency oxygen flow.)
- e. Depress the EMERGENCY pressure lever while holding the breath to test the mask for leakage. (A properly fitted mask will retain the EMER-GENCY oxygen pressure until normal breathing is resumed.)
- Make sure the mask hose fittings are properly seated and secure.
- g. Check the mask hose attachment to the parachute.

| AIC filter switch | As desired |
|--|------------------------|
| Circuit breakers | In |
| Clock | Set |
| Altimeter | Set to field elevation |
| Spotlight switch | As desired |
| Radio compass function selector switch | OFF |
| Lighting control switches | As desired |
| Fire extinguisher | Secure |
| C-4A light | Secure and off |
| | |

BEFORE TAXIING.

| Indicator and warning lights | Press to test |
|------------------------------|---|
| Radio compass | Obtain control and check for proper operation |
| Seat safety pin | Remove and stow |

and radio cord

DURING FLIGHT.

It is assumed that the observer fully understands his duties as a navigator. The navigation equipment is discussed in Section IV.

C-4A light OFF

Lighting control switches OFF

BEFORE LEAVING AIRPLANE.

AFTER LANDING.

Radio compass


OFF

Seat safety pin

Install

Oxygen supply lever

OFF



Section IX



ALL WEATHER OPERATIONS

11709

TABLE OF CONTENTS

| | Page | | Page |
|------------------------------|------|--------------------------|------|
| GENERAL INSTRUMENT FLIGHT | 9-1 | FLIGHT IN TURBULENCE AND | |
| INSTRUMENT FLIGHT PROCEDURES | 9–1 | THUNDERSTORMS | 5573 |
| INSTRUMENT APPROACHES | 9–2 | HOT-WEATHER PROCEDURES | |
| ICE, SNOW, AND RAIN | 9-3 | DESERT PROCEDURES | 9–8 |
| | | | |

GENERAL INSTRUMENT FLIGHT.

Flying the B-57B airplane in instrument weather conditions requires instrument proficiency and thorough preflight planning. In planning for instrument flight, remember to consider the fuel requirements for completing an instrument let down and approach. This additional requirement reduces maximum range and endurance accordingly. The airplane has good stability characteristics and flight-handling qualities for weather flying. The limitations on the aircraft result primarily from the lack of navigational equipment and anti-icing provisions. Except for some repetition necessary for emphasis or continuity of thought, this

section contains only those procedures that differ from, or are in addition to, the normal operating instructions covered in Section II.

INSTRUMENT FLIGHT PROCEDURES.

ON ENTERING THE AIRCRAFT.

- 1. External power-ON.
- 2. Inverters-ON.
- APX-6A IFF master switch—STANDBY, if use is anticipated.

- Radio compass—check all positions. Set to first unroute station frequency or to local approach radio fix station frequency.
- UHF radio—check all channels pertinent to instrument flight.
- 6. Pitot heater—check operation (with crew chief).
- Delay engine start until immediate take-off is assured. Conserve fuel by performing as many operations as possible before starting engines, including ARTC approval and clearance.

TAXIING.

- Turn-and-slip indicator—check operation during taxi turns.
- Directional indicator—check for proper operation.

BEFORE TAKE-OFF.

- Attitude indicator—check operation and adjust the miniature airplane to align with the horizon bar.
- Set the runway heading to the top of the directional indicator.
- 3. Pitot heater—ON as required.

TAKE-OFF AND INITIAL CLIMB PROCEDURES.

- Maintain direction with brakes until the rudder becomes effective at approximately 50 knots.
- At approximately 110 knots during take-off roll, raise the nose to position the miniature airplane one bar width above the horizon bar and allow the airplane to fly off at 130 to 140 knots.
- Gear UP, when the upward trend of both the altimeter and vertical velocity indicator show that the aircraft is definitely climbing.

CAUTION

Maintain airspeed below 200 knots until the gear locks up (approximately 7 to 10 seconds).

Maintain take-off attitude until the airplane accelerates to its best climb speed, and anticipate
a rate of climb of approximately 4000 feet per
minute at 96 percent rpm.

TURNS.

To keep control forces down and reduce your work-

load, limit the maximum angle of bank in climbing and level turns to 30 degrees. Steep turns also lead to over controlling the airplane in instrument procedures.

COMMUNICATION AND NAVIGATION EQUIPMENT.

The AN/ARN-6 radio compass is susceptible to precipitation static and false indications in the vicinity of a thunderstorm. Switching to the loop position and rotating the needle 90° from the station bearing and/ or reducing IAS and/or changing altitude usually improves the reception.

DESCENTS.

The optimum power setting for fuel economy during descent is IDLE. The recommended descent airspeed is 250 knots or limit Mach, whichever is lower, with landing gear and flaps retracted and dive brakes extended. Increasing the descent airspeed for higher rate of descent through icing layers slightly reduces the handling characteristics. Decreasing the descent airspeed for more comfortable turbulence penetration results in a small penalty in fuel consumption. Normally, thirty degrees of bank is the limit for high-speed descending turns.

INSTRUMENT LOITERING AND HOLDING. (MAXIMUM ENDURANCE)

For airspeeds, refer to the performance charts in Appendix I. When making turns during instrument loiter, add power as necessary to hold the recommended IAS.

INSTRUMENT APPROACHES.

GENERAL.

The stability and handling characteristics for instrument flight are excellent in all configurations; however, the dive brakes are not effective at low airspeeds and their use is not recommended for approach patterns. The use of wing flaps is not recommended for instrument approaches other than GCA finals, due to the fuel penalty and buffeting encountered. Visibility in moderate precipitation is good. Letdowns and approaches on a single engine can be made satisfactorily. Normal penetrations can be made from initial penetration altitude and go-around characteristics are satisfactory. For minimum landing roll, lower the nose and brake immediately. See figure 9-6 for landing roll distances.

RADAR RECOVERY. (See figure 9-1.)

The handling characteristics and stability in instrument conditions facilitate satisfactory radar recovering procedures. Radar control for the letdown and the turn on to final approach (GCA) offers maximum economy of fuel and time.

CAUTION

Radar recovery in precipitation or heavy clouds is not effective without an operational AN/APX-6 (IFF).

RADIO RANGE AND JET PENETRATION. (See figures 9-2, 9-3.)

If icing is anticipated, retract the dive brakes to prevent icing of the speed and dive brakes. Also, when descending through icing layers, increase penetration speed to 350 knots but within the limit Mach in order to decrease intake duct icing. In the event icing is built up while dive brakes are retracted, leave dive brakes extended and descend at 250 knots or limit Mach, whichever is lower. For a penetration turn use the 90–270° turn method, unless another procedure is specified.

WARNING

Actual altitude during high rate descents may be as much as 1,000 feet lower than indicated altitude, because of altimeter lag.

MISSED APPROACH GO-AROUND PROCEDURE. (See figures 9-2, 9-4.)

Acceleration characteristics of the aircraft are excellent. The missed approach procedure is similar to the go-around procedure described in Section II.

- Advance throttles to FULL, level off and check for acceleration. Be alert for asymmetrical power conditions resulting from uneven engine acceleration.
- Retract flaps below 170 knots IAS and landing gear below 200 knots IAS.
- 3. Execute missed-approach for the particular field.
- 4. Go-around on a single engine can be made without loss of altitude at 155 knots IAS. At slower speeds, accelerate to at least 155 knots before attempting to hold altitude. From 135 knots, you will lose approximately 400 feet of altitude

in accelerating to 155 knots. Advance the throttle to at least 90 percent rpm as soon as possible and retract flaps and gear. As rudder control becomes more effective with increasing airspeed, advance the throttles to FULL for climb.

WARNING

When making a single-engine approach at less than 500 feet with gear and flaps extended, you are committed to land. Under these conditions, do not attempt a go-around.

GROUND CONTROLLED APPROACH (GCA). (See figures 9-4, 9-5.)

The airplane has good handling qualities during ground control approaches. However, keep in mind that during heavy precipitation, the GCA controller may have some difficulty in keeping the airplane on the scope. Try to anticipate this condition.

ICE, SNOW, AND RAIN.

Normally, the heaviest icing takes place in clouds with strong vertical currents. Icing conditions in stratus clouds are generally light to moderate, but heavy icing conditions may occur in this type of cloud. Prolonged flights through moderate icing can build up as much ice as a short flight through heavy icing conditions. You can expect icing when the temperature is between approximately -10°C (14°F) and 5°C (41°F) if fog is present or the dew point is within 4°C (7°F) of the ambient temperature. From 0°C (32°F) to approximately 5°C (41°F) and the dew point within 4°C (7°F) of the ambient temperature, conditions exist under which jet engine icing can occur without wing icing. The heaviest type of ice formation generally occurs about -5°C (23°F). There is no anti-icing equipment on this airplane except for the windshield. Therefore, if you can avoid flight through icing conditions, make every effort to do so. Ice can build up on the engine's inlet guide vanes when the airplane is flown through areas where icing conditions prevail and may occur when no evidence of ice can be visually detected on the airplane. Icing on the guide vanes restricts the flow of inlet air thus causing the loss of thrust and a rapid rise in exhaust gas temperatures. The fuel control attempts to control the loss in engine rpm by adding more fuel to the engine, thereby worsening the condition. Under

severe conditions, engine failure can occur in four minutes or less. Therefore, to avoid engine icing, proceed as follows:

- Avoid flying into areas where icing conditions may prevail, if at all possible.
- If the ambient temperature is within the approximate range of 0°C (32°F) to 5°C (41°F) and sufficient moisture is present in the atmosphere:
 - Reduce airspeed, if practicable, to minimize the rate of ice buildup.
 - b. Change altitude rapidly by climb or descent in layer clouds or vary your course as necessary to avoid cloud formation.
 - c. Observe the exhaust gas temperature and reduce engine rpm as necessary to prevent excessive exhaust gas temperature.

WARNING

Do not attempt flight when icing conditions are forecasted at the pattern level of the proposed destination.

FLIGHT IN TURBULENCE AND THUNDERSTORMS.

BEFORE TAKE-OFF.

- Make a complete analysis of the existing and forecast weather conditions to determine thunderstorm areas, and prepare a flight plan which avoids flight through thunderstorms.
- Check the proper operation of all flight instruments, navigation equipment, pitot heater, instrument panel lights, and the defogging systems before undertaking any instrument flights and before attempting to fly through a thunderstorm

APPROACHING THE STORM.

Power settings and the attitude of the airplane are the keys to the proper flight technique in turbulent air. The power settings and airplane attitude required for desired penetration airspeed should be established before entering the storm. If you maintain these power settings and attitude throughout the storm, the result will be a constant airspeed regardless of any false readings of the airspeed indicator. The most turbuent air in a thunderstorm is generally between 10,000 and 20,000 feet. The least turbulence is usually above 30,000 feet or below 10,000 feet, and the recommended penetration procedure is to penetrate a thunderstorm above or below these altitudes. Icing conditions are very common near the top of these storms. See ICE, SNOW, AND RAIN in this section. If the storm cannot be seen, you can determine its approximate nearness by radio crash static. Use the following procedure to prepare the airplane for entry into the turbulent area:

- Adjust the throttles as necessary to obtain an airspeed derived from the Extremely Gusty Air Chart.
- 2. Turn the pitot heat switch on.
- 3. Trim the airplane.
- 4. Check the gyro instruments.
- Lock the seat belt and adjust the shoulder harness (both stations).
- Turn off any radio equipment which static has rendered useless.
- 7. Turn on the thunderstorm lights.

Note

Do not lower the landing gear or flaps, because they will merely decrease the aerodynamic efficiency of the airplane.

IN THE STORM.

To maintain safe flight after entering the storm, follow this procedure:

- Expect turbulence, precipitation, and lightning; do not allow them to cause undue concern.
- Maintain power settings and attitudes throughout the storm. If they are held constant, airspeed will remain constant regardless of the reading of the airspeed indicator.
- 3. Devote all attention to flying the airplane.
- Concentrate principally on holding a level attitude by using the attitude indicator.
- Maintain the original headings. Do not make any turns unless it is absolutely necessary.
- Use as little elevator control as possible to maintain attitude in order to minimize stress on the airplane.

Note

The altimeter may be unreliable in thunderstorms because of differential barometric pressures. Therefore, make allowance for this error when determining the minimum safe altitude. It may amount to several thousand feet. The vertical velocity indicator is of little value during periods of high turbulence and should not be referred to for altitude indication.

WARNING

Do not fly through thunderstorms unless there is no alternative. If flight through a thunderstorm cannot be avoided, follow the preceding steps.

NIGHT FLYING.

Night flying imposes no particular problem except that the landing light must supplement the taxi lights when taxiing in dark areas.

CAUTION

Limit the continuous use of landing light to two minutes during ground operation.

COLD-WEATHER PROCEDURES.

Most cold weather difficulties will be encountered on the ground. The following instructions are additional to the normal procedures in Section II. Follow them when operating in regions of extremely cold weather. Icing conditions in flight will not be covered here as they are discussed under ice, snow, and rain in this section.

BEFORE ENTERING THE AIRPLANE.

- Check that the pressurized cabin has been preheated if the temperature is below -18°C (0°F).
- Inspect the fuel tank vents and the pitot tube and remove any ice which may be present.
- Check the entire airframe surface and the landing gear of the airplane for freedom from frost, snow, or ice. Brush off light snow or frost andremove any ice which may have formed by

using a direct flow of hot air from a portable heater.

CAUTION

- All ice and snow must be removed from the airplane.
- Chipping or scraping ice may damage the airplane.
- 4. Check all visible hydraulic lines and fittings for signs of leakage.

ON ENTERING THE AIRPLANE.

- Carefully check surface controls and trim devices for proper operation.
- If the temperature is -29°C (-20°F), attempt normal start. If unsuccessful, make a second starting attempt. Heat from the first starting attempt should then allow a satisfactory start. If at all possible, use cartridges which have been stored in a warm place.
- 3. If the ambient temperature is -40°C (-40°F) or less, use a portable heater to blow hot air into the engine intake duct for 20 to 30 minutes to insure a successful start and to prevent the starter from being damaged if ice has seized the compressor rotor.
- 4. Operate the surface controls several times to insure that no ice has formed in the hinges.

STARTING ENGINES.

- 1. Start the engines in a normal manner.
- If there is no oil pressure within 30 seconds after starting, or if the pressure drops after a few minutes of ground operation, shut down the engines and check for clogged oil lines.

Note

During cold weather starts, the oil pressure may temporarily exceed the maximum limits until the oil temperature approaches normal.

WARM-UP AND GROUND TESTS.

1. Inspect all instruments for normal operation.

CAUTION

Do not turn on the unneeded electrical equipment until the generators show output.

- Operate all the hydraulic circuits except the bomb door to check for proper operation.
- 3. Use cabin heat as desired.

TAXIING.

- Keep the engines running at a high enough rpm to keep up the generator output while taxiing, as low temperatures decrease the battery output.
- Increase the normal taxi interval between airplanes and reduce the taxiing speed for approaches on ice or snow-covered area.

Note

Take extreme care when maneuvering near other aircraft. The blast and heat may blow snow and slush which will freeze into ice on contact.

CAUTION

Do not taxi in deep snow or slush because steering will be more difficult and brakes, landing gear, and flaps are apt to freeze after takeoff. Use extreme caution when taxiing on ice-covered taxi strips or runways because excessive speeds or crosswinds can start a skid, and remember that brakes are ineffective on ice.

Note

Taxi time on snow and ice will be longer than under normal conditions; therefore, plan the shortest route to take-off to reduce fuel consumption.

BEFORE TAKE-OFF.

CAUTION

Make sure that all snow is removed from the runway or is firmly packed. If snow has been removed from the runway, be sure that the banks are piled far enough from the runway to permit a safe takeoff.

WARNING

Do not attempt a take-off with a badly frosted canopy, or with snow, ice, or frost on the wings or control surfaces.

TAKE-OFF.

- If precipitation is present, or if icing conditions are expected during or immediately following take-off, place the pitot heat switch to ON and turn on the windshield anti-icing system.
- Apply the brakes and advance the throttles to take-off power. If the airplane begins to slide before take-off power is reached, immediately release the brakes and commence the take-off.

Note

Continue the engine check during the early part of the take-off run. If any portion of the engine check is not satisfactory, retard the throttles and bring the airplane to a normal stop.

AFTER TAKE-OFF.

- After take-off from a snow or slush-covered field, operate the flaps and the landing gear several times to prevent their freezing in the up position.
- Watch closely for icing on critical areas, and if ice begins to form, attempt flight in a more suitable area, if possible.
- Adjust the cabin air selector switch to give the desired cabin temperature.
- Under certain conditions, fog may form in the cabin and restrict visibility. If this should happen, turn the cabin temperature control rheostat to WARM until the fog clears.

DESCENT.

Note

At least 30 minutes before a descent, pull the defogging blower knob out (ON) and place the defogging hot air switch in the DEFOG HOT AIR position to avoid frost or icing on the canopy during descent.

LANDING.

The landing pattern is similar to a normal landing but because of thrust augmentation caused by extremely low temperatures, the approach must be made with a flatter glide than usual.

STOPPING ENGINES.

The engines are stopped in the normal manner.

BEFORE LEAVING AIRPLANE.

- Have the chocks put in place so that the parking brake can be released. If moisture has entered the brake assembly around the brake shoe, leaving the parking brake released will forestall the possibility that the brakes will freeze in position.
- Be sure that the airplane is serviced with fuel and oil and that the sumps are drained before the condensates reach the freezing point.
- Have all covers for the engine, pitot tube, and landing gear installed if there is the slightest possibility of drifting snow.
- 4. If a layover of several days is anticipated, have the battery removed. If the temperature is -7°C (20°F), the battery should be removed if a layover of four hours or more is expected.

HOT-WEATHER PROCEDURES.

Successful hot-weather operation will require attention and preparation other than the normal operating instructions covered in Section II.

CAUTION

Metal surfaces exposed to the sun will be burning hot to touch. Wear gloves to prevent burns.

BEFORE ENTERING THE AIRPLANE.

- Check tires and shock struts carefully to assure proper inflation. Overinflation is often encountered during high temperatures.
- Check that all electrical equipment is completely dry.
- Check carefully for hydraulic leaks because heat and moisture can cause valves and packing to swell.

ON ENTERING AIRPLANE.

- Place the cabin pressure selector switch in RAM for cabin ventilation.
- If high humidity has caused moisture to form on the instruments and controls, direct a flow of warm air from a portable ground heater, if available, on the instruments and controls to dry them.

BEFORE STARTING ENGINES.

Check the take-off distances for existing atmospheric conditions by using the charts in Appendix I.

STARTING ENGINES.

Start the engines in the normal manner.

Note

The engines will accelerate to idle rpm much more slowly on a hot day than on a normal or cold day.

TAXIING.

CAUTION

Use the brakes as little as possible, because high temperatures will retard cooling.

TAKE-OFF.

WARNING

Take-off distances in hot weather will show a considerable increase over the distance required during normal operation.

CLIMB.

Follow the normal climb pattern for the existing conditions.

Note

When the fuel in the tanks is warm, it is more susceptible to vaporization losses during rapid climbs. To avoid vaporization, hold the rate of climb to the minimum requirements of the mission.

DURING FLIGHT.

Under high-temperature conditions, it will be necessary to increase rpm to obtain the desired combination of Mach number and altitude for the best range performance.

DESCENT.

Use the normal descent procedure.

LANDING.

Use the normal landing technique and remember that the ground roll will be longer than usual.

WARNING

During extremely high temperature true airspeed is much higher than indicated airspeed. Therefore, stall and touchdown speeds will be higher.

STOPPING ENGINES.

 Stop the engines by using the normal procedure and release the parking brakes to avoid possible damage to the brake assemblies due to excessive heat generated during taxiing.

BEFORE LEAVING AIRPLANE.

- 1. Have the covers for the engine, canopy, and tire installed for protection from the sun.
- 2. Leave the cabin access door open for ventilation.
- 3. Have the fuel and oil tanks serviced.

DESERT PROCEDURES.

Desert operation which presents high temperatures with blowing sand and dust is considerably more difficult than the normal operating procedures which are covered in Section II. Damage can occur to both the airplane and the engines if the extra precautions presented here are not observed.

BEFORE ENTERING AIRPLANE.

 Check tires and shock struts for proper inflation. Overinflation is encountered often during hightemperature conditions.

WARNING

If necessary, position the airplane so that the jet blast will not blow sand toward other airplanes or personnel. Sand blown by the engines can severely damage other airplanes and can also harm personnel.

- Inspect all control surface hinges for sand and/ or excess dust and, if present, have it removed.
- Check the shock struts for sand and have it removed, if present.
- Remove all protective covers before entering the airplane.

ON ENTERING AIRPLANE.

- Check all dials, flight controls, and switches for sand accumulation, and have them cleaned if present.
- Place the cabin pressure selector switch in RAM for cabin ventilation.

BEFORE STARTING ENGINES.

- Operate all control surfaces several times to be sure that they move freely and easily.
- Check take-off distances in Appendix I for the existing conditions.

STARTING ENGINES.

- Complete as much of the preflight as possible before starting the engines so that ground operation will be held to a minimum.
- 2. Start the engines by using the normal procedure.

Note

The engines will accelerate to idle rpm much more slowly on a hot day than on a cold or normal day.

WARM-UP AND GROUND TESTS.

- Be sure the airplane is clear of other airplanes and personnel before accelerating the engines.
- The only warm-up period required is for the exhaust gas temperatures to stabilize.

TAXIING.

- Use the brakes as little as possible, because high temperatures retard cooling.
- Keep a sufficient taxi interval between other airplanes to prevent blowing sand into other engines.

TAKE-OFF.

Get the airplane into the air as soon as possible after starting the engines so that dust and sand will not be drawn into the engines.

Note

The take-off distance will be increased appreciably in high temperatures.

WARNING

It is necessary to adhere strictly to the suggested take-off and climbing speeds during hot weather operation since stalling speeds increase with temperature.

CLIMB.

Follow the normal climb procedure.

Note

Warm fuel is more susceptible to vaporization losses during rapid climbs. To avoid this condition, hold the rate of climb as low as practicable.

CAUTION

Avoid flying through dust or sand storms because grit or dust will cause damage to the engines.

Under high-temperature conditions, it will be necessary to increase rpm to obtain desired Mach numberaltitude combination for the best range performance.

DESCENT.

Use the normal descent procedure.

LANDING.

WARNING

During extremely high temperature true airspeed is much higher than in dicated airspeed. Therefore, stall and touchdown speeds will be higher.

Use the normal landing technique and remember that the ground roll will be longer than usual.

STOPPING ENGINES.

- 1. When the airplane is taxied to a parking position, shut down the engines at once.
- Have the chocks put in place and release the parking brakes as soon as possible, because the brake assemblies may be damaged due to excess heat generated by taxiing.
- Have the covers for the engine, wheel, pitot tube and canopy installed as soon as possible.

BEFORE LEAVING AIRPLANE.

- 1. Check that all covers are installed.
- 2. Leave the canopy partially open for ventilation.

Note

In extremely dusty locations where it is necessary to leave canopy open for ventilation purposes, all equipment in the cabin should be protected with dust covers.




Figure 9-1




Figure 9-2




Figure 9-3

typical GCA pattern BASELEG GEAR — DOWN IAS — 140 TO 160 K DOWNWIND **CLEAN CONFIGURATION** IAS - 180 TO 200 K FINAL & GLIDE PATH GEAR — DOWN FLAPS — DOWN IAS — 140 K ENTRY CLEAN CONFIGURATION IAS — 180 TO 200 K. GO-AROUND POWER — 100 % RPM GEAR & FLAPS — UP IAS — 180 TO 200 K

Figure 9-4

GCA FIX POINT

11636

typical single engine GCA pattern





Figure 9-5

typical runway roll after GCA landing



11638

hypical runway roll after GCA landing





Figure 9-7

Appendix I



PERFORMANCE DATA

11735

TABLE OF CONTENTS

| | Page | The state of the s | Page |
|----------------------|------|--|------|
| INTRODUCTION | A-1 | LANDING | A-: |
| AIRSPEED CORRECTIONS | A-1 | MAXIMUM ENDURANCE | A-3 |
| EFFECTIVE WIND | A-2 | COMBAT ALLOWANCE | A-3 |
| TAKE-OFF DISTANCE | A-2 | MAXIMUM CONTINUOUS POWER FLIGHT OPERATION INSTRUCTION | A-3 |
| CLIMB | A-2 | CHARTS | A-3 |
| DESCENT | A-3 | MAXIMUM RANGE SUMMARY | |

INTRODUCTION.

The following charts set forth the estimated performance capabilities of this airplane. These data are based on operation in NACA standard atmospheric conditions. Additional take-off data are presented with temperature and pressure altitude as variants. The flight operation instruction charts are also applicable to operation in non-standard atmosphere if the recommended CAS values are maintained.

AIRSPEED CORRECTIONS.

- Instrument correction to airspeed.
 The error in the individual airspeed indicator, considered negligible in most cases, may be obtained from the instrument calibration card to obtain indicated airspeed (IAS).
- Installation correction to airspeed.
 Figures (A-3 and A-4) gives the airspeed installation correction to be applied to indicated air-

speed in order to obtain calibrated airspeed (CAS).

3. Compressibility correction to airspeed.

The compressibility correction to airspeed is obtained from figure A-2 and when applied to calibrated airspeed (CAS) provides equivalent airspeed (EAS). The conversion of equivalent airspeed to true airspeed is accomplished by multiplying (EAS) by the reciprocal of the square root of the relative density. The vector addition of wind velocity and true airspeed provides ground speed. A free air temperature correction table (figure A-1) is also furnished, as true free air temperature must be known to obtain true airspeed (TAS).

USE OF AIRSPEED CORRECTION TABLES.

Consider an airplane flying at 15,000 feet with an indicated free air temperature of $+5^{\circ}$ C and an airspeed indicator reading of 300 knots.

300 knots

The value of 300 knots is the calibrated airspeed (CAS).

Free air temperature indicator reading.. +5°C

Correction for temperature error..... -15°C

-10°C

The value of -10°C is the true free air temperature. Use CAS and true free air temperature with a type D-4 or type G-1 airspeed computer to determine true airspeed (TAS) of 374 knots. When the dead reckoning computer is used, the CAS (300 knots) must be corrected for compressibility. The airspeed compressibility correction table shows that 6 knots must be subtracted from CAS (300 knots) to obtain equivalent airspeed (294 knots). Use the dead reckoning computer and the values of 294 knots and -10°C to determine the true airspeed of 374 knots.

EFFECTIVE WIND.

The effective wind chart, figure A-5, is used for computing the wind component (head or tail wind) for take-off. Enter the chart at the known wind velocity. Move horizontally and intersect the line representing the wind distance in degrees, relative to the take-off runway. Move down vertically to the base line. The

figure read from the base line is the wind component figure to be used with the take-off distance chart.

TAKE-OFF DISTANCE.

Figure (A-6) presents ground-run distances and the distance to clear a 50-foot obstacle for a military-thrust take-off. The distances shown are for normal technique on a dry hard-surface runway. The chart includes variable of gross weight, temperature, pressure altitude, and head wind; and may be used for both clean and tip tank configurations. Use the chart as follows:

- Enter the chart at ambient temperature and pressure altitude.
- 2. Proceed horizontally to the line corresponding to your take-off gross weight.
- Move vertically downward to Wind Baseline.
 If there is no headwind continue downward and
 read ground distance. If you have a head wind,
 follow the wind guide line to the correct wind
 value and read the distance on the ground reference line.
- 4. The lower portion of the chart will give the distance needed to clear a 50-foot obstacle; that is, for a ground run of 5900 feet, you need 7300 feet of runway distance to clear a 50-foot obstacle.

TAKE-OFF SPEEDS.

Figure A-7 should be used to determine the airspeed for the best-take-off performance. On this chart there are curves for both the normal take-off and a maximum effort take-off. Also included are the minimum single engine control speed (155 knots) and the initial stall warning (outside ground effect). In the flaps-up configuration, initial stall warning occurs 10 to 12 knots above the stall speed.

CLIMB.

The climb charts (figure A-8 to A-17) present the estimated time to climb, distance covered, fuel used, best climb speed, and rate of climb for military and normal thrust with two engines operating. Separate charts include single engine climb data at military thrust. The fuel allowance for starting engines, taxing, take-off, and acceleration to climb speed is listed at sea level. Fuel required at other altitudes includes this allowance plus the fuel needed to climb from sea level. Fuel required for an in-flight climb from one altitude to another is the difference of the tabulated

fuel required to climb to each altitude from sea level. Time and distance covered in an in-flight climb may be obtained in the same manner. All of the data appearing on the climb charts are presented at the tabulated gross weight for purposes of interpolation.

DESCENT.

The descent charts (figures A-18, A-19 and A-20) are based on the use of both wing dive brakes and fuselage speed brakes to obtain moderately high rates of descent. A constant Mach number speed schedule is shown for the clean airplane (M = .74). With wing tip tanks installed, this speed schedule is maintained until the airplane level flight structural limitation (434 knots EAS) is attained. The remaining descent with tip tanks installed is scheduled at this airspeed limitation. To minimize fuel consumption, idling power is used throughout the descent with both engines operating. The single engine descent data are presented for a constant Mach number schedule (M = .74), with one engine windmilling and one engine idling, dive brakes extended. Neither the fuel or time tabulated includes any allowance for loitering while awaiting landing clearance, for taxiing after landing, or for any navigational errors.

LANDING.

The landing distances presented in figure A-21 are based on the normal landing technique described in Section II. The percentage decrease noted on the charts for landing with dive brakes extended may be applied when this configuration is assumed. Dry, hard-surface runway and no wind are the only conditions shown.

MAXIMUM ENDURANCE.

Estimated airspeed, rpm, and fuel consumption for maximum endurance are presented in figures A-22 thru A-27. These data are shown for all configurations used in the flight operation instruction charts and include altitudes ranging from sea level to cruise ceiling.

COMBAT ALLOWANCE.

The combat allowance chart (figure A-28) includes estimated fuel flow at military thrust, normal thrust, and level flight thrust at the proved limit of normal control. Data are shown for the clean airplane.

MAXIMUM CONTINUOUS POWER.

The maximum continuous power charts (figures A-29 thru A-34) show estimated percentages of rpm, airspeed, and fuel consumption required at normal rated thrust. Configuration and weights correspond to those used in the flight operation instruction charts. Data shown for the airplane is within proved limit of normal control.

FLIGHT OPERATION INSTRUCTION CHARTS.

The flight operation instruction charts (figures A-35 to A-68) are presented to facilitate mission planning. The charted values include long-range airspeeds, fuel quantities, and altitudes in increments of 5,000 feet to the altitude where 300 fpm rate of climb at normal rated power can be maintained (cruise ceiling). In general, two range values are estimated for each fuel quantity and altitude shown. One is for continued operation at the initial altitude, and the other is maximum range obtainable by climbing to and cruising at the optimum altitudes shown for the specific initial conditions. Fuel consumed and distance covered during engine starting, taxiing, take-off, and initial climb at the start of a flight are not included in these charts. However, distances covered and fuel consumed during let-down or during in-flight climbs to optimum altitudes are taken into account. Operating conditions are shown on the lower portion of the charts. These operating conditions must be maintained if the range listed in the upper section of the chart are to be obtained. Under different wind conditions, ranges in ground miles are varied by the effect of wind on ground speed. The quoted let-down distances are affected for the same reason. Recommended CAS values also may change in order to obtain optimum ground miles per gallon. The lower half of each chart includes operating instructions to be followed when various wind conditions are encountered. Range in a wind is obtained by multiplying chart air miles by the range factor presented for the specific altitude and effective wind. Thus range factors may be used to determine the best altitude for cruise when there is a known wind difference at different altitudes. Effective wind has the same effect on the airplane ground speed as if it were a straight head wind or tail wind. The wind component in the direction of the airplane heading is the effective wind. For instance, a 100 knot wind at 30 degrees to the course is an effective head wind of approximately 85 knots. If the true airspeed

of the airplane is 500 knots, the true ground speed is approximately 415 knots. The approximate rpm values quoted on any one chart are based on the gross weight of the airplane equal to the high limit of the chart weight band. If the recommended CAS values are maintained, the rpm values will decrease slightly as the gross weight decreases. No allowances are made for navigation errors, combat, formation flight, landing, or similar contingencies.

PRE-FLIGHT RANGE PLANNING.

Select the applicable flight operation instruction charts. Determine the amount of fuel available. Available fuel is the total fuel aboard less allowances for starting engines, taxiing, take-off, initial climb, and reserve. Select a figure in the fuel column equal to, or less than, the amount available for flight planning. Interpolate as necessary. To determine maximum range at a given altitude, move horizontally right or left to the desired altitude column. The range value thus obtained must be multiplied by the correct range factor. Add the distance covered in the initial climb to obtain total range. To fly a given distance, determine range factors for the effective wind, and altitudes to be considered. From the desired distance subtract the climb distance. Divide the resultant figure by the range factor to obtain distance in cruise and descent. Enter the chart as previously. Move horizontally right or left to a calculated distance which exceeds the calculated air distance to be covered in cruise and descent. Use the operating conditions for the altitude so obtained, changing charts as fuel load decreases, or wing tip tanks are dropped. If altitude, wind, or disposable load does not remain reasonably constant, divide the flight into separate sections, planning each section individually.

IN-FLIGHT RANGE PLANNING.

To use the charts in flight, determine altitude, effective wind, and fuel available. Fuel available is equal to total usable fuel aboard less necessary reserves. Enter the flight operation instruction chart applicable to the specific airplane weight and fuel available. Move horizontally right or left to the desired altitude column. Determine the altitude at which flight is to be continued. Operating conditions for continued flight at this altitude can be found directly below. When changing charts, refer to cruising instructions on the new chart at the flight altitude. Ranges shown at optimum altitude may be obtained by immediately climbing at recommended climb procedure to this altitude. Cruising instructions at this new altitude

will be found in the lower half of the chart in the column under the new altitude. In order to obtain best range, it is necessary to observe the optimum altitude when changing charts due to configuration change and weight changes.

SAMPLE PROBLEMS BASED ON JP-4 FUEL.

PROBLEM I.

Ferry Range Required—1500 nautical miles Reserve Fuel Needed—1000 pounds

Payload (bombs)-none

Initial gross weight with wing tip tanks full—47,500 pounds with 2,972 gallons of fuel (19,318 pounds). Effective winds—80 knot head wind above 35,000 feet

Effective winds—40 knot head wind below 35,000 feet

From the climb charts, figure A-8 to A-17 and the flight operation instruction charts for 320 gallon wing tip tanks carried the entire distance, figures A-53 and A-54, the following data are obtained.

| 1. | Cruising Altitude (feet) | 25,000 | 30,000 | 35,000 |
|-----|--|--------|--------|--------|
| 2. | Fuel Capacity (pounds) | 19,318 | 19,318 | 19,318 |
| 3. | Reserve Fuel (pounds) | 1,000 | 1,000 | 1,000 |
| 4. | Fuel used in Climb to altitude at MRP (pounds) | 2,385 | 2,700 | 3,060 |
| 5. | Available Cruise Fuel (pounds) | | 15,618 | |
| 6. | Cruise and Descent Air Distance (interpolate nautical miles) | 1,558 | 1,701 | 1,797 |
| 7. | Range Factor | .90 | .89 | .80 |
| 8. | Cruise and Descent Ground Distance (6 x 7) | 1,400 | 1,510 | 1,440 |
| 9. | Nautical Miles in Initial Climb | 48 | 66 | 91 |
| 10. | Nautical Ground Miles (8 + 9) | 1,448 | 1,576 | 1,531 |

These preliminary calculations indicate that the range of 1,500 nautical miles may be attained at a cruise altitude of 30,000 feet. At this altitude with a 40-knot head wind the initial cruise speed, while within the weight bracket of 48,000 to 44,300 pounds, is 266 knots CAS. When gross weight reduces to the weight range of 44,300 to 39,800 pounds, airspeed reduces to 262 knots CAS and is further reduced to 255 knots CAS when operating within the weight band of 39,800 to 35,300 pounds.

PROBLEM II.

DATA BASIS ESTIMATED DATA AS OF: 1 MAY 1953

Suppose that changing winds throughout the previous range problem make an extension of range necessary. Fuel aboard is approximately 6,000 pounds and empty wing tip tanks remain. Flight altitude is 30,000 feet. Gross weight is within the weight bracket of 35,300 to 30,800 pounds. Continued flight at this altitude will result in a range of approximately 540 nautical miles with a 40-knot head wind, maintaining a 1,000 pound fuel reserve. However, by immediately dropping the empty wing tip tanks, a range of 575 nautical miles may be obtained with a similar reserve fuel allowance. The previous example shows that when empty wing tip tanks are installed and maximum

range is essential, the wing tip tanks should be jettisoned.

MAXIMUM RANGE SUMMARY.

The maximum range summary charts (figures A-69 thru A-74) summarize the no-wind flight operating conditions for the data in the flight operation instruction charts. The maximum range summary charts presents the airspeeds, fuel flow, and percent rpm for maximum range flight at various altitudes and for various weights and configurations given in the flight operation instruction charts.

| PRESSURE | CALIBRATED AIRSPEED - KNOTS | | | | | | | | | |
|-----------|-----------------------------|-----|-----|-----|-----|-----|-----|-----|--|--|
| ALTITUDE | 150 | 200 | 250 | 300 | 350 | 400 | 450 | 500 | | |
| SEA LEVEL | 2 | 4 | 7 | 9 | 13 | 17 | 21 | 26 | | |
| 5,000 | 3 | 5 | 8 | 11 | 15 | 19 | 24 | | | |
| 10,000 | 3 | 6 | 9 | 13 | 17 | 22 | 28 | | | |
| 15,000 | 4 | 7 | 10 | 15 | 20 | 25 | | | | |
| 20,000 | 4 | 8 | 12 | 17 | 23 | 29 | | | | |
| 25,000 | 5 | 9 | 14 | 20 | 26 | | | | | |
| 30,000 | 6 | 11 | 16 | 23 | | | | | | |
| 35,000 | 7 | 13 | 19 | 27 | | | | | | |
| 40,000 | 9 | 16 | 24 | | | | | | | |
| 45,000 | 12 | 20 | 29 | | | | | | | |
| 50,000 | 14 | 24 | | | | | | | | |

TEMPERATURE (°C) TO OBTAIN TRUE FREE AIR TEMPERATURE (°C)

DATA BASIS: ESTIMATED DATA AS OF: I MAY 1953

| COMPRESSIBILITY | CORRECTION | TARIF |
|-----------------|------------|-------|
| COMPRESSIBILIT | COMMEDITOR | IADLL |

| PRESSURE | | | | C.A.S K | NOTS | | | | |
|----------|-----|-----|-----|---------|------|------|-----|-----|------|
| ALTITUDE | 150 | 200 | 250 | 300 | 350 | 400 | 450 | 500 | 550 |
| 5,000 | 0 | 0 | - 1 | - 2 | - 2 | - 3 | - 5 | - 6 | - 8 |
| 10,000 | 0 | - 1 | - 2 | - 3 | - 5 | - 7 | -10 | -13 | - 17 |
| 15,000 | -1 | - 2 | - 3 | - 6 | - 8 | - 12 | -16 | -21 | |
| 20,000 | -1 | - 3 | - 5 | - 8 | -12 | - 17 | -23 | | |
| 25,000 | -2 | - 4 | - 7 | - 11 | -17 | -24 | | | |
| 30,000 | -2 | - 5 | - 9 | - 15 | -23 | | | | |
| 35,000 | -3 | - 7 | -12 | -20 | | | | | |
| 40,000 | -4 | - 9 | -16 | | | | | | |
| 45,000 | -5 | -11 | -20 | | | | | | |
| 50,000 | -7 | -14 | | | | | | | |

REMARKS:

ADD CORRECTION TO CALIBRATED AIRSPEED

TO OBTAIN EQUIVALENT AIRSPEED

C.A.S : CALIBRATED AIRSPEED

Figure A-2




Figure A-3




Figure A-4




Figure A-4A




Figure A-4B




Figure A-5




Figure A-6

take-off speeds

HARD SURFACE RUNWAY
MILITARY THRUST
FLAPS UP

MODEL(S): B-57B

ENGINE(S): (TWO) J65-W-5 FUEL GRADE: JP-4 FUEL DENSITY: 6.5 LB PER GAL




Figure A-7

STANDARD DAY

MODEL(S): B-57B

ENGINE(S): (TWO) J65-W-5

CONFIGURATION: CLEAN

WEIGHT:

30,500 POUNDS

CONFIGURATION: WEIGHT:

| | APPRO | XIMATE | | | PRESSURE | | | APPRO) | CIMATE | |
|-------|-------|--------------|--------|-------|-----------|-----|------|----------------|--------|-------------|
| RATE | | FROM SEA LEV | EL | CAS | ALTITUDE | CAS | FI | FROM SEA LEVEL | | RATE |
| CLIMB | DIST. | TIME | FUEL | KNOTS | FEET | × * | PUEL | TIME | DIST. | OF CLIMB |
| 6400 | 0 | 0 | 985(1) | 314 | SEA LEVEL | | | | | |
| 5750 | 5 | 0.8 | 1160 | 312 | 5,000 | | | | | |
| 5100 | 10 | 1.8 | 1330 | 305 | 10,000 | | | | | |
| 4500 | 16 | 2.8 | 1500 | 297 | 15,000 | | | | | |
| 3900 | 23 | 4.0 | 1660 | 286 | 20,000 | | | | | |
| 3350 | 32 | 5.3 | 1830 | 271 | 25,000 | | | | | |
| 2800 | 43 | 6.9 | 2000 | 256 | 30,000 | | | | | |
| 2200 | 57 | 8.8 | 2180 | 240 | 35,000 | | | | | |
| 1500 | 74 | 11.6 | 2370 | 214 | 40,000 | | | | | |
| 750 | 105 | 16.0 | 2610 | 192 | 45,000 | | | | | |
| | | | | | 50,000 | | | | | |

CONFIGURATION:

WEIGHT:

CONFIGURATION: WEIGHT:

| | APPROX | KIMATE | | | PRESSURE | CAS | | APPRO) | CIMATE | |
|-------------|--------|--------------|------|-----|------------------|-----|----------------|--------|--------|-------|
| RATE | FI | ROM SEA LEVE | L | CAS | ALTITUDE FEET | CAS | FROM SEA LEVEL | | | RATE |
| OF CLIMB | DIST. | TIME | FUEL | | PEEI | | FUEL | TIME | DIST. | CLIMB |
| | | | | | SEA LEVEL | | | | | |
| | | | | | 5,000 | | | | | |
| | | | | | 10,000 | | | | | |
| | | | | | 15,000 | | | | | |
| | | | 100 | | 20,000 | | | | | |
| | | | | | 25,000 | | | | | |
| | | | | | 30,000 | | | | | |
| | | | | | 35,000 | | | | | L. |
| | | | | | 40,000 | | | | | |
| | | | | | 45,000 | | | | | |
| | | | | | 50,000 | | | | | |

REMARKS:

- (1) ALLOWANCE FOR START ENGINES, TAXI, TAKE-OFF AND ACCELERATE TO CLIMB SPEED
- (2) CLIMB AT RECOMMENDED CAS.

RATE OF CLIMB: FEET PER MINUTE DISTANCE: NA U'RILES

TIME: MINUTES FUEL: POUNDS

CAS: CALIBRATED AIRSPEED - KNOTS

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

STANDARD DAY

MODEL(S): B-57B

ENGINE(S): (TWO) J65-W-5

CONFIGURATION: CLEAN

WEIGHT:

48,500 POUNDS

CONFIGURATION: CLEAN WEIGHT: 44,000 1

44,000 POUNDS

| | APPRO | XIMATE | | | PRESSURE | | | APPRO | XIMATE | |
|-------------|-------|--------------|---------|-------|-----------|---------|----------------|-------|--------|-------|
| RATE | F | ROM SEA LEVI | EL | KNOTS | ALTITUDE | KNOTS | FROM SEA LEVEL | | | RATE |
| OF CLIMB | DIST. | TIME | FUEL | | FEET | 111,012 | FUEL | TIME | DIST. | CLIMB |
| 3800 | 0 | 0 | 985 (1) | 320 | SEA LEVEL | 318 | 985 (1) | 0 | 0 | 4250 |
| 3350 | 7 | 1.4 | 1280 | 317 | 5,000 | 316 | 1240 | 1.2 | 6 | 3750 |
| 2900 | 17 | 3.0 | 1560 | 310 | 10,000 | 310 | 1500 | 2.7 | 15 | 3300 |
| 2500 | 28 | 4.8 | 1860 | 302 | 15,000 | 301 | 1770 | 4.3 | 25 | 2800 |
| 2100 | 42 | 7.0 | 2180 | 290 | 20,000 | 290 | 2040 | 6.2 | 37 | 2400 |
| 1700 | 60 | 9.6 | 2500 | 276 | 25,000 | 276 | 2320 | 8.5 | 52 | 2000 |
| 1250 | 82 | 13.0 | 2870 | 259 | 30,000 | 259 | 2610 | 11.4 | 71 | 1550 |
| 750 | 117 | 18.1 | 3330 | 241 | 35,000 | 241 | 2950 | 15.0 | 96 | 1000 |
| | | | | | 40,000 | 216 | 3450 | 21.7 | 143 | 400 |
| | | | | | 45,000 | | | | | |
| | | | | | 50,000 | | | | | |

CONFIGURATION: CLEAN WEIGHT:

39, 500 POUNDS

CONFIGURATION: CLEAN

WEIGHT: 35,000 POUNDS

| | APPRO | XIMATE | | 212 | CAS PRESSURE CAS | | | APPRO | XIMATE | |
|-------|-------|--------------|---------|-------|------------------|-------|----------------|-------|--------|-------|
| RATE | F | ROM SEA LEVI | IL. | KNCTS | ALTITUDE | KNOTS | FROM SEA LEVEL | | | RATE |
| CLIMB | DIST. | TIME | FUEL | | FEET | | FUEL | TIME | DIST. | CLIMB |
| 4750 | 0 | 0 | 985 (1) | 317 | SEA LEVEL | 316 | 985 (1) | 0 | 0 | 5500 |
| 4250 | 6 | 1.1 | 1210 | 316 | 5,000 | 314 | 1190 | 1.0 | 5 | 4850 |
| 3750 | 13 | 2.4 | 1450 | 308 | 10,000 | 307 | 1390 | 2.1 | 11 | 4300 |
| 3250 | 22 | 3.8 | 1680 | 300 | 15,000 | 299 | 1590 | 3.3 | 19 | 3800 |
| 2800 | 32 | 5.5 | 1910 | 289 | 20,000 | 288 | 1790 | 4,8 | 28 | 3300 |
| 2300 | 45 | 7.4 | 2150 | 275 | 25,000 | 273 | 1990 | 6.3 | 39 | 2800 |
| 1900 | 61 | 9.8 | 2400 | 258 | 30,000 | 258 | 2200 | 8.3 | 52 | 2300 |
| 1350 | 81 | 12.7 | 2660 | 241 | 35,000 | 241 | 2420 | 10.7 | 68 | 1750 |
| 700 | 114 | 17.4 | 3000 | 216 | 40,000 | 215 | 2660 | 14.2 | 92 | 1100 |
| | | | | | 45,000 | 192 | 3060 | 21.2 | 140 | 400 |
| | | | | | 50,000 | | | | | |

REMARKS:

(1) ALLOWANCE FOR START ENGINES, TAXI, TAKE-OFF AND ACCELERATE-TO-CLIMB SPEED.

(2) CLIMB AT RECOMMENDED CAS.

RATE OF CLIMB: FEET PER MINUTE DISTANCE NA U TRILES

TIME: MINUTES FUEL: POUNDS

CAS: CALIBRATED AIRSPEED KNOTS

DATA AS OF: 1 OCTOBER 1953
DATA BASIS: ESTIMATE

STANDARD DAY

MODEL(S): B-57B

ENGINE(S): (TWO) J65-W-5

CONFIGURATION: 2 X 320 GAL W ING TIP TANKS WEIGHT: 35,300 POINTS

35,300 POUNDS

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT: 30,800 POUNDS

30,800 POUNDS

| | APPRO | XIMATE | | 25.5 | PRESSURE | 202 | | APPRO | CIMATE | |
|-------|-------|-------------|---------|--------|-----------|-------|----------------|-------|--------|-------|
| RATE | F | ROM SEA LEY | EL | KNOTS | ALTITUDE | KNOTS | FROM SEA LEVEL | | | RATE |
| CLIMB | DIST. | TIME | FUEL | 12.015 | FEET | | FUEL | TIME | DIST. | CLIMB |
| 5350 | 0 | 0 | 985 (1) | 306 | SEA LEVEL | 305 | 985 (1) | 0 | 0 | 6150 |
| 4750 | 5 | 1.0 | 1190 | 300 | 5,000 | 298 | 1160 | 0.9 | 5 | 5600 |
| 4190 | 11 | 2.2 | 1390 | 294 | 10,000 | 293 | 1330 | 1.9 | 10 | 4900 |
| 3650 | 19 | 3.5 | 1600 | 286 | 15,000 | 285 | 1510 | 3.0 | 16 | 4300 |
| 3100 | 28 | 4.9 | 1810 | 276 | 20,000 | 275 | 1690 | 4.2 | 24 | 3700 |
| 2600 | 39 | 6.7 | 2020 | 264 | 25,000 | 263 | 1870 | 5.7 | 34 | 2130 |
| 2100 | 53 | 8.9 | 2250 | 249 | 30,000 | 248 | 2050 | 7.6 | 45 | 2550 |
| 1590 | 73 | 11.7 | 2500 | 233 | 35,000 | 233 | 2240 | 9.8 | 60 | 2000 |
| 910 | 98 | 15.5 | 2770 | 210 | 40,000 | 209 | 2450 | 12.7 | 80 | 1350 |
| | | | | | 45,000 | 188 | 2720 | 17.2 | 113 | 670 |
| | | | | | 50,000 | | | | | |

CONFIGURATION: WEIGHT:

CONFIGURATION: WEIGHT:

| | APPROX | KIMATE | | | PRESSURE | | | APPRO | KIMATE | |
|-------------|--------|--------------|------|-----|------------------|-----|------|----------------|--------|-------------|
| RATE | FI | ROM SEA LEVI | EL . | CAS | ALTITUDE FEET | CAS | F | FROM SEA LEVEL | | RATE |
| OF CLIMB | DIST. | TIME | FUEL | | FEET | | PUEL | TIME | DIST. | OF CLIMB |
| | | | | | SEA LEVEL | | | | | |
| | | | | | 5,000 | | | | | |
| | | | | | 10,000 | - | | | | |
| | | | | | 15,000 | | | | | |
| | | | | | 20,000 | | | | 4 | |
| | | | | | 25,000 | | | | | |
| | | | | | 30,000 | | | | | |
| | | | | | 35,000 | | | | | |
| | | 17.00 | | | 40,000 | | | | | |
| | | | | | 45,000 | | | | | |
| | | | | | 50,000 | | | | | |

REMARKS:

- (1) ALLOWANCE FOR START ENGINES, TAXI, TAKE-OFF AND ACCELERATE-TO-CLIMB SPEED.
- (2) CLIMB AT RECOMMENDED CAS.

RATE OF CLIMB: FEET PER MINUTE DISTANCE NA UTAILES TIME: MINUTES FUEL: POUNDS CAS: CALIBRATED AIRSPEED KNOTS

DATA AS OF: 1 OCTOBER 1953
DATA BASIS: ESTIMATE

STANDARD DAY

MODEL(S): B-57B

ENGINE(S): (TWO) J65-W-5

WEIGHT:

CONFIGURATION: 2 X 320 GAL WING TIP TANKS 53,000 POUNDS

WEIGHT:

CONFIGURATION: 2 X 320 GAL WING TIP TANKS

48,800 POUNDS

| | APPRO | NIMATE | | | PRESSURE | - | 17-33 | APPRO | XIMATE | |
|-------|-------|------------|---------|-------|------------------|--------|---------|-------|--------|-------------|
| RATE | | ROM SEA LE | VEL | KNOTS | ALTITUDE FEET | KNOTS | F | RATE | | |
| CLIMB | DIST. | TIME | PUEL | 1 | | ILIOID | PUEL | TIME | DIST. | OF CLIMB |
| 3350 | 0 | 0 | 985 (1) | 310 | SEA LEVEL | 309 | 985 (1) | 0 | 0 | 3700 |
| 2920 | 8 | 1.5 | 1300 | 305 | 5,000 | 303 | 1280 | 1.4 | 8 | 3250 |
| 2480 | 19 | 3.5 | 1670 | 298 | 10,000 | 297 | 1580 | 3.1 | 17 | 2800 |
| 2100 | 32 | 5.7 | 2020 | 290 | 15,000 | 289 | 1890 | 5.1 | 28 | 2350 |
| 1700 | 47 | 8.3 | 2380 | 280 | 20,000 | 279 | 2200 | 7.4 | 42 | 1950 |
| 1290 | 69 | 11.6 | 2800 | 266 | 25,000 | 265 | 2550 | 10.2 | 60 | 1500 |
| 840 | 98 | 16.3 | 3280 | 250 | 30,000 | 250 | 2940 | 14.0 | 84 | 1110 |
| 410 | 154 | 24.0 | 4060 | 235 | 35,000 | 235 | 3440 | 19.7 | 123 | 620 |
| | | | | | 40,000 | | | | | |
| | | | | | 45,000 | |). | | | |
| | | | | | 50,000 | | | | | |

WEIGHT:

CONFIGURATION: 2 X 320 GAL WING TIP TANKS

44,300 POUNDS

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT: 39,800 POUNDS

| | APPRO | STAMIX | | CAS | DDECCUDE | 57.57 | | APPRO | XIMATE | |
|-------|-------|----------------|---------|-----|----------------------|-------|---------|-------------|--------|-------------|
| RATE | | FROM SEA LEVEL | | | PRESSURE ALTITUDE | KNOTS | F | ROM SEA LEV | EL | RATE |
| CLIMB | DIST. | TIME | FUEL | | FEET | | PUEL | TIME | DIST. | OF CLIMB |
| 4100 | 0 | 0 | 985 (1) | 308 | SEA LEVEL | 307 | 985 (1) | 0 | 0 | 4640 |
| 3680 | 7 | 1.3 | 1250 | 302 | 5,000 | 301 | 1220 | 1.2 | 6 | 4120 |
| 3200 | 15 | 2.8 | 1500 | 296 | 10,000 | 295 | 1450 | 2.4 | 13 | 3620 |
| 2700 | 24 | 4.5 | 1780 | 288 | 15,000 | 287 | 1690 | 4.0 | 21 | 3110 |
| 2270 | 37 | 6.5 | 2050 | 278 | 20,000 | 277 | 1930 | 5.7 | 32 | 2610 |
| 1820 | 52 | 8.9 | 2360 | 265 | 25,000 | 264 | 2190 | 7.8 | 46 | 2180 |
| 1390 | 72 | 12.0 | 2680 | 250 | 30,000 | 249 | 2460 | 10.4 | 62 | 1690 |
| 880 | 102 | 16.4 | 3060 | 234 | 35,000 | 234 | 2760 | 13.8 | 86 | 1200 |
| 300 | 154 | 24.4 | 3660 | 213 | 40,000 | 211 | 3140 | 19.2 | 121 | 610 |
| | | | | | 45,000 | | | | | |
| | | | | | 50,000 | | | | | |

REMARKS:

ALLOWANCE FOR START ENGINES, TAXI, TAKE-OFF AND ACCELERATE-TO-CLIMB SPEED.

(2) CLIMB AT RECOMMENDED CAS.

RATE OF CLIMB: FEET PER MINUTE DISTANCENA UTAILES TIME: MINUTES

FUEL: POUNDS CAS: CALIBRATED AIRSPEED KNOTS

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

STANDARD DAY

MODEL(S): B-57B

ENGINE(S): (TWO) J65-W-5

CONFIGURATION: CLEAN

CONFIGURATION: WEIGHT:

WEIGHT: 30, 500 POUNDS

APPROXIMATE APPROXIMATE **PRESSURE** CAS ALTITUDE FROM SEA LEVEL RATE FROM SEA LEVEL KNOTS OF OF FUEL TIME DIST. TIME FUEL DIST. CLIMB CLIMB SEA LEVEL 985 (1) 361 8000 0 0 0.6 350 5,000 7300 4 1140 10,000 9 1310 336 6550 1.4 5800 14 2.2 1460 320 15,000 1620 302 20,000 5050 20 3.1 4300 28 4.2 1780 283 25,000 5.5 1930 263 30,000 36 3550 35,000 2800 47 7.1 2080 243 40,000 2000 61 9.2 2260 217 45,000 84 12.4 2470 194 1150 50,000 129 19.3 2830 172 350

CONFIGURATION: WEIGHT:

CONFIGURATION: WEIGHT:

| | APPRO | KIMATE | | CAS | PRESSURE | CAS | | APPRO) | CIMATE | |
|-------------|----------------|--------|------|---------------|-----------|----------------|------|--------|--------|-------|
| RATE | FROM SEA LEVEL | | | ALTITUDE FEET | CAS | FROM SEA LEVEL | | | RATE | |
| OF CLIMB | DIST. | TIME | FUEL | | PEET | | FUEL | TIME | DIST. | CLIME |
| | | | | The Diff | SEA LEVEL | | | | | |
| | | | | | 5,000 | 11.0 | | | | |
| | | | | | 10,000 | | | | | |
| | | | | | 15,000 | | | | 18 | |
| | | | | | 20,000 | | | | | |
| | | | | | 25,000 | | | | | |
| | 107 | | 144 | | 30,000 | | | | | |
| | | | | | 35,000 | | | | | |
| | | | | | 40,000 | | | | | |
| | | | | | 45,000 | | | | | |
| | | | | | 50,000 | | | | | |

REMARKS:

(1) ALLOWANCE FOR START ENGINES, TAXI, TAKE-OFF AND ACCELERATE-TO-CLIMB SPEED.

(2) CLIMB AT RECOMMENDED CAS.

RATE OF CLIMB: FEET PER MINUTE DISTANCE NA UTHLES TIME: MINUTES FUEL: POUNDS CAS: CALIBRATED AIRSPEED KNOTS

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

MODEL(S): B-57B

STANDARD DAY

ENGINE(S): (TWO) J65-W-5

CONFIGURATION: CLEAN

CONFIGURATION: CLEAN

| WEIGHT: | 48, 500 POUNDS | WEIGHT: | 44,000 POUNDS |
|---------|----------------|---------|---------------|
| APPR | OXIMATE | T | I AF |

| | APPROXIMATE | | | CAS | PRESSURE | CAS | | APPRO | XIMATE | |
|-------|----------------|------|---------|-------|------------------|--------|---------|------------|--------|-------|
| RATE | FROM SEA LEVEL | | | ALTI | ALTITUDE FEET | KNOTS | FI | ROM SEA LE | YEL | RATE |
| CLINS | DIST. | TIME | PUEL | MIOIS | FEEI | MINOIS | FUEL | TIME | DIST. | CLIMB |
| 4950 | 0 | 0 | 985 (1) | 366 | SEA LEVEL | 365 | 985 (1) | 0 | 0 | 5500 |
| 4400 | 6 | 1,1 | 1260 | 354 | 5,000 | 353 | 1220 | 0.9 | 6 | 4900 |
| 3850 | 15 | 2.3 | 1530 | 342 | 10,000 | 339 | 1460 | 2.0 | 13 | 4300 |
| 3350 | 24 | 3.7 | 1790 | 326 | 15,000 | 323 | 1700 | 3.2 | 21 | 3750 |
| 2800 | 35 | 5.4 | 2060 | 306 | 20,000 | 304 | 1940 | 4.7 | 31 | 3200 |
| 2300 | 48 | 7.2 | 2350 | 287 | 25,000 | 285 | 2180 | 6.4 | 42 | 2650 |
| 1750 | 66 | 9.7 | 2630 | 267 | 30,000 | 266 | 2440 | 8.5 | 57 | 2100 |
| 1100 | 89 | 13.1 | 2960 | 245 | 35,000 | 245 | 2720 | 11.3 | 76 | 1400 |
| 400 | 130 | 19.0 | 3480 | 221 | 40,000 | 220 | 3090 | 15.7 | 108 | 750 |
| | | | | | 45,000 | 191 | | | T III | |
| | | | | | 50,000 | | | | | |

CONFIGURATION: CLEAN WEIGHT:

39,500 POUNDS

CONFIGURATION: CLEAN

WEIGHT: 35,000 POUNDS

| - | APPROXIMATE | | | | PRESSURE | CAS | APPROXIMATE | | | | |
|-------|----------------|------|---------|-------|-----------|--------|-------------|------------|-------|-------|--|
| RATE | FROM SEA LEVEL | | | KNOTS | ALTITUDE | KNOTS | F | OM SEA LEY | /EL | RATE | |
| CLIMB | DIST. | TIME | FUEL | | FEET | LLIOID | PUEL | TIME | DIST. | CLIMB | |
| 6200 | 0 | 0 | 985 (1) | 364 | SEA LEVEL | 363 | 985 (1) | 0 | 0 | 7050 | |
| 5500 | 5 | 0.8 | 1200 | 352 | 5,000 | 351 | 1170 | 0.8 | 5 | 6300 | |
| 4850 | 11 | 1.8 | 1410 | 338 | 10,000 | 337 | 1360 | 1.6 | 10 | 5600 | |
| 4250 | 19 | 2.9 | 1610 | 322 | 15,000 | 321 | 1540 | 2.5 | 16 | 4950 | |
| 3650 | 27 | 4.2 | 1830 | 303 | 20,000 | 302 | 1720 | 3.6 | 23 | 4300 | |
| 3050 | 37 | 5.6 | 2040 | 284 | 25,000 | 283 | 1900 | 4.8 | 32 | 3650 | |
| 2450 | 49 | 7.4 | 2260 | 265 | 30,000 | 264 | 2090 | 6.4 | 42 | 3000 | |
| 1850 | 65 | 9.7 | 2490 | 244 | 35,000 | 244 | 2280 | 8.3 | 56 | 2250 | |
| 1100 | 90 | 13.1 | 2780 | 219 | 40,000 | 218 | 2500 | 11.0 | 74 | 1450 | |
| 350 | 147 | 20.4 | 3260 | 195 | 45,000 | .194 | 2810 | 15.7 | 107 | 650 | |
| | | | | | 50,000 | | : | | 1 | | |

REMARKS:

(1) ALLOWANCE FOR START ENGINES, TAXI, TAKE-OFF AND ACCELERATE-TO-CLIMB SPEED.

(2) CLIMB AT RECOMMENDED CAS.

RATE OF CLIMB: FEET PER MINUTE DISTANCENA UTMILES TIME: MINUTES FUEL: POUNDS

CAS: CALIBRATED AIRSPEED KNOTS

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

STANDARD DAY

MODEL(S): B-57B

ENGINE(S): (TWO) J65-W-5

CONFIGURATION: 2 X 320 GAL WING TIP TANKS

WEIGHT:

35,300 POUNDS

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT:

30,800 POUNDS

| | APPRO | XIMATE | | CAS | PRESSURE | CAS | | APPRO | XIMATE | |
|-------|-------|----------------|---------|-------|------------------|---------|---------|-------|--------|-------------|
| RATE | | FROM SEA LEVEL | | | ALTITUDE FEET | KNOTS | F | RATE | | |
| CLIMB | DIST. | TIME | FUEL | KNOTS | , | 12.1015 | FUEL | TIME | DIST. | OF CLIMB |
| 6700 | 0 | 0 | 985 (1) | 340 | SEA LEVEL | 339 | 985 (1) | 0 | 0 | 7760 |
| 5910 | 5 | 0.8 | 1170 | 331 | 5,000 | 330 | 1150 | 0.7 | 4 | 6950 |
| 5230 | 10 | 1.8 | 1370 | 320 | 10,000 | 319 | 1310 | 1.6 | 9 | 6150 |
| 4570 | 16 | 2.7 | 1560 | 307 | 15,000 | 306 | 1470 | 2.4 | 14 | 5400 |
| 3920 | 24 | 3.9 | 1760 | 292 | 20,000 | 291 | 1635 | 3.4 | 20 | 4680 |
| 3310 | 33 | 5.3 | 1950 | 276 | 25,000 | 275 | 1800 | 4.6 | 28 | 4000 |
| 2700 | 44 | 7.0 | 2150 | 258 | 30,000 | 258 | 1970 | 6.0 | 37 | 3335 |
| 2090 | 58 | 9.0 | 2370 | 238 | 35,000 | 238 | 2140 | 7.6 | 47 | 2620 |
| 1320 | 79 | 11.8 | 2600 | 214 | 40,000 | 213 | 2320 | 9.9 | 63 | 1820 |
| 600 | 114 | 16.1 | 2950 | 190 | 45,000 | 189 | 2550 | 13.3 | 88 | 1020 |
| | | | | | 50,000 | 169 | 2870 | 21.1 | 137 | 260 |

CONFIGURATION: WEIGHT:

CONFIGURATION: WEIGHT:

| | APPRO | KIMATE | | | PRESSURE | | | APPRO | XIMATE | |
|-------|----------------|--------|------|--------|-------------|----------|--------------|-------|--------|-------------|
| RATE | FROM SEA LEVEL | | | CAS | ALTITUDE | CAS | F | RATE | | |
| CLIMB | DIST. | TIME | FUEL | | Patential I | | PUEL | TIME | DIST. | OF CLIMB |
| | | | | Tin . | SEA LEVEL | n in its | | | | |
| | | | 1001 | E89. / | 5,000 | | | | | |
| | | 1 man | | | 10,000 | 1 | | | | |
| | | N.B. | | | 15,000 | | | | | |
| | | | | | 20,000 | | | | | |
| | | 1 14 | | | 25,000 | Y/10 | L Option | | 70 | |
| | | 1 10 | | 111 | 30,000 | | and the same | | | |
| | | 1.1 | | T IVII | 35,000 | Hill | | T.y. | | |
| (de) | | - Date | | - mr | 40,000 | | | 1.19 | | 1011 |
| reta. | | 1.01 | 1121 | | 45,000 | 191 | | 1,00 | | |
| | | | | | 50,000 | | | | | |

REMARKS:

- (1) ALLOWANCE FOR START ENGINES, TAXI, TAKE-OFF AND ACCELERATE-TO-CLIMB SPEED.
- (2) CLIMB AT RECOMMENDED CAS.

RATE OF CLIMB: FEET PER MINUTE DISTANCE: Naut, MILES

TIME: MINUTES
FUEL: POUNDS

CAS: CALIBRATED AIRSPEED KNOTS

DATA AS OF: 1 OCTOBER 1953
DATA BASIS: ESTIMATE

STANDARD DAY

MODEL(S): B-57B

ENGINE(\$): (TWO) J65-W-5

CONFIGURATION: 2 X 320 GAL WING TIP TANKS 53,000 POUNDS

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT: 48,800 POUNDS

| | APPRO | STAMIX | | CAS | PRESSURE | | | APPROX | IMATE | |
|-------|----------------|--------|---------|-------|------------------|-------|---------|--------------|-------|-------|
| RATE | FROM SEA LEVEL | | | KNOTS | ALTITUDE FEET | KNOTS | F | ROM SEA LEVE | iL . | RATE |
| CLIMB | DIST. | TIME | FUEL | | 1-5. | | FUEL | TIME | DIST. | CLIME |
| 4250 | 0 | 0 | 985 (1) | 345 | SEA LEVEL | 344 | 985 (1) | 0 | 0 | 4700 |
| 3750 | 8 | 1.2 | 1290 | 335 | 5,000 | 334 | 1260 | 1.1 | . 7 | 4150 |
| 3250 | 15 | 2.8 | 1600 | 324 | 10,000 | 323 | 1550 | 2.5 | 14 | 3600 |
| 2750 | 27 | 4.4 | 1920 | 311 | 15,000 | 310 | 1830 | 4.0 | 24 | 3050 |
| 2250 | 39 | 6.5 | 2250 | 296 | 20,000 | 295 | 2120 | 5.7 | 36 | 2550 |
| 1760 | 56 | 9.2 | 2590 | 280 | 25,000 | 279 | 2430 | 8.0 | 49 | 2050 |
| 1280 | 78 | 12.2 | 2980 | 261 | 30,000 | 260 | 2760 | 10.6 - | 69 | 1550 |
| 780 | 110 | 17.0 | 3470 | 240 | 35,000 | 240 | 3150 | 14.4 | 95 | 1050 |
| 100 | 189 | 28.8 | 4360 | 216 | 40,000 | 216 | 3750 | 21.5 | 145 | 350 |
| | | | | | 45,000 | | | | | |
| | | | | | 50,000 | | | | | |

WEIGHT:

CONFIGURATION: 2 X 320 GAL WING TIP TANKS 44, 300 POUNDS

WEIGHT:

CONFIGURATION: 2 X 320 GAL WING TIP TANKS 39,800 POUNDS

| 0 | APPRO | STAMIX | | CAS | PRESSURE | | | APPRO | KIMATE | |
|-------|----------------|--------|---------|-------|------------------|--------|---------|-------------|--------|-------|
| RATE | FROM SEA LEVEL | | | KNOTS | ALTITUDE FEET | KNOTS | P | ROM SEA LEV | EL | RATE |
| CLIMB | DIST. | TIME | FUEL | MIOID | PECI | MINOIS | FUEL | TIME | DIST. | CLIMB |
| 5250 | 0 | 0 | 985 (1) | 342 | SEA LEVEL | 341 | 985 (1) | 0 | 0 | 5820 |
| 4600 | 0 | 1.0 | 1230 | 333 | 5,000 | 332 | 1200 | 0.9 | 6 | 5200 |
| 4000 | 13 | 2.2 | 1490 | 322 | 10,000 | 321 | 1430 | 2.0 | 12 | 4500 |
| 3500 | 22 | 3.5 | 1740 | 309 | 15,000 | 308 | 1650 | 3.1 | 19 | 3950 |
| 2950 | 32 | 5.0 | 2000 | 294 | 20,000 | 293 | 1880 | 4.4 | 28 | 3350 |
| 2400 | 43 | 6.9 | 2270 | 278 | 25,000 | 277 | 2110 | 6.0 | 38 | 2800 |
| 1850 | 60 | 9.2 | 2550 | 260 | 30,000 | 259 | 2350 | 8.0 | 52 | 2250 |
| 1350 | 81 | 12.3 | 2860 | 239 | 35,000 | 239 | 2600 | 10.6 | 69 | 1700 |
| 650 | 119 | 17.3 | 3280 | 215 | 40,000 | 214 | 2910 | 14.3 | 98 | 980 |
| | | | | | 45,000 | 191 | 3460 | 22.6 | 153 | 250 |
| | | | | | 50,000 | | | | | |

REMARKS:

- (1) ALLOWANCE FOR START ENGINES, TAXI, TAKE-OFF AND ACCELERATE-TO-CLIMB SPEED.
- (2) CLIMB AT RECOMMENDED CAS.

RATE OF CLIMB: FEET PER MINUTE DISTANCE: Naut, MILES

TIME: MINUTES FUEL: POUNDS/HR

CAS: CALIBRATED AIRSPEED KNOTS

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

MODEL(S): B-57B

STANDARD DAY ONE ENGINE OPERATION

ENGINE(S): (ONE) J65-W-5

CONFIGURATION:

WEIGHT:

CLEAN

30,500 POUNDS

CONFIGURATION:

WEIGHT:

| | APPRO | XIMATE | | 100 | PRESSURE | 913 | | APPRO) | CIMATE | |
|-------------|----------------|--------|--------------------|-------|------------------|-----|----------------|--------|--------|-------------|
| RATE | FROM SEA LEVEL | | | KNOTS | ALTITUDE FEET | CAS | FROM SEA LEVEL | | | RATE |
| OF CLIMB | DIST. | TIME | FUEL | | PEET | | FUEL | TIME | DIST. | OF CLIMB |
| 2450 | 0 | 0 | 985 (1) | 234 | SEA LEVEL | | | | | |
| 2100 | 9 | 2.2 | 1230 | 223 | 5,000 | | | | | |
| 1750 | 18 | 4.8 | 1490 | 213 | 10,000 | | | | | |
| 1400 | 33 | 8.0 | 1780 | 208 | 15,000 | | | | | |
| 1040 | 51 | 12.1 | 2100 | 198 | 20,000 | | | | | |
| 700 | 76 | 17.6 | 2450 | 188 | 25,000 | | | | | |
| 400 | 120 | 27.6 | 2990 | 178 | 30,000 | | | | | |
| | | | THE REAL PROPERTY. | | 35,000 | | | | | |
| | | 1.0 | | | 40,000 | | | | | |
| | | | | | 45,000 | | | | | |
| | | | | | 50,000 | | | | | |

CONFIGURATION: WEIGHT:

CONFIGURATION: WEIGHT:

| | APPRO | KIMATE | | CAS | PRESSURE | CAS | | APPRO | CIMATE | |
|-------------|----------------|--------|------|------------------|-----------|-------|-------------|-------|--------|-------------|
| RATE | FROM SEA LEVEL | | | ALTITUDE FEET | CAS | F | ROM SEA LEV | EL | RATE | |
| OF CLIMB | DIST. | TIME | FUEL | | 1 221 | | FUEL | TIME | DIST. | OF CLIMB |
| | | | | | SEA LEVEL | LIN | Januar | | | |
| - 4015 | | | | 1 195 | 5,000 | 11 | | | | |
| DOC | | | | ULI | 10,000 | | | | | |
| AST | | 1.4 | | N. International | 15,000 | | | | | |
| | | | | | 20,000 | | | | | |
| | | | | | 25,000 | | | | | |
| -0.015 | | 10.0 | | | 30,000 | 1 500 | | | | |
| 101 | | II.UI | | | 35,000 | | | | | |
| | | . 6.10 | | | 40,000 | | | | | |
| 100 | T III | | | | 45,000 | | | | | |
| | | | | | 50,000 | | | | | |

REMARKS:

- (1) ALLOWANCE FOR START ENGINES, TAXI, TAKE-OFF AND ACCELERATE-TO-CLIMB SPEED.
- (2) CLIMB AT RECOMMENDED CAS.

RATE OF CLIMB: FEET PER MINUTE DISTANCE: NA UTILES TIME: MINUTES
FUEL: POUNDS

CAS: CALIBRATED AIRSPEED KNOTS

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

CLIMB CHART FOR MILITARY POWER

MODEL(S): B-57B

STANDARD DAY ONE ENGINE OPERATION

ENGINE(S): (ONE) J65-W-5

CONFIGURATION: CLEAN WEIGHT:

48, 500 POUNDS

CONFIGURATION: CLEAN

WEIGHT: 44,000 POUNDS

| | APPRO | DXIMATE | | | PRESSURE | 2000 | | APPRO | XIMATE | |
|-------|-------|-------------|---------|-------|-----------|--------|---------|-------------|--------|-------------|
| RATE | | FROM SEA LE | VEL | KNOTS | ALTITUDE | KNOTS | F | ROM SEA LEY | 'EL | RATE |
| CLIMB | DIST. | TIME | FUEL | | FEET | ALIOID | FUEL | TIME | DIST. | OF CLIME |
| 1170 | 0 | 0 | 985 (1) | 246 | SEA LEVEL | 243 | 985 (1) | 0 | 0 | 1400 |
| 900 | 21 | 4.6 | 1560 | 242 | 5,000 | 237 | 1430 | 3.8 | 16 | 1130 |
| 660 | 48 | 11.1 | 2190 | 232 | 10,000 | 227 | 1940 | 8.9 | 38 | 860 |
| 400 | 89 | 20.5 | 2980 | 226 | 15,000 | 222 | 2550 | 15.8 | 68 | 580 |
| 140 | 177 | 41.0 | 4460 | 216 | 20,000 | 212 | 3390 | 27.2 | 122 | 300 |
| | | | | | 25,000 | | | | | |
| | | | | HELL | 30,000 | | | | | |
| | | | | | 35,000 | Lift I | | | | |
| | | | | | 40,000 | 100-1 | | | | |
| | | | | | 45,000 | 10-1 | | | | |
| | | | | | 50,000 | | | | | |

CONFIGURATION: CLEAN WEIGHT:

39,500 POUNDS

CONFIGURATION: CLEAN WEIGHT:

35,000 POUNDS

| | APPRO | DXIMATE | | | Docesing | | | APPRO | XIMATE | |
|-------|-------|-------------|---------|--------|----------------------|-------|---------|-------|--------|-------------|
| RATE | | FROM SEA LE | VEL. | KNOTS | PRESSURE ALTITUDE | KNOTS | F | RATE | | |
| CLIMB | DIST. | TIME | FUEL | 12.010 | FEET | MOIS | FUEL | TIME | DIST. | OF CLIMB |
| 1700 | 0 | 0 | 985 (1) | 240 | SEA LEVEL | 237 | 985 (1) | 0 | 0 | 2050 |
| 1400 | 13 | 3.1 | 1340 | 232 | 5,000 | 228 | 1280 | 2.5 | 11 | 1740 |
| 1100 | 30 | 7.1 | 1760 | 222 | 10,000 | 218 | 1600 | 5.7 | 24 | 1400 |
| 800 | 53 | 12.4 | 2220 | 217 | 15,000 | 213 | 1960 | 9.8 | 41 | 1080 |
| 500 | 88 | 20.0 | 2800 | 207 | 20,000 | 203 | 2370 | 15.3 | 65 | 750 |
| 200 | 152 | 33.8 | 3630 | 197 | 25,000 | 193 | 2910 | 24.0 | 105 | 450 |
| | | | | | 30,000 | 183 | 3800 | 46.0 | 210 | 130 |
| | | | | | 35,000 | | | | | |
| | | | | | 40,000 | | | | | |
| | | | | | 45,000 | | | | | |
| | | | | | 50,000 | | | | | |

REMARKS:

- (1) ALLOWANCE FOR START ENGINES, TAXI, TAKE-OFF AND ACCELERATE-TO-CLIMB SPEED.
- (2) CLIMB AT RECOMMENDED CAS.

RATE OF CLIMB: FEET PER MINUTE DISTANCENA UTMLES TIME: MINUTES
FUEL: POUNDS

CAS: CALIBRATED AIRSPEED KNOTS

DATA AS OF: 1 OCTOBER 1953
DATA BASIS: ESTIMATE

DESCENT CHART

STANDARD DAY

MODEL B-57B

FUSELAGE AND WING BRAKES EXTENDED IDLING POWER

ENGINE(S):(TWO) J65-W-5

CONFIGURATION: CLEAN

WEIGHT:

35,600 POUNDS

CONFIGURATION: CLEAN

WEIGHT:

30, 100 POUNDS

| | APPROX | IMATE | | | DDECCUDE | | | APPR | DXIMATE | |
|---------------|----------|------------|------|-------|----------------------|-------|------|------|----------|---------|
| RATE | , | O SEA LEVE | | CAS | PRESSURE ALTITUDE | CAS | | RATE | | |
| OF DESCENT | DISTANCE | TIME | FUEL | KNOTS | FEET | KNOTS | PUEL | TIME | DISTANCE | DESCENT |
| | | | | | 50,000 | i see | | | | |
| 4, 200 | 34 | 4.8 | 105 | 200 | 45,000 | 200 | 91 | 4.2 | 29 | 4, 500 |
| 5. 150 | 26 | 3.7 | 91 | 220 | 40,000 | 220 | 78 | 3.2 | 22 | 5, 700 |
| 6,200 | 20 | 2,8 | 80 | 250 | 35,000 | 250 | 68 | 2.4 | 17 | 7,000 |
| 7, 750 | 15 | 2.0 | 69 | 280 | 30,000 | 280 | 60 | 1.8 | 12 | 8, 900 |
| 9, 700 | | 1.5 | 57 | 310 | 25,000 | 310 | 49 | 1,2 | 9 | 11, 200 |
| 12,300 | 7 | 1.0 | 46 | 345 | 20,000 | 345 | 39 | . 9 | 6 | 14, 400 |
| 15, 900 | 3 | . 7 | 31 | 378 | 15,000 | 378 | 26 | . 5 | 4 | 18,900 |
| 20,800 | 2 | . 4 | 17 | 415 | 10,000 | 415 | 14 | . 3 | 2 | 24, 800 |
| 26,300 | 1 | . 2 | 6 | 451 | 5,000 | 451 | 5 | .1 | 1 | 31,600 |
| 31,900 | 0 | 0 | 0 | 490 | SEA LEVEL | 490 | 0 | 0 | 0 | 38,000 |

CONFIGURATION: WEIGHT: CONFIGURATION: WEIGHT:

| | APPROX | IMATE | | | DDECCUDE | | | APPRO | DXIMATE | |
|---------------|----------|------------|--------|------|----------|------|--------------|-------------|----------|------------|
| RATE | 1 | O SEA LEVE | | CAS | PRESSURE | CAS | | TO SEA LEVI | EL . | RATE OF |
| OF DESCENT | DISTANCE | TIME | FUEL | | FEET | | FUEL | TIME | DISTANCE | DESCENT |
| Her | | | or the | | 50,000 | 1018 | | | | |
| | | | | 1111 | 45,000 | | 1911 | | | |
| 100 | | 711 | DUEC | 10.0 | 40,000 | | The state of | 777 | | |
| VIII | | | | 141 | 35,000 | THE | | 1.11 | | |
| DEF | | | | 12 1 | 30,000 | 102 | | THE PERSON | | |
| 0.4 | | 111 | PIN. | | 25,000 | | | | | |
| 68.1 | | U-iii | | 191 | 20,000 | | | | | |
| | | | | | 15,000 | | | | | |
| | | | | | 10,000 | | | | | |
| | | 34 | | | 5,000 | | | | | |

SEA LEVEL

REMARKS:

RATE OF DESCENT FEET FOR MINUTE DISTANCE NAUT, MILES TIME: MINUTES FUEL: POUNDS
CAS: CALIBRATED AIRSPEED KNOTS

- MAINTAIN IDLE POWER THROUGHOUT DESCENT.
- (2) REFER TO MAXIMUM GLIDE CHART FOR OPTIMUM DESCENT RANGE WITHOUT POWER, SPEED BRAKES RETRACTED.

DATA AS OF:15 DECEMBER 1953 DATA BASIS:ESTIMATE

DESCENT CHART

STANDARD DAY

MODEL B-57B

FUSELAGE AND WING BRAKES EXTENDED IDLING POWER

ENGINE(S):(TWO) J65-W-5

WEIGHT:

CONFIGURATION: 2 X 320 GAL WING TIP TANKS

36,500 POUNDS

CONFIGURATION: 2 X 320 GAL WING TIP TANKS

31,000 POUNDS

| | APPRO) | CIMATE | | | Docesion | | | APPR | DXIMATE | |
|---------|----------|-------------|------|--------|-----------|--------|------|------------|----------|---------|
| RATE | | TO SEA LEVE | | CAS | PRESSURE | CAS | ** | TO SEA LEV | EL | RATE |
| DESCENT | DISTANCE | TIME | FUEL | KNOTS | FEET | KNOTS | FUEL | TIME | DISTANCE | DESCENT |
| | | | | | 50,000 | | | | | |
| 4, 400 | 33 | 4.7 | 106 | 200 | 45,000 | 200 | 91 | 4.2 | 29 | 4,650 |
| 5, 250 | 26 | 3.7 | 90 | 220 | 40,000 | 220 | 78 | 3.2 | 22 | 5,800 |
| 6,300 | 20 | 2.8 | 80 | 250 | 35,000 | 250 | 68 | 2.4 | 16 | 7, 150 |
| 7, 800 | 14 | 2.1 | 70 | 280 | 30,000 | 280 | 60 | 1.8 | 12 | 9,000 |
| 9,850 | 10 | 1.4 | 59 | 310 | 25,000 | 310 | 50 | 1.2 | 9 | 11,400 |
| 12,700 | 7 | 1.0 | 47 | 345 | 20,000 | 345 | 39 | . 8 | 6 | 14,600 |
| 16, 400 | 5 | .6 | 32 | 380 | 15,000 | 380 | 27 | . 5 | 4 | 19, 200 |
| 20, 900 | 3 | .4 | 19 | 415 | 10,000 | 415 | 16 | .3 | 2 | 24, 700 |
| 24, 300 | 1 | .2 | 8 | 440(1) | 5,000 | 440(1) | 7 | .1 | 1 | 28,600 |
| 25,000 | 0 | 0 | 0 | 434(1) | SEA LEVEL | 434(1) | 0 | 0 | 0 | 29,700 |

CONFIGURATION: WEIGHT:

CONFIGURATION: WEIGHT:

| | APPROX | IMATE | | - | DDECCUDE | Aust | | APPRO | DXIMATE | |
|---------|----------|------------|------|-----|-----------|------|------|--------------|---------|---------|
| RATE | r | O SEA LEVE | | CAS | PRESSURE | CAS | | TO SEA LEVEL | | RATE |
| DESCENT | DISTANCE | TIME | FUEL | | FEET | | PUEL | | | DESCENT |
| | | | | | 50,000 | | | | | |
| | | 1045 | | | 45,000 | | | | | _ |
| | | | | | 40,000 | 1 | | | - | - |
| | | | | | 35,000 | | | | | |
| | | | | | 30,000 | | | | | |
| | | | | | 25,000 | | | | | |
| | | | | | 20,000 | | | | | |
| | | | | | 15,000 | | | | | |
| | | | | | 10,000 | | | | | |
| | | | | | 5,000 | | | | | |
| | | | | | SEA LEVEL | | | | | |

REMARKS:

- (1) SPEED LIMITED BY PROVED LIMITS OF NORMAL CONTROL
- (2) MAINTAIN IDLE POWER THROUGHOUT DESCENT.
- (3) REFER TO MAXIMUM GLIDE CHART FOR OPTIMUM DESCENT RANGE WITHOUT POWER, SPEED BRAKES RETRACTED.

DATA AS OF: 15 DECEMBER 1953 DATA BASIS: ESTIMATE

RATE OF DESCENT DISTANCE: Naut MILES TIME: MINUTES FUEL: POUNDS CAS: CALIBRATED AIRSPEED KNOTS

DESCENT CHART

STANDARD DAY

MODEL B-57B

ONE ENGINE OPERATION

ENGINE(S): (ONE) J65-W-5

CONFIGURATION: CLEAN

CLEAN 35 600 POUNDS ____

CONFIGURATION: CLEAN

WEIGHT:

30, 100 POUNDS

| | APPROX | IMATE | | | PRESSURE | | | APPR | DXIMATE | |
|---------------|----------|------------|------|-------|-----------|--------|--------------|------|----------|-------------|
| RATE | 7 | O SEA LEVE | | CAS | ALTITUDE | DE CAS | TO SEA LEVEL | | | RATE |
| OF DESCENT | DISTANCE | TIME | FUEL | KNOTS | FEET | KNOTS | FUEL | TIME | DISTANCE | DESCENT |
| | | | | | 50,000 | | | | | |
| | | | | | 45,000 | | | | | |
| | | | | | 40,000 | | | | | The VILLAGE |
| | | | | | 35,000 | | | | | 1 |
| 9600 | 13 | 1.8 | 32 | 280 | 30,000 | 280 | 27 | 1.6 | 11 | 11,500 |
| 11, 200 | 10 | 1.3 | 27 | 310 | 25,000 | 310 | 23 | 1.1 | 8 | 13,300 |
| 13,900 | 7 | . 9 | 22 | 345 | 20,000 | 345 | 18 | . 8 | 5 | 16, 400 |
| 17,300 | 4 | . 6 | 14 | 378 | 15,000 | 378 | 12 | .5 | 3 | 20,600 |
| 21,600 | 3 | .3 | 8 | 415 | 10,000 | 415 | 7 | .3 | 2 | 26,000 |
| 27, 400 | 1 | .1 | 3 | 451 | 5,000 | 451 | 2 | .1 | 1 | 33, 100 |
| 34,600 | 0 | 0 | 0 | 490 | SEA LEVEL | 490 | 0 | 0 | 0 | 41,800 |

CONFIGURATION: WEIGHT:

CONFIGURATION: WEIGHT:

+

| | APPROX | IMATE | | | DDECCUDE | | | APPRO | XIMATE | un u |
|---------------|----------|-------------|------|-----|----------------------|-----|------|-------------|----------|---------|
| RATE | т | O SEA LEVEL | | CAS | PRESSURE ALTITUDE | CAS | | TO SEA LEVI | L | RATE |
| OF DESCENT | DISTANCE | THE | FUEL | | FEET | | FUEL | TIME | DISTANCE | DESCENT |
| | | | | | 50,000 | | | | | |
| | | | | | 45,000 | | | | | |
| | | | | | 40,000 | | | | | |
| | | | | | 35,000 | | | | | |
| | | | | | 30,000 | | | | | |
| | | | | | 25,000 | | | | | |
| | | | | | 20,000 | | | | | |
| | | | | | 15,000 | | | | | |
| | | | | | 10,000 | | | | | |
| | | | | | 5,000 | | | | | |
| | | | | | SEA LEVEL | | | | | |

REMARKS:

- (1) MAINTAIN IDLE POWER ON OPERATING ENGINE THROUGHOUT DESCENT.
- (2) REFER TO MAXIMUM GLIDE CHART FOR OPTIMUM DESCENT RANGE WITHOUT POWER. SPEED BRAKES RETRACTED.
- (3) SPEED SCHEDULE IS APPROXIMATELY M = .74

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE DESCENT
RATE OF FEET PER MINUTE
DISTANCE: NA UTILES
TIME: MINUTES
FUEL: POUNDS
CAS: CALIBRATED AIRSPEED KNOTS

LANDING DISTANCE - FEET STANDARD DAY

MODEL (S): B-57C AND B

ENGINE (S)(TWO) J65-W-5

| GROSS | | BEST CAS FOR APPROACH | | 60 DEGREE FLAPS - HARD SURFACE - NO WIND | | | | | | | | | |
|--------------|-------|--------------------------|--------------|--|------------|--------------|------------|--------------|----------------|-------|--|--|--|
| WEIGHT LB | POWER | POWER | AT SEA LEVEL | | AT 2000 FT | | AT 4000 FT | | AT 6000 FT | | | | |
| L.D | OFF | ON | GROUND | CLEAR 58' | GROUND | CLEAR 50° | GROUND | CLEAR 50° | GROUND ROLL | CLEA! | | | |
| 50,000 | 143 | 143 | 2180 | 4250 | 2310 | 4500 | 2460 | 4760 | 2620 | 5030 | | | |
| 40,000 | 128 | 128 | 1750 | 3580 | 1850 | 3800 | 1970 | 4030 | 2100 | 4250 | | | |
| 30,000 | 111 | 111 | 1310 | 2930 | 1400 | 3110 | 1490 | 3300 | 1570 | 3470 | | | |
| 26,000 | 103 | 103 | 1140 | 2670 | 1220 | 2840 | 1300 | 3010 | 1370 | 3170 | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |

REMARKS:

- (a) DATA BASED ON LANDING WITH SPEED BRAKES RETRACTED.
- (b) FOR LANDING WITH SPEED BRAKES EXTENDED, REDUCE THESE DISTANCES BY 5%.
- (c) THESE LANDING DISTANCES AND APPROACH SPEEDS ARE PART OF NORMAL LANDING PROCEDURE. OPTIMUM LANDING TECHNIQUE RESULTS IN SHORTER DISTANCES.

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

CAS: CALIBRATED AIRSPEED

Figure A-21

STANDARD DAY

MODEL (S): B-57B

ENGINE(S): (TWO) J65-W-5

CONFIGURATION: CLEAN
WEIGHT: 30,500 POUNDS

CONFIGURATION:

WEIGHT:

| APPRO | XIMATE | | PRESSURE | CAS | APPROX | IMATE |
|--------|--------|-------|------------------|-----|--------|----------------|
| LB/MR. | %RPM | KNOTS | ALTITUDE FEET | CAS | SRPM | /HR. |
| 3240 | 71 | 150 | SEA LEVEL | | | |
| 2920 | 72 | 150 | 5,000 | | | |
| 2650 | 73 | 150 | 10,000 | | | |
| 2450 | 74 | 150 | 15,000 | | | |
| 2280 | 75 | 150 | 20,000 | | | |
| 2150 | 77 | 151 | 25,000 | | | Sy 12 (2 3) 17 |
| 2070 | 78 | 153 | 30,000 | | | |
| 2020 | 81 | 156 | 35,000 | | | |
| 2110 | 84 | 160 | 40,000 | | | |
| 2200 | 89 | 163 | 45,000 | | | |
| 2280 | 95 | 167 | 50,000 | | | |

CONFIGURATION: WEIGHT:

CONFIGURATION: WEIGHT:

| APPRO | XIMATE | CAS | PRESSURE | resuma s | APPROX | IMATE |
|-------|------------|-----|------------------|----------|--------|-------|
| /HR. | SRPM | CAS | ALTITUDE FEET | CAS | %RPM | /HR |
| | 7-27-27-20 | -66 | SEA LEVEL | | | |
| | | | 5,000 | | | |
| | | | 10,000 | | | |
| | | | 15,000 | | | |
| | | | 20,000 | | | |
| | | | 25,000 | | | |
| | | | 30,000 | | | |
| | 8 | | 35,000 | | | |
| | | | 40,000 | | | |
| | | | 45,000 | | | |
| | | | 50,000 | - | | |

REMARKS:

CAS - CALIBRATED AIRSPEEDKN. LB/HR. - FUEL CONSUMPTION

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

MODEL (S): B-57B

STANDARD DAY

ENGINE(S):(TWO) J65-W-5

CONFIGURATION: CLEAN WEIGHT: 48.500

48, 500 POUNDS

CONFIGURATION: CLEAN

WEIGHT:

44,000 POUNDS

| APPRO | XIMATE | | PRESSURE | | APPR | DXIMATE |
|--------|--------|-------|------------------|-------|------|---------|
| LB/MR. | %RPM | KNOTS | ALTITUDE FEET | KNOTS | SRPM | LB/MR. |
| 4200 | 76 | 188 | SEA LEVEL | 180 | 74 | 3900 |
| 3910 | 77 | 188 | 5,000 | 180 | 76 | 3650 |
| 3700 | 79 | 188 | 10,000 | 180 | 78 | 3420 |
| 3530 | 80 | 188 | 15,000 | 180 | 79 | 3260 |
| 3400 | 82 | 188 | 20,000 | 180 | 80 | 3130 |
| 3350 | 84 | 190 | 25,000 | 182 | 82 | 3070 |
| 3350 | 86 | 193 | 30,000 | 184 | 84 | 3030 |
| 3450 | 90 | 198 | 35,000 | 187 | 88 | 3030 |
| | | | 40,000 | 192 | 92 | 3200 |
| | | | 45,000 | | | |
| | | | 50,000 | | | |

CONFIGURATION: CLEAN 89,500 POUNDS

CONFIGURATION: CLEAN WEIGHT: 35,000 I

35,000 POUNDS

| | | 7 | | | | |
|---------|--------|-------|------------------|-------|------|---------|
| APPRO | XIMATE | CAS | PRESSURE | CAS | APPR | OXIMATE |
| LB /MR. | %RPM | KNOTS | ALTITUDE FEET | KNOTS | SRPM | LB /MR. |
| 3700 | 73 | 171 | SEA LEVEL | 160 | 72 | 3460 |
| 3400 | 75 | 171 | 5,000 | 160 | 73 | 3150 |
| 3160 | 76 | 171 | 10,000 | 160 | 74 | 2900 |
| 3000 | 77 | 171 | 15,000 | 160 | 76 | 2710 |
| 2850 | 79 | 171 | 20,000 | 160 | 77 | 2570 |
| 2750 | 80 | 172 | 25,000 | 162 | 79 | 2460 |
| 2700 | 82 | 174 | 30,000 | 164 | 80 | 2400 |
| 2660 | 85 | 177 | 35,000 | 167 | 83 | 2350 |
| 2810 | 90 | 182 | 40,000 | 170 | 87 | 2460 |
| 2960 | 96 | 190 | 45,000 | 174 | 92 | 2600 |
| | | | 50,000 | | | |

REMARKS:

CAS - CALIBRATED AIRSPEEDKN.
L B/HR. - PUEL CONSUMPTION

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

STANDARD DAY

MODEL (\$): B-57B

ENGINE(S): (TWO) J65-W-5

| APPRO | KIMATE | | PRESSURE | | APPRO | DXIMATE | |
|--------|--------|-------|------------------|-------|-------------|--------------|--|
| LB/MR. | %RPM | KNOTS | ALTITUDE | KNOTS | SRPM | LB /HR. | |
| 3470 | 72 | 156 | SEA LEVEL | 145 | 71 | 3280 | |
| 3180 | 73 | 156 | 5,000 | 145 | 71 | 2930 | |
| 2930 | 75 | 156 | 10,000 | 145 | 73 | 2670 | |
| 2740 | 76 | 156 | 15,000 | 145 | 74 | 2480 | |
| 2620 | 78 | 158 | 20,000 | 145 | 76 | 2340 | |
| 2500 | 79 | 158 | 25,000 | 150 | 77 | 2230 | |
| 2450 | 81 | 160 | 30,000 | 150 | 79 | 2140 | |
| 2440 | 84 | 163 | 35,000 | 150 | 81 | 2080 | |
| 2580 | 88 | 166 | 40,000 | 155 | 85 | 2180 | |
| 2720 | 94 | 170 | 45,000 | 160 | 91 | 2300 | |
| | | | 50,000 | | | | |
| APPRO | XIMATE | CAS | PRESSURE | CAS | APPROXIMATE | | |
| /HR. | SRPM | | ALTITUDE FEET | | SRPM | /HR. | |
| | | | SEA LEVEL | | | | |
| | | | 5,000 | | | | |
| | | | 10,000 | | | | |
| -/ | | | 15,000 | | | | |
| | | | 20,000 | | | | |
| | | | 25,000 | | | | |
| 1000 | | | 30,000 | | | | |
| | | | 35,000 | | | | |
| | | | 40,000 | | | | |
| ONE C | | | 45,000 | | | | |
| | 19 | 4 4 4 | 50,000 | | | | |
| | | | | | | | |

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

MODEL (S): B-57B

STANDARD DAY

ENGINE(S): (TWO) J65-W-5

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT: 53,000 POUNDS 53,000 POUNDS

WEIGHT:

CONFIGURATION: 2 X 320 GAL WING TIP TANKS 48,800 POUNDS

| APPRO | XIMATE | CAS | PRESSURE | | APPR | DXIMATE |
|--------|--------|-------|------------------|-------|------|---------|
| LB/MR. | SRPM | KNOTS | ALTITUDE FEET | KNOTS | SRPM | LB/HR |
| 4440 | 77 | 194 | SEA LEVEL | 185 | 76 | 4190 |
| 4200 | 78 | 194 | 5,000 | 185 | 77 | 3960 |
| 4010 | 80 | 194 | 10,000 | 185 | 79 | 3750 |
| 3880 | 82 | 194 | 15,000 | 185 | 81 | 3610 |
| 3800 | 84 | 195 | 20,000 | 187 | 83 | 3500 |
| 3780 | 86 | 195 | 25,000 | 187 | 85 | 3480 |
| 3830 | 89 | 198 | 30,000 | 190 | 87 | 3490 |
| 3940 | 92 | 202 | 35,000 | 193 | 91 | 3560 |
| | | | 40,000 | | | |
| | | | 45,000 | | | |
| | | | 50,000 | | | |

CONFIGURATION: 2 X 320 GAL WING TIP TANKS 44,300 POUNDS

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT: 39,800 POUNDS

| APPRO | XIMATE | CAS | PRESSURE | | APPR | OXIMATE |
|---------|--------|-------|------------------|-------|------|--------------|
| LB /HR. | SRPM | KNOTS | ALTITUDE FEET | KNOTS | SRPM | LB/MR. |
| 3940 | 75 | 176 | SEA LEVEL | 166 | 74 | 3700 |
| 3700 | 77 | 176 | 5,000 | 166 | 75 | 3440 |
| 3470 | 78 | 176 | 10,000 | 166 | 77 | 3200 |
| 3300 | 79 | 176 | 15,000 | 166 | 78 | 3020 |
| 3200 | 81 | 178 | 20,000 | 169 | 79 | 2900 |
| 3140 | 83 | 178 | 25,000 | 169 | 81 | 2820 |
| 3120 | 85 | 180 | 30,000 | 171 | 83 | 2780 |
| 3180 | 88 | 184 | 35,000 | 174 | 86 | 2800 |
| 3340 | 94 | 188 | 40,000 | 177 | 91 | 2960 |
| | | | 45,000 | | | |
| | | | 50,000 | | | |

REMARKS:

CAS - CALIBRATED AIRSPEEDKN. LB /MR. - FUEL CONSUMPTION

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

MODEL (S): B-57B

STANDARD DAY ONE ENGINE OPERATION

ENGINE(S): (ONE) J65-W-5

CONFIGURATION: CLEAN WEIGHT: 30,500 1

30,500 POUNDS

CONFIGURATION: WEIGHT:

| APPRO | XIMATE | CAS | PRESSURE | 545 | APPROXIMATE | | |
|---------|--------|-------|------------------|----------|-------------|------|--|
| LB /wr. | %RPM | erona | ALTITUDE FEET | CAS | %RPM | /HR. | |
| 2600 | 80 | 142 | SEA LEVEL | | | | |
| 2370 | 81 | 148 | 5,000 | | | | |
| 2200 | 82 | 151 | 10,000 | | | | |
| 2130 | 83 | 154 | 15,000 | | | | |
| 2120 | 86 | 154 | 20,000 | fine the | | | |
| 2230 | 89 | 154 | 25,000 | | | | |
| | | | 30,000 | | | | |
| | | | 35,000 | | | | |
| | | | 40,000 | | | | |
| | | | 45,000 | | | | |
| | | | 50,000 | | | | |

CONFIGURATION: WEIGHT:

CONFIGURATION: WEIGHT:

| APPRO | XIMATE . | CAS | PRESSURE ALTITUDE | CAS | APPRO) | CIMATE |
|-------|----------|-----|----------------------|--------------|--------|--------|
| /HR. | %RPM | | ALTITUDE FEET | CAS . | %RPM | /HR |
| | | | SEA LEVEL | | | |
| | | | 5,000 | L ITA | | |
| | | | 10,000 | | | |
| | | | 15,000 | | | |
| | | | 20,000 | I I I I I | 10 | |
| | | | 25,000 | | | |
| mani. | | 174 | 30,000 | | | |
| And I | | | 35,000 | | | |
| | | | 40,000 | The state of | | |
| 2000 | | 2 | 45,000 | | | |
| | | | 50,000 | | | |

REMARKS:

CAS - CALIBRATED AIRSPEED KN
LB/MR. - FUEL CONSUMPTION

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

STANDARD DAY

MODEL (S): B-57B

ENGINE(S): (ONE) J65-W-5

CONFIGURATION: CLEAN WEIGHT: 48,500 POUNDS

CONFIGURATION: CLEAN

WEIGHT:

44,000 POUNDS

| APPRO | XIMATE | CAS | PRESSURE | | APPR | OXIMATE |
|--------|--|-------|------------------|-------|------|---------|
| LB/MR. | 5RPM | KNOTS | ALTITUDE FEET | knots | %RPM | LB /HR. |
| 3800 | 88 | 184 | SEA LEVEL | 174 | 86 | 3500 |
| 3630 | 90 | 188 | 5,000 | 177 | 88 | 3320 |
| 3540 | 92 | 190 | 10,000 | 180 | 89 | 3200 |
| 3550 | 93 | 191 | 15,000 | 181 | 91 | 3180 |
| | | | 20,000 | 182 | 92 | 3300 |
| | | | 25,000 | | | 0000 |
| | | | 30,000 | | | 1,07 |
| | | | 35,000 | | | |
| | | | 40,000 | | | |
| | | | 45,000 | ONL | m | 0.01 |
| | University of the Control of the Con | | 50,000 | | | 1 |

CONFIGURATION: CLEAN WEIGHT: 39,500 PC

39,500 POUNDS

CONFIGURATION: CLEAN

WEIGHT:

35,000 POUNDS

| APPRO | XIMATE | CAS | PRESSURE | | APPR | OXIMATE |
|---------|--------|-------|------------------|-------|-----------|--------------------|
| LB /MR. | %RPM | KNOTS | ALTITUDE FEET | KNOTS | %RPM | LB/HR. |
| 3200 | 84 | 163 | SEA LEVEL | 153 | 82 | 2880 |
| 3020 | 85 | 168 | 5,000 | 158 | 83 | 2690 |
| 2900 | 87 | 171 | 10,000 | 161 | 84 | 2550 |
| 2840 | 88 | 172 | 15,000 | 163 | 86 | 2460 |
| 2870 | 90 | 173 | 20,000 | 163 | 88 | 2500 |
| 3050 | 93 | 173 | 25,000 | 164 | 91 | 2630 |
| | | | 30,000 | | | |
| | | | 35,000 | | | |
| | | | 40,000 | | ARA MARIA | THE REAL PROPERTY. |
| | | | 45,000 | | | |
| | | | 50,000 | | | |

REMARKS:

CAS - CALIBRATED AIRSPEED KN L B/HR. - FUEL CONSUMPTION

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

COMBAT ALLOWANCE CHART

CLEAN CONFIGURATION STANDARD DAY

MODEL: B-57B

ENGINES:(TWO) J65-W-5

| Trapporter. | FUEL REQUIR | ED - POUNDS PER MINUT | |
|------------------------|--|---|-------------------------------------|
| AT ALTITUDE FEET | 96.5 % RPM NORMAL POWER MAXIMUM CONTINUOUS | IOO% RPM MILITARY POWER 30 MINUTE LIMIT | FOR LEVEL FLIGHT AT PROVED LIMIT OF |
| SEA LEVEL | | | 210 |
| 5,000 | | | 182 |
| 10,000 | | _ | 163 |
| 15,000 | | _ | 157 |
| 20,000 | 150 | 169 | |
| 25,000 | 124 | 143 | |
| 30,000 | 104 | 111 | |
| 35,000 | 91 | 98 | |
| 40,000 | 6.5 | 78 | |
| 4 5,000 | | | 8 |
| NA I | | 1 -//- | |
| | | | |

REMARKS:

CLEAN: GROSS WEIGHT = 42,000 LB.

DATA AS OF: | OCTOBER 1953

DATA BASIS: ESTIMATE

FUEL GRADE: JP-4

FUEL DENSITY: 6.5 LB/GAL.

STANDARD DAY

MODEL : B-57B

ENGINE(S): (TWO) J65-W-5

CONFIGURATION: 2 X 320 GAL WING TIP TANKS 53,000 POUNDS

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT:

48,800 POUNDS

| A | PPROXIMAT | E | | PRESSURE | | | APPROXIMAT | rE |
|---------|--------------|--------------|------|------------------|------|--------------|--------------|--------|
| LB/ HR | TAS KNOTS | CAS KNOTS | %RPM | ALTITUDE FEET | %RPM | CAS KNOTS | TAS KNOTS | LB/HR |
| 10,500 | 434 | 434 | 92 | SEA LEVEL | 91 | 434 | 434 | 10,300 |
| 10, 400 | 468 | 438 | 93 | 5,000 | 93 | 438 | 468 | 10,300 |
| 9,300 | 477 | 420 | 92 | 10,000 | 92 | 420 | 477 | 9,300 |
| 7,900 | 470 | 384 | 92 | 15,000 | 92 | 384 | 470 | 7,700 |
| 6,300 | 460 | 348 | 91 | 20,000 | 91 | 348 | 460 | 6,300 |
| 5,500 | 450 | 313 | 90 | 25,000 | 90 | 313 | 450 | 5, 400 |
| 4,850 | 441 | 281 | 92 | 30,000 | 92 | 281 | 441 | 4, 850 |
| 4,600 | 431 | 251 | 94 | 35,000 | 93 | 251 | 431 | 4, 500 |
| | | | | 40,000 | | | | |
| | | | | 45,000 | | | | |
| | | | | 50,000 | | | | |

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT: 44, 300 POUNDS

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT: 3 9, 800 POUNDS

| A | PPROXIMATI | E | | PRESSURE | | A | PPROXIMAT | E |
|--------|--------------|--------------|------|------------------|------|--------------|--------------|---------|
| LB/ HR | YAS KNOTS | CAS KNOTS | %RPM | ALTITUDE FEET | %RPM | CAS KNOTS | TAS KNOTS | LEMR |
| 10,300 | 434 | 434 | 91 | SEA LEVEL | 91 | 434 | 434 | 10, 200 |
| 10,300 | 468 | 438 | 93 | 5,000 | 93 | 438 | 468 | 10, 200 |
| 9,300 | 477 | 420 | 92 | 10,000 | 92 | 420 | 477 | 9,300 |
| 7,600 | 470 | 384 | 91 | 15,000 | 91 | 384 | 470 | 7,600 |
| 6,300 | 460 | 348 | 91 | 20,000 | 90 | 348 | 460 | 6,000 |
| 5, 400 | 450 | 313 | 90 | 25,000 | 89 | 313 | 450 | 5,200 |
| 4,600 | 441 | 281 | 91 | 30,000 | 90 | 281 | 441 | 4, 400 |
| 4,000 | 431 | 251 | 92 | 35,000 | 90 | 251 | 431 | 3,750 |
| 3,900 | 430 | 225 | 96 | 40,000 | 93 | 225 | 430 | 3,500 |
| | | | | 45,000 | | | | |
| | | | | 50,000 | | | | |

REMARKS:

(1) SPEED LIMITED BY PROVED LIMITS OF NORMAL CONTROL (.75 M ABOVE 8,000 FEET ALTITUDE).

CAS - CALIBRATED AIRSPEED KNOTS TAS - TRUE AIRSPEED KNOTS LB /HR - FUEL CONSUMPTION

DATA AS OF: 15 DECEMBER 1953

DATA BASIS: ESTIMATE

STANDARD DAY

MODEL(S): B-57B

ENGINE(S): (TWO) J65-W-5

CONFIGURATION: CLEAN WEIGHT: 48,500 POUNDS

CONFIGURATION: CLEAN

WEIGHT: 44,000 POUNDS

| | | | | | 11,000 100120 | | | | |
|--------|--------------|--------------|------|------------------|---------------|--------------|--------------|---------|--|
| - | PPROXIMATI | E | | PRESSURE | | A | PPROXIMAT | E | |
| L8/HR | TAS KNOTS | cas KNOTS | %RPM | ALTITUDE FEET | %RPM | cas KNOTS | tas KNOTS | LB /HR | |
| 12,780 | 495 x | 495 x | 94 | SEA LEVEL | 94 | 495 x | 495 x | 12,700 | |
| 11,000 | 496 x | 465 x | 93.5 | 5,000 | 93.5 | 465 x | 496 x | 10, 950 | |
| 9,950 | 499 x | 438 x | 93.5 | 10,000 | 93.5 | 438 x | 499 x | 9,820 | |
| 9,700 | 504 x | 413 x | 95.5 | 15,000 | 95 | 413 x | 504 x | 9,530 | |
| 8,750 | 497 | 378 | 96.5 | 20,000 | 96.5 | 379 | 498 | 8, 750 | |
| 7, 400 | 485 | 339 | 96.5 | 25,000 | 96.5 | 341 | 487 | 7,500 | |
| 6,300 | 473 | 304 | 96.5 | 30,000 | 96.5 | 306 | 476 | 6,300 | |
| 5,250 | 457 | 269 | 96,5 | 35,000 | 96.5 | 272 | 462 | 5, 250 | |
| | | | | 40,000 | 96.5 | 232 | 444 | 4,000 | |
| | | | | 45,000 | | | | | |
| | | | | 50,000 | | | | | |

CONFIGURATION: CLEAN WEIGHT: 39,500 I

39,500 POUNDS

CONFIGURATION: CLEAN

35,000 POUNDS WEIGHT:

| A | PPROXIMATE | | | PRESSURE | | | APPROXIMAT | E |
|---------|--------------|--------------|------|------------------|------|--------------|--------------|---------|
| LB/HR | tas KNOTS | CAS KNOTS | %RPM | ALTITUDE FEET | %RPM | CAS KNOTS | TAS KNOTS | LB/HR |
| 12, 620 | 495 x | 495 x | 94 | SEA LEVEL | 94 | 495 x | 495 x | 12,600 |
| 10, 860 | 496 x | 465 x | 93 | 5,000 | 93 | 465 x | 496 x | 10, 750 |
| 9,720 | 499 x | 438 x | 93 | 10,000 | 93 | 438 x | 499 x | 9,640 |
| 9,360 | 504 x | 413 x | 94.5 | 15,000 | 94.5 | 413 x | 504 x | 9,220 |
| 8,740 | 499 | 380 | 96.5 | 20,000 | 96.5 | 380 | 500 | 8,750 |
| 7,500 | 489 | 343 | 96.5 | 25,000 | 96.5 | 343 | 490 | 7,500 |
| 6,300 | 478 | 308 | 96.5 | 30,000 | 96.5 | 310 | 480 | 6,320 |
| 5, 250 | 466 | 274 | 96.5 | 35,000 | 96.5 | 278 | 469 | 5, 280 |
| 4,000 | 452 | 238 | 96.5 | 40,000 | 96.5 | 241 | 459 | 4, 120 |
| | | | | 45,000 | 96.5 | 207 | 444 | 3,200 |
| | | | | 50,000 | | | | |

REMARKS:

(x) PROVED LIMITS OF NORMAL CONTROL (COMPRESSIBILITY, BUFFET AND/OR PITCH CHANGE).

CAS - CALIBRATED AIRSPEED KNOTS
TAS - TRUE AIRSPEED KNOTS LBHR - FUEL CONSUMPTION

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

STANDARD DAY

ENGINE(S): J65-W-5

MODEL : B-57B

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT: 35,300 POUNDS

WEIGHT

CONFIGURATION: 2 X 320 GAL WING TIP TANKS

T: 30,800 POUNDS

| A | PPROXIMATI | E | HARAS . | PRESSURE | | | APPROXIMAT | rE |
|---------|--------------|--------------|---------|------------------|------|--------------|--------------|---------|
| LB/HR | TAS KNOTS | CAS KNOTS | SRPM | ALTITUDE FEET | %RPM | cas KNOTS | TAS KNOTS | L Bus |
| 10, 100 | 434 | 434 | 91 | SEA LEVEL | 91 | 434 | 434 | 10, 100 |
| 10, 100 | 468 | 438 | 93 | 5,000 | 93 | 438 | 468 | 10, 100 |
| 9,300 | 477 | 420 | 92 | 10,000 | 92 | 420 | 477 | 9,300 |
| 7,500 | 470 | 384 | 91 | 15,000 | 91 | 384 | 470 | 7, 400 |
| 6,000 | 460 | 348 | 90 | 20,000 | 90 | 348 | 460 | 5, 900 |
| 5,000 | 450 | 313 | 89 | 25,000 | 88 | 313 | 450 | 4, 800 |
| 4,200 | 441 | 281 | 89 | 30,000 | 88 | 281 | 441 | 4,000 |
| 3,500 | 431 | 251 | 88 | 35,000 | 87 | 251 | 431 | 3,300 |
| 3,100 | 430 | 225 | 91 | 40,000 | 89 | 225 | 430 | 2,900 |
| | | | | 45,000 | 93 | 200 | 430 | 2,700 |
| | | | | 50,000 | | | | |

CONFIGURATION: WEIGHT:

CONFIGURATION: WEIGHT:

| | APPROXIMATE | E | | PRESSURE | | - | APPROXIMAT | E |
|-----|-------------|-----|------|------------------|------|-----|------------|------|
| LB/ | TAS | CAS | %RPM | ALTITUDE FEET | %RPM | CAS | TAS | /HR |
| | | | | SEA LEVEL | | | | |
| | | | | 5,000 | | | | |
| | | | | 10,000 | | | | |
| | | | | 15,000 | | | | 10.1 |
| | | | | 20,000 | | | | |
| | | | | 25,000 | | | | |
| | | | | 30,000 | | | | |
| | | | | 35,000 | | | | |
| | | | | 40,000 | | | | |
| | | | | 45,000 | | | | |
| | | | | 50,000 | | | | |

REMARKS:

 SPEED LIMITED BY PROVED LIMITS OF NORMAL CONTROL (.75 M ABOVE 8,000 FEET ALTITUDE). CAS - CALIBRATED AIRSPEED KNOTS
TAS - TRUE AIRSPEED KNOTS
/MR - FUEL CONSUMPTION

DATA AS OF: 15 DECEMBER 1953 DATA BASIS: ESTIMATE

STANDARD DAY

MODEL : B-57B

ENGINE(S): (TWO) J65-W-5

CONFIGURATION: 2 X 320 GAL WING TIP TANKS

53,000 POUNDS

CONFIGURATION: 2 X 320 GAL WING TIP TANKS

48,800 POUNDS

| A | PPROXIMAT | E | | PRESSURE | | | APPROXIMAT | E |
|---------|--------------|--------------|------|------------------|------|--------------|--------------|--------|
| LB/ HR | TAS KNOTS | cas KNOTS | %RPM | ALTITUDE FEET | %RPM | CAS KNOTS | TAS KNOTS | LB/HR |
| 10,500 | 434 | 434 | 92 | SEA LEVEL | 91 | 434 | 434 | 10,300 |
| 10, 400 | 468 | 438 | 93 | 5,000 | 93 | 438 | 468 | 10,300 |
| 9,300 | 477 | 420 | 92 | 10,000 | 92 | 420 | 477 | 9,300 |
| 7, 900 | 470 | 384 | 92 | 15,000 | 92 | 384 | 470 | 7,700 |
| 6,300 | 460 | 348 | 91 | 20,000 | 91 | 348 | 460 | 6,300 |
| 5,500 | 450 | 313 | 90 | 25,000 | 90 | 313 | 450 | 5, 400 |
| 4, 850 | 441 | 281 | 92 | 30,000 | 92 | 281 | 441 | 4, 850 |
| 4,600 | 431 | 251 | 94 | 35,000 | 93 | 251 | 431 | 4,500 |
| | 110 | | | 40,000 | | | | |
| | | 1 | | 45,000 | | | | 1977 |
| | | 1000 | | 50,000 | | | | |

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT: 44,300 POUNDS

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT: 39,800 POUNDS

APPROXIMATE **APPROXIMATE PRESSURE** ALTITUDE %RPM **SEPH** CAS TAS LBHR CAS TAS LB/ HR KNOTS KNOTS KNOTS KNOTS SEA LEVEL 91 434 434 10,200 434 91 434 10,300 5,000 438 468 10,200 93 468 438 93 10,300 10,000 92 420 477 9,300 420 92 477 9,300 15,000 91 384 470 7,600 470 384 91 7,600 20,000 460 6,000 348 91 90 460 348 6,300 5,200 25,000 89 313 450 90 450 313 5,400 30,000 281 441 4,400 90 441 281 91 4,600 35,000 90 251 431 3,750 92 431 251° 4,000 40,000 93 225 430 3,500 96 3,900 430 225 45,000 50,000

REMARKS:

(1) SPEED LIMITED BY PROVED LIMITS OF NORMAL CONTROL (.75 M ABOVE 8,000 FEET ALTITUDE).

CAS - CALIBRATED AIRSPEED KNOTS TAS - TRUE AIRSPEED KNOTS

LB /HR - FUEL CONSUMPTION

DATA AS OF: 15 DECEMBER 1953

DATA BASIS: ESTIMATE

STANDARD DAY

MODEL(S): B-57B

ENGINE(S): (ONE) J65-W-5

CONFIGURATION: CLEAN

WEIGHT: 30,500 POUNDS

CONFIGURATION:

| A | PPROXIMATE | | | PRESSURE | | | APPROXIMAT | E |
|-------|--------------|---|------|------------------|------|-----|------------|-----|
| LB/HR | TAS KNOTS | cas KNOTS | %RPM | ALTITUDE FEET | %RPM | CAS | TAS | /HR |
| 6650 | 355 | 355 | 96.5 | SEA LEVEL | | 101 | | |
| 5940 | 362 | 337 | 96.5 | 5,000 | | | | |
| 5230 | 362 | 317 | 96.5 | 10,000 | | | | |
| 4550 | 368 | 298 | 96.5 | 15,000 | | | | |
| 3900 | 365 | 272 | 96.5 | 20,000 | | | | |
| 3250 | 362 | 247 | 96.5 | 25,000 | | | | |
| | | | | 30,000 | | | | |
| | | | | 35,000 | | | | |
| | | NEW COLUMN TO THE PARTY OF THE | | 40,000 | | | | |
| | | | | 45,000 | | | | |
| | | | | 50,000 | | | | |

CONFIGURATION: WEIGHT:

CONFIGURATION: WEIGHT:

| | PPROXIMATI | E | | PRESSURE | | | APPROXIMAT | E |
|-----|------------|-----|------|------------------|------|-----|------------|--|
| LB/ | TAS | CAS | %RPM | ALTITUDE FEET | %RPM | CAS | TAS | /HR |
| | | | 4.0 | SEA LEVEL | | | | |
| | | | | 5,000 | | | , her | |
| | | | | 10,000 | | | T. | TO DESCRIPTION OF THE PERSON O |
| | | | | 15,000 | | | | |
| | | | | 20,000 | | | | |
| | | | | 25,000 | | | | |
| | | | | 30,000 | | | | |
| | | | | 35,000 | | | | |
| | | | | 40,000 | | | | |
| | | | | 45,000 | | | | |
| | | | | 50,000 | | | | |

REMARKS:

CAS - CALIBRATED AIRSPEED KNOTS
TAS - TRUE AIRSPEED KNOTS LB /HR - FUEL CONSUMPTION

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

STANDARD DAY

MODEL(S): B-57B

ENGINE(S): (ONE) J65-W-5

CONFIGURATION: CLEAN

WEIGHT:

48,500 POUNDS

CONFIGURATION: CLEAN

WEIGHT:

44,000 POUNDS

| A | PPROXIMATI | E | | PRESSURE | | 1 | PPROXIMAT | E |
|-------|--------------|--------------|------|------------------|------|--------------|--------------|-------|
| LB/HR | tas KNOTS | cas KNOTS | %RPM | ALTITUDE FEET | %RPM | cas KNOTS | tas KNOTS | LB/MR |
| 6550 | 344 | 343 | 96.5 | SEA LEVEL | 96.5 | 347 | 347 | 6630 |
| 5860 | 343 | 318 | 96.5 | 5,000 | 96.5 | 323 | 348 | 5880 |
| 5130 | 335 | 291 | 96.5 | 10,000 | 96.5 | 302 | 346 | 5150 |
| | | | | 15,000 | 96.5 | 277 | 348 | 4410 |
| | | | | 20,000 | | | | 7 7 7 |
| | | | | 25,000 | | | | |
| | | | | 30,000 | | | | |
| | | | | 35,000 | | | | |
| | | | | 40,000 | | | | |
| | | | | 45,000 | | | | |
| | | | | 50,000 | | | , | |

CONFIGURATION: CLEAN WEIGHT: 39.500 1

39,500 POUNDS

CONFIGURATION: CLEAN

WEIGHT: 35,000 POUNDS

| A | PPROXIMAT | E | | PRESSURE | | A | PPROXIMAT | E |
|--------|--------------|--------------|------|------------------|------|--------------|--------------|--------|
| LB/ HR | tas KNOTS | cas KNOTS | %RPM | ALTITUDE FEET | %RPM | cas KNOTS | tas KNOTS | LB /HR |
| 6650 | 350 | 350 | 96.5 | SEA LEVEL | 96.5 | 354 | 353 | 6650 |
| 5900 | 353 | 328 | 96.5 | 5,000 | 96.5 | 333 | 358 | 5910 |
| 5170 | 353 | 308 | 96.5 | 10,000 | 96.5 | 313 | 358 | 5200 |
| 4500 | 353 | 288 | 96.5 | 15,000 | 96.5 | 292 | 360 | 4500 |
| | | | | 20,000 | 96.5 | 266 | 355 | 3860 |
| | | | | 25,000 | | | | |
| | | | | 30,000 | | | | |
| | | | | 35,000 | | | | |
| | | | | 40,000 | | | | |
| | | | | 45,000 | | | | |
| | | | | 50,000 | | | | |

REMARKS:

CAS - CALIBRATED AIRSPEED KNOTS
TAS - TRUE AIRSPEED KNOTS

LB'HR - FUEL CONSUMPTION

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

| | | instruction in the state of the state of the state of Fer a fill of the cruising | onecs re | | F | 33 | AT S.L. | | 180 | 120 | 09 | ū | <u></u> | RP M | | | 293 80 | 272 78 | 257 77 | - | |
|--------------------------|------------------------------------|---|----------------------------|--------|----------------------|-------------------|-----------------------------|---|------|------|------|--------------------|-------------|----------------------|--------|---------|----------|----------|----------|----------|----------|
| AIR . | ENG | CTIONS I fuel on be section as mether all light of his section. | ances to range values. | | IF YOU ARE AT S.L. | RANGE IN AIRMILES | 9 | | 45 | 45 | 15 | CRUISING AT S.L. | APP | тВм | | | 5000 253 | 4530 | 4250 | 21 | |
| CRAF | ENGINE(S) | FOR USI | | | RE AT | AIRMIL | | | 10 | 10 | 10 | G AT S | APPROXIMATE | 6.5. | | | 253 | 272 | 297 | | |
| E | J65-W-5 | HASTRUCTIONS FOR USING CHART: (A) IN FLIGHT - Solect figure in fuel column equal to or less than fuel available for revise (fuel on blood minus allowance for reserve, cambar, movigational error, farmation flight, etc.), Allowe hastiannelly right or left to section according to present altitude and record total range ovailable (no wind) by cruising at that altitude or by climbing to another autitude and maximum range. For a flight in intellight postering instructions are given directly below. For a flight or higher altitude, climb immediately to desired altitude and read evuising instructions in appropriate cruising altitude accision. (B) FLIGHT PLANNING - Fram initial fuel on board subtract fuel for tok-off and climb to desired cruising altitude and all other necessory allowances. Then use chart as for IN FLIGHT above, adding initial climb distinctions. | | | S.L. | .Es | BY CRUISING AT OPT.ALT. | | 365 | 190 | | i.L. | TE | R.F. DOWN DIST. | | | . 85 0 | 1.00 0 | 1.16 0 | | |
| S) B-57B | 121 | A) IN FLIGH reserve, com ude and read o e. For a flig modiately to (G · Frem in | | | 5 | FUEL | POUNDS | | 3000 | 2000 | 1000 | 0000 | TIVE | | 120 HW | WH 08 | 40 HW | 0 | 40 TW | WT 00 | M4 001 |
| 60 | | bot, novi totel run ght et in desired vitial fue | | | (1) | | | (RA | 63 | 17 | | L | | C.A.2 | | | 279 | 261 | 243 | | |
| | | gational gational ge availal altitude altitude use chart | | | IF YO | RA | BY CRUISING AT 5000' | NGE F | 210 | 140 | 75 | CRU | | RPM | | | 80 | 79 3 | 17 | | |
| ш. | Đ | erro, formo ble (no wir rude, opera and read ci d subtract | | | IF YOU ARE | RANGE IN AI | OP T. | IGURES | 45 | 45 | 15 | CRUISING A | APPRO | L.B. G.S. | | | 4360 26 | 3970 280 | 3680 301 | | |
| FLIGHT | HART WT. LIMITS 30, 500 POUNDS | olumn equal to or less than fuel available for motion Hight, are, Move bestaantally right or vind) by cruising at that altitude at by ellmb- terion instructions are given directly below, ervising instructions in appropriate cruising art fuel for toke-off and climb to desired IN PLIGHT above, adding initial climb dist | | 1 | AT 5000' | AIRMILES | - | (RANGE FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA | 67 | N | | AT 5000' | APPROXIMATE | S. R.F. | | | 60 .84 | 0 1.00 | 1 1.16 | | |
| T OP | . LIMIT | or less to otc.).Moving at that etions are ructions is or take-off ibove, edd | | Ľ | | | BY CRUISING AT OPT.ALT. | DE ALL | 390 | 210 | | | | DOWN DIST. | | | 1 | 1 | 1 | | |
| ERA | \$ 30, | hen fuel to altitude given dir. appropriate fond climing initia | | LOW | | | BY CRUISING AT 16005 | OWANG | 245 | 165 | 85 | | | C.A.5 | | 278 | 267 | 251 | 233 | 206 | |
| OPERATION | 500 PC | eveileble or by clin ecily belo inte croisi ob to desii | | | F YOU | RANG | | ES F0 | | | 711 | CRUIS | | RPM LA | | 82 4320 | 80 3870 | 79 3560 | 77 32 | 76 29 | |
| NNDAR | CUNDS | p o d % to b te | | AL | ARE A | RANGE IN AIRMILES | 00°T. ALT. 1600 FT | R PRE | 45 | 45 | 25 | ING AT | APPROXIMATE | HR G.S. | | 20 242 | 70 269 | 60 290 | 3290 309 | 2920 319 | |
| S | OR LESS | MOTES: one chart en pach lewences | DATA AS | ALTITU | IF YOU ARE AT 10000' | MILES | | SCRIBE | 410 | 240 | 1 | CRUISING AT 10000' | MATE | я. я. | | . 69 | . 85 | 1.00 | 1,15 | 1.34 | |
| AY A | ESS | Renges s (due to chert; i.e. | 0F: 1 | D | | | BY CRUISING AT OPT.ALT. | D CLIM | | | | | | LET DOWN DIST. | | 63 | 73 | 2 | 69 | 61 | |
| NO | | bown at or external co , when ch | DATA AS OF: 1 OCTOBER 1953 | DE | Ŧ | | BY CRUISING AT 15000" | B & DE | 280 | 190 | 100 | | -, | C.A.2 | | 281 82 | 257 80 | 243 80 | 225 78 | 211 77 | |
| HAR | | onfiguration and subject of fuel. | ER 19 | | YOU A | RANGE | | CENT | | | | RUISIN | AP | LB. | | 4050 | 3550 | 3280 | 3000 | 2810 | |
| <u></u> | | HOTES: Renges shown at optimum altitudes are maximum. one chart (due to external configuration or gross weight of on each chart; i.e., when changing charts a climb may be a lewences for descent distance and fuel. Climb distance and lewences for Descent distance DATA BELOW CONTAIN MO | 53 | | IF YOU ARE AT 15000' | RANGE IN AIRMILES | OPT. ALT. 1000 FT | TO SEA | 45 | 45 | 35 | CRUISING AT 15000' | APPROXIMATE | 6.5 | | 270 | 281 | 302 | 321 | 343 | |
| | NON | maximum. In weight chan b may be requirence and fue | | | ,0005 | ES | BY CRUISING AT OPT.ALT. | LEVEL ⁽¹⁾ | 435 | 260 | | 2000, | <u> </u> | R.F. DOWN | - | . 72 4 | . 86 4 | 1.00 4 | 1.16 4 | 1,32 4 | |
| EXTER | NUMBER OF ENGINES OPERATING: (TWO) | HOTES: Renges shown at optimum altitudes are maximum. In order to obtain maximum renge on flights requiring more shown one chost (due to external configuration or gross veright chonges), it is necessary to observe the aptimum rensing altitude on each chart; i.e., when charging charts a climb may be required to obtain a maximum rensor. All renge values include allewances for descent distance and fuel. Climb distance and fuel are included where climbs are indicated. DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | | | (1) | FUEL | POUNDS | | 3000 | 2000 | 1000 | 1 | TIVE | QN IA | 120 HW | WH 09 | 40 MW | ۰ | 40 TW | WT 08 | |
| EXTERNAL LOAD ITEMS NONE | GINES O | sory to observed to observe the climbs of Por LANDII | BASED | | | | AT 20000' | | 315 | 210 | 110 | | - | C.A.S | - | 279 83 | 254 81 | 239 80 | 223 79 | 214 78 | 200 |
| D ITEMS | ERATIN | se on flights ve the eptir go. All rem pre indicate | BASED ON: ESTIMATE | | IF YOU ARE AT 20000' | RANGE IN AIRMILES | AT 20000' 1000 FT | | 45 | 45 | 35 | CRUISING AT 20000" | APPR | LBun | 4260 | 3770 | 3330 | 3090 | 2840 | 2710 | 0000 |
| | G:(TWC | requiring aum cruising of values in it. | MATE | | AT 200 | IRMILES | | | 4 | 8 | 11 | AT 200 | APPROXIMATE | 6.5. R.F. | _ | 294 | 301 | 322 1.00 | 341 1.15 | 369 1.30 | 26 1 000 |
| | <u>@</u> | nore than g altitude sclude of- | | | .00 | | BY CRUISING AT OP T.ALT. | | 455 | 280 | 120 | l.e | | POWH DOWN | - | . 75 5 | 86 6 | 9 00 | 5 6 | 7 0 | 0 |

Figure A-35

| INSTRUCT | ONS FOR | INSTRUCTIONS FOR USING CHART. (A) IN FLIGHT - Select figure in feel cell | : (A) IN FL! | | | | CHAR | CHART WT. LIMITS 30, 500 POUNDS | MITS 3 | | | | OR LESS | 0,500 POUNDS OR LESS | | | | Z | UMBER | NUMBER OF ENGINES OPERATING: (TWO) | SINES OP | PERAT | ING:(T | (OM |
|---|---|---|---|--|--|---|--|---|--|--|--|----------------------|------------------------------------|--------------------------------------|--|--|---|---|-------------------------------------|---|---|--|--------------------------|-----------------------------|
| left to sec ing to enet For a fligh altitude soc cruising alt | her altitude t at higher trion. (B) I | left to saction according to present attitude and road total renge available (no wind) by cruising at that altitude or by climbing a anather altitude of maximum range. For a flight at initial altitude, operating instructions are given directly below. For a flight to thinker altitude vicins inneadiately to desired attitude and read extraining instructions in appropriate cruising altitude as excition. (B) FLICHT PLANING . Frem initial fuel on board subtract. Fust for toke-off and climb to desired cruising altitude and all other necessary allowances. Then use chart as for IN FLIGHT above, adding initial climb districtions. | range. For a immediately INING • From sary allowans | IGHT - Sc combat, na sad total r flight of to desir n initial f | avigation range ava i initial rad altitu fuel on h | ine in fuel nel error, f sileble (ni eltitude, de de and rei board sub | ormation o wind) b operating isd cruisi | INSTRUCTIONS FOR USING CHARTI. (A) IN FLIGHT - Scloct figure in fuel column equal to at less than fuel available for cruise (fuel on board minus allowance for roserve, combat, navigational error, formation flight, arc, i, Move herizantally right or left to saction according to present attitude and road foral range available (no wind) by cruising at their altitude or by climbing to another altitude of maximum range. For a flight or initial altitude, operating instructions are given directly below, are a flight or initial altitude and eval excising instructions in appropriate cruising altitude section. (B) FLIGHT PANNING: Prem initial fuel on board subtrict. Fuel for toke-off and climb to desired cruising altitude socion. (B) FLIGHT PRANING: Prem initial fuel on board subtrict. Fuel for toke-off and climb to desired cruising altitude and all other necessary allowances. Then use chart as for IN FLIGHT above, adding initial climb dist- | to or less than fuel evailable for ising at their britished by cilinb- ising at their altitude or by climb- terions are given directly below, structions in appropriate crusting for note-off and climb to desired abovo, adding initial climb distr | uel eveil Izentally tude or by a directly ropriete climb to | right or y climb. r below. cruising desired nb dist. | ¥ 5 5 5 | OTES: Re c chart (r cach chu | due to es ert; i.e., r descent | own of op other cha distance | finum al Inging ch and fuel. DATA B | nitudes are lorts a clim Climb di | NOTES: Renges shown at optimum altitudes are maximum. one chart (due to external configuration or gross weight e on each chart; i.e., when changing charts a climb may be to lowances for descent distance and fuel. Climb distance and DATA BELOW CONTAIN MC | hangos), raquired to fuel are | NOTES: Ranges shown ot optimum altitudes are maximum. In order to obtain maximum ronge on flights requiring more than one chart (due to external configuration or gross weight changes), it is nocessary to observe the optimum eruising altitude on acech chart; i.c., when changing charts a climb may be required to obtain a maximum range. All range values include allowances for descent distance and fuel. Climb distance and fuel are included where climbs are indicated. DATA BELOW CONTAIN HO FUEL RESERVE FOR LANDING | aximum rai aximum rai aximum ra bre elimbs | nge on flig srve the ol nge. All i are indica | ptimum cru range valu | ing more ising alt |
| onecs to range values. | nge values. | | | | | | | | | | * | ď | DATA AS OF: 1 OCTOBER 1953 | F. 10 | CTOB | ER 19 | 53 | | | | BASED | BASED ON: ESTIMATE | TIMA | E |
| | | li | | | | | | | 0 | % 0 | - | 17 | ALTITU | 10 | ш | | | | | | | | | |
| IF Y(| IF YOU ARE AT S.L. | AT S.L. | | (1) | H | IF YOU ARE | | AT 5000' | - | F | YOU AF | IF YOU ARE AT 10000' | 100001 | | 쁘 | YOU A | IF YOU ARE AT 15000' | 15000' | - | Ē | <u>_</u> | IF YOU ARE AT 20000' | RE AT | 20000 |
| RA | RANGE IN AIRMILES | MILES | FUEL | ير | | RANGE IN | IN AIRMILES | LES | - | | RANGE | RANGE IN AIRMILES | ES | - | | RANGE | RANGE IN AIRMILES | .ES | T | FUEL | | RANGE | RANGE IN AIRMILES | ES |
| BY CRUISING OPT. ALT. AT S.L. 1000 FT | OPT. ALT. 1000 FT | BY CRUISING AT OPT.ALT. | ING POUNDS | - | Y CRUISIN AT 5000' | 9 | PT. ALT. 1000 FT | BY CRUISING AT OPT.ALT. | 40 | BY CRUISING AT 10000' | | 0PT. ALT. 1600 FT | BY CRUISING AT OPT.ALT. | | BY CRUISING OPT. ALT. AT 15000' 1000 FT | ING OF | 3PT. ALT. | BY CRUISING AT OPT.ALT. | | POUNDS | BY CRUISING AT 20009' | 0 | PT. ALT. | BY CRUISING AT OP T.ALT. |
| | | | | 5 | RANGE | FIGUI | RES IN | (RANGE FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL(1) | LLOW | ANCES | FOR | PRESC | RIBED | CLIMB | & DE | CENT | TO SE | \ LEVE | (i) | | | | | |
| | | | | | | | | Ē | | | | | | | | | | | | | | | | |
| 180 | 45 | 365 | 3000 | | 210 | 4 | 45 | 390 | | 245 | | 45 | 410 | | 280 | | 45 | 435 | 69 | 3000 | 315 | | 45 | 455 |
| 120 | 45 | 190 | 2000 | | 140 | 4 | 45 | 210 | | 165 | | 45 | 240 | | 190 | | 45 | 260 | 64 | 2000 | 210 | | 45 | 280 |
| 09 | 15 | 1 | 1000 | | 75 | | 15 | 1 | | 82 | | 25 | 1 | | 100 | | 35 | 1 | - | 1000 | 110 | | 35 | 120 |
| S | CRUISING AT S.L. | T S.L. | | 1 | | CRUISING | | AT 5000' | - | 0 | RUISIN | CRUISING AT 10000' | ,0000 | - | | RUISI | CRUISING AT 15000' | 15000 | | | | CRUISING AT 20000' | NG AT | ,00007 |
| - | APPROXIMATE | MATE | TIVE | _ | - | A | APPROXIMATE | TATE | | | AP | APPROXIMATE | TE | | -5 | A | APPROXIMATE | TE | Γ | TIVE | -, | AP | APPROXIMATE | TE |
| E % | L.Bur G.S. | я. Р. | DOWN DIST. | - 1 | C.A.S | LB TH | 6.5. | R.F. DIS | DOWN CA | RPM M | LBH | 6.5. | F. F. | DOWN DIST. | C.A. | L.B. | 6.5 | R.F. | LET DOWN DIST. | QNIM | .A.2 | RPM LBHR | R G.S. | R.F. |
| | | | 120 HW | 2 | | | | | | | | | | | | | | | | 120 HW | 304 84 | 4 4260 | 0 285 | .64 |
| | | | WH 08 | A | 0.00 | - | | | 22 | 278 82 | 4320 | 242 | 69 | 64 | 281 82 | 4050 | 270 | . 72 | 4 | 80 HW | 279 83 | 3 3770 | 294 | .75 |
| 293 80 | 5000 253 | . 85 | WH 05 0 | | 279 80 | 4360 | 260 | . 84 | 1 26 | 267 80 | 3870 | 269 | . 85 | G/8 | 257 80 | 3550 | 281 | 98. | 4 | 40 MW | 254 81 | 1 3330 | 0 301 | . 86 |
| 272 78 | 4530 272 | 1.00 | 0 | 26 | 261 79 | 3970 | 280 | 1.00 | 1 251 | 11 79 | 3560 | 290 | 1.00 | 63 | 243 80 | 3280 | 302 | 1.00 | 4 | 0 | 239 80 | 0 3090 | 0 322 | 1.00 |
| 257 77 | 4250 297 | 1.16 | 0 40 TW | | 243 77 | | 3680 301 | 1.16 | 1 233 | 13 77 | 3290 | 309 | 1.15 | 62 | 225 78 | 3000 | 321 | 1.16 | 4 | 40 TW | 223 79 | 9 2840 | 341 | 1,15 |
| | | | 90 TW | A. | | | | | 20 | 206 76 | 2920 | 319 | 1.34 | 64 | 211 77 | 2810 | 343 | 1.32 | 4 | WT 08 | 214 78 | 8 2710 | 0 369 | 1.30 |
| | | | 120 TW | | | | | | | - | | | | | | | | | | | | | | |

Figure A-36

| The calcus figure in fact column equal to at leas them fact available for mobile, newtyperional entret forwards affect, newtyperional entret forwards affect at least them fact available for mobile a finite and activates an experimentally right or desired altitude and error function in the fact of the section altitude and entret and entre | | | eruise (fur left to see ing to one For a High altitude so cruising al | anees to re | | IF Y | RA | BY CRUISING AT S.L. | | 415 | 355 | 295 | 235 | 175 | 115 | 09 | CRI | | KP X | | | 300 80 | 279 79 | 266 78 | I | |
|--|-----------------|-----------|---|-------------|----------|-----------|--------------|------------------------------|------------|------|------|------|------|------|------|------|---------------------|----------|----------|---------|--------|---------|---------|----------|---------|--------|
| The CHART AND PERATION IN STANDARIA STANDARIA STANDARIA STANDARIA STANDARIA STANDARIA STANDARIA STANDARIA States in large and read road road road road road road road ro | AIRCR | ENGIN | 10MS FOR if on board then eccent ther eltitud to at higher ction. (B) | mge values. | | OU ARE | NGE IN AII | 1000 F | | 45 | 45 | 45 | 45 | 45 | 45 | 10 | JISING A | APPROX | | - | XI-9 | | - | | | |
| CHT OPERATION IN STANDARI STANDARI STANDARI STANDARI STANDARI Standario St | AFT MODEL (| | USING CHART: In the constant of other necessor, | HILLIAN | E E | AT S.L. | MILES | | | 086 | 795 | 625 | 470 | 320 | 180 | - | T S.L. | | ei ei | | | . 85 | 1.00 | 1.16 | | |
| CHT OPERATION IN STANDARI STANDARI STANDARI STANDARI STANDARI Standario St | S) B-57B | -5 | (A) IN FLIGHT reserve, combined and read 1 pe. For a flig smediately to NG . Frem inity allowences. | 7 | | 5 | FUEL | - | | 7000 | 0009 | 2000 | 4000 | 3000 | 2000 | 1000 | THE PERSON NAMED IN | - | | | WH 09 | 40 HW | 0 | 40 TW | WT 08 | 120 TV |
| CHT OPERATION IN STANDARI STANDARI STANDARI STANDARI STANDARI Standario St | | | T - Soloet figure bot, navigational total range avail, ght at latital alt desired altitude itial fuel on box. Then use char | | N. I | | 2 | | (RANGE F | 485 | 410 | 345 | 275 | 205 | 135 | 04 | | | C.A. | | | 81 | 80 | 78 | | |
| AREA1 NA AIREA 1 15 45 45 45 45 45 45 45 45 45 45 45 45 45 | I | CHAR | in feel column orres, formation while (see wind) litude, operating and read cruis and subtract ri as for IN FL | | | | ANGE IN AIRM | OPT. ALT. | FIGURES IN | 45 | 45 | 45 | 45 | 45 | 45 | 15 | | APPROXIL | 0 | | | 6.4 | | 63 | 1 | |
| AREA1 NA AIREA 1 15 45 45 45 45 45 45 45 45 45 45 45 45 45 | GHT O | T WT. LIM | equal to or les if fight, erc.).M by cruising of i j instructions ing instruction uel for take IGNT above, | | _ | 2000, | ILES | | CLUDE AL | 1000 | 820 | 650 | 490 | 335 | 190 | | 2000, | | _ | | | | | | | |
| AREA1 NA AIREA 1 15 45 45 45 45 45 45 45 45 45 45 45 45 45 | PERA | IITS | ta then fuel a tave herizent that elitiude of are given dire s in opproprie off and climb | | № | _ | - | | LOWANC | | - | | - | | | *** | | _ | C.A. | | | 280 | 263 | 244 | | • |
| AREA1 NA AIREA 1 15 45 45 45 45 45 45 45 45 45 45 45 45 45 | AND | 35,000 | veilable fer ally right or or by climb- icity below. The cruising to desired climb dist- | | | - YOU A | RAMGE | IISING OP | ES FOR | 2 | 0 | 2 | 100 | 2 | 10 | 0 | CRUISIN | AP | M LB | | | | | - | | |
| | | 0 TO | | DATA AS OF: | 117 | RE AT 1 | IN AIRMIL | T. ALT. | PRESCR | 45 | 45 | 45 | 45 | 45 | 45 | 15 | IG AT 10 | PROXIMAT | | | | | | | | |
| | ONO | | shown at og to external co i.e., when cha cent distance | 1 OCTOE | DE | 4 | | | IMB & DES | 625 | 530 | 445 | 355 | 265 | 175 | 06 | 0 | *5 | V') | | 295 83 | 272 82 | 259 83 | 238 78 | 224 78 | _ |
| Carte Cart | HART | S | artimum altitus catiguration o anging charts and fuel. CI DATA BELO | 3ER 1953 | | YOU ARE | RANGE IN A | ING OPT. A | CENT TO | | 45 | 45 | 45 | | 45 | 25 | RUISING | APPRO | LB | | 4430 | 3950 | 3650 | 3340 | 3140 | _ |
| NOTES Ranges thoun of optimum eliting conc chart (due to existent stands card fund) Langes thous chart stands card fund) Langes thous chart stands Langes thous card fund) Langes thous chart stands Langes thous card fund) Langes thous ca | | | dos are maximu « gross weigh e climb may b imb distance a | | | AT 15000' | VIRMILES | LT. BY CRI | | | - | | | | | 1 | AT 15000' | DXIMATE | R.F. | | 86 .74 | 98 . 86 | 21 1.00 | 137 1.15 | 60 1.31 | |
| ON CHART | | NUMBER | m. In order r changes), is a required to nd fuel are i | | | - | T | - | (i) TE | | | | | | | | - | | | | 4 | 4 | 4 | 4 | 4 | - |
| ON CHART NUMBER | EXTERN | OF ENG | to obtain me obtain a ma neluded who | | | (5) | FUEL | | | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 1 | TIVE | QN A | | - | 40 MM | | 40 TW | | _ |
| ON CHART EXTERN | AL LOAD NONE | INES OPE | nimum ranga ximum ranga re climbs are | BASED ON | | IF YO | RAI | AT 2000' | | 705 | 009 | 200 | 400 | 300 | 200 | 100 | CRI | | 16 ER | 311 85 | 8 4 | 82 | 81 | 80 | 80 | 0 |
| ON CHART | ITEMS | RATING: | on flights rec the eptimum All range v indicated. | | | U ARE A | NGE IN AIR! | OPT. ALT 1000 FT | | 45 | 45 | 45 | 45 | 45 | 45 | 35 | JISING A | APPROXI | | 4540 29 | | | - | | | 2000 |
| NUMBER OF ENGINES OPERATIN | | (TWO) | puring more cruising al- ulues inclu | ATE | | T 20000 | AILES | BY CRUISING AT OP T. ALT. | | 1070 | 882 | 715 | 920 | 395 | 245 | - | r 20000' | MATE | ar ar | 99. 9 | 97. 6 | 78. 0 | 3 1.00 | 1 1.14 | 0 1.37 | , |

Figure A-37

| FUCINE (8) 785-W-5 FUCINE (8 72 000 FOLKEY FOLK | AIRCRAF | T MODEL | AIRCRAFT MODEL (S) B-57B | | | | | 16 | I | IT | HIGH ALTITUDE | DE | | | | | EXT. LOAD | | NONE | | |
|--|--|------------|--------------------------------------|-------------|------------|------------|--|---|--|---|--------------------------------|---|----------------------------|-----------|------------------------------------|---|---------------------------|-------------------------------------|----------------|----------------------|-----------|
| F TOU ARE A1 35007 | ENGINE | 5): J65-1 | V-5 | 1 | ō | HART WT. | | 5,000 T | | 100 DOI | NDS | | | | | | NO. O | | ES OPE | RATING | (TWO) |
| Public P | IF YC | U ARE A | 7 25000' | | IF YO | AR | AT 30000' | = | YOU A | RE AT 3 | ,2000 | | F YOU | ARE A | T 40000 | | | F | rou ARI | E AT 45 | ,000 |
| CRUISING AT 2000 CRUISING AT 2000 CRUISING AT 3000 CRUISING AT | R | MGE IN AIR | AILES | FUEL | 2 | | MILES | | RANGE I | N AIRMILE | £\$ | - | RAN | GE IN AIR | MILES | | FUEL | | RANGE IN | AIRMILE | S |
| 12 100 100 100 100 110 110 110 1045 145 1120 1120 145 1140 1700 1150 145 1110 145 1140 1700 1150 145 1110 145 1140 1700 1150 145 1110 145 | BY CRUISING AT 25000' | OPT ALT. | BY CRUISING AT OPT. ALT. | | | 190 100 | | | | | SY CRUISING | | SUISING | OPT AL | _ | | POUNDS | P A | 9 | | T OPT. AL |
| 1100 45 1000 1000 1000 11 | | | | | (RANGE | FIGURES | INCLUDE AL | LLOWANC | | PRESCI | RIBED CL | IMB & | DESCE | NT TO | SEA LE | VEL) | | | | | |
| 1 | 800 | 45 | 1090 | 7000 | 920 | 45 | 1105 | 104 | | 2 | 1125 | 11 | 20 | 45 | 116 | 01 | 7000 | 115 | | 45 | - |
| 1.00 4.5 5.00 6.45 4.5 5.00 5.15 4.6 5.00 6.45 4.5 5.00 6.45 6.5 6 | 680 | 45 | 902 | 0009 | 775 | 45 | 925 | 88 | | 2 | 940 | OI . | 20 | 45 | 96 | 12 | 0009 | 1.6 | | 45 | **** |
| 45 450 425 3000 385 45 450 440 45 465 460 45 3000 460 45 3000 460 45 3000 325 3000 325 | 282 | 45 | 735 | 2000 | 645 | 45 | 750 | 73 | | 2 | 770 | | 82 | 45 | i | , | 2000 | 80 | | 45 | |
| Carrolling At 250 According to the control of t | 450 | 45 | 570 | 4000 | 515 | 45 | 290 | 58 | | 2 | 610 | 9 | 25 | 45 | i | | 4000 | 64 | | 45 | 1 |
| Charles Char | 340 | 45 | 425 | 3000 | 385 | 45 | 450 | 44 | | 2 | 465 | 4 | 02 | 45 | 1 | ! | 3000 | 48 | | 45 | |
| CRUISING AT 2500° CRUI | 225 | 45 | 260 | 2000 | 255 | 45 | 280 | 29 | | 2 | 300 | en | 15 | 45 | i | | 2000 | 32 | | 45 | - |
| CRUISING AT 25000 CRUISING AT 35000 CA3 R. P. PROXIMATE TIVE CA3 R. P. PROXIMATE R. P. | 120 | 35 | - | 1000 | 135 | 35 | - | 15 | | 2 | - | - | 09 | 40 | - | | 1000 | 171 | | 45 | - |
| Color Colo | CRI | IISING AT | 25000' | | | 17355 | r 30000' | | CRUISIN | G AT 3 | 2000 | | CRU | ISING A | T 40000 | | - | | RUISING | 3 AT 45 | ,000 |
| Fig. Light G.S. R.F. Dorm C.A. R. R.F. Dorm C.A. R.F. Dorm C.A. R.F. Light C.S. R.F. Dorm C.A. R.F. Dorm C.A. R.F. Dorm C.A. R.F. Dorm C.A. R.F. Light C.A. R.F. Dorm C.A. R.F. Light R.F. Light R.F. L.F. R.F. L.F. R.F. L.F. R.F. L.F. R.F. L.F. R.F. L.F. R.F. | | APPROXIM | ATE | TIVE | | APPROX | MATE | | API | PROXIMAT | m | | | APPRC | XIMATE | | TIVE | | AP | PROXIMA | |
| 84 3770 326 . 77 7 80 kg 248 8 40 | R M | | я. п. | | C. A. S. | ТЪ | R.F. | C.A.S. | | | | | RPM | | | 17.5 | QNIM | C.A.S. | | - | |
| 83 3490 344 .88 8 .25 84 389 334 .77 10 241 85 2950 335 .80 13 220 88 2780 342 .90 18 60 mm 195 93 2740 345 .80 .80 18 34 .88 9 .30 18 .22 88 2780 342 .90 20 .20 mm 195 93 2740 345 .90 .82 3310 345 1.00 9 0 0 247 83 3070 390 1.00 12 235 84 280 369 .90 17 220 88 2780 423 1.00 22 0 195 93 2740 425 1.00 .81 20 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 | 85 | | .68 | 120 HW | | 3460 | .68 | 243 | | | | | | _ | | | 120 HW | $\overline{}$ | 200 | - | _ |
| 82 318 349 344 .88 8 4 4 | 84 | | .77 | 80 MW | _ | 3390 | .77 | _ | | | | _ | 88 | | | _ | WH 08 | 100 | | | _ |
| 82 3310 369 1.00 9 0 247 88 3000 424 1.11 13 234 84 2840 405 1.00 17 220 88 2780 428 1.10 24 0.0 19 15 10 20 14 11 13 234 84 2820 444 1.10 19 216 87 2700 458 1.10 24 0.0 19 19 3700 50 1.10 21 1.30 1.30 1.10 24 0.0 19 19 216 87 2700 458 1.10 24 0.0 19 38 2740 455 1.10 1.30 1.30 1.30 1.30 1.30 1.30 1.30 | 83 | | . 88 | 40 HW | | _ | . 89 | | | | 90 | | 88 | | | | 40 HW | | | | _ |
| 82 3180 397 1.12 10 20 TW 243 83 3000 424 1.11 13 234 84 2820 444 1.10 19 216 87 2700 456 1.10 24 40 TW 195 93 2740 455 1.10 24 1.1 13 234 84 2820 444 1.10 19 216 87 2700 456 1.10 24 65 1.10 24 1.30 12 1.30 14 23 82 2900 450 1.22 14 230 84 2770 478 1.21 2 1 2 15 87 2700 456 1.20 26 60 TW 194 93 2700 503 1.19 1.30 12 1 13 12 13 13 12 13 12 13 13 12 13 13 12 13 13 12 13 13 12 13 13 12 13 13 12 13 13 12 13 13 12 13 13 12 13 13 12 13 13 12 13 13 12 13 13 12 13 13 13 13 13 13 13 13 13 13 13 13 13 | 82 | | 1.00 | • | | - | 1.00 | _ | | $\overline{}$ | - | | 88 | | - | | 0 | _ | | 425 | |
| 81 3030 448 1.24 11 so TW 229 82 2830 450 1.22 14 230 84 2770 512 1.32 22 215 87 2700 496 1.20 26 60 TW 194 93 2700 503 1.19 SPECIAL NOTES Climb at 100% RPM Multiple Naultcal units by L.15, to obtain Statute fuel, you can fly 445 nautical air-sors, combat, formation flight etc. as required. SECIAL NOTES Climb at 100% RPM Make additional allowances for landing, navigational allowances for landing navigational allowances for landing from the destination. SECIAL NOTES Climb at 100% RPM Multiple Naultcal units by L.15, to obtain Statute fuel, you can fly 445 nautical air-sites at 195 knot combat, formation flight etc. as required. SED ON: ESTIMATE SET 2700 496 1.20 26 11 34 93 2700 543 1.190 LEGEND LEGE | 82 | 3180 397 | 1.12 | 40 TW | - | _ | 1.11 | 234 | | 444 | _ | | 87 | _ | _ | 1 | 40 TV | | | 465 | 1. 10 32 |
| SPECIAL NOTES Climb at 100% RPM Multiple Nautical units by 1.15, to obtain Statute from a sadditional allowances for landing, navigational and start let down 29 nautical miles. Combat, formation flight etc. as required. SED ON: ESTIMATE SPECIAL NOTES EXAMPLE EXAMPLE EXAMPLE EXAMPLE EXAMPLE EXAMPLE Climb at 100% RPM EXAMPLE EXAMPLE EXAMPLE EXAMPLE EXAMPLE EXAMPLE EXAMPLE Climb at 100% RPM EXAMPLE Corresponding winds Correspond | 81 | 3030 42 | 1.24 | WT 08 | | _ | 1.22 | 230 | | 478 | | | 87 | _ | | | 90 TW | _ | | 503 | 1.1935 |
| EXAMPLE If you are at 15,000 ft. with 5000 lb. of available fuel, you can fly 445 nautical airmiles by holding 259 knots CAS. However, you can fly 695 nautical airmiles by holding 259 knots CAS. However, you can fly 695 nautical airmiles by immediately climbing to 45,000 ft. using miles by immediately climbing to 45,000 ft. using 100% RPM. At 45,000 ft. cruise at 195 knots CAS and start let down 29 nautical miles from home. With a 120 knots CAS and start let down 21 nautical miles from destination. ESTIMATE 1.0CTOR ER 1953 | 81 | | 1.38 | 120 TW | | _ | 1.34 | 226 | | | _ | - | 87 | _ | | | 120 TW | | | 543 | 30 |
| Nautical units by 1.15. to obtain Statute fuel, you can fly 445 nautical airmiles by holding 259 knots CAS. However, you can fly 695 nautical airmiles by holding 259 knots CAS. However, you can fly 695 nautical airmiles by immediately climbing to 45,000 ft. using 100% RPM. At 45,000 ft. cruise at 195 knots CAS and start let down 29 nautical miles from home. With a 120 knots CAS with this wind and start let down 21 nautical miles from destination. | | | SPECIAL | NOTES | | | | | EXA | MPLE | | | | | | |] | GEND | | | |
| heat, formation flight etc. as required. a 120 knot headwind the range at 45,000 ft. would be 71 x 695 or 493 nautical miles. Cruise at 197 RANGE IN PA POLATION P ESTIMATE 1 OCTOR ER 1953 | 2 Mul 2 Mul 2 Mul 3 Read only. | tple Nau | & RPM tical units half of char | by 1.15. | to obtain: | | If you are a fuel, you ca knots CAS. miles by in 100% RPM. | th 15,00 an fly 4. Howeve imediate At 45, | o ft. wi | th 5000 cal air can fly ving to cruise | miles by 695 nat 45,000 at 195 | availab holdin rtical a ft. usi knots | g 259 dir- ng CAS | | FRang for c 3Grou S-Callb | VE WIN refacto correspond special rated | r-Ratio conding wed in Kn | of ground inds ots in Knot | TW, Ta | dlwind: se to ali | Knots |
| ESTIMATE miles from destination. 1 OCTOR ER 1953 | errors | combat | formation | flight etc. | as requir | 100,000 | a 120 knoi .71 x 695 knots CAS | t down t headwir or 493 | 29 naut nd the ra nautica wind an | ical mi inge at il miles d start | 45,000 | ft. wo | With | | NGE-N RANGE POLAT | autica IN PA | miles RENTHI URPOSE | S ONLY | R INTE | d; | |
| | BASED | | CTOR ER 1 | 953 | | | miles from | destinat | ion. | | | | | | | | FUEL GR | ADE: | JP-4 6.5 LB | /GAL | |

Figure A-38

| STRUCTION CHART |
|-----------------|
| |

Figure A-39

| AIRCRA | AIRCRAFT MODEL (S) | .(S) B-57B | 1B | | | | | I | 0 | I | ALI | HIGH ALTITUDE | 20 | ш | | | | ă | EXT. LOAD | | NONE | | |
|---|--|--|-------------------------|--|--|--|---|--|---|--|---|--|---|---|---|--|---|--|--|--------------------------|---|-------------|----------------------------|
| ENGINE (S): | | J65-W-5 | | | CHART | | WT. LIMITS | 39, 5 | 39, 500 TO | | 35, 000 POUNDS | OUNDS | | | | | | ž | NO. OF | ENGINE | ENGINES OPERATING: (TWO) | TING: (| TWO) |
| F | IF YOU ARE AT 25000' | r 25000' | _ | = | IF YOU / | ARE AT | E AT 30000' | | F | YOU | IF YOU ARE AT 35000' | 35000' | - | IF.) | OU A | IF YOU ARE AT 40000' | 40000 | | | IF Y | IF YOU ARE AT 45000' | 4T 4500 | .0 |
| | RANGE IN AIRMILES | MILES | FUEL | | RANGE | RANGE IN AIRMILES | LES | | | RANGE | RANGE IN AIRMILES | LES | T | | RANGE | RANGE IN AIRMILES | LES | FUEL | EL | - | RANGE IN AIRMILES | IRMILES | |
| BY CRUISI AT 25000" | BY CRUISING OPT ALT. AT 25000' 1000 FT. | BY CRUISING AT OPT. ALT. | POUNDS | S BY CRUISING AT 30000' | 250 | 1000 FT. | BY CRUISING AT OPT. ALT. | - : | BY CRUISING AT 35000' | | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | -0.0 | BY CRUISING AT 40000' | - | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | HIG POUNDS | NAME OF TAXABLE PARTY. | BY CRUISING AT 45000' | 1000 FT. | | BY CRUISING AT OPT. ALT |
| | | | | (RANGE | E FIGUR | | CLUDE | ALLC | MANC | ES FO | R PRES | CRIBED | CLIME | 3 & DE | CENT | TO SE | ES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | 7 | | | | | |
| 1345 | 9 04 | 1800 | 12,000 | 1525 | | 40 | 1820 | 20 | 1695 | | 94 04 | 1835 | 00 | 1830 | | 40 | 1845 | 12,000 | 000 | | | | |
| 1110 | 9 9 | 1450 | 10,000 | 1255 | | 40 | 1465 | 92 | 1380 | | 40 | 1480 | 0 10 | 1325 | | 40 | | 10,000 | 000 | | | | |
| 880 | \$ 4 | 1115 | 8,000 | | | 40 | 1135 | 10 | 1090 | | 40 | 1155 | 0 | 1170 | | 40 | - | 8,0 | 000 | | | 1154 | |
| 760 650 540 | 444 | 955 810 670 | 7,000 6,000 5,000 | 860 785 610 | - | 94 94 | 975 830 690 | 000 | 940 810 670 | | 40 | 990 845 705 | 200 | 1010 865 725 | | 404 | | 7,000 6,000 5,000 | 888 | 818 | | | |
| 440 325 225 | 333 | 535 400 265 | 4,000 3,000 2,000 | 495 375 255 | | 344 | 555 420 295 | 000 | 540 415 285 | | 94 94 94 94 | 570 435 310 | 000 | 590 450 315 | | 333 | | 3,000 | 999 | 1111 | 233 | | |
| 0 | CRUISING AT 25000' | . 25000' | | | CRUISING | | AT 30000' | | | CRUIS | CRUISING AT 35000' | 35000' | | 0 | RUISII | CRUISING AT 40000' | ,00001 | - | | 2 | CRUISING AT 45000' | AT 4500 | ,0 |
| | APPROXIMATE | IATE | - EFFEC. | | Y | APPROXIMATE | ATE | | | A | APPROXIMATE | ATE | | - | 4 | APPROXIMATE | AATE | i F | TIVE | | APPR | APPROY'4ATE | |
| C.A.S. % | L.Bur G.S. | R.F. DOWN | | C.A.S. | RPM LB | R 6.5. | R.F. | LET O | C.A.S. | RPM LBMR | HR G.S. | a, | DOWN DIST. | C.A.S. % | LB/HR | AR G.S. | R.F. | LET WIN | - | C.A.S. RPM | MM/ | 6.5 R. | R.F. DOWN DIST. |
| 297 86 | 4230 309 | 69' | 120 MW | 269 | 87 3690 | 304 | 69. | 00 | 245 8 | 87 3240 | 40 302 | 07. | 12 | 221 91 | 3080 | 30 302 | 17. | 16 120 HW | ММ | | | | |
| 287 85 | 4040 336 | 7 67. 8 | 90 HW | 267 8 | 86 3630 | 0 340 | . 79 | 10 | 243 8 | 86 3200 | 00 339 | . 80 | 13 | 221 91 | 3080 | 3 45 | .81 | 18 80 MW | ¥ | | | - | 31 |
| 273 85 | 3770 357 | 8 68. 7 | 40 HW | 258 | 86 3420 | 998 0 | 88 | 11 | 241 8 | 86 3130 | 30 375 | . 90 | 15 | 220 90 | 3060 | 384 | 06. | 20 40 HW | AH A | | | | |
| 267 84 | 3640 387 | 7 1.00 9 | 0 | 256 8 | 85 3360 | 0 403 | 1.00 | 12 | 241 8 | 86 3130 | 30 415 | . 86 | 17 | 220 90 | 3060 | 10 424 | .91 | 22 0 | | | | | |
| 258 83 | 3520 416 | 6 1.11 10 | WT 07 | 251 8 | 84 3310 | 0 437 | 1,10 | 13 | 238 8 | 86 3100 | 00 450 | 1.10 | 19 | 217 90 | 3000 | 00 480 | 1.11 | 24 40 TW | TW | 311 | | | |
| 247 83 | 3360 441 | 1 1.24 11 | WT 08 | 244 8 | 84 3220 | 0 466 | 1.21 | 14 | 235 8 | 86 30 | 3060 486 | 1.20 | 21 | 216 90 | 3000 | 499 | 1.20 | 26 ao TW | T.W | | | + | _ |
| 237 83 | 3240 468 | 1.36 12 | 2 120 TW | 238 8 | 84 3140 | 0 498 | 1.32 | 16 | 234 8 | 86 3060 | 30 524 | 1.30 | 22 | 216 90 | 3 000 | 00 539 | 1.30 | 28 120 TW | AL | - | | | 4 |
| | | SPECIA | SPECIAL NOTES | | | | | | | Û | EXAMPLE | 273 | | | | | | | LEG | LEGEND | | | |
| 1 Climb at 1 2 Multiple 1 units. 3 Read low only. 4 Make additerors, comferrors, comferrors, comferrors. BASED ON: DATA AS OF: | mb at 100 Ittple Nau ad lower ke addition s, combat ON: ES | 1 Climb at 100 % RPM 2 Multiple Nautical units by 1.15 to obtain Statute units. 3 Read lower half of chart opposite effective wind only where additional allowances for landing, navigational errors, combat, formation flight etc. as required. AASED ON: ESTIMATE AASED ON: ESTIMATE | art opposit | te effect te effect fing, nav . as requ | live will distribute and integration direct. | And the second of the second o | If you are at 20,000 ft. with 11,000 lb. of available fuel, you can fly 1075 nautical miles by holding 270 knots CAS. However, you can fly 1600 nautical miles by immediately climbing to 40,000 ft. at 100% RPM. At 40,000 ft. cruise at 220 knots CAS. When reduced weight allows, continue climbs to and cruises at higher altitudes until 45,000 ft. is attained. At 45,000 ft. cruise at 195 knots CAS and start let down 29 nautical miles from home. With a 40 knot headwind, the range at optimum altitude would be .90 x 1600 or 1440 nautical miles. Cruise at 195 knots CAS and start let down 26 nautical miles from destination. | e at I. can I. can I. can Giatel Oo ft. Llows, until I. 195 Dim ho Im all miles naut | 20,00 oweve oweve y clim cruis conti 45,0 knots me. itude | of ft. 775 na 77, you 77, you 78, you 79, you 70, y | 0,000 ft. with 11,000 y 1075 nautical miles I wever, you can fly 160 climbing to 40,000 ft. cruise at 220 knots CA continue climbs to and cA5,000 ft. is attained. knots CAS and start let ne. With a 40 knot heat the would be ,90 x 1 Cruise at 195 knots (cal miles from destinat) | are at 20,000 ft. with 11,000 lb. of available cou can fly 1075 nautical miles by holding 270 CAS. However, you can fly 1600 nautical miles nediately climbing to 40,000 ft. at 100% RPM.,000 ft. cruise at 220 knots CAS. When reduce allows, continue climbs to and cruises at higher es until 45,000 ft. is attained. At 45,000 ft. at 195 knots CAS and start let down 29 nautica from home. With a 40 knot headwind, the range mum altitude would be .90 x 1600 or 1440 at miles. Cruise at 195 knots CAS and start let 26 nautical miles from destination. | b. of a y hold y hold y hold y hold y at 10 %. What to own twind, oo or AS and n. | lb. of available by holding 270 on autical miles at 100% RPM. S. When reduced ruises at higher At 45,000 ft. down 29 nautical dowind, the range 600 or 1440 c. As and start let on. | les les M. uced her t, tical nge | R.F. G.S. CAS. CAS. () RAN | ECTIVI For conformation of the conformation of | EFFECTIVE WIND-HW, Headwind, TW, Tailwind-Knots R.FRange factor-Ratio of ground distance to airmiles for corresponding winds G.SGround speed in Knots G.SGround speed in Knots LEB/HR-Fuel consumption-Pounds per hour RANGE-Nautical miles () RANGE-Nautical miles POLATION PURPOSES ONLY FUEL GRADE: JP-4 FUEL GRADE: JP-4 | W, Hea titlo of a knoth Knoth Seed in ption-I ss CYHESI OSES (| Sround (18 For ONL X | D-HW, Headwind, TW, Tailwin r-Ratio of ground distance to a conding winds ad in Knots ad in Knots ad surppeed in Knots sumption-Pounds per hour miles RENTHESIS FOR INTER- URPOSES ONLY FUEL GRADE: JP-4 FUEL GRADE: JP-4 | wind K | lles |

Figure A-40

| M M | ng more the sing elfind s include a | į, | | .0000 | 8 | BY CRUISING AT OP T. ALT. | | 2105 | 1740 | 1590 | 1430 | 1295 | 1175 | 915 (785) | ,000 | | R.F. DOWN | 1 | 79 5 | 9 68. | 1.00 6 | 1.12 6 | 1.26 7 | 0000 |
|---|--|----------------------------|-------|----------------------|-------------------|---|---|--------------------|--------|--------|--------|--------|-------|--------------|--------------------|-------------|-------------|----------|-----------|-----------|--------------|-------------|-------------|------------|
| TEMS | i flights requiring to applicate and penge value adicated. | BASED ON: ESTIMATE | | IF YOU ARE AT 20000' | RANGE IN AIRMILES | 1000 FT. A | | 40 | 40 | 40 | 40 | 40 | 4 0 | 40 | CRUISING AT 20000' | ABBROWNAN | LB G.S. II | 311 | 4730 332 | 4400 348 | 4260 3 79 1. | 3980 398 1. | 3790 426 1. | 9840 459 1 |
| EXTERNAL LOAD ITEMS NONE OF ENGINES OPERATIN | rry to observe the series of t | BASED ON: | | IF YOU | RANC | BY CRUISING AT 20000' | | 1440 | 1215 | 1120 | 1025 | 930 | 750 | (570) | CRUI | - | S.A.S. | | 308 86 47 | 290 85 44 | 284 84 42 | 267 83 39 | 257 83 37 | 946 R9 RE |
| EXTERNAL LOAD ITEMS NONE NUMBER OF ENGINES OPERATING: (TWO) | MOTES: Renges shown of optimum altitudes are maximum. In order to obtain monimum renge on flights requiring more than one chart (deu to external configuration or gross veright changes), it is necessory to observe the optimum cruising elitivate on one chart (i.e., when changing charts a clind may be required to obtain a manimum range. All prange values include allowances for descent distance and feel. Clind distance and feel are included where climbs are indicated. DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | | 2 | (1) | FUEL | POUNDS | | 15, 158 14, 000 | 13,000 | 12,000 | 11,000 | 10,000 | 8,000 | 7,000 | | EFFEC. | N N | 120 HW 3 | 80 HW 3 | 40 MW 2 | 0 | 40 TW 2 | 80 TW 2 | 6 |
| NUMB | azinum. In or neight chango. may be require nce and fuel a | | | ,000 | | BY CRUISING AT OPT.ALT. | LEVEL (1) | | 1720 | | 1410 | | 1030 | 895 | .00 | | LET DOWN | DIST. | 5 4 | 4 1 | 0 4 | 4 | 7 4 | |
| 22 | for are ma a climb a imb distern | | | YOU ARE AT 15000' | RANGE IN AIRMILES | _ | 1 3 | | + | - | - | + | | | CRUISING AT 15000' | APPROXIMATE | R.F. | - | 97. 0 | 9 .87 | 4 1.00 | 9 1.13 | 4 1.27 | _ |
| ART | um altitus qualion e ng charts fuel. CI | 1953 | | UARE | NGE IN | OPT. ALT. 1000 FT | NT TO | 40 | 40 | 40 | 40 | 40 | 9 9 | 40 | ISING / | APPRO | HR G.S. | 1 | 5100 310 | 4740 329 | 4440 354 | 4100 369 | 3880 394 | |
| N CH | of optimed configurations of the configurati | OBER | | IF YO | RA | BY CRUISING AT 15000" | DESCE | 1285 | 1090 | 1000 | 915 | 830 | 029 | 585 | CRU | | RPM RPM | | 86 5 | 8 4 4 | 83 4 | 82 41 | 82 3 | |
| 0 0 | s shown to extern i.e., whi | LOO 4 | DE | _ | - | | IMB & | | - | | _ | _ | | | 1 | 1 | C.A.S. | | 315 | 297 | 286 | 265 | 252 | |
| INSTRUCTION CHART ARD DAY TO 39, 500 POUNDS | MOTES: Renges shown of optimum altitudes are maximum, one chart (due to externe) configuration or gross weight of one overheart i.e., when changing charts a climb may be relevances for descent distance and fuel. Climb distance and DATA BELOW CONTAIN HO | DATA AS OF: P OCTOBER 1953 | LTITU | ,000 | | BY CRUISING AT OP T.ALT. | (RANGE FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA | 2060 | 1690 | 1540 | 1390 | 1255 | 1010 | 875 | | | DOWN | Š | | 63 | 0 | 2 | 7 2 | |
| NST To | MOTE one e en ce lewen | DATA | F | IF YOU ARE AT 10000' | RANGE IN AIRMILES | | ESCRIE | | + | - | H | - | _ | | CRUISING AT 10000' | CIMATE | 8. 8. | | 3 .72 | 98. 0 | 1.00 | 8 1.14 | 1.27 | _ |
| | 111111 | | A | I ARE | GE IN A | OPT. ALT. 1000 FT | OR PR | 4 04 | 40 | 40 | 40 | 40 | 3 4 | 40 | SING A | APPROXIMATE | AR G.S. | - | 00 283 | 40 310 | 50 331 | 348 | 10 358 | |
| OPERATION INS STANDARD | everlably right of the control of the control of the credit of the credit of the credit of the credit of the control of the co | | > | IF YOU | RAN | BY CRUISING AT 10000" | CES F | 1140 | 016 | 890 | 815 | 740 | 595 | 520 (455) | Segre | | N N N | + | 86 5500 | 83 5040 | 82 4650 | 81 4300 | 81 3940 | - |
| E . | than fuel re berizo ri altitud given d in approp if and cli | | MO | | | | OWAN | 44 | | | | | | 2,4 | | | ,2.A.5, | | 314 | 303 | 287 | 266 | 241 | |
| | wam equal to or less than feel available for enten Hight, esc.). Mays bestsoartelly right as all by cruising or that altitude or by climb- whigh instructions are given directly below. Traising instructions in appropriate revising it foul for take-off and climb to desired IN FLIGHT ebevo, adding initial climb dire- | | ľ | , | | BY CRUISING AT OPT.ALT. | DE ALL | 2040 | 1670 | 1515 | 1365 | 1230 | 066 | 855 (720) | | | DOWN | 2 | | 1 | 1 | 1 | | |
| FLIGHT | on flight by cruiting instruction itsing instruction fuel | | | AT 5000' | AIRMILES | | NCLU | 2 -1 | 1 | - | - | | 1,770 | -6 | 2000 | IMATE | ex. | | | . 86 | 1.00 | 1.15 | | |
| 표 용 | val calus or, formati o, aporat i read en subfract a for IN | | | | | BY CRUISING OPT. ALT. AT 5000" 1000 FT | URES | 40 | 40 | 9 | 90 | 40 | 40 | 40 | CRUISING AT 5000' | APPROXIMATE | 0,5 | | | 0 290 | 4910 311 | 4600 333 | | |
| | igure in f lonel erre everifeble al altitud itude and a board | | | IF YOU ARE | RANGE IN | ISING C | E FIG | 35 | 22 | 190 | 0 | 00 | o uo | 96 | CRUIS | | RPH AR | _ | | 5310 | | _ | | |
| | Sclact for navigal al responsive to the school of the o | | | - | | BY CRUISIN AT 5000" | (RANG | 1005 | 88 | 2 2 | , | 650 | 52 | 460 (400) | | - | C.A.5 | | _ | 307 82 | 290 81 | 273 80 | | - |
| AIRCRAFI MUDEL (S) 35-57B ENGINE(S) 365-W-5 | HASTRUCTIONS FOR USING CHART: (A) IN FLIGHT - Scient figure in feel column equal to at less than feel available for crutes (finel as board minus allowence for tozervo, combat, navigational error, formation flight, erc.). Mayor bestatemelly right as effect to section according to present alithude and road force if uppe ovoifiable (no wind) by crutising at that alithude es by climbing to enother alithude of manifum range. For a flight at latital alithude, poperations are given directly below. Far a flight or higher alithude, climb immediately to desired elithude and error crutising instructions in appropriate revising alithude and all other necessory efformances. Then use chost subfront fuel for toke-off and climb to desired elithude and all other necessory efformances. Then use chost as fer IN FLIGHT above, adding initial climb districtions once to ronge volues. | | | 3 | FUEL | POUNDS | | 15, 158 14, 000 | 13,000 | 12,000 | 77,000 | 10,000 | 8,000 | 7,000 | 0 | TIVE | QNIA | 120 HW | AH 08 | 40 HW 3 | 0 | 40 TW | WT 00 | 120 TW |
| -W-5 | once for removed in removed in the line into LAMMING | | | | | | | 2020 | 1645 | 92 | 040 | 05 | 965 | 830 | | Γ | LET DOWN | | | 0 | 0 | 0 | | _ |
| S) J65 | SING CH nus allow a to present of maxims Light p | | | T S.L. | LES | BY CRUISING AT OPT.ALT. | | 18 | 16 | 14 | TO | 1205 | 0 | 830 | S.L. | TE | P. P. | | | . 87 | 1.00 | 1.15 | Ī | |
| AIRCRAFT MODEL (3 | beard mu according shirted higher a (B) FL | | | ARE A | RANGE IN AIRMILES | PT. ALT. 1000 FT | | 40 | 40 | 40 | 0# | 40 | 40 | 40 | IG AT | APPROXIMATE | 6.5. | | 11-7.0 | 272 | 293 | _ | | |
| K W | HASTRUCTIONS FOR cruise (feel on board , left to section accord ing to another altitudal ing to another altitudal per a flight or higher altituda section. (B) cruising altitude and cruise range volues. | | | IF YOU ARE AT S.L. | RANGE | 9 | | | - | _ | - | | | | CRUISING AT S.L. | APP | LB Mm | | | 2600 | 5270 | 5000 320 | | |
| | cruise left to ing to Por a altitude cruising | | | <u>=</u> | | AT S.L. | | 865 | 740 | 685 | 670 | 565 | 455 | 400 (345) | 0 | | R M M | | | 312 82 | - | 280 80 | | |

Figure A-41

| AIRCKAP | T MODEL | AIRCRAFT MODEL (S) B-57B | | | | | | | I | AL | HIGH ALTITUDE | | 0 0 0 | | | | EXT. LOAD | OAD NONE | ıl Z | | |
|--|--|---|--|---|------------------------------|-------------|---|--|--|--|--|--------------------------|---|----------------------|---|---|--|---|--|-----------------------------------|------------------|
| ENGINE (S): | s): J65-W-5 | V-5 | | | CHART WT. LIMITS | 7. LII | | 44,000 | TO 3 | 39, 500 POUNDS | SUNDO | | | | | | NO. 01 | NO. OF ENGINES OPERATING:(TWO) | OPERA | TING:(TV | (OA |
| IF YO | IF YOU ARE AT 25000' | 25000' | | IF YOU | AR | E AT 30000' | 30000, | _ | IF YOU | IF YOU ARE AT 35000' | T 35000' | - | IF YC | IF YOU ARE AT 40000' | AT 400 | .00 | | IF YO | U ARE | IF YOU ARE AT 45000' | |
| RA | RANGE IN AIRMILES | ILES | FUEL | | RANGE IN | AIRMILES | ES | - | RAN | RANGE IN AIRMILES | HLES | | a. | RANGE IN AIRMILES | VIRMILES | | FUEL | ~ | RANGE IN AIRMILES | RMILES | |
| BY CRUISING OPT ALT. AT 25000' 1000 FT. | OPT ALT. | BY CRUISING AT OPT. ALT. | POUNDS | BY CRUISIN AT 30000" | 100 TO | PPT ALT. B | BY CRUISING AT OPT. ALT. | | BY CRUISING AT 35000' | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | - | BY CRUISING AT 40000' | G OPT ALT. | | BY CRUISING AT OPT. ALT. | POUNDS | BY CRUISING AT 45000' | IG OPT ALT. | T. BY CRUISING T. AT OPT. ALT. | UISING T. ALT |
| | | | | (RANG | FIGUR | ES INC | LUDE A | LOWA | ACES F | OR PRE | (RANGE FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | CLIMB | & DESC | ENT T | O SEA | LEVEL) | | | | | |
| 1650 | 99 | 2125 | 15, 158 14, 000 | 1695 | 40 | | 2140 | 2 -1 | 2040 | 40 | 2155 | | 2165 | 40 | | | 15, 158 14, 000 | | | | |
| 1395 | 40 | 1760 | 13,000 | 1560 | | | 1780 | 1 | 1695 | 40 | 1790 | | 1800 | 40 | | | 13,000 | | | | |
| 1280 | 40 | 1600 | 12,000 | 1435 | 8 9 | | 1620 | | 1420 | 40 | 1485 | | 1500 | 40 40 | | | 11,000 | | | | |
| 1050 | 40 | 1310 | 10,000 | 1190 | | | 1380 | | 1290 | 40 | 1345 | | 1355 | 40 | | 1 | 10,000 | | | | |
| 845 | 3 4 | 1065 | 8,000 | 096 | 4 | | 1080 | - | 1045 | 4 6 | 1095 | | 1115 | 40 | | | 8,000 | | | | |
| 755 (650) | 44 | 935 (800) | 7,000 | 840 (735) | 94 | | 950 (820) | = | 920 (800) | 40 | 970 (840) | | 982 (860) | 40 | | | 7,000 | | | | |
| CE | CRUISING AT 25000' | 25000' | | | CRUISING | AT 30000' | ,000 | + | CRU | CRUISING AT 35000' | 35000, | + | 2 | CRUISING AT 40000' | AT 400 | ,00 | | 8 | UISING | CRUISING AT 45000' | |
| | APPROXIMATE | ATE | - EFFEC- | | APP | | 2 | - | | APPROXIMATE | MATE | - | - | APP | APPROXIMATE | ш | TIVE | | APPR | APPROXIMATE | |
| C.A.S. % | L.Bur G.S. | R.F. DOWN | | CAS | RPM LB | 4.9 | R.F. DOWN DIST. | C.A.S. | RPR | L.Вия G.S. | R.F. | LET C./ DOWN DIST. | C.A.S. SE | LB/HR | 6.5 | R.F. DOWN DIST. | | C.A.S. % | /HR | G.S. R.F. | DOWN DIST. |
| 301 87 | 4480 315 | . 70 | 120 HW | 272 88 | 3940 | 308 | 8 69 | 246 | 88 3 | 3500 304 | . 71 | 12 22 | 221 93 | 3400 | 305 | .71 16 | 120 HW | | | | |
| 291 86 | 4300 343 | 7 67. | WH 00 | 270 87 | 3860 | 345 | . 79 10 | 244 | 88 | 3450 338 | .81 | 13 2 | 221 93 | 3400 | 345 | . 82 18 | WH 08 | | | - | |
| 281 86 | 4100 369 | 8 68. | 40 HW | 262 87 | 3680 | 374 | . 90 | 244 | 88 3 | 3450 378 | 06. | 15 2 | 221 93 | 3400 | 385 | . 90 20 | 40 HW | | | | |
| 277 85 | 3960 400 | 1.00 9 | 0 | 262 86 | 3 3640 | 411 | 1.00 12 | 244 | 88 | 3450 418 | 1.00 | 17 2 | 221 93 | 3400 | 425 1 | 1.00 22 | 0 | | | | |
| 266 85 | 3830 428 | 1.11 10 | 40 TW | 257 86 | 3 3590 | 445 | 1.10 13 | 1 241 | 88 | 3400 455 | 1.10 | 19 2 | 219 93 | 3350 | 462 1 | 1.10 24 | 40 TW | | | | |
| 258 84 | 3700 456 | 1.22 11 | WT 08 | 252 86 | 6 3540 | 478 | 1.20 14 | 1 240 | 88 | 3400 493 | 1.20 | 21 2 | 219 93 | 3350 | 502 1 | 1.20 26 | WT 08 | | | - | |
| 251 84 | 3600 487 | 1.34 12 | 120 TW | 248 86 | 3480 | 512 | 1.30 16 | 3 239 | 88 | 3400 531 | 1.30 | 22 23 | 219 93 | 3350 | 542 1 | 1.30 28 | 120 TW | | | | |
| | | SPECIAL | SPECIAL NOTES | | | | | | 2 1:2) | EXAMPLE | щ | | | | | | _ | LEGEND | | | |
| 1 Climb at 2 Multiple. units. 3 Read low only. 4 Make addd errors, com | 1 Climb at 100% RPM 2 Multiple Nautical ununits. 3 Read lower half of conf. 4 Make additional allows errors, combat, formati | 2 Multiple Nautical units by 1.15 to obtain Statute units. 3 Read lower half of chart opposite effective wind only. 4 Make additional allowances for landing, navigational errors, combat, formation flight etc. as required. BASED ON: ESTIMATE | by 1.15 rt opposit es for land flight etc. | to obtain e effect ling, nav as requ | Ive wind gationa ired. | | If you are at 10,000 ft. with 11,000 fteel, you can fly 815 nautical miles knots CAS. However, you can fly 1by immediately climbing to 40,000 At 40,000 ft. cruise at 221 knots weight allows, continue climbs to ar altitudes until 45,000 ft. is attaine cruise at 195 knots CAS and start! miles from home. With an 80 knot at optimum altitude would be .81 x cal miles. Cruise at 196 knots CAS and start. | n fly the Hower the fit. cruise known. | tills na ret, your fittinue cooo ft tis CAS With at 196 at 196 at 196 at 196 at 196 at 196 | with 11 utical m utical m utical m to 40,0 221 km limbs to is atta and sta an 80 h 1 be . 81 | o 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 | | 390 nautical miles ft. at 100% RPM. CAS, When reduced decruises at higher d. At 45,000 ft. et down 29 nautical headwind, the range 1390 or 1125 nauti. S and start let down | o -1 | EFFEC C.FR fo ASS-Ca ASS-Ca ANGE) RAN POL | ange fact r. correct cound sp lilbrated -Fuel co -Nautica GE IN P | EFFECTIVE WIND-HW, Headwind, TW, Tailwind-Knots R.FRange factor-Ratio of ground distance to airmiles for corresponding winds G.SGround speed in Knots CAS-Cailbrated airspeed in Knots LB/HR-Fuel consumption-Pounds per hour RANGE-Mautical miles () RANGE IN PARENTHESIS FOR INTER- POLATION PURPOSES ONLY FUEL GRADE: JP-4 EIEL GRADE: JP-4 | D-HW, Headwind, TW, Tailwin r-Ratio of ground distance to a conding winds ed in Knots ed in Knots sumption-Pounds per hour miles IRENTHESIS FOR INTER- URPOSES ONLY FUEL GRADE: JP-4 FUEL GRADE: JP-4 | TW, Tail: listance per hou INTER- | to airmil | e s |

Figure A-42

| | | INSTR craise left to ing to affind cruisin | anecs | | - | = | | BY CRUISING OPT. ALT. AT S.L. 1000 FT | | 820 | 785 | 730 | 675 | 620 | (265) | | *5 | AD RPM | | | 318 82 | - | 286 80 | | |
|-----------------------------------|------------------------------------|--|------------------------|--|-----|----------------------|-------------------|---|---|---------|--------|--------|--------|--------|--------|--------------------|-------------|----------------------|----------|----------|----------|-----------|----------|----------|--------|
| IV i | H L | CTIONS section and section and section and section at section. | ances to range values. | | 100 | IF YOU ARE AT S.L. | RANGE | ING OP | | | | | | | | CRUISING AT S.L. | APP | LB HR | | | 8000 | | 5210 326 | | |
| RCRAF | ENGINE(S) | board mir according altitude o higher al | olues. | | 1 | ARE A | RANGE IN AIRMILES | | | 35 | 35 | 35 | 35 | 35 | 35 | IG AT | APPROXIMATE | 6.5. | | | 278 | | | | |
| 2 | 2-M-99F (c | NATRUCTIONS FOR USING CHART: (A) IM FLIGHT - Scleet figure in fuel celeman equal to ar less than fuel evailable for earlies (fuel on board minus allowance for instance, combat, navigational error, formation (light, etc.), Mere bestsentally right explore that to section according to present altitude and rood total range evailable (no wind) by cruising at that altitude or by clinabing to another altitude of maximum range. For a flight or initial elitinds, pecualing instructions are given directly below. For a flight or initial elitinds, pecualing instructions in appropriate cruising altitude section. (B) FLIGHT PLANNING - From initial down board subtreet fuel for take off and climb in desired cruising altitude and all other necessary allowances. Then use chari as for IN FLIGHT above, adding initial climb districtions | | | | S.L. | LES | BY CRUISING AT OPT.ALT. | | 1800 | 1670 | 1560 | 1450 | 1330 | (1205) | 3.L. | TE | R.F. DOWN DIST. | | | 0 98. | _ | 1.16 0 | | |
| (S) B-57B | -2 | (A) iN FLIG er reserve, ce trude and rea- ige. For a f immediately iNG - Fram- ry allowence | | | _ | i | FUEL | POUNDS . | | 15, 158 | 14,000 | 13,000 | 12,000 | 11,000 | 10,000 | 0 | TIVE | | 120 HW | 80 HW | 40 HW | 0 | WT 04 | WT 08 | 120 TW |
| 7.B | | SMT - Sel. ambot, nor di totel ru Hight et te desire initial fu | | | 107 | | -1 | | - | | 0 | 0 | 0 | | | | | C.A.2 | | | 315 | 299 | 283 | | |
| | | act figure i | | | | IF YO | RAI | Y CRUISING AT 5000" | INGE F | 970 | 006 | 840 | 780 | 710 | (650) | CRUI | | RPM LE | | | 84 | 82 | 81 | | |
| Ü. | E. | in fuel celus erros, format ble (ne wirn tudo, operes and read err d subtract as fer IN | | | | 111 | RANGE IN AIR | BY CRUISING OPT. ALT. AT 5000' 1000 FT | GURES | 35 | 35 | 35 | 35 | 35 | 35 | CRUISING AT | APPROXIMATE | LB G.S. | | | 5650 299 | 5250 321 | 4950 344 | 7.65 | |
| IGHT | CHART WT. | form equal to or less than fuel available for notion flight, are, i Mave bectsoatally right or trading instructions or than altitude or by climb- rating instructions or given directly below, versing instructions in appropriate crusing etc. fuel for rade-off and climb to desired IN P.LIGHT above, adding initial climb dist- | | | | AT 5000' | AIRMILES | | (RANGE FIGURES INCLUDE ALL | 18 | 1695 | 1585 | 1470 | 1355 | (1230) | AT 5000' | MATE | R.F. | | | .86 | 1.00 | 1.14 | | |
| OPE | LIMITS | or less the tc.).Move ig at that a liens are gl crions in take-off a two, edding | | | | | | _ | E ALLO | 1820 | 98 | 82 | 01 | 22 | 30) | - | | LET DOWN DIST. | | 65 | 1 3 | 1 28 | 1 2 | 23 | |
| STA | | to or less than foel available for sing or that elitiude or by climb- scrips or that elitiude or by climb- betions are given directly below. Tructions in appropriate cruising for take off and climb to desired above, adding initial climb dist- | | MO MO | | IF Y | a. | BY CRUISING AT 10000' | WANCES | 1100 | 1020 | 950 | 880 | 802 | (740) | 8 | - | 2.A.5 | | 327 87 | 313 84 | 299 83 | 278 82 | 253 82 | |
| LIGHT OPERATION INSTRUCTION CHART | 48,800 | right or right or y ellub- r below. r below. revising desired | | A | | IF YOU ARE AT 10000' | RANGE IN AIRMILES | 1000 FT | OWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA | 35 | 35 | 35 | 35 | 35 | 35 | CRUISING AT 10000' | APPROXIMATE | L.B. G.S. | | 5890 296 | 5360 321 | 5040 345 | 4700 362 | 436C 373 | |
| NSTR D | T0 | NOTES, one che on each lowence | DATA AS OF: | E | | AT 1000 | RMILES | | SCRIBE | - | 1 | 1 | 1 | 1 | 1) | T 10000 | IMATE | 5. F. | | 8 . 73 | 1 .87 | 5 1.00 | 2 1.13 | 1.25 | |
| UCTI | 44,000 | Ranges ort (due to chart; i.e | | LIL | | ,, | | BY CRUISING AT OP T.ALT. | ED CLIN | 1845 | 1720 | 1610 | 1500 | 1375 | (1255) | | | DOWN DIST. | | 64 | 64 | 23 | 64 | 61 | |
| NO | POUNDS | shown at op external co i., when cha not distance | 1 OCTOBER 1953 | F | - 1 | F | | BY CRUISING AT 15000' | B & DES | 1230 | 1140 | 1070 | 995 | 902 | (830) | Ū | - | 2.A.5 | | 324 87 | 308 85 | 298 85 | 276 83 | 265 83 | A |
| HAR | S | primum altitantiquestion and fuel. t | ER 195 | | | IF YOU ARE AT 15000' | RANGE IN | 0 | CENT T | 6 | | 8 | | | 35 | CRUISING AT 15000' | APPR | L.B. | | 5450 3 | 5120 3 | 4810 3 | 4540 3 | 4280 4 | |
| - | | or gross res m or gross res estimb | 63 | | | E AT 15 | RANGE IN AIRMILES | | | | 35 | 35 | 35 | 35 | | AT 150 | APPROXIMATE | 6.5. R.F. | | 321 | 342 .8 | 3 69 1.0 | 388 1.11 | 410 1.25 | |
| | NUM | eximum. In a veight change may be requi- nce and fuel | | | | ,000 | | BY CRUISING AT OPT.ALT. | LEVEL (1) | 1865 | 1735 | 1630 | 1515 | 1400 | (1275) | ,00 | | . DOWN | | .77 4 | 87 4 | 90 4 | 1 4 | 15 4 | |
| EXTER | SER OF EN | rder to obtain 15), it is noces cd to obtain a are included w | | F | | 5 | FUEL | POUNDS | | 15, 158 | 14,000 | 13,000 | 12,000 | 11,000 | 10,000 | | EFFEC. | QNIM | 120 HW | 90 HW | 40 HW | 0 | 40 TW | WT 08 | |
| EXTERNAL LOAD ITEMS NONE | NUMBER OF ENGINES OPERATING: (TWO) | NOTES: Ranges shown at optimum altitudes are maximum. In erder to obtain maximum range on Hights requiring more than one chart (due to extraval configuration or gross weight charapes), it is necessary to ebserve the aptimum cruising altitude on each chart i.e., when changing charts a climb may be required to obtain a maximum range. All range values include at loweness for descent distance and fuel. Climb distance and fuel are included where climbs are indicated. DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | RASED ON | a de la companya de l | | | RA | | | 1380 | 1280 | 1190 | 1110 | 1015 | (930) | CRL | | C.A.5 | 327 88 | 316 87 | 300 86 4 | 296 86 4 | 279 85 4 | 271 84 4 | |
| ITEMS N | RATING: | on flights req the optimum. All range ve indicated. | RASED ON: ESTIMATE | | | IF YOU ARE AT 20000' | RANGE IN AIRMILES | AT 20000" 1000 FT | | 35 | 35 | 32 | 35 | 35 | 35 | CRUISING AT 20000' | APPROXIMATE | LB/HR 6.5. | 5130 315 | 499C 340 | 4760 362 | 4 620 394 | 4380 414 | 4160 443 | |
| ONE | (TWO) | uiring more cruising altr slues includ | a E | 9 | | 20000 | ILES | BY CRUISING AT OPT.ALT. | | 1885 | 1755 | 1650 | 1535 | 1415 | (1295) | 20000 | ATE | R.F. DOWN | . 72 | . 80 | . 89 6 | 1.00 6 | 1.11 6 | 1.26 7 | |

Figure A-43

| AIRCRAFT MODEL (S) | T MODEL | (S) B-57B | 6 | | | I | I U | ALI | HIGH ALTITUDE |)E | | | EXI. LUAD | DAD NONE | 9 | |
|--|--|--|--|--|-------------------|--|---|--|---|--|----------------------|---|---|---|--|-----------------------------|
| ENGINE (S): J65-W-5 | 5): J65-W | 7-5 | | 5 | CHART WT. | WT. LIMITS 48,800 | 10 | 44, 000 POUNDS | OUNDS | | | | NO. 0F | ENGINES OPERATING:(TWO) | OPERAT | ING:(TWO |
| IF YO | IF YOU ARE AT 25000' | . 25000' | | IF YOU | AR | E AT 30000' | IF YO | IF YOU ARE AT 35000' | 35000, | IF YOU | IF YOU ARE AT 40060' | 40000, | | IF YOU | IF YOU ARE AT 45000' | 42000, |
| RA | RANGE IN AIRMILES | AILES | FUEL | R, | RANGE IN AIRMILES | ILES | RA | RANGE IN AIRMILES | LES | RAB | RANGE IN AIRMILES | 7.65 | FUEL | RAI | RANGE IN AIRMILES | MILES |
| BY CRUISING OPT ALT. AT 25000' 1000 FT. | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | POUNDS | BY CRUISING AT 30000" | OPT ALT. | BY CRUISING AT OPT. ALT. | BY CRUISING AT 35000' | OPT'ALT. | BY CRUISING AT OPT. ALT. | BY CRUISING AT 40000* | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | POUNDS | BY CRUISING AT 45000" | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. |
| | | | | (RANGE FIGUR | FIGURES I | ES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | OWANCES | FOR PRES | CRIBED CLI | MB & DESCE | NT TO SE | A LEVEL) | | | | |
| 1570 | 32 | 1900 | 15, 158 | 1740 | 35 | 1915 | 1865* | 35 | 1930 | | | | 15, 158 | | | |
| 1470 | 35 | 1770 | 14,000 | 1620 | 35 | 1785 | 1735 | 35 | 1800 | | | | 14,000 | | | |
| 1355 | 35 | 1665 | 13,000 | 1510 | 35 | 1680 | 1620 | 35 | 1690 | | | | 13,000 | | | |
| 1255 | 35 | 1550 | 12,000 | 1410 | 35 | 1565 | 1510 | 35 | 1580 | | | | 12,000 | | | |
| 1165 | 35 | 1430 | 11,000 | 1300 | 35 | 1440 | 1390 | 35 | 1460 | | | | 11,000 | | | |
| (1060) | 35 | (1310) | 10,000 | (1190) | 35 | (1330) | (1280) | 35 | (1345) | | | | 10,000 | | | |
| CRI | CRUISING AT 25000' | . 25000' | | | CRUISING AT | AT 30000' | CRI | CRUISING AT 35000' | 35000' | CRU | CRUISING AT 40000 | 40000, | 0000 | CRU | CRUISING AT 45000' | 45000' |
| - | APPROXIMATE | ATE | TIVE | | APPROXU | ROXIMATE | | APPROXIMATE | ATE | | APPROXIMATE | MATE | TIVE | | APPROXIMATE | 20.00 |
| C.A.S. % | LBHR G.S. | R.F. DOWN | | C.A.S. % | LBHR G.S. | R.F. DOWN | C.A.S. RPM | LВия с.s. | R.F. DOWN DIST. | C.A.S. % | /HR G.S. | R.F. DOWN DIST. | | C.A.S. % | /HR G.S. | S. R.F. DOWN DIST. |
| 326 88 5 | 5150 349 | 9 04. | 120 HW | 274 89 | 4210 310 | 8 07. 0 | 247 90 3 | 3830 302 | .71 12 | | | | 120 HW | | | |
| 297 88 | 4525 349 | 7 08. | 90 HW | 272 88 | 4120 347 | 01 08. | 246 90 | 3800 343 | . 81 13 | | | | 80 HW | | | |
| 288 87 | 4400 378 | 8 88 8 | 40 MW | 267 88 | 3940 379 | . 90 11 | 244 90 | 3800 380 | . 90 15 | | | | 40 HW | | | |
| 283 87 | 4270 410 | 0 1.00 9 | 0 | 266 88 | 3940 417 | 1.00 12 | 244 90 3 | 3800 422 | 1.00 17 | | | | 0 | | | |
| 275 86 | 4150 440 | 01 01.10 | 40 TW | 261 88 | 3900 452 | 1.10 13 | 243 90 3 | 3750 459 | 1.10 19 | | | | 40 TW | | | |
| 268 86 | 4030 470 | 1.21 11 | WT 08 | 257 87 | 3850 486 | 1.20 14 | 243 90 3 | 3750 499 | 1.19 21 | | | | WT 08 | | | |
| 264 85 | 3970 504 | 1.32 12 | 120 TW | 255 87 | 3850 522 | 1.29 16 | 243 90 3 | 3750 539 | 1.29 22 | | | | 120 TW | | | |
| | | SPECIAL | SPECIAL NOTES | | | | | EXAMPLE | | | | | ב | LEGEND | | |
| 1 Climb at 2 Multiple 2 Multiple 3 Read low only. 4 Make addierrors, com | 1 Climb at 100% RPM 2 Multiple Nautical units. 3 Read lower half of only. 4 Make additional allowerrors, combat, formal errors, combat, formal based on: ESTIMATE DATA AS OF: 1 OCTOBE | 1 Climb at 100% RPM 2 Multiple Nautical units by 1.15 to obtain Statute. anits. 3 Read lower half of chart opposite effective wind only. 4 Make additional allowances for landing, navigational errors, combat, formation flight etc. as required. 3ASED ON: ESTIMATE DATA AS OF: 1 OCTOBER 1953 | by 1.15 art opposit esfor land flight etc. | to obtainS e effective ling, navig: as requir | | If you are at 5000 ft. with 14,000 lb. of available fuel, you can fly 900 nautical miles by holding 299 knots CAS. However, you can fly 1695 nautical miles by immediately climbing to 35,000 ft. at 100% RPM. At 35,000 ft. cruises at 244 knots CAS. When reduced weight allows, continue climbs to and cruises at higher cruise at 195 knots CAS and start let down 29 nautical miles from home. With an 80 knot tailwind, the range at optimum altitude would be 1,19 x 1695 or 2015 at optimum altitude would be 1,19 x 1695 or 2015 down 35 nautical miles. Cruise at 194 knots CAS and start let down 35 nautical miles from destination. | 5000 ft. I fly 900 However, ely climbir t. cruise a t, cruise a thouse C ome. With littude wo c. Cruise c. Cruise | with 14,0 nautical nayou can fl g to 35,0 it 244 kn it 244 kn it 244 kn it 245 kn it 34 kn it 30 it is atta AS and sta in an 80 in an 194 is at 194 is standed | 1000 lb. of illes by hol y 1695 na y 1695 na otors CAS. I o o and cruis illned. At it let down kinot tailwin kinot tailwin kinot tailwin kinot case case stination. | ft. with 14,000 lb. of available on nautical miles by holding 299 er, you can fly 1695 nautical miles his set 244 knots CAS. When reduced into climbs to and cruises at higher 00 ft. is attained. At 45,000 ft. s CAS and start let down 29 nautical would be 1.19 x 1695 or 2015 uise at 194 knots CAS and start let miles from destination. | | EFFECTIVE WIND-HW, Headwind, TW, Tailwind-Knots R.FRange factor-Ratio of ground distance to airmiles for corresponding winds G.SGround speed in Knots CAS-Calibrated airspeed in Knots LB/HR-Fuel consumption-Pounds per hour RANGE-Nauticalmiles RANGE IN PARENTHESIS FOR INTER- POLATION PURPOSES ONLY FUEL GRADE: JP-4 FUEL GRADE: JP-4 FUEL BENSITY: 6.5 LB/GAL | or-Ratio or-Ratio or-Ratio ponding weet in a latesed in a nsumption almiles ARENTH PURPOSE: | D-HW, Headwind, TW, Tailwind ra-Ratio of ground distance to a conding winds of the Mots at Nots are sumption-Pounds per hour lamiles remained result of the CRADE: JP-4 FUEL GRADE: JP-4 FUEL DENSITY: 6.5 LB/GAL | W, Tailwistance to ser hour INTER- | airmiles |

Figure A-44

| (TWO) | ng more shen sing afritude s include al- | (c) | | .0000 | 2 | BY CRUISING AT OP T.ALT. | | 430 | 265 | 110 | | ,0000 | | R.F. DOWN DIST. | .63 5 | . 75 5 | .86 6 | 00 8 | 1.15 6 | 1.29 7 | 1.45 7 |
|---|--|----------------------------|-------|----------------------|-------------------|---|--|------|----------|------|---|--------------------|-------------|--------------------|-----------|-----------|----------|-------------|------------|------------|------------|
| ος <u>:</u> | flights requirin a aptimum crui ill range value dieated. | BASED ON: ESTIMATE | | IF YOU ARE AT 20000" | RANGE IN AIRMILES | 1000 FT. A | | 45 | 45 | 32 | | CRUISING AT 20000' | APPROXIMATE | L.В.нк G.S. | 1280 271 | 3800 284 | 3450 298 | 3170 318 1 | 2900 333 1 | 2780 361 1 | 1 068 0792 |
| EXTERNAL LOAD ITEMS GAL WING TIP TANK ED ENTIRE DISTANCE OF ENGINES OPERATIN | rimum renge on y to observe th ximum renge. A c climbs ere in R LANDING | BASED ON: | | IF YOU | RANG | BY CRUISING AT 20000" | | 305 | 205 | 100 | | CRUI | - | RP R | 293 84 42 | 271 83 38 | 51 82 34 | 236 80 31 | 217 79 29 | 208 78 27 | 201 78 26 |
| EXTERNAL LOAD ITEMS 2 X 320 GAL WING TIP TANKS CARRIED ENTIRE DISTANCE NUMBER OF ENGINES OPERATING: | NOTES. Renges shown of optimum allitudes are maximum. In order to obtain maximum range on flights requiring more whom one chart (dan to external configuration or gross weight changes), it is necessary to observe the optimum cruising affittude on each chart; i.e., when changing charts a climb may be required to obtain a maximum range. All range values include allowances for descent distance and fool. Climb distance and fool where climbs are indicated. DATA BELOW CONTAIN NO PUEL RESERVE FOR LANDING | | | (1) | FUEL | POUNDS | | 3000 | 2000 | 1000 | | 1 | TIVE | Q | 120 MW 2 | SO MW 2 | 40 MW 25 | 0 | 40 TW 2 | 80 TV 2 | 120 TW 2 |
| 2 X 3 CARR NUMBE | nzimum. In ord reight changes may be required see and fuel ar | | | .000 | | BY CRUISING J | LEVEL ⁽¹⁾ | 410 | 245 | 95 | | .00 | | P. DOWN DIST. | | 3 4 | 5 4 | 00 4 | 15 4 | 30 4 | |
| F | Remges shown of optimum altitudes are maximum. (date to external configuration or goes weight chemit i.e., when changing chorts a climb may be refer descent distance and fact. Climb distance and fact. Climb distance and DATA BELOW CONTAIN MO | 62 | | IF YOU ARE AT 15000' | RANGE IN AIRMILES | OPT. ALT. BY 1000 FT AT | TO SEA 1 | 45 | 45 | 30 | | CRUISING AT 15000" | APPROXIMATE | G.S. R.P. | | 264 .73 | 281 .85 | 300 1.0 | 318 1.15 | 344 1.30 | |
| INSTRUCTION CHART ARD DAY US OR LESS | primem alti- configuration henging choi e and fuel. DATA BE | DATA AS OF: 1 OCTOBER 1953 | | YOU AR | RANGE IN | | INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA | | | | | CRUISIN | APP | RPH LAR | | 4100 264 | 3750 | 3400 | 3100 | 2950 | |
| NO | shown of o external of e., when el- | OCTO |)E | = | | BY CRUISING AT 15000" | MB & DE | 265 | 180 | 06 | | | -5 | C.A. | | 277 83 | 257 81 | 2 41 79 | 222 78 | 212 77 | |
| DAY OR LESS | Se Runges hart (dee to ch churt; i ces fer desc | AS OF: 1 | TUL | ,000 | | BY CRUISING AT OPT.ALT. | BED CLI | 385 | 220 | 80 | | .00 | | F. DOWN | | . 70 2 | 85 2 | 2 00 | 16 2 | 28 2 | |
| STANDARD DAY 5,800 POUNDS OR LESS | NOTES. one char en cach lewences | DATA | ALTIT | IF YOU ARE AT 10000' | RANGE IN AIRMILES | | RESCRI | 45 | 45 | 20 | | CRUISING AT 10000' | APPROXIMATE | G.S. R.F. | | 242 | 266 | 285 1.00 | 306 1.16 | 327 1.28 | - |
| NON | right or right or y climb. y below. cruising dosired mb dist- | | A | rou AR | RANGE IN | NG OPT. | FOR P | 4 | | | | RUISING | APP | LB m | | 4440 2 | 4030 2 | 3670 2 | 3370 | 3160 | |
| RATI STA 30, 800 | n feel avai mentacetally Hitude ar h ven directi appropriate nd climb to | | MO | IF) | | AT 10000' 1000 FT | WANCES | 235 | 155 | 80 | | ō | - | C.A.S | | 280 82 | 265 81 | 247 79 | 229 78 | 212 76 | |
| FLIGHT OPERATION IN STANDAR CHART WT. LIMITS 30, 800 POUNDS | an equel to at less than fuel available for ten flight, atc.). Allow hartzontally right or it by cruising at that altitude as by Limb- hing instructions ore given directly below, using instructions ore given directly below, using instructions in appropriate cruising fuel. for tokeoff and climb to desired FLIGHT above, adding sitial climb dissi- | | LC | | T | BY CRUISING AT OPT.ALT. | E ALLO | 365 | 200 | 02 | | | | DOWN DIST. | | 8 | 1 2 | 1 2 | 1 | N | |
| LIGH' | an equal to tion flight, d) by cruis; ting instruc- tuel for FLIGHT of | | | AT 5000' | RMILES | | INCLUE | | | | | VT 5000' | APPROXIMATE | R.F. | | | 1 . 85 | 1.00 | 5 1.17 | | |
| H H | in feel celus orrer, fermat ble (ne win tude, opera and reod er rd subtract t as fee IN | | | IF YOU ARE | RANGE IN AIRMILES | BY CRUISING OPT. ALT. AT 5000' 1000 FT | (RANGE FIGURES | 45 | 45 | 15 | 1 | CRUISING A | APPRO | LB G.S. | | | 4430 254 | 4030 273 | 3750 29 | 1 | |
| | det figure vigational maga availa fattiule el ti ed el titude vel on bos n use chor | | | IF YO | RA | Y CRUISING AT 5000' | ANGE F | 205 | 135 | 02 | | CRU | - | 8 4 | | | 80 | 78 | 77 | | |
| 57B | LIGHT - So combat, no read total n o flight of ly to desir om initial f mcos. The | | | (1) | FUEL | POUNDE | E | 00 | <u> </u> | 9 | | - | _ | C.A.S | HW. | AM. | HW 274 | 254 | 40 TW 237 | 1 | 2 |
| (S) B-E | (A) IN F1 trude and ege. For immediate ING - Fre ary allowe | | | | 3 | - | | 3000 | 2000 | 1000 | | 1 | TIVE | - | 120 HW | WM 09 | 40 HW | ۰ | 40 | VT 00 | 120 TW |
| MODEL J65-W- | G CHART: allowence to present elt maximum ran ude, climb HT PLANM | | | S.L. | ES | BY CRUISING AT OPT.ALT. | | 340 | 175 | 09 | | ند | | R.P. DOWN DIST. | | | .84 0 | 1.00 0 | 1.17 0 | | |
| AIRCRAFT MODEL (S) B-57B ENGINE(S) J65-W-5 | FOR USIN beard minus eccording to shiftede of higher altit (B) FLIG | .500,100 | | IF YOU ARE AT S.L. | RANGE IN AIRMILES | | | 45 | 45 | 15 | | CRUISING AT S.L. | APPROXIMATE | 6.5. | | | 243 | 4480 261 1. | 285 | | |
| EN AI | INSTRUCTIONS FOR USING CHART. (A) IM FLIGHT - School figure in final column equal to at less than final available for strutes (final on bood minus allowence for issuers, combat, navigational error, formation flight, atc.). Allow hartzenfoldy right or left to section according to present attitude and road total range available (no wind) by cruising at that altitude as by climating to another altitude and according instructions are given directly below. For a flight or faithed entired, operating instructions ore given directly below, for a flight or higher altitude, climb immediately to desired attitude and road ervising instructions in appropriate cruising altitude secries. (6) FLIGHT PLANNING · From initial feel on board subfront for 1 for tok-off and climb to desired cruising altitude and all other necessory allowences. Then use chart as for IN FLIGHT obove, adding sittind climb distinctions. | ances to range values. | | IF YOU | RANGE | 9 | | | | | | CRUISH | AP | RPM /HR | | | 80 4960 | 78 4480 | 76 4200 | | |
| | For alth | 9 | | | | BY CRUISH AT S.L. | - | 175 | 115 | 09 | | | ٠, | כיעיי | | R | 283 8 | 261 | 245 | | |

Figure A-45

| AIRCRAF | T MODEL | AIRCRAFT MODEL (S) B-57B | | | | | | 1 | I | AL | HIGH ALTITUDE | DE | | | | Т | EXT. L | OAD O GAL W | 2 X 320 GAL WING TIP TANKS | TANKS |
|--|------------------------|---|---|------------------------------------|---------------------------|------------|--|------------------------------|--------------------------|----------------------|---|--|-------------------------|--|--|----------------------------|-----------------------------|-------------------------------------|--|--|
| ENGINE (S): | 3): J65-W-5 | V-5 | | | CHART | WT. LIMITS | | 30,800 | PO | POUNDS OR LESS | R LESS | | | | | | NO. OF | ENGINE | S OPERAT | NO. OF ENGINES OPERATING: (TWO) |
| IF YO | IF YOU ARE AT 25000' | 25000' | | IF YOU | OU AR | RE AT | E AT 30000' | _ | IF YO | IF YOU ARE AT 35000' | T 35000' | _ | IF YOU | IF YOU ARE AT 40000' | r 40000' | | | IF Y | IF YOU ARE AT 45000 | T 45000' |
| RA | RANGE IN AIRMILES | IILES | FUEL | | RANGE IN AIRMILES | N AIRMIL | .ES | | RAP | RANGE IN AIRMILES | AILES | - | RAN | RANGE IN AIRMILES | MILES | I | FUEL | | RANGE IN AIRMILES | MILES |
| BY CRUISING OPT ALT. AT 25000' 1000 FT. | OPT ALT. | BY CRUISING AT OPT. ALT. | POUNDS | BY CRUISING OPT AT 30000' 1000 | NG OPT | ALT. | BY CRUISING AT OPT. ALT. | - | BY CRUISING AT 35000" | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | - | Y CRUISING AT 40000" | BY CRUISING OPT ALT. AT 40000' 1000 FT. | BY CRUISING AT OPT. ALT. | - | POUNDS | BY CRUISING AT 45000' | OPT ALT. | T. BY CRUISING |
| | | | | (RANGE | (RANGE FIGUR | SES IN | CLUDE A | LOWA | NCES F | OR PRE | ES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | LIMB & | DESCE | NT TO | SEA LEV | EL) | | | | |
| 345 | 45 | 450 | 3000 | 390 | | 45 | 410 | , | 445 | 45 | 485 | 490 | 0 | 45 | 200 | 0 | 3000 | 515 | 1 | |
| 230 | 45 | 285 | 2000 | 260 | 4 | 45 | 300 | | 300 | 45 | 320 | 330 | 0 | 45 | 335 | 10 | 2000 | 350 | 1 | 1 |
| 115 | 40 | 125 | 1000 | 135 | 4 | 40 | 140 | | 155 | 45 | 1 | 170 | 0 | 45 | ı | | 1600 | 180 | I | - |
| | | | | | | | | | | | | - | | | | | | | | |
| CRL | CRUISING AT 25000' | 25000' | | | CRUISING | | AT 30000' | | CRU | CRUISING AT 35000' | . 35000, | - | CRUI | CRUISING AT 40000' | 40000, | | | | CRUISING AT 45000" | T 45000' |
| | APPROXIMATE | ATE | TIVE | | APP | PROXIMATE | TE | | | APPROXIMATE | MATE | | | APPROXIMATE | KIMATE | | TIVE | | APPRO | APPROXIMATE |
| C.A.S. 75 II | LB,HR G.S. | R.F. DOWN | | C.A.S. % | L.Bun | 6.5. | R.F. DOWN DIST. | C.A.S. | % RPM | LIBAR G.S. | R.F. | LET C.A.S. DOWN DIST. | RPM | L.Bine G.S. | S. R. F. | LET DOWN DIST. | MIND | C.A.S. RPM | LBHR | G.S. R.F. DOWN DIST. |
| 271 85 3 | 3730 274 | . 65 | 120 HW | 257 85 | 3320 | 284 | 6 99. | 240 | 85 2 | 2920 293 | 3 .69 13 | 3 219 | 88 2 | 2700 303 | | 16 | 120 HW | 195 93 | 2570 306 | . 71 21 |
| 259 84 3 | 3470 297 | 7 27. | WH 08 | 247 84 | 3160 | 311 | .76 10 | 232 | 85 2 | 2820 320 | . 78 | 14 217 | 88 | 2650 339 | 9 .80 | 18 | 80 HW | 194 92 | 2540 | 342 .81 24 |
| 245 82 3 | 3250 318 | 8 98. | 40 HW | 237 83 | 2960 | 336 | . 88 11 | 226 | 84 2 | 2700 351 | 1 .88 15 | 5 215 | 87 | 2610 373 | 8.89 | 20 | 40 HW | 1 93 92 | 2200 | 378 .89 26 |
| 232 81 2 | 2990 339 | 1.00 9 | 0 | 226 82 | 2780 | 359 | 1.00 12 | 222 | 83 | 2620 383 | 3 1.00 17 | 7 214 | 87 | 2560 412 | 2 1.00 | 22 | 0 | 193 92 | 2500 | 418 1.00 29 |
| 217 80 2 | 2750 356 | 1, 13 10 | WT 05 | 217 81 | 2650 | 386 | 1.13 13 | 216 | 83 2 | 2540 414 | 4 1.12 19 | 9 211 | 98 | 2530 449 | 9 1.10 | 24 | 40 TW | 193 91 | 2470 | 458 1.10 32 |
| 207 80 2 | 2650 383 | 1.25 11 | WT 08 | 207 81 | 2550 | 409 | 1.27 14 | 209 | 83 | 2540 445 | 1.23 | 20 208 | 86 | 2500 485 | 5 1.19 | 26 | WT 00 | 191 90 | | 1, 17 |
| 201 79 2 | 2570 416 | 1. 42 11 | 120 TW | 201 80 | 2500 | 450 | 1.39 15 | 208 | 82 | 2400 481 | 481 1.35 21 | 1 208 | 86 | 2490 525 | 5 1.31 | 28 | 120 TW | 190 90 | 2470 534 | 4 1.29 37 |
| | | SPECIAL NOTES | NOTES. | | | | | | | EXAMPLE | ш | | | | | | LE | LEGEND | | |
| 1 Clim 2 Mult | b at 100 9 | Climb at 100 % RPM Multiple Nautical units by 1.15to obtain Statute | by 1.15t | to obtain | Statute | | you are a | t 20,0 | 00 ft. | with 2 | If you are at 20,000 ft. with 2000 lb. of available fuel, you can fly 205 nautical airmiles by holding | f availa y holdin | ble | F. F. | FECTIV Range | E WIN | D-HW, He | f ground | rW, Tailw | EFFECTIVE WIND-HW, Headwind, TW, Tailwind-Knots R.F Range factor - Ratio of ground distance to airmiles |
| units. 3 Read only. 4 Make errors, | lower addition combat, | units. Read lower half of chart opposite effective wind only. Make additional allowances for landing, navigational errors, combat, formation flight etc. as required. | rt opposit esforlandi flight etc. | e effecti ing, navi as requi | ve win gationa red. | | airmiles by immediately climbing to 100% RPM. At 45,000 ft. cruise at and start let down 29 nautical miles is and start let down 29 nautical miles is a few thought to during the man of the product of the cruise of the country of th | imme imme At t down | diately 15,000 29 na | r, you c | airmiles by immediately climbing to 45,000 ft. using 110% RPM. At 45,000 ft. cruise at 133 knots CAS and start let down 29 nautical miles from home. With | 45,000 ft. using to 1993 knots CAS from home. With 1994 knots CAS from from home. With 1995 ft. usual days | using CAS With | | for corresponding. SGround speed in CAS-Calibrated airsp. LB/HR-Fuel consump. RANGE-Nautical mile. | d speed a sel constitution | d in Knot irspeed in whites | inds ots in Knots - Pounds | for corresponding winds G.SGround speed in Knots CAS-Cailbrated airspeed in Knots LE /HR-Fuel consumption-Pounds per hour RANGE-Nautical miles | |
| | | | | | | | 1 x 265 S with th | or 21 | 5 nan | tical mi | .81 x 265 or 215 nautical miles. Cruise at 194 knots CAS with this wind and start let down 24 nautical miles | se at 10 | k kno | 53 | POLAT | ON P | POLATION PURPOSES ONLY | SONLY | IN I ER- | |
| BASED | - | TMATE | | | | | rom destination. | ation. | | | | | | | | | UEL GR | ADE: JI | FUEL GRADE: JP-4 | |
| DATA AS OF: | | 1 OCTOBER 1953 | 953 | | | | | | | | | | | | | | חבר חב | NO. I LICA | 7D/9T C | - |

Figure A-46

| 40 40 40 FRES 2899 2299 2299 2299 2299 2299 2299 229 | 40 40 40 FRES 2899 2299 2299 2299 2299 2299 2299 229 | 40 40 40 FRES 40 40 40 40 40 40 40 40 40 40 40 40 40 | NOTRUCTION CHART | AIRCRAFT MODEL (S) B-57B FLIGHT OPER S SENGINE(S) J65-W-5 CHART WT. LIMITS | INSTRUCTIONS FOR USING CHART: (A) IN FLIGHT - Solect figure in fuel column equal to ar less than fuel available for cruits (fuel on board minus allowance for reserve, combat, navigational error, fermation flight, arc.). Aleave herizantally right or left to saction according to present allitude and read total remains and that altitude or by climb. The site another charties are given directly below. For a flight is initial clinicity, specialism state states are stored directly below. For a flight or higher altitude, climb immediately to desired altitude and read existing instructions in oppopitate cruising altitude accertion. (B) FLIGHT PLANHING - From initial fuel on board subtract live! for toke off and climb to desired existing altitude and all other necessory allowances. Then use chart as for IN FLIGHT above, adding initial climb distinctions are some values. | 11005. | MOT | IF YOU ARE AT S.L. (1) IF YOU ARE AT 5000' | RANGE IN AIRMILES FUEL RANGE IN AIRMILES | BY CRUISING OPT. ALT. BY CRUISING POUNDS BY CRUISING OPT. ALT. BY CRUISING BY AT 514. 1000 FT AT OPT.ALT. AT | (RANGE FIGURES INCLUDE ALLOWA | 40 915 7000 465 40 940 | 40 750 6000 395 40 775 | 40 590 5000 325 40 610 3 | 40 435 4000 260 40 460 2 | 40 290 3000 195 40 315 2 | 40 170 2000 130 40 185 1 | 1000 65 10 5 | CRUISING AT S.L. | APPROXIMATE | TLBR G.S. R.P. DIST. WIND RPM TRPM G.S. R.F. DOWN U | 120 HW | 80 HW | 5200 250 .85 0 as hw 285 82 4740 266 .85 1 279 | 4720 268 1.00 0 0 264 80 4330 283 1.00 1 259 | 4490 295 1.16 0 40 TW 249 78 4100 307 1.16 1 243 | 80 TW | |
|--|--|--|--|--|---|---------------|-------|--|--|--|-------------------------------|------------------------|------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------|------------------|-------------|---|--------|---------|--|--|--|---------|---|
| STRUCTION CHART CARRIER | DAY | STRUCTION CHART 2 X 330 GALL WING TIP TAD IT A STANDARY CARRIED ENTIRE DISTANDARY CARRIED DISTANDARY CA | EXTERNAL LOAD ITEMS S20 CAL WING TIP TANKS RIED DENTING DISTANCE (TIP TANKS RIED DENTING DISTANCE (TIP TANKS AND TANKS RIED DENTING DISTANCE (TIP TANKS AND | OPERATION IN STANDARI | et available for decally right or directly balou. oprier cruising ilimb to desired irial climb to desired | | | IF YOU ARE A | RANGE IN AIR | AT 10000' 1000 FT | NCES FOR PRE | 530 40 | 455 40 | 370 40 | 295 40 | 225 40 | 145 40 | | CRUISING AT | APPROX | LB HR | | 83 4950 | 82 4410 | 80 4030 | 79 3750 | 78 3470 | |
| POUNDS | POUNDS | POUNDS | EXTERNAL LOAD ITEMS S20 CAL WING TIP TANKS RIED DENTING DISTANCE (TIP TANKS RIED DENTING DISTANCE (TIP TANKS AND TANKS RIED DENTING DISTANCE (TIP TANKS AND | STRUCTI D DAY | NOTES: Ranges one chart (due on each thert; i.e lowences for desc | DATA AS OF: 1 | TITUE | T 10000' | MILES | _ | SCRIBED CLI | 096 | 795 | 635 | 480 | 335 | 205 | 1 | 10000, | MATE | R.F. | | .71 | .86 | 1.00 | 1.15 | 1.32 | |
| ### GENT CARRIER #### GENT CARRIER ################################### | ### GARRIED ENTERNA ################################### | A R T | EXTERNAL LOAD ITEMS S20 CAL WING TIP TANKS RIED DENTING DISTANCE (TIP TANKS RIED DENTING DISTANCE (TIP TANKS AND TANKS RIED DENTING DISTANCE (TIP TANKS AND | ON CH | shown at optimu external config s., when changing ent distance and DA | OCTOB E |)E | IF YO | RA | BY CRUISING AT 15000' | MB & DESCE | 009 | 210 | 425 | 335 | 250 | 165 | 82 | CRI | -5 | C.A. | | 84 | 83 | 81 | 80 | 48 | _ |
| 2 X 320 CARRIE NUMBER NUMBER Eight chorace; it is not be required to ce and fact are in the NOT TUEL RE IN HO FUEL | 2 X 320 GAL WING CARRIED ENGIN NUMBER OF ENGIN NUMBER OF ENGIN NUMBER OF ENGIN Eight changes), it is necessary by be required to ebtein a maximum. In addr to bhain massin ce and froit are included where ce and froit are included where opy the required to ebtein a maximum. TOWN ET LEL CRUISING OPT.ALT. EVEL (1) 125 5000 100 110 125 120 1000 110 125 120 1000 110 125 120 120 120 120 120 120 120 120 120 120 | 2 X 320 GAL WING TIP TA CARRIED ENTRED LOAD IT TA CARRIED ENTRED DISTRANCE OF EACH WING TIP TA CARRIED ENTRED DISTRANCE OF EACH WIND Store of dred for clothele meatinum reage of the count for the co | EXTERNAL LOAD ITEMS S20 CAL WING TIP TANKS RIED DENTING DISTANCE (TIP TANKS RIED DENTING DISTANCE (TIP TANKS AND TANKS RIED DENTING DISTANCE (TIP TANKS AND | ART | m altitudes are ma reation or gross w ge charts a climb fuel. Climb distan 'A BELOW CONTA | 1953 | | U ARE AT 150 | NGE IN AIRMILES | 0PT. ALT. 1000 FT | NT TO SEA L | | | | | | | | IISING AT 150 | APPROXIMATE | 6.5 | | 283 | 299 | 316 | 335 | 361 | |
| | EXTERNAL WINDS OF ENGTH NOT EXPENSION OF ENGLY WINDS OF ENGINE OF ENGINE OF ESERVE FOR ESERVE FOR OF | CAL WING LOAD IT CALL COLD IT CALL WING CAL WING CALL | ### CAPPENS ### C | 2 X 320 CARRIE NUMBER | sight changes), i or be required to ce and fuel are in IN NO FUEL R | | | ,00 | | | EVEL (1) | | | | | | | | | | DOWN DIST. | | | | | | | |

Figure A-47

| F YOU ARE AT 25000' RANGE IN AIRMILES AT 25000' 1000 FT. AT OPT AT 25000' 40 100 40 545 40 68 430 40 55 40 | M-5 7 25000' AILES BY CRUISING AT OPT. ALT. 1025 695 695 695 255 | FUEL POUNDS 7000 6000 | (20) | CHART WT. | | 35 300 TO | 00000000000000000000000000000000000000 | | | | | NO. OF | NO. OF ENGINES OPERATING: (TWO) | OPERATI | MC. (TWO) |
|--|--|----------------------------|---------------------------|---------------|--|--|--|---|---|---------------------|---|--|---------------------------------|-------------------------|----------------------------|
| CRUISING OPT ALT. 25000' 1000 FT. 70 40 45 40 45 40 45 40 415 40 416 40 416 40 | | | 200 | | 1. LIMIIS 33, | | 30, 800 F | 30, 800 POUNDS | | | | THE RESERVE | | | 10:17 1101 |
| CRUISING OPT ALT. 25000' 1000 FT. 70 40 55 40 45 40 25 40 115 40 110 30 | | | 0.00 | ARE | AT 30000' | IF Y | IF YOU ARE AT 35000' | T 35000' | IF YO | IF YOU ARE AT 40000 | 40000, | | IF YOU | IF YOU ARE AT 45000 | 45000 |
| CRUISING OPT ALT. 23000' 1000 FT. 70 40 45 40 46 40 25 40 115 40 110 30 | | | (202) | RANGE IN AIRN | AIRMILES | R | RANGE IN AIRMILES | ILES | RA | RANGE IN AIRMILES | LES | FUEL | RA | RANGE IN AIRMILES | ILES |
| | 1025 860 895 545 395 255 | 0000 | | OPT ALT. | BY CRUISING AT OPT. ALT. | BY CRUISING AT 35000' | G OPT ALT. | BY CRUISING AT OPT. ALT. | BY CRUISING | OPT ALT. | BY CRUISING AT OPT. ALT. | POUNDS | BY CRUISING AT 45000' | OPT ALT. | BY CRUISING AT OPT. ALT |
| | 1025 860 695 395 255 | 0000 | (RANGE | FIGURES | (RANGE FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | OWANCES | FOR PRES | SCRIBED CL | IMB & DESC | ENT TO SE | A LEVEL) | | | | |
| | 860 695 395 255 | 0009 | 875 | 40 | 1040 | 975 | 40 | 1055 | 1065 | - | 1070 | 7000 | | | |
| | 545 395 255 | 2000 | 745 | 40 | 875 | 830 | 40 | 890 | 902 | 1 | | 0009 | | | |
| | 395 | 2000 | 615 | 40 | 710 | 680 | 40 | 725 | 740 | | | 2000 | | | |
| | 395 | 4000 | 485 | 40 | 565 | 540 | 40 | 575 | 290 | | 1 | 4000 | | | |
| | 255 | 3000 | 365 | 40 | 415 | 410 | 40 | 430 | 445 | 1 | | 3000 | | | |
| | - | 2000 | 245 | 40 | 275 | 275 | 40 | 285 | 295 | - | - | 2000 | | | |
| | | 1000 | 125 | 35 | 1 | 140 | 40 | | 155 | - | | 1000 | | | |
| CRUISING AT 25000" | 25000' | L | CRL | CRUISING AT | AT 30000' | CR | CRUISING AT 35000' | 35000' | CRI | CRUISING AT 40000' | 40000, | 1 | CRU | CRUISING AT 45000" | 45000* |
| APPROXIMATE | ATE | TIVE | | APPROXIMATE | MATE | | APPROXIMATE | MATE | | APPROXIMATE | MATE | TIVE | | APPROXIMATE | MATE |
| C.A.S. % LIBHR G.S. | R.F. DOWN DIST. | _ | C.A.S. % RPM | L.Я. с.s. | R.F. DOWN | C.A.S. % | Г. Вня с.s. | R.F. DOWN | C.A.S. % | LBHR G.S. | R.F. DOWN | | C.A.S. * | /HR G.S. | R.F. DOWN DIST. |
| 278 86 4000 284 | 7 99. | 120 HW | 262 86 | 3600 292 | 6 19. | 242 87 | 3170 298 | .70 13 | 220 90 | 3000 | . 70 16 | 120 HW | and a | | |
| 269 85 3750 311 | T TT. | 90 HW | 254 86 | 3430 321 | .77 10 | 237 86 | 8100 328 | . 79 14 | 219 89 | 2900 340 | . 80 18 | WH 08 | igiraz | | |
| 256 84 3560 334 | 8 88 1 | 40 HW | 247 85 | 3300 351 | . 89 11 | 233 86 | 3000 364 | . 90 15 | 219 89 | 2900 380 | . 91 20 | 40 HW | | | |
| 246 83 3360 359 | 1.00 9 | 0 | 240 84 | 3130 379 | 1.00 12 | 230 85 | 2920 396 | 1.00 17 | 219 89 | 2900 420 | 1.00 22 | 0 | | | |
| 232 82 3150 380 | 1, 13 10 | 40 TW | 232 84 | 3050 410 | 1, 12 13 | 228 85 | 2900 434 | 1.11 19 | 2 16 89 | 2850 456 | 1,10 24 | 40 TW | | | |
| 225 81 3020 409 | 1.25 11 | WT 08 | 224 83 | 2910 435 | 1.24 14 | 222 84 | 2850 465 | 1.22 20 | 214 89 | 2850 493 | 1.20 26 | 80 TW | | | |
| 219 81 2970 440 | 1.40 11 | 120 TW | 219 83 | 2870 473 | 1.37 15 | 219 84 | 2800 502 | 1.33 21 | 214 89 | 2850 533 | 1.30 28 | 120 TW | | | |
| | SPECIAL | SPECIAL NOTES | | | | | EXAMPLE | ш | | | | H | LEGEND | | |
| 2 Multiple Nautical units by 1.15 to obtain Statute units. 3 Read lower half of chart opposite effective wind | ERPM Lical units | by 1.15 t | o obtain s | | If you are at 10,000 ft. with 3000 lb. of available fuel, you can fly 225 nautical airmiles by holding 259 krots CAS. However, you can fly 335 nautical airmiles by immediately climbing to 40,000 ft. using | 10,000 f fly 225 NS. Hower mmediate | t. with 30 nautical a. ver, you c | u are at 10,000 ft. with 3000 lb. of available you can fly 225 nautical airmiles by holding krots CAS. However, you can fly 335 nautical illes by immediately climbing to 40,000 ft. usin | available holding nautical ft. using | | EFFECTIVE WIND-HW, Headwind, TW, Tailwind-Knots R.FRange factor-Ratio of ground distance to airmiles for corresponding winds G.SGround speed in Knots | ND-HW, He or-Ratio of | adwind, Tr | W, Tallwin stance to | id-Knots |
| 4 Make additional allowances for landing, navigational errors, combat, formation flight etc. as required. | al allowanc formation | es for land flight etc. | ing, naviga as require | | 100% RPM. At 40,000 ft. cruise at 219 knots CAS and start let down 22 nautical miles from home. With a 40 knot headwind, the range at 40,000 ft. would be 91 x 335 or 305 nautical miles. Cruise at 219 | At 40,00 down 22 adwind, the 305 na | oft. cru nautical n he range a utical mil | At 40,000 ft. cruise at 219 knots CAS down 22 nautical miles from home. Wit adwind, the range at 40,000 ft. would be 7305 nautical miles. Cruise at 219 | t 219 knots CAS from home. With 900 ft. would be Cruise at 219 | | CAS-Candrance arspect in Allows LANGE-Nautical miles () RANGE IN PARENTHESIS FOR INTER- POLATION PURPOSES ONLY | arrspeed nsumption- almiles ARENTHE PURPOSES | Pounds po | er hour | |
| BASED ON: ESTI | ESTIMATE | 60 | | 4 11 | knots CAS with this win miles from destination. | estination | nd and sta | rt let down | 20 nautical | al | | FUEL GRADE: | | JP-4 | |

Figure A-48

| AIRCRAFT MODEL (S) B-57B - ENGINE(S) J65-W-5 | INSTRUCTIONS FOR USHIC CHART. (A) IN FLIGHT - Schoot figure in fuel column equal to at less than feel available fee cruiss (fuel as based minus allowance for reserve, combot, mayigational error, formation flight, etc.). Aleave heritexically right or left to assistion according to present attitude and road total range available (no wind) by cruising at that altitude or by climbing to another altitude of maximum eneage. For a flight of initial editude, operating instructions are given directly below. For a flight or listing end road erusing instructions in opporpriet cruising attitude scenion. (b) PLIGHT PLANNING - Frem initial feel on local auchiect fuel for tok-off and climb to desired cruising altitude scenion. (d) PLIGHT PLANNING - Frem initial feel on local auchiect fuel for tok-off and climb to desired cruising altitude and all other necessory allowences. Then use chort or fer IN FLIGHT above, adding initial climb distri- | anecs to range values. | | IF YOU ARE AT S.L. | RANGE IN AIRMILES FUEL | BY CRUISING OPT. ALT. BY CRUISING POUNDS AT 3.L. 1000 FT AT OPT.ALT. | 680 40 1590 12,000 625 40 1420 11,000 | 565 40 1255 10,000 505 40 1105 9,000 445 40 955 8,000 | 395 40 810 7,000 335 40 665 6,000 285 40 540 5,000 | 225 40 415 4,000 170 40 280 3,000 115 40 145 2,000 | CRUISING AT S.L. | APPROXIMATE TIVE | RPM G.S. R.F. DOWN | 120 HW | 82 5470 256 .85 0 40 HW | 80 4980 276 1.00 0 0 | 79 4750 304 1.16 0 40 TW | WT 00 | 200 |
|--|---|----------------------------|------|----------------------|------------------------|---|---|---|--|--|--------------------|------------------|--------------------|-----------|-------------------------|----------------------|--------------------------|------------|----------|
| 8Z | GHT - Schoer figure ombot, novigetlonel ad total range avail (Hight of initial at to desired altitude i initial fuel on bo | | | (I) IF Y | | NDS BY CRUISING AT 5000' | (RANGE FIGURES 00 775 40 00 710 40 | 00 640 00 575 00 510 | 00 445 00 380 00 320 | 00 255 00 190 00 125 | | -5 | C.A. | | 293 82 | 274 81 | , 260 80 | | |
| FLIGHT CHART WT. | in fool column equal lerrer, formation III able (no wind) by at fitude, operating is and read eraising i and subtract fuel eri as for IM FLIGH | | | IF YOU ARE AT 5000' | RANGE IN AIRMILES | OPT. ALT. 1000 FT | FIGURES INC | 04 04 | 9 9 9 | 0 4 4 | CRUISING AT 5000' | APPROXIMATE | LB G.S. R | | 5050 276 | 4680 294 1. | 4400 318 1. | | |
| and and | asi to or less th ght, etc.).Move cruising at that structions are g instructions in for take-off iT ebow, addit | | 7 | .000 | 13 | BY CRUISING AT OPT.ALT. | 1610 1445 | 1280 1125 975 | 830 690 565 | 435 300 165 | .00 | | R.F. DOWN | | 1 98 1 | 1 00. | 1.16 1 | | |
| QE. | untions equal to or loss than fool evailable for untion flight, stc.). Move her resentally right or trad) by crutising at that altitude or by climb- varing instructions in operopriere crutising erusing instructions in operopriere crutising critical for take-off and climb to desired the FLIGHT observe, adding initial climb dist- | | MO | IF YOU | RAN | BY CRUISING AT 10000' | S INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB 1610 885 40 1635 1445 805 40 1470 | 730 655 580 | 505 430 360 | 290 215 145 | CRUI | 7 | C.A.S | 0 0 | 82 | 270 82 43 | 255 80 41 | 240 79 38 | |
| | | .vo | ALT | J ARE AT 10000' | RANGE IN AIRMILES | OPT. ALT. 1000 FT | OR PRESCR | 40 40 40 | 04 04 | 40 40 40 | CRUISING AT 10000' | APPROXIMATE | LB G.S. | 5400 991 | | 4380 312 1 | 4150 335 1 | 3840 355 1 | - |
| 20 | TES: Ranges s chart (daw to each chart; i.a. ances for descen | TA AS OF: 1 (| ITUD | .0000 | ES | BY CRUISING AT OPT.ALT. | 1635 1635 1470 | 1305 1150 1000 | 855 715 585 | 455 320 190 | ,000 | | R.F. DOWN DIST. | 90 | | 1.00 2 | 1.15 2 | 1.30 2 | |
| JCTION CHART AY 35, 300 POUNDS | MOTES: Ranges shown at optimum altitudes are maximum. In order to obtain maximum range on flights requiring more than one chart (due to external configuration or gross veright changes), it is necessary to observe the aprimum cruising altitude on each chart i.e., when changing charts a climb may be required to obtain a maximum range. Alt range values include atlawances for descent distance and fool. Climb distance and fool are included where climbs are indicated. DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | DATA AS OF: 1 OCTOBER 1953 | DE | IF YOU | RAN | BY CRUISING AT 15000' | B & DESCENT 1005 915 | 825 745 655 | 575 485 410 | 325 250 165 | CRU | .2 | RP R | 30E 9E 46 | 84 | 267 83 4 | 251 81 38 | 2 40 80 3 | 5 |
| TRT | a altitudes are ration ar gross 9 chorts a clim vol. Climb dis A BELOW CON | 1953 | | IF YOU ARE AT 15000' | RANGE IN AIRMILES | OPT. ALT. 1000 FT | NT TO SEA 40 40 | 04 04 | 40 40 40 40 | 40 40 40 | CRUISING AT 15000' | APPROXIMATE | L.B. G.S. | 4000 301 | | 4140 332 1 | 3870 353 1 | 3650 378 1 | |
| 2 X 3 CARI | inturn altitudos aro maximum. In ardor to obtain maximum range fit generiten er gross veright changes), it is necessory te eleserv. nging charts a climb may be required te obtain a maximum remge end fuel. Climb distence and fuel are included where climbs are DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | | | 2000 | ES | BY CRUISING AT OPT.ALT. | LEVEL(1) 1655 1490 | 1325 1170 1020 | 875 735 605 | 475 345 210 | 2000, | | R.F. DOWN DIST. | 76 | | 1.00 4 | 1.14 4 | 1.29 4 | |
| EXTERNAL 2 X 320 GAL WING CARRIED ENTIRE NUMBER OF ENGINE | der to obtain m s), it is necess of to obtain a re re included wh | | | (i) | FUEL | POUNDS | 12,000 | 10,000 9,000 8,000 | 7,000 6,000 5,000 | 4,000 3,000 2,000 | 1 | TIVE | AINO | 120 MW | 80 HW 40 MW | | 40 TW | WT 08 | - |
| | In arder to obtain maximum range on flights requiring more then empos), it is necessory to observe the optimum crussing altitude squired to obtain a maximum range. Altitunge values include altural are included where climbs we indicated. FUEL RESERVE FOR LANDING | BASED ON: | | IF YOU | RAN | BY CRUISING AT 20000' | 1135 1035 | 935 835 740 | 645 550 460 | 370 280 190 | CRU | | .A.2 % P % P | 308 86 | 85 | 264 84 | 247 82 3 | 242 82 | 231 89 |
| LOAD ITEMS TIP TANKS DISTANCE S OPERATING:(T | n flights requi he optimum er All range vali ndicated. | BASED ON: ESTIMATE | | IF YOU ARE AT 20000' | RANGE IN AIRMILES | OPT. ALT. 1000 FT | 40 | 40 | 40 40 40 | 40 40 40 | CRUISING AT 20000' | APPROXIMATE | LB/HR G.S. | 4860 291 | | 3910 353 | 3670 374 | 3500 404 | 3400 430 |
| (OM | ing more than dising allitude res include al- | LE | | 20000 | ES | BY CRUISING AT OPT.ALT. | 1675 | 1345 1190 1040 | 895 755 625 | 495 365 235 | ,00002 | | R.F. DOWN DIST. | 3 99. | | 1.00 6 | 1,13 6 | 1.27 7 | 1 40 7 |

Figure A-49

| AIRCRAF | T MODEL | AIRCRAFT MODEL (S) B-57B | | | | | 三 | HIGH | | ALTITUDE | DE | | | | | EXT. LOAD 2 X 320 G | EXT. LOAD 2 X 320 GAL WING TIP TANKS CABBIED ENTIRE DISTANCE | ING TIP | TANKS | |
|---|---|-----------------------------|--|---|-------------------------------------|---|---|---|--|---|--|---|--------|---|--|---|---|--|-------------------------------|----------------------|
| ENGINE (5): | S): J65-W-5 | W-5 | | Ū | CHART WT. | WT. LIMITS | 39,8 | 00 TO 3 | 39, 800 TO 35, 300 POUNDS | UNDS | | | | | au fil | NO. OF | ENGINES | OPERA | LING: (TV | (0) |
| IF YO | IF YOU ARE AT 25000' | T 25000' | | IF YOU | AR | E AT 30000' | - | IF Y(| IF YOU ARE AT 35000' | 1 35000' | | IF YO | U ARE | IF YOU ARE AT 40000' | ,000 | | IF YO | IF YOU ARE A | AT 45000' | |
| R | RANGE IN AIRMILES | MILES | FUEL | a | RANGE IN AIL | AIRMILES | 1 | RA | RANGE IN AIRMILES | ILES | - | R | NGE IN | RANGE IN AIRMILES | | FUEL | RA | RANGE IN AIRMILES | RMILES | APRIL DE |
| BY CRUISING AT 25000" | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | POUNDS | BY CRUISING AT 30000' | G OPT ALT. 1000 FT. | T. BY CRUISING | | BY CRUISING AT 35000' | OPT ALT. | BY CRUISING AT OPT. ALT. | | BY CRUISING AT 40000" | 0 | - | BY CRUISING AT OPT. ALT. | POUNDS | BY CRUISING AT 45000' | 3 OPT ALT. 1000 FT. | T. BY CRUISING | ISING |
| | | | | (RANGE | FIGUR | INCLUDE | ALLO | WANCES | ES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | CRIBED C | CLIMB (| DESC | ENT | O SEA | LEVEL) | | | | | |
| 1285 | 40 | 1700 | 12,000 | 1455 | 40 | 1715 | 20 | 1605 | 40 | 1730 | | 1740 | | | 1745 | 12,000 11,000 | | | | |
| 1060 940 830 | 333 | 1365 1210 1060 | 10,000 8,000 | 1190 1060 935 | 04 04 | 1385 1230 1080 | 900 | 1305 1160 1025 | 444 | 1400 1245 1095 | | 1415 1255 1110 | | 111 | | 10,000 9,000 8,000 | | | | |
| 730 620 515 | 9 9 9 | 915 775 645 | 7,000 6,000 5,000 | 815 695 475 | 04 04 04 | 935 795 665 | 20.00 | 890 760 635 | 40 04 04 04 | 950 805 675 | | 960 820 685 | | 111 | | 7,000 6,000 5,000 | | | | |
| 415 315 215 | 3 4 4 | 515 385 255 | 4,000 3,000 2,000 | 465 350 235 | 04 04 | 535 400 270 | 1000 | 510 385 265 | 94 4 | 545 415 285 | | 555 425 295 | 111 | 111 | | 4,000 3,000 2,000 | | | | |
| CR | CRUISING AT | r 25000' | | | CRUISING A | AT 30000' | | 25 | CRUISING AT 35000' | 35000, | - | S | UISING | CRUISING AT 40000' | ,000 | 0000 | CR | UISING A | CRUISING AT 45000' | |
| | APPROXIMATE | IATE | TIVE | | APPRO | APPROXIMATE | | | APPROXIMATE | LATE | | | APP | APPROXIMATE | re | TIVE | | APPR | APPROXIMATE | |
| C.A.S. % | LBHR G.S. | R.F. DOWN | | C.A.S. % | LAM | G.S. R.F. | LET C DOWN DIST. | C.A.S. % | LIPHR G.S. | R.F. | LET C.A.S. DOWN DIST. | S. RPE | LBHR | 6.5 | R.F. DOWN DIST. | MIND | C.A.S. % | LBHR | G.S. R.F. | LET DOWN DIST. |
| 284 87 | 4250 293 | 3 .67 7 | 120 HW | 265 87 | 3850 2 | 298 .68 | 9 | 245 88 | 3450 302 | 69. | 13 221 | 11 92 | 3230 | 305 | .70 16 | 120 HW | | | | |
| 277 86 | 4050 325 | 5 .78 7 | 90 HW | 259 87 | 3710 3 | 330 .79 | 10 2 | 241 88 | 3390 335 | . 79 | 14 2 | 221 92 | 3230 | 345 | .80 18 | 80 HW | | | | |
| 267 85 | 3900 348 | 8 88 8 | 40 HW | 255 86 | 3600 | 364 .89 | 11 2 | 240 87 | 3330 374 | . 89 | 15 22 | 221 92 | 3230 | 385 | . 90 20 | 40 HW | | | | |
| 259 85 | 3690 376 | 1.00 9 | | 250 86 | 3470 38 | 394 1.00 | 12 2 | 236 87 | 3250 407 | 1.00 | 17 221 | 11 92 | 3230 | 425 | 1.00 22 | 0 | | | | |
| 246 83 | 3540 401 | 1 1,12 10 | 40 TW | 246 85 | 3410 | 428 1.11 | 13 | 236 87 | 3250 447 | 11.11 | 19 219 | 9 92 | 3190 | 460 | 1.10 24 | 40 TW | | | | |
| 240 83 | 3400 430 | 0 1.24 11 | WT 08 | 238 85 | 3300 | 456 1.22 | 14 | 232 87 | 3200 481 | 1.21 | 20 2 16 | 16 92 | 3150 | 498 | 1.19 26 | 80 TW | | | H | |
| 231 83 | 3350 461 | 1 1.37 11 | 120 TW | 231 85 | 3250 4 | 491 1.34 | 15 | 230 87 | 3150 518 | 1.31 | 21 211 | 1 92 | 3140 | 538 | 1.29 28 | 120 TW | | | - | |
| 1 Climb at 2 Multiple units. 3 Read love only. 4 Make add errors, con | tiple Nau tiple Nau d lower e addition , combat | Ila for | SPECIAL NOTES PM Lunits by 1.15 of chart opposit llowances for land mation flight etc. ATE OBER 1953 | to obtain te effectiv ting, navig | statute e wind atlonal ed. | EXAM If you are at 5000 ft, with 1 fuel, you can fly 710 nautica knots CAS. However, you can by immediately climbing to 4 At 40,000 ft. cruise at 221 weight allows, continue climb altitudes until 45,000 ft. is cruise at 193 knots CAS and miles from home. With an 8 at optimum altitude would be nautical miles. Cruise at 19 down 24 nautical miles from | e at 5 Can f S. H diately 00 ft. lows, until 193 m alti miles. nautic | ou are at 5000 ff. w you can fly 710 na is CAS. However, you can fly 710 na fis CAS. However, you can fly 710 na 40,000 ff. cruise at ght allows, continue on the sum of t | | XAMPLE th 11,000 lb, of ava utical miles by holdin ucan fly 1445 nauti to 40,000 it, at 100 221 knots CAS. Wh limbs to and cruises . is attained. At 45, and start let down 2 an 80 knot headwind at be . 81 x 1445 or tt 194 knots CAS and rom destination. | of avail solding nautics t 100% when tises a t 45,6 t 45,6 whind, 5 or S and 4 | available lding 274 autical miles autical miles 100% RPM. When reduced ses at higher 45,000 ft. n 29 nautical ring, the range or 1170 and start let | | EFFEC C.SF CAS-C CAS-C CANGE CANGE POIN | CTIVE WI Lange fact for correst allbrated Ruel co Ruel co Ruel co Ruel co Ruel co Ruel co Ruel co Ruel co | LEGEND EFFECTIVE WIND-HW, Headwind, TW, Tallwind-Knots R.FRangefactor-Ratio of ground distance to airmiles for corresponding winds G.SGround speed in Knots CAS-Calibrated airspeed in Knots LIB/HR-Fuel consumption-Pounds per hour RANGE-Munical miles () RANGE IN PARENTHESIS FOR INTER- POLATION PURPOSES ONLY FUEL GRADE: JP-4 FUEL GRADE: JP-4 | LEGEND TRatho of ground distance to a sonding winds and ground distance to a sonding winds ed in Knots atraspeed in Knots males per hour miles TOR INTER-URPOSES ONLY FUEL GRADE: JP-4 FUEL GRADE: JP-4 FUEL DENSITY: 6.5 LB/GAL | W, Taily istance istance hour per hour in TER- | vind- <u>Kno</u> to airmil | es s |

Figure A-50

| | INSTRUCTIONS FOR USING CHART: (A) IN PLIGHT. Select figure in fact certise (fact enbead manus allowance terroservo, combas, navigational error, far left to sertien exceeding to present elitivde wad read total range available, (as virgi se emerher elitivade of maximum range. For a flight at initial elitivade and read elitinde scribes. (as the elight at initial elititude and read elitinde scribes. (B) PLIGHT PLANNING. From initial fuel on board subtractivity processory allowances. Then use chart as far accession name values. | | | IF YOU ARE | | POUNDS BY CRUISING OPT. | 16,000 1015 40 15,000 945 40 | 14,000 880 13,000 815 12,000 750 | 11,000 690 10,000 625 9,000 565 | 8,000 500 7,000 445 6,000 380 | CRUISING | | C.A. | 120 HW | 300 83 | 82 | 81 | WT 08 | |
|---|--|--------------------|---------|----------------------|-------------------|--|--|--|---------------------------------------|-------------------------------------|--------------------|-------------|-------------------------|--------|----------------------------|----------|----------|---------------|-------------|
| FLIGHT OPE | olown equal motion High wind) by cru erating instr erating in erating in 100°C fuel | | 1 | J ARE AT 5000' | RANGE IN AIRMILES | OPT. ALT. BY CRUISING 1000 FT AT OPT.ALT. | GURES INCLUDE ALL 40 2070 40 1905 | 40 1745 40 1595 40 1445 | 40 1305 40 1175 40 1055 | 40 940 40 820 40 685 | SING AT 5000" | PROXIMATE | LB G.S. R.F. DOWN DIST. | | 5400 289 86 1 | 303 1.00 | 330 1.15 | | |
| STAND/ | alones equal to or less than fuel available for moriton flight, esc.). Move betriannelly right or ringly by cruising at that altitude or by climb- trating instructions are given ilrecity below. eruising instructions in operaption evuising critical for take-off and climb to desired IN FLIGHT above, adding initial climb dist | | MO | IF YOU AR | RANGE IN | BY CRUISING AT 10000' | S INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA 2070 1150 40 2095 1305 40 1905 1075 40 1930 1215 40 | 995 40 925 40 855 40 | 780 40 705 40 635 40 | 570 40 500 40 430 40 | CRUISING | - | C.A. | | 322 85 5850 | 83 4750 | 82 4500 | 252 81 4300 3 | |
| INSTRUCT RD DAY | NOTES: Ranges one than (due i an each chart; i | DATA AS OF: | ALTITUI | IF YOU ARE AT 10000' | RANGE IN AIRMILES | OPT. ALT. BY CRUISING 1000 FT AT OPT.ALT. | RESCRIBED CLI 2095 1930 | 0 1770 1620 0 1465 | 1325 1195 1080 | 965 845 710 | CRUISING AT 10000' | APPROXIMATE | G.S. R.F. DOWN DIST. | | 305 87 2 | 1 00 | 1.14 | 369 1.28 2 | |
| INSTRUCTION CHART ARD DAY TO 39,800 POUNDS | NOTES: Ronges shown at optimum altitudes are maximum. In order to obtain maximum range on flights requiring more than one chart (due to external configuration or gross weight changes), it is necessory to observe the optimum croising altitude on each chart i.e., when changing charts a climb may be required to obtain a maximum range. All range values include allowences for descent distance and fuel. Climb distance and fuel are included where climbs are indicated. DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | 1 OCTOBER 1953 | DE | IF YOU AR | RANGE IN | BY CRUISING AT 15000' | MB & DESCENT 7 | 1130 4 1045 4 960 4 | 880 40 795 40 715 40 | 645 40 565 40 485 40 | CRUISING | | C.A. RPM L.B. | | 315 86 5275 | 84 4530 | 83 4230 | | |
| | inwan altitudes are meximum. In erder to obtain meximum range figureation are gross weight changes), it is necessory to observe, aging chorts a climb may be required to obtain a meximum range and fivet. Climb distance and fivel are included where climbs are DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | 89 | | IF YOU ARE AT 15000' | RANGE IN AIRMILES | OPT. ALT. BY CRUISING 1000 FT AT OPT.ALT. | TO SEA LEVEL ⁽¹⁾ 40 2115 40 1950 | 40 1790 40 1640 40 1485 | 1345 1215 1100 | 985 | CRUISING AT 15000' | APPROXIMATE | G.S. R.F. DOWN DIST. | | 311 .77 4 | 00. | 1.14 | 1.27 | |
| 820 GAL WRIED ENT | refer to obtain an 53), it is nacess ed to obtain a m are included wh EL RESERVE FI | | | (1) | FUEL | POUNDS | 16,000 15,000 | 14, 000 13, 000 12, 000 | 11,000 10,000 9,000 | 8,000 7,000 6,000 | | EFFEC. | QNIM | 120 HW | мн | 40 MW | | | |
| EXTERNAL LOAD ITEMS 2 X 320 GAL WING TIP TANKS CARRIED ENTIRE DISTANCE NUMBER OF ENGINES OPERATING | nimum renge on my te ebserve, the minum renge. A rec climbs are ind | BASED ON: E | | IF YOU | RANG | BY CRUISING O | 1475 | 1275 1175 1075 | 985 895 805 | 725 635 550 | CRUIS | | RPM LB/HR | 87 | 302 87 4750 288 86 4530 | 3 4 | 84 | 83 | 244 83 3770 |
| EXTERNAL LOAD ITEMS 2 X 320 GAL WING TIP TANKS CARRIED ENTIRE DISTANCE NUMBER OF ENGINES OPERATING: (TWO) | In order to obtain maximum range on flights requiring more thon onges), it is necessory to observe the optimum cruising altitude apprined to obtain a maximum range. All range values include altust are included where climbs are indicated. FUEL RESERVE FOR LANDING | BASED ON: ESTIMATE | | IF YOU ARE AT 20000' | RANGE IN AIRMILES | OPT. ALT. BY CRUISING 1000 FT AT OPT.ALT. | 40 2135 40 1975 | 40 1810 40 1660 40 1505 | 40 1365 40 1235 40 1120 | 40 1005 40 885 40 750 | CRUISING AT 20000' | APPROXIMATE | HR G.S. R.F. | 299 | 50 323 ,79 | 000 | _ | 421 | 0 448 1.37 |

Figure A-51

| ENGINE (S): | | | | | | | | | 5 | FIGH ALITIONE | | 2 | 2 | 1 1 | 6 | | | CAF | 2 X 320 GAL WING TIP TANKS CARRIED ENTIRE DISTANCE | NTIR | G TIP | TANK | 100 |
|---------------------------------|----------------------|-----------------------------|--|--------------------------|---|-------------|--|--------------------------|----------------------|---|------------------------------------|-----------------------------|--------------------------|---|--------------|----------------------|-----------------------------|--|---|--------------------------|-------------------|----------------------|-----------------------------|
| | J65-W-5 | V-5 | | | CHART W | T. LIMITS | | 44,300 | 10 | 39,80 | 39, 800 POUNDS | NDS | | | | | | NO. | NO. OF ENGINES OPERATING: (TWO) | INES C | PERA | LING: (3 | (OM. |
| IF YOU ARE AT 25000' | IRE AT | 25000 | | IF YOU | AR | E AT 30000" | ,0000 | - | 보 | IF YOU ARE AT 35000' | AT 3 | 2000 | - | IF Y | OU AR | IF YOU ARE AT 40000' | ,0000 | | | F YOU | ARE A | IF YOU ARE AT 45000' | ,, |
| RANGE | RANGE IN AIRMILES | .ES | FUEL | | RANGE IN A | AIRMILES | 2 | - | ~ | RANGE IN AIRMILES | AIRMILE | 5 | - | 2 | ANGE IN | RANGE IN AIRMILES | ES | FUEL | | RAN | RANGE IN AIRMILES | RMILES | |
| BY CRUISING OF | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | POUNDS | BY CRUISING AT 30000' | 100 | ALT. B | BY CRUISING AT OPT. ALT. | | AT 35000" | BY CRUISING OPT ALT. AT 35000' 1000,FT. | | BY CRUISING AT OPT. ALT. | | BY CRUISING AT 40000' | | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | NG POUNDS | | BY CRUISING AT 45000" | OPT ALT. | | BY CRUISING AT OPT. ALT. |
| | | | | (RANGE | FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | SINC | LUDE A | LLOWA | NCES | FOR P | RESCR | IBED (| CLIMB | & DES | CENT | TO SE | 1 LEVE | 7 | | | | | |
| 1650 | 40 | 2155 | 16,000 | 1865 | 40 | | 2170 | N P | 2055 1905 | 9 4 | | 2025 | | 2195 | 1 1 | | 2040 | 16,000 | 00 | | | | |
| 1435 1315 1205 | 04 04 04 | 1830 1680 1525 | 14,000 13,000 12,000 | 1605 1475 1355 | 40 40 | | 1845 1695 1545 | | 1750 1615 1475 | 40 40 40 | | 1860 1710 1560 | | 1875 1720 1575 | 1 1 1 | | 1880 | 14,000 13,000 12,000 | 000 | | | | |
| 1100 1005 900 | 94 94 | 1385 1255 1140 | 11,000 10,000 9,000 | 1235 1120 1010 | 04 94 | | 1405 1275 1155 | | 1350 1220 1105 | 04 | | 1425 1290 1170 | | 1440 1305 1185 | 111 | | | 11,000 10,000 9,000 | 000 | | | | TR |
| 810 710 620 | 40 40 40 | 1020 900 770 | 8,000 7,000 6,000 | 905 800 695 | 40 40 | | 1035 915 790 | | 990 875 765 | 40 40 40 | | 1050 930 805 | | 1065 940 820 | 111 | 111 | | 8,000 7,000 6,000 | 866 | | | | |
| CRUISING | 1 | 25000' | | 0 | CRUISING | AT 30000' | .000 | - | 5 | CRUISING AT 35000' | AT 35 | .000 | - | 5 | NISIN | CRUISING AT 40000' | ,0000 | 1 | | CRU | ISING / | CRUISING AT 45000' | |
| A | XIM | TE | - EFFEC- | - | APPR | ROXIMATE | ш | - | _ | APPR | APPROXIMATE | ш | - | - | A | APPROXIMATE | ATE | TYEC | ر | | APPR | APPROXIMATE | |
| C.A.S. % LB/HR | HR G.S. | R.F. DOWN | | C.A.S. % | н | 6.5 | R.F. DOWN DIST. | T. C.A.S. | 2 M M | LAHR | 6.5 | R.F. D | LET C./ DOWN DIST. | C.A.S. % | LB/HR | 6.5. | R.F. | LET WINE | C.A.S. | R M | /HR | G.S. R.F. | , DOWN DIST. |
| 290 88 45 | 4530 301 | 7 69. | 120 HW | 269 89 | 9 4110 | 304 | . 70 | 247 | 06 4 | 3700 | 304 | .71 | 13 2 | 220 94 | 3560 | 306 | .71 | 16 120 HW | | | | _ | |
| 284 87 43 | 4380 333 | 7 87. | WH OR | 264 89 | 9 4000 | 337 | .80 10 | 244 | 4 90 | 3700 | 341 | . 80 | 14 .2 | 220 94 | 3560 | 346 | .81 | 18 90 HW | | | T | + | _ |
| 277 87 42 | 4220 362 | 8 68. | 40 HW | 262 89 | 9 3970 | 374 | .89 | 244 | 4 90 | 3700 | 381 | . 89 | 15 2 | 220 94 | 3560 | 386 | . 89 | 20 40 HW | | | | | + |
| 268 86 4030 | 30 389 | 1.00 9 | 0 | 258 88 | 8 3820 | 407 | 1.00 12 | 2 243 | 3 89 | 3620 | 417 1 | 1.00 | 17 2 | 220 94 | 3560 | 426 | 1.00 | 22 0 | | | | | - |
| 259 85 3880 | 80 418 | 1.12 10 | 40 TW | 255 87 | 7 3750 | 441 | 1.11 | 13 243 | 3 89 | 3620 | 457 1 | 1.10 | 19 2 | 220 94 | 3 560 | 0 466 | 1.10 | 24 40 TW | - | 8 | | | |
| 252 85 37 | 3780 448 | 1.22 11 | WT 08 | 248 87 | 7 3670 | 473 | 1.21 14 | 4 240 | 0 88 | 3570 | 492 | 1.20 | 20 2 | 217 94 | 3520 | 201 | 1.18 | 26 80 TW | _ | | | - | _ |
| 244 85 3700 | 00 479 | 1.34 11 | 120 TW | 243 87 | 3600 | 909 | 1.31 15 | 5 236 | 6 88 | 3520 | 528 | 1.29 | 21 2 | 217 94 | 3520 | 541 | 1.28 | 28 120 TW | - | | 1 | - | 4 |
| | | SPECIAL | SPECIAL NOTES | | | | | | | EXAMPLE | IPLE | | | | | | | | LEGEND | 0 | | | |
| 2 Multipl units. 3 Read 1 | at 100% le Naut | RPM ical units alf of cha | 1 Climb at 100% RPM 2 Multiple Nautical units by 1.15 to obtain Statute units. units. 3 Read lower half of chart opposite effective wind | to obtain | a Statute | If y fue | If you are at 25,000 ft. with 12,000 lb. of available fuel, you can fly 1205 nautical airmites by holding 268 knots CAS. However, you can fly 1525 nautical airmites by immediately climbing to 40,000 ft. using | at 2f can fly CAS. | 120 How | NOO ft. with 12,000 lb. of availab 1205 nautical airmites by holding dowever, you can fly 1525 nautic diately climbing to 40,000 ft. usi | h 12, ical ai you ca | rmiles n fly to 40 | b. of a by hc 1525 | b. of available s by holding 1525 nautical 0,000 ft. using | le ul | R.F. | Range for cor Ground | EFFECTIVE WIND-HW, Headwind, TW, Tallwind-Knots R.FRange factor-Ratio of ground distance to airmiles for corresponding winds G.SGrund speed in Knots G.SCollynoid airmond in Knots | , Headwi | and dis | V, Tail | rind-K | lles |
| only. 4 Makea errors, c | dditions ombat, | d allowand formation | only. 4 Make additional allowances for landing, navigational errors, combat, formation flight etc. as required. | as requ | gational ired. | and and | 8 8 8 5 | art let down knot tailwi | 40, vind t | 10,000 ft. cruise at 220 knots C 22 nautical miles from home. at the range at 40,000 ft. would 1900 mutteal miles. Cruise at 1900 mutteal miles. | cruis cal mi ge at ical m | les fro | om hor of ft. v | ome, With would be ise at 217 | With lbe 217 | RANC () RA | R-Fue FE- Nau INGE D | LECHRETOR TO THE POUNT OF THE P | HESIS F | OR II | er hou | 6 | |
| BASED ON: ESTIMATE | F. EST | TOBER 1 | 953 | | | mi | miles from destination. | n dest | inatio | p. | | | | | | | | FUEL | FUEL GRADE: JP-4 FUEL DENSITY: 6.5 LB/GAL | JP- | .4 LB/G | AL | |

Figure A-52

| NOTES! Ranges shown of optimum altitudes are maximum. In acide 1 one catch chart i.e., when changes shown of optimum altitudes are maximum. In acide 1 one catch chart i.e., when changes shown of patrial cacinavatical shorts of catch charges. State of descent distincts and four are it acide are it are catch chart i.e., when changes shown of bart a clind may be required its one catch chart i.e., when changes shown of bart as catch charges. State are it acide are it accent chart i.e., when changes it accent distincts and for larving because the descent distincts and for larving are activated to accent chart. In accent chart. At 18000 The AT 10000' IF YOU ARE AT 15000' IF YOU ARE AT 15000' IF AT 0PT.ALT. AT 18000 TT AT 0PT.ALT. AT 0PT.ALT. AT 0PT.ALT. AT 0PT.ALT. AT 18000 TT AT 0PT.ALT. AT | AIRCRAFT MODEL (S) B-57B FLIGHT OPERATION STAND. ENGINE(S) 365-W-5 CHART WT. LIMITS 48, 800 | HSTRUCTIONS FOR USHIG CHART: (A) IN FLIGHT - Scloet figure in fool column equal to or less than fuel available for cruize (fuel an based minus allowence for roserve, combut, navigational error formation flight, atc.), flow braitistic solutions are strongly right or left to sestion according present allitude and fool from a consider allitude of maximum range. For a flight at initial allitude, speciating instructions are given directly below. For a flight of higher allitude, climb immediately to desired allitude and read eruising instructions in appropriate cruising allitude and all other necessary allowences. Then use chart as above, fool take-off and climb to desired cruising allitude and all other necessary allowences. Then use chart of for IN FLIGHT above, adding initial climb distruction and all other necessary allowences. | and the state of t | MON | IF YOU ARE AT S.L. (1) IF YOU ARE AT 5000' IF YO | RANGE IN AIRMILES FUEL RANGE IN AIRMILES RAI | BY CRUISING OPT. ALT. BY CRUISING POUNDS BY CRUISING OPT. ALT. BY CRUISING BY CRUISING AT 5.4. 1000 FT AT OPT.ALT. AT 10000 FT AT OPT.ALT. | (RANGE FIGURES INCLUDE ALLOWANCES F | 1060 35 2330 19,318 1200 35 2355 1355 | 2135 18,000 1110 35 2155 | 35 1985 17,000 35 1835 16,000 | 15,000 925 35 1715 1 14,000 865 35 1610 | 35 1490 13,000 810 | 665 35 1385 12,000 755 35 1410 850 610 35 1265 11,000 690 35 1290 780 | CRUISING AT 5000' | APPROXIMATE | RPM C.S. R.F. DOWN C RPM | 120 HW | 331 87 7 | 307 82 6050 267 .85 0 40 HW 307 84 5660 290 .87 1 307 85 | 288 82 5530 288 1.00 0 0 291 83 5320 313 1.00 1 292 84 6 | 279 81 5320 319 1.15 0 40 TW 280 82 5060 341 1.14 1 278 83 | so TV 263 82 4 | |
|--|--|---|--|--------|--|--|--|-------------------------------------|---------------------------------------|--------------------------|----------------------------------|--|--------------------|---|-------------------|-------------|--------------------------|---------|----------|--|--|--|----------------|----------|
| CCTOBER 1953 | - | 150000000 | DATA AS OF: | ALTITU | J ARE AT 10000' | GE IN AIRMILES | 0PT. ALT. 1000 FT | OR PRESCRIBED CL | | | | | + | | ISING AT 10000' | | G.S. R.F. | | 301 .72 | 314 .88 | 336 1.00 | 362 1.12 | 384 1.22 | |
| CARRIED ENTIRE DISTANCE CARRIED ENTIRE DISTANCE NUMBER OF ENGINES OPERATING NUMBER OF ENGINES OF ENGINES NUMBER OF ENGINES | ION CHAR | s shown at optimum alt) Lee, when changing the scent distance and feel. DATA BE | 1 OCTOBER 195 | DE | IF YOU AF | RANGE | BY CRUISING AT 15000' | IMB & DESCENT | | | - | | + | | CRUISIN | -5 | A.D. | | 322 87 | 3 05 86 | 291 85 | 277 84 | 266 84 | |
| EXTERNAL LOAD ITEMS RESIDENCY ALLOAD ITEMS ER OF ENGINES OPERATING der to obtain moximum roage on flights s. der to obtain moximum roage on flights s. der to obtain a moximum roage on flights s. der to obtain a moximum roage on flights s. in is necessory to observe the optimal der obtain a moximum roage. All roage of the obtain a moximum roage on flights s. (1) it is necessory to observe the optimal roage of flights s. (1) it is necessory to observe the optimal roage. (1) it is necessory to observe the optimal roage. (2) it is necessory to observe the optimal roage. (3) it is necessory to observe the optimal roage. (4) it is necessory to observe the optimal roage. (5) it is necessory to observe the optimal roage. (6) it is necessory to observe the optimal roage. (7) 000 1305 35 14, 000 1225 35 14, 000 1225 35 15, 000 1495 35 15, 000 1495 35 16, 000 1695 35 1145 35 114, 000 1695 35 114, 000 1695 35 1225 35 114, 000 1696 35 1226 35 114, 000 1696 35 1227 35 120 hw 323 88 5480 35 40 hw 297 87 4890 3 40 TW 274 86 4430 4 125 4150 4 126 4150 4 | | ludes ore maximum. In or or gross weight change arts a climb may be require Climb distance and fuel a LOW CONTAIN NO FUE | 33 | | RE AT 15000' | N AIRMILES | | | | | | | + | | IG AT 15000' | | G.S. R.F. | | 319 .78 | 338 . 88 | 360 1.00 | 3 84 1, 13 | 411 1.24 | |
| LANDING IES OPERATING EDISTANKS EDISTANKS EDISTANKS EDISTANKS ESTATING Is a basero, the aprimum reage on flights s. Is a basero, the aprimum reage on flights s. Is a basero, the aprimum reage on flights s. Is a basero, the aprimum reage on flights s. Is a basero, the aprimum reage of | EXTERNAL 20 GAL WIN RIED ENTIR ER OF ENGIN | der to obtain maxin s), it is necessory d to obtain a maxii are included where L RESERVE FOR | | | (u) | FUEL | | | 19, 318 | 18,000 | 17, 000 | 15,000 | 700, 000 | 12, 000 11, 000 | 0 | TIVE | MIND | | | | | | | 120 TW 2 |
| | G TIP TANKS G TIP TANKS E DISTANCE ES OPERATIN | uum range on flights te abserve the aptim num rango. All rang climbs are indicated climbs are indicated LANDING | BASED ON: ESTU | | IF YOU ARE | RANGE IN A | | | | | | | + | | CRUISING | 2 | RPM L.PHR | 88 5480 | 88 5110 | 87 4890 | 87 4640 | 86 4430 | 85 4310 | 85 |

| CHART WT. LIMITS 49, 800 TO 44, 300 POUNDS F YOU ARE AT 30000 F YO | AIRCRA | AIRCRAFT MODEL (S) | - (S) B-57B | 8 | | | | | I | 5 | | LI | | HIGH ALTITUDE | 100 | | | | EXT. | EXT. LOAD 2 X 320 GAL WING TIP TANKS | WING | TIP T. | ANKS |
|--|-------------------------|--------------------|---------------------|----------------------------|-----------|----------------|---------|------------|--------------|---|----------|---------|-----------------|-----------------|----------------------|--------|--------------|----------|-----------|--|----------------------|----------------------|-----------------------------|
| F YOU ARE AT 35000 | ENGINE | | .W-5 | | | CHAR | | | 18, 800 | | 44, 3 | 00 PO | UNDS | | | | | | NO. | CARRIED ENTIRE DISTANCE NO. OF ENGINES OPERATING: (TWO) | ES OP | ERATIN | NCE VG: (TW |
| Part | IF Y | OU ARE A | T 25000' | | 1 | | ARE A | T 30000' | | Ŧ | YOU AR | E AT 3 | 2000, | - | IF YO | U ARE | AT 40 | ,000 | | = | IF YOU ARE AT 45000' | RE AT | 45000 |
| 19 19 19 19 19 19 19 19 | - | ANGE IN AIR | MILES | FUEL | | RANG | | ILES | + | | RANGE IN | AIRMILE | 23 | - | RA | NGE IN | AIRMILES | | FUEL | | RANGE | RANGE IN AIRMILES | ILES |
| Secondary Seco | BY CRUISIN AT 25000" | G OPT ALT | | | | | PT ALT. | | | Y CRUISI | NG OP T | | T OPT. | | CRUISING T 40000" | 10001 | _ | OPT. ALT | | AT 45000" | | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. |
| 25 2450 19,318 2155 35 2250 2155 2265 2150 2155 2250 2155 2150 2155 2150 2150 2150 2155 2150 215 | | | | | (RANG | E FIG | URES II | NCLUDE | ALLO | VANCE | SFOR | PRESCI | SIBED (| CLIMB | & DESC | ENT | O SEA | LEVEL) | | | | | |
| 1955 1950 19,000 1990 35 2250 2155 2165 2155 2165 2155 | 1920 | 35 | 2430 | 19,318 | 218 | 22 | 35 | 245 | 0 | 2345 | i | ; | 2460 | | | | | | 19,318 | | | | |
| 1985 2477 1900 1745 35 1985 2085 2015 1965 2015 1965 2015 | 1785 | 35 | 2230 | 18,000 | 198 | 0 | 35 | 225 | 0 | 2155 | i | 1 | 2265 | - | | | | | 18,000 | | | | |
| 1965 15,000 1530 35 1700 1660 1825 1710 1660 1615 1710 1650 1615 1710 1650 1615 1710 1650 1710 | 1565 | 35 | 1935 | 16,000 | 174 | 2 2 | 35 | 195 | 0.10 | 1890 | ii | 11 | 1965 | | | | | | 16,000 | | | | |
| 156 1566 1500 1330 35 1500 1430 35 1500 1450 1450 1450 1450 1400 1230 35 1500 1450 1450 1400 1230 35 1500 1450 1400 1230 1500 1400 1230 1500 14 | 1455 | 35 | 1795 | 15,000 | 163 | 00 | 30.00 | 181 | 10.0 | 1765 | 1 | | 1825 | + | | | | | 15,000 | | | | |
| CRUISING AT 25000' EFFEC CRUISING AT 30000' 1350 1350 1350 | 1275 | 35 | 1585 | 13,000 | 143 | 0 | 3 22 | 160 | 210 | 1560 | i | 1 | 1615 | | | | 1182 | | 13,000 | | XII: | | |
| CRUISING AT 25000' CRUISING AT 30000' CRUISING AT 35000' CAS. | 1190 | 35 | 1485 | 12,000 | 133 | 0 | 35 | 150 | 10 | 1450 | • | | 1515 | _ | | | | | 12,000 | | | | |
| CRUISING AT 25000' EFFEC. APPROXIMATE | 1100 | 35 | 1375 | 11,000 | 123 | 0 | 35 | 139 | 6 | 1350 | i | ! | 1405 | | | | | | 11,000 | | | | |
| ## Land Case | CR | | 7 25000' | 1 | | RUISI | | 30000. | - | ō | RUISING | 3 AT 35 | ,000 | - | CRI | JISING | AT 400 | ,00 | | A THE C | CRUISING AT 45000' | NG AT | 45000' |
| 86 4550 340 . 30 . 70 7 120 HW 259 89 4300 344 . 8C 10 247 91 4060 345 . 8C 1. Dist. RPM 4550 340 . 30 . 70 7 120 HW 259 89 4300 344 . 8C 10 247 91 4060 345 . 8O 14 88 4550 373 . 9O 8 40 HW 269 89 4240 379 . 8G 11 246 91 4010 383 . 9O 15 88 4500 422 1.11 10 40 TW 256 89 4140 415 1.00 12 245 91 3950 420 1.00 17 86 4260 422 1.11 10 40 TW 257 88 4000 485 1.21 14 242 90 3840 497 1.19 20 86 4000 485 1.21 14 242 90 3840 497 1.19 20 88 4100 450 1.10 13 243 91 3850 535 1.31 21 80 Malke additional allowances for landing, navigational allows, confine climbs to and cruises at higher altitudes until 40,000 ft. is attained. At 40,000 ft. is attained at 100 ft | | APPROXIM | IATE | TIVE | | 4 | PPROXIL | ATE | | | APP | ROXIMAT | | | | APP | ROXIMAT | w | TIVE | | 4 | APPROXIMATE | MATE |
| 88 4550 309 .70 7 120 kW 273 90 4400 309 .70 9 250 91 4100 309 .71 13 88 4550 340 .80 7 80 kW 269 89 4300 344 .80 10 247 91 4060 345 .80 14 88 4530 373 .90 8 40 kW 266 89 4240 379 .80 11 246 91 4010 383 .90 15 86 4260 432 1.11 10 40 TW 260 88 4100 450 1.10 12 245 91 3980 420 1.00 17 86 4260 432 1.11 10 40 TW 257 88 4000 485 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 10 TW 257 88 4000 485 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.32 11 10 TW 257 88 4000 485 1.21 14 242 90 3940 497 1.19 20 86 4160 495 1.32 11 10 TW 252 88 3940 518 1.31 15 241 90 3880 535 1.31 21 87 AMPLE Climb at 100 % RPM Multiple Maurical units by 1.15 to obtain Statute fuel, you can fly 1025 nautical miles by holding 291 knots CAS. Flowever, you can fly 1550 nautical miles by immediately climbing to 35,000 ft. at 100% RPM. Read lower half of chart opposite effective wind by immediately climbing to 35,000 ft. at 100% RPM. At 35,000 ft. is attained. At 40,000 ft. satulated laminances for landing, navigational weight allows, continue climbs to and cruises at higher attainting the range at other proposition light etc. as required. EXAMPLE Cruise at 320 knots CAS and start let down 22 nautical miles from home. With an 40 knot taily with reading at other proposition light etc. as required. | | LBHR | я. | | C.A.S. | | | R.F. | | Total Control of the | L.BHR | | | DWN ST. | | /HR | _ | | | C.A.S. | RPM /H | /HR G.S. | R.F. DOWN |
| 88 4530 373 . 90 8 40 1 1 266 89 4240 379 . 88 11 246 91 4010 383 . 90 15 88 4570 401 1.00 9 0 265 89 4140 415 1.00 12 245 91 3980 420 1.00 17 86 4260 432 1.11 10 40 TW 260 88 4100 450 1.10 13 243 91 3950 420 1.00 17 86 4160 462 1.21 11 80 TW 257 88 4000 485 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 80 TW 257 88 3940 518 1.31 15 241 90 3880 535 1.31 21 SPECIAL NOTES Climb at 100% RPM Multiple Nautical units by 1.15 to obtain Statute file, you can fly 1025 nautical miles by holding 291 Kead lower half of chart opposite effective wind by immediately climbing to 35,000 ft. at 100% RPM. Make additional allowances for landing, navigational weight allows, continue climbs to and cruises at higher crors, combat, formation flight etc. as required. The corresponding to the range at 320 knots CAS and start let down 22 nautical miles from home. With an 40 knot tailwind, the range at optimal allowance for landing and relief from 32 nautical miles from home. With an 40 knot tailwind, the range at optimal allowance for landing and cruise at 1500 or 1706. | | | 07. | | - | | _ | 01. | | _ | | | 7.1 | 13 | | | | | 120 HW | | | | |
| 86 4260 432 1.11 10 40 TW 266 89 4240 379 .89 11 246 91 4010 383 .90 15 86 4260 432 1.11 10 40 TW 260 88 4100 450 1.10 13 245 91 3950 420 1.00 17 86 4260 432 1.11 10 40 TW 257 88 4000 485 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.31 11 10 10 TW 257 88 4000 485 1.21 14 242 90 3940 497 1.19 20 86 4160 495 1.32 11 10 TW 255 88 3940 518 1.31 15 241 90 3880 535 1.31 21 86 4080 495 1.32 11 10 TW 252 88 3940 518 1.31 15 241 90 3880 535 1.31 21 87 EXAMPLE EXAMPLE EXAMPLE EXAMPLE Ityou are at 15,000 ft. with 13,000 lb. of available field, you can fly 1025 nautical miles by holding 291 knots CAS. However, you can fly 1550 nautical miles by holding 291 knots CAS. However, you can fly 1550 nautical miles by holding 291 knots CAS. However, you can fly 1650 nautical miles by holding 291 knots CAS. However, you can fly 1650 nautical miles from additional allowances for landing, navigational weight allows, continue climbs to and cruises at higher are stitudes until 40,000 ft. is attained. At 40,000 ft. cruise at 320 knots CAS and start let down 22 nautical miles from home. With an 40 knot tailwind, the range at optimum altitude would be 110 x 150 or 1705. | | | . 80 | 80 MW | | _ | _ | . 80 | _ | | | | | 14 | - Ing | | | | MH 08 | | | | |
| 86 4260 432 1.11 10 40 TW 260 88 4140 415 1.00 12 245 91 3980 420 1.00 17 86 4160 462 1.21 11 80 TW 255 88 4000 485 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 80 TW 255 88 9940 518 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 TW 255 88 3940 518 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 TW 255 88 3940 518 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 TW 255 88 4000 485 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 TW 255 88 3940 518 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 TW 255 88 4000 485 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 TW 255 88 3940 518 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 TW 255 88 3940 518 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 TW 255 88 3940 518 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 TW 255 88 3940 518 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 TW 255 88 3940 518 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 TW 255 88 3940 518 1.21 14 242 90 3940 497 1.19 20 86 4160 462 1.21 11 10 TW TW 255 88 1.10 19 86 4160 462 1.21 11 10 TW TW 255 88 1.10 19 86 4160 462 1.21 11 10 TW TW 255 88 1.10 19 86 4160 462 1.21 11 10 TW TW 255 88 1.10 19 86 4160 462 1.21 11 10 TW TW 255 88 1.10 19 86 4160 462 1.21 11 10 TW | | | 06. | | 400 | | | | _ | | - | | | 12 | | | | | AH 07 | | | | |
| 86 4260 432 1.11 10 40 TW 250 88 4100 450 1.16 13 243 91 3950 458 1.10 19 86 4160 462 1.21 11 80 TW 257 88 4000 485 1.21 14 242 90 3940 497 1.19 20 86 4160 495 1.32 11 120 TW 252 88 3940 518 1.31 15 241 90 3880 535 1.31 21 EXAMPLE EXAMPLE EXAMPLE EXAMPLE It you are at 15,000 ft. with 13,000 lb. of available knottle. You can fly 1025 mattical miles by holding 291 knots CAS. However, you can fly 1550 mattical miles by 1.15 to obtain Statute wind by immediately climbing to 35,000 ft. at 100% RPM. At 35,000 ft. cruise at 245 knots CAS. When reduced weight allows, continue climbs to and cruises at higher altitudes until 40,000 ft. is attained. At 40,000 ft. cruise at 320 knots CAS and start let down 22 mattical miles from home. With an 40 knot tailwind, the range at optimum altitude would be 110 x 150 or 1705. | | | 1.00 | | - | - | | | | | | | | 17 | | | | | 0 | | | - | |
| 86 4160 462 1.21 11 so TW 257 88 4000 485 1.21 14 242 90 3940 497 1.19 20 86 4080 495 1.32 11 120 TW 252 88 3940 518 1.31 15 241 90 3880 535 1.31 21 SPECIAL NOTES Climb at 100 RPM Multiple Nautical units by 1.15 to obtain Statute fuel, you can fly 1025 nautical miles by holding 291 knots CAS. However, you can fly 1550 nautical miles by holding 291 knots CAS. However, you can fly 1550 nautical miles by holding 291 knots CAS. However, you can fly 1550 nautical miles by immediately climbing to 35,000 ft. at 100% RPM. At 35,000 ft. cruise at 245 knots CAS. When reduced weight allows, continue climbs to and cruises at higher attitudes until 40,000 ft. is attained. At 40,000 ft. cruise at 320 knots CAS and start let down 22 nautical miles by navigational allowances for infinite from home. With an 40 knot tailwind, the range at optimum altitude would be 110 x 1550 or 1705. | | | 1.11 | | | - | | | _ | | | 458 | | 13 | | | | | 40 TW | | | | |
| SPECIAL NOTES Climb at 100 % RPM Multiple Nautical units by 1.15 to obtain Statute Multiple Nautical Company, formation flight etc. as required. SPECIAL NOTES EXAMPLE EXAMPLE EXAMPLE EXAMPLE EXAMPLE If you are at 15,000 ft. with 13,000 lb. of available fuel, you can fly 1025 nautical miles by holding 291 knotic CAS. However, you can fly 1550 nautical miles by holding 291 knotic CAS. However, you can fly 1550 nautical miles by holding 291 knotic CAS. However, you can fly 1550 nautical miles by mediately climbing to 35,000 ft. at 100% RPM. At 35,000 ft. cruise at 245 knots CAS. When reduced weight allows, continue climbs to and cruises at higher altitudes until 40,000 ft. is attained. At 40,000 ft. cruise at 320 knots CAS and start let down 22 nautical miles from home. With an 40 knot tailwind, the range at optimum altitude would be 110 x 150 or 1705. | 1111111111 | | 1.21 | | | | | | | | | 497 | | 20 | | | | | WT 00 | | ļ., | ļ. | |
| If you are at 15,000 ft. with 13,000 lb. of available fuel, you can fly 1025 nautical miles by holding 291 knots CAS. However, you can fly 1550 nautical miles by immediately climbing to 35,000 ft. at 100% RPM. At 35,000 ft. cruise at 245 knots CAS. When reduced weight allows, continue climbs to and cruises at higher altitudes until 40,000 ft. is attained. At 40,000 ft. cruise at 326 knots CAS and start let down 22 nautical miles from home. With an 40 knot tailwind, the range at optimum altitude would be 110 x 1550 or 1705. | 100 | | 1.32 | | 200 | _ | Charles | 1.31 | | _ | | | | 21 | | | | | 120 TW | | | | |
| If you are at 15,000 ft. with 13,000 lb. of available fuel, you can fly 1025 nautical miles by holding 291 knots CAS. However, you can fly 1550 nautical miles by notinue immediately climbing to 35,000 ft. at 100% RPM. At 35,000 ft. cruise at 245 knots CAS. When reduced weight allows, continue climbs to and cruises at higher altitudes until 40,000 ft. is attained. At 40,000 ft. cruise at 320 knots CAS and start let down 22 nautical miles from home. With an 40 knot tailwind, the range at optimum altitude would be 1.10 x 1550 or 1705. | | | SPECIAL | NOTES | | | | | | | EXA | MPLE | | | | | | | | LEGEND | | | |
| knots CAS. However, you can fly 1550 nautical miles opposite effective wind by immediately climbing to 35,000 ft. at 100% RPM. At 35,000 ft. cruise at 245 knots CAS. When reduced weight allows, continue climbs to and cruises at higher altitudes until 40,000 ft. is attained. At 40,000 ft. cruise at 320 knots CAS and start let down 22 nautical miles from home. With an 40 knot tailwind, the range at optimum altitude would be 110 x 1550 or 1705. | | ub at 100 | RPM ical units | by 1.15 | to obtain | Statu | | f you are | can fl | 5,000 | ft, will | th 13, | dl 000 | of a | railable | | FR. | TIVEW | IND-HW, | Headwind | TW, T | 'allwin | d- Kno |
| for landing, navigational At 35,000 ft. cruise at 245 knots CAS. When reduced weight allows, continue climbs to and cruises at higher altitudes until 40,000 ft. is attained. At 40,000 ft. cruise at 320 knots CAS and start let down 22 nautical miles from home. With an 40 knot tailwind, the range at optimum altitude would be 1.10 x 1550 or 1705. | 3 Rea | d lower | half of cha | rt opposit | e effect | we w | | nots CA | S. Ho | wever | you c | 35.00 | 1550 0 ft. a | nautic t 100 | al mile | | 5.5 | r corre | sponding | winds | | | |
| cruise at 320 knots CAS and start let down 22 nautical miles from home. With an 40 knot tailwind, the range at optimum altitude would be 1.10 × 1550 or 1705 | 4 Mal | e addition | al allowanc | es for land flight etc. | ing, nav | gatto ired. | | reight all | ows, | cruise | at 24 | ibs to | and cri | whe | n reduction the | ъ | B/HR ANGE | Fuel co | d airspee | d in Kno | S per | nour | |
| | | | | | | | 0 1 | ruise at | 320 m hon | knots | CAS an | d star | t let do | wn 2 | 2 nauti | _ | POL | ATION | PURPOS | ES ONLY | K IN I | - 22 | |
| BASED ON: ESTIMATE nautical miles. Cruise at 220 kinds and start let FUEL GRADE: DATA AS OF: 1 OCTOBER 1953 | BASED | ON: ES | TIMATE CTOBER 19 | 53 | | | ल दे रे | t optimu | niles. | Cruis | se at | 220 km | ots CA | 550 or S and | 1705 start le | t. | | | FUEL G | RADE: | JP-4 | JP-4 6 5 LB/GAL | |

Figure A-54

| AIRCRAFT MODEL ENGINE(S) J65-W | INSTRUCTIONS FOR USING CHART: (A) IN FLIGHT - Scient figure in foot column equal to at less than foot available for states (fuel as beard minus allowance for instance, combat, mavigational error, formation flight, etc.). Aleas betterated by cities ing to anather altitude and road total range available (as wind) by critising at that altitude on by climsing to anather altitude and available and road total range available (as wind) by critising at their altitude as another management. For a flight at initial attitude, generalizing instructions no given directly below. For a flight of higher elitude, clims immediately to desired elithode and road exciting instructions in appropriate cruising altitude section. (B) FLIGHT PLANNING of From initial fuel on load subhoot 1 for toke off and climb to desired cruising altitude and all other necessory allowances. Then use chort of fer ILGHT above, adding initial climb distinctions. | onecs to range values. | | | IF YOU ARE AT S.L. | RANGE IN AIRMILES | BY CRUISING OPT. ALT. BY ON AT S.L. 1000 FT AT C | | (1035) 35 () | 975 35 | 925 35 | 870 35 | 820 35 | CRUISING AT S.L. | APPROXIMATE | RPM G.S. R.F. | | | 83 6240 271 .85 | 82 5740 293 1.00 | 82 5540 324 1.14 | | |
|---|---|----------------------------|-------------|------------|----------------------|-------------------|--|---|--------------|--------|------------|--------|--------|--------------------|-------------|-----------------------|----------|----------|-----------------|------------------|------------------|----------|----------|
| MODEL J65-W-5 | CHART: (lowance for research alith winnum rang e, climb in T PLANNIM r necessor | | | | i. | | BY CRUISING AT OPT.ALT. | * | (2125) | 2000 | 1895 | 1795 | 1695 | | | F. DOWN DIST. | | | 0 98 | 0 00 | 14 0 | | |
| B-57B | A) IN FLIGHT reserve, combe use and read to re. For a fligh modestely to NG · Frem init y allowences. | | | | (1) | FUEL | POUNDS | | 19,318 | 18,000 | 17,000 | 16,000 | 15,000 | 0 | TIVE | | 120 HW | WH OS | WH 00 | 0 | 40 TW | WT 08 | |
| | - Solect figuration att, novigation state range avon to et initial a fezired attitud feel on by Then use ch | | IF YOU ARE | (00) | | (RANGE | (1175) | 1095 | 1045 | 988 | 925 | D | - | C.A.5 | | | 313 85 | 297 83 | 286 83 | | | | |
| L 45 | c in feet celus of error, format libble (ne wind fritude, operat to and read express oard subtract war as fer IN | | | NG OPT. AL | (RANGE FIGURES | 32 | 35 | 35 | 35 | 32 | CRUISING A | APPRO | LB G. | | | 5880 296 | 5520 319 | 5260 347 | | | | | |
| FLIGHT OPERATION INSTRUCTION CHART STANDARD DAY SHART WT. LIMITS 53,000 TO 48,800 POUNDS | man equal to or less than fuel available for iton flight, etc.). Mayor bestromelly right ea al) by cruising at that altitude or by climb- riting instructions are given directly below, tryising instructions in oppopiote cruising to let for tokeroff and climb to desired fuel Tenbero, edding initial climb dist- | | | | AT 5000' | RMILES | T. BY CRUISING | INCLUDE A | (2150) | 2020 | 1915 | 1815 | 1715 | AT 5000' | APPROXIMATE | S. R.F. DOWN DIST. | | | . 87 | 1.00 1 | 7 1.14 1 | | |
| PERA STITS | to or less than fuel evoitable for sing or that altitude or by climb- sizing or that altitude or by climb- actions are given directly below, actions in apprepiate evuising for take off and climb to desired above, adding initial climb dist- | | | MO. | | _ | - | LLOWAN | 1 | (1) | - | 1 | 1 | _ | - | - ₹ + | | 334 | 312 | 298 | 286 | 269 | |
| TION FANDA | eveilable intelly right or by clist rectly belo right cruisismus to desir all climb displays | | | > | IF YOU | RANG | BY CRUISING AT 10000' | CES FO | (1325) | (1240) | 1175 | 1115 | 1045 | CRUIS | | RPM LB | | 87 6420 | 86 5630 | 84 5310 | 84 5130 | 83 495 | |
| STANDARD 53,000 TO | | - | 9 | ALTI | IF YOU ARE AT 10000' | RANGE IN AIRMILES | OPT. ALT. 1000 FT | R PRESC | 35 | 35 | 35 | 35 | 35 | CRUISING AT 10000' | APPROXIMATE | HR G.S. | | 304 | 0 320 | 343 | 370 | 4950 391 | |
| D DAY | NOTES: Rangone chart (due se cach chart) | DATA AS OF: 1 OCTOBER 1953 | AIA AS OF: | 110 | 100001 | LES | BY CRUISING AT OPT.ALT. | RIBED C | (2175) | (2040) | 1940 | 1840 | 1740 | ,0000 | | R.F. DOWN | | .74 2 | . 88 2 | 1.00 2 | 1.12 2 | 1.22 2 | |
| NOI | to extern | 1 OCT | 3 | DE | | - | | LIMB & | 5 | - | | | | _ | _ | C'V'3 | | 326 | 308 | 296 | 283 | 273 | |
| N CH | ot optimum el configur e changing tance and f | OBER | Mago | | IF YOU | RAN | BY CRUISING AT 15000" | DESCE | (1485) | (1390) | 1320 | 1250 | 1175 | CRUI | | RPM LI | | 88 5780 | 87 54 | 86 5100 | 85 48 | 84 46 | |
| RT | attitudes or ation or gro charts a eli vel. Climb d | 953 | 000 | | IF YOU ARE AT 15000' | RANGE IN AIRMILES | OPT. ALT. 1000 FT | IT TO SE | 35 | 35 | 35 | 35 | 35 | CRUISING AT 15000' | APPROXIMATE | L.B. G.S. | | 30 324 | 5430 344 | 367 | 4840 392 1 | 4680 419 | |
| 2 X CAF NUME | NOTES: Ranges shown of optimum altitudes are maximum. In order to obtain maximum range on flights requiring more than one chart does to actume configuration or gross weight charges), it is necessary to observe the optimum reusising altitude on each chart; i.e., when changing chars a climb may be required to obtain a maximum range. All angue values include all lawcences for descent distance and fuel. Climb distance and fuel are included where climbs are indicated. DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | | | | 15000, | LES | BY CRUISING AT OPT.ALT. | INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL(1) | (2200) | (3060) | 1960 | 1860 | 1760 | 15000, | TE | R.F. DOWN DIST. | | .78 4 | . 88 4 | 1.00 4 | 12 4 | 1.24 4 | |
| EXTER 320 GAL V RIED ENT | rder 10 obtain m 15), i) is naces; ed to obtain a r are included wh | | | | (E) | FUEL | POUNDS | | 19,318 | 18,000 | 17,000 | 16,000 | 15,000 | 0000 | TIVE | | 120 HW | 80 HW | 40 HW | 0 | 40 TW | WT 08 | WT 061 |
| EXTERNAL LOAD ITEMS 2 X 320 GAL WING TIP TANKS CARRIED ENTIRE DISTANCE NUMBER OF ENGINES OPERATING: (TWO) | oximum renge on ory to observe the animum renge. ere climbs ere i ere LANDING | Tuo casta | BASED ON | | IF YOU | RAN | BY CRUISING OPT. ALT. AT 20000' 1000 FT | | (1655) | (1550) | 1470 | 1390 | 1310 | CRU | -1 | RP R | 88 | 313 88 5 | 304 87 5 | 290 87 4 | 279 86 4 | 271 85 4 | 263 85 4 |
| TEMS CANKS LNCE RATING: (| flights requ he eptimum c All range vo ndicated. | BASED ON ESTIMA TE | T WATT T CO | | IF YOU ARE AT 20000" | RANGE IN AIRMILES | OPT. ALT. | | 32 | 35 | 35 | 35 | 35 | CRUISING AT 20000' | APPROXIMATE | L.B. 6.5. | | 5260 338 | 5070 365 | 4830 338 | 1600 414 | 4480 443 | 4330 473 |
| rwo) | ring more than uising attitude ues include al- | Œ | a | | 20000 | LES | BY CRUISING AT OPT.ALT. | | (2220) | (2085) | 1980 | 1880 | 1780 | 200002 | ATE | R.F. DOWN DIST. | . 70 5 | . 80 5 | 9 06. | 1.00 6 | 1, 12 6 | 1.23 7 | 1.36 7 |

| | | | | | | | | | _ | 5 | П | | | 2 X 320 CARRI | 2 X 320 GAL WING TIP TANKS CARRIED ENTIRE DISTANCE | IE DIST | TANKS | |
|-----------------------------------|--------------------------|-----------------------------|---|--------------------------|------------------------|--|---|--|--------------------------------------|-----------------------------|---|----------------------|--|---|---|-----------------------|-------------|-----------------------------|
| ENGINE (S): | J65-W-5 | | | U | CHART WT | T. LIMITS 53,000 | 3,000 TO | 48, 800 POUNDS | POUN | IDS | 1 | | 12.0 | NO. 0F | ENGINES | OPERAT | LING: (T | (OM. |
| U AR | IF YOU ARE AT 25000' | .0 | | IF YOU | AR | E AT 30000' | <u> </u> | IF YOU ARE AT 35000' | E AT 35 | ,000 | IF YOU | IF YOU ARE AT 40000' | 40000, | | IF YO | IF YOU ARE AT 45000' | T 45000 | |
| NGE 1 | RANGE IN AIRMILES | | FUEL | er . | RANGE IN A | AIRMILES | | RANGE IN AIRMILES | AIRMILES | | RAP | RANGE IN AIRMILES | ILES | FUEL | RA | RANGE IN AIRMILES | RMILES | |
| BY CRUISING OPT AT 25000' 1000 | OPT ALT. BY CR | BY CRUISING AT OPT. ALT. | POUNDS | BY CRUISING AT 30000' | G OPT ALT. 1000 FT. | T. AT OPT. ALT. | NG BY CRUISING LT. AT 35000" | SING OPT ALT. | | BY CRUISING AT OPT. ALT. | BY CRUISING AT 40000' | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | POUNDS | BY CRUISING AT 45000" | OPT ALT. 1000 FT. | | BY CRUISING AT OPT. ALT. |
| 67 | 35 (22 | (2240) | 19.318 | (RANGE (2055) | | FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | ALLOWANCE (2220) | ES FOR PR | RESCR | RIBED CLIN | MB & DESCE | ENT TO SI | EA LEVEL) | 19 318 | | | | |
| | | | | | | | | | | | | | | 20,000 | | | | |
| 63 | 35 (21 | (2100) | 18,000 | (1925) | 35 | (2120) | (2080) | 35 | | (2130) | | | | 18,000 | | | | |
| 63 | 35 2000 | 00 | 17,000 | 1830 | 35 | 2015 | 1975 | 35 | | 2030 | | | | 17,000 | ace parties | | | |
| 60 | 35 1900 | 00 | 16,000 | 1730 | 35 | 1915 | 1875 | 35 | - | 1930 | | | | 16,000 | | | | |
| 63 | 35 1795 | 95 | 15,000 | 1630 | 35 | 1815 | 1765 | 35 | | 1825 | | | | 15,000 | | | | |
| | | | | 7 8 | | | | | | | | | | | | | | |
| IISING | CRUISING AT 25000' | | i i | S | CRUISING A | AT 30000' | | CRUISING AT 35000' | AT 350 | ,000 | CRU | CRUISING AT 40000' | 40000, | | CRL | CRUISING AT 45000' | T 45000 | |
| APPR | APPROXIMATE | | TIVE | | APPRO | APPROXIMATE | | APPRO | APPROXIMATE | 700 | | APPROXIMATE | MATE | TIVE | _ | APPRO | APPROXIMATE | |
| LBMR | G.S. R.F. | DOWN DIST. | _ | C.A.S. % | LIAM | G.S. R.F. DOWN | C.A.S. | RPM LAMR | G.S. R | R.F. DOWN DIST. | C.A.S. % | /HR G.S. | R.F. DOWN DIST. | QN | C.A.S. % | /HR G | G.S. R.F. | DOWN DIST. |
| 2000 | 315 .70 | 2 0 | 120 HW | 273 90 | 4470 31 | 310 .70 9 | 251 92 | 4170 | 310 | .71 13 | | | | 120 HW | | | | |
| 4820 | 344 . 79 | 7 6 | WH 08 | 270 90 | 4410 34 | 345 .80 10 | 247 91 | 4120 | 346 | .81 14 | | | | WH 08 | | | H | |
| 4660 | 376 .89 | 8 | 40 HW | 267 89 | 4290 38 | 380 .90 11 | 246 91 | 4080 | 384 | .90 15 | | | | WH 05 | | t | H | |
| 4470 | 404 1,00 | 6 | ۰ | 265 89 | 4220 41 | 416 1.00 12 | 245 91 | 4040 | 421 1. | 1.00 17 | | | | ۰ | | | | |
| 4370 | 437 1.11 | 10 | 40 TW | 262 89 | 4180 45 | 153 1, 10 13 | 3 243 91 | 4000 | 459 1. | .10 19 | | | | 40 TW | | | | |
| 4300 | 467 1.20 | 111 | 80 TW | 257 88 | 4130 48 | 486 1.20 14 | 4 242 91 | 4000 | 496 1. | 1.19 20 | | | | WT 00 | | | - | |
| 4200 | 500 1.32 | 1.32 11 | 120 TW | 254 88 | 4030 52 | 520 1.31 15 | 5 241 91 | 3950 | 535 1. | 1.30 21 | | | | 120 TW | | | | _ |
| | SP | ECIAL | SPECIAL NOTES | | | | | EXAMPLE | PLE | | | | | LE | LEGEND | | | |
| iple l | lautical er half on | units f char | Climb at 100% RPM Multiple Nautical units by 1:15 to obtain Statute its. Read lower half of chart opposite effective wind | o obtain | Statute e wind | If you are at 15,000 ft. with 18,000 lb. of available fuel, you can fty 1390 nautical miles by holding 296 knots CAS. However, you can fty 2060 nautical miles by immediately climbing to 35,000 ft. at 100% RDM. | at 15,000 an fly 13! However | ft. with nautical, you can | al mil. n fly 2 5.000 | es by hold naut | ft. with 18,000 lb. of available natical miles by holding 296, you can fly 2060 natical miles in to 35,000 ft. at 100% RPM. | | EFFECTIVE WIND-HW, Headwind, TW, Tallwind-Knots R.FRange factor-Ratio of ground distance to airmiles for corresponding winds G.SGround speed in Knots | CTIVE WIND-HW, Headw Range factor-Ratio of gro for corresponding winds Fround speed in Knots | I ground di Inds | W, Tailw stance to | ind-Kn | ots |
| com | tional allo bat, form | ation f | only. 4 Make additional allowances for landing, navigational errors, combat, formation flight etc. as required. | ng, navig as requir | ational ed. | Weight allows, continue climbs to and cruises at higher altitudes until 40,000 ft. is attained. At 40,000 ft. cruise at 220 knots CAS and start let down 22 nautical cruise at 220 knots can be seen to be seen t | ft, cruise ws, continutil 40,00 220 knots | o at 245 nue climbi 0 ft. is a CAS and | knots s to ar attaine start | CAS. Wilder | s at higher 5,000 ft. | 7 79 | CAS-Calibrated airspeed in Knots LB/HR-Fuel consumption-Pounds per hour RANGE-Rautical miles () RANGE IN PARENTHESIS FOR INTER- POLATION PURPOSES ONLY | airspeed nsumption il miles ARENTHE | - Pounds p SIS FOR I | er hour | | |
| ON: | BASED ON: ESTIMATE | BASED ON: ESTIMATE | | | | innes iron forme. With an account at optimum altitude would be .80 × 2060 matrical miles. Cruise at 220 knots CAS and | altitude | ude would be .80 x 2060 Cruise at 220 knots CAS | . 80 x | 2060 ol | or 1648 and start let | 2 | | FUEL GRADE: | ADE: JP. | JP-4 | | |

Figure A-56

| B-57B FLIGHT OPERATION INSTRUCTION CHART STANDARD DAY CHART WT. LIMITS 53,000 TO 48,800 POUNDS | NOTES Ranges shown of operating the state of | DATA AS OF: 1 OCTOBER 1953 | LOW ALTITUDE | IF YOU ARE AT 5000' IF YOU ARE AT 10000' | FUEL RANGE IN AIRMILES | POUNDS BY CRUISING OPT. ALT. BY CRUISING BY CRUISING OPT. ALT. BY CRUISING BY CRUISING AT 5000' 1000 FT AT OPT.ALT. AT 10000' 1000 FT AT OPT.ALT. AT 15000' | (RANGE FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL(1) | 19,318 (1210) 35 (2240) (1365) 35 (2265) (1535) | 18,000 1135 35 2105 (1280) 35 (2130) (1445) | 17,000 1075 35 2005 1215 35 2030 1370 | 16,000 1020 35 1900 1150 35 1925 1295 | 15,000 965 35 1785 1090 35 1810 1225 | CRUISING AT 5000' CRUISING AT 10000' | APPROXIMATE . APPROXIMATE | ND 4 N. L.B. C.S. R.P. DOUN J RPM G.S. R.P. DIST. RPM DIST. | | 334 87 8420 304 .74 2 326 | 85 5880 296 . 87 1 | 0 297 83 5520 319 1.00 1 298 84 5310 343 1.00 2 296 86 | 40 TW 286 83 5260 347 1.14 1 286 84 5130 370 1.12 2 283 85 | 269 83 4950 391 1.22 2 273 84 | |
|---|--|----------------------------|--------------|--|------------------------|---|--|---|---|---------------------------------------|---------------------------------------|--------------------------------------|--------------------------------------|---------------------------|---|---------------------|---------------------------|-------------------------|--|--|-------------------------------|------------------------|
| | MOTES: Ranges shown of opitinum altitudes are maxinum. In order to obtain moxinum range on flights, one chart (due to external configuration or gooss weight changes), it is necessary to abserve the opitinum on each chart; i.e., when changing charts a climb may be required to obtain a maxinum range. All temps lowences for descent distance and fuel. Climb distance and fuel are included where climbs are indicated. DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | 3ER 1953 | | IF YOU ARE AT 15000' | RANGE IN AIRMILES FUEL | SING OPT. ALT. BY CRUISING POUNDS | SCENT TO SEA LEVEL(1) | 35 (2295) 19,318 | 35 (2160) 18,000 | 35 2055 | 35 1950 16,000 | 35 1830 | CRUISING AT 15000' | APPROXIMATE TIVE | LB G.S. R.P. DOWN | 120 HW | 5780 324 .78 | 5430 344 .88 4 40 HW | 5100 367 1.00 4 0 | 4840 392 1.12 4 40 TW | 4680 419 1.24 4 80 TW | |
| EXTERNAL LOAD ITEMS. 2 X 320 GAL WING TIP TANKS DROPPED WHEN EMPTY NUMBER OF ENGINES OPERATING(TWO) | MOTES: Ranges shown of opitinum altitudes are maxinum. In order to obtain moxinum range on flights requiring more than one chart (due to external configuration or gross weight changes), it is necessary to observe the opitimum crusing altitude on each chart; i.e., when changing charts a climb may be required to obtain a maxinum range. All temps values include allowances for descent distance and fuel. Climb distance and fuel are included where climbs are indicated. DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | BASED ON: ESTIMATE | | (1) IF YOU ARE AT 20000' | EL RANGE IN AIRMILES | BY CRUIS AT 2000 | | 18 (1710) 35 (2310) | 00 (1605) 35 (2175) | 00 1525 35 2070 | 00 1445 35 1970 | 00 1365 35 1850 | CRUISING AT 20000* | | RPM C.S. R.F. DOWN | 325 88 5590 313 .70 | 313 88 5260 338 .80 | w 304 87 5070 365 .90 6 | 290 87 4830 388 1.00 6 | w 279 86 4600 414 1.12 6 | w 271 85 4480 443 1.23 7 | 263 85 4330 473 1.36 7 |

Figure A-57

| AIRCR | AIRCRAFT MODEL | EL | B-57B | | | | | | Ī | HIGH ALTITUDE | | III. | | ш | | | | 2 X 3 | 2 X 320 GAL WING TIP TANKS | VING T | P TAN | IKS |
|---|--|------------------------|--------------------------------------|---|--|--------------------------------|--------------|---|-----------------------------|---|---|--|---|--|----------------------|--|---|---|---|------------------------|-------------------|-----------------------------|
| ENGIN | ENGINE (S): J65-W-5 | 5-W-5 | 120 | | 0 | CHART W | WT. LIMITS | | 53,000 | | TO 48, 800 POUNDS | OUNDS | | | | | | NO. 0 | NO. OF ENGINES OPERATING: (TWO) | OPERA | TING: (| (TWO) |
| F | IF YOU ARE AT 25000' | AT 25 | ,000 | | IF YOU | | ARE AT 30000 | 30000 | - | IF YO | IF YOU ARE AT 35000' | AT 3500 | .01 | IF Y | IF YOU ARE AT 40000' | AT 4000 | 0,0 | | IF YC | IF YOU ARE AT 45000' | AT 4500 | ,00 |
| | RANGE IN AIRMILES | AIRMILE | 10 | FUEL | | RANGE IN | AIRMILES | 22 | - | RAP | RANGE IN AIRMILES | SMILES | | | RANGE IN AIRMILES | IRMILES | | FUEL | æ | RANGE IN AIRMILES | IRMILES | |
| BY CRUISING AT 25000" | SING OPT ALT. | | BY CRUISING AT OPT. ALT. | POUNDS | S BY CRUISING AT 30000' | | | BY CRUISING AT OPT. ALT. | | BY CRUISING AT 35000' | OPT ALT. | | BY CRUISING AT OPT. ALT. | BY CRUISING AT 40000' | OPT ALT. | | BY CRUISING AT OPT. ALT. | POUNDS | BY CRUISING AT 45000" | G OPT ALT. 1000 FT. | | BY CRUISING AT OPT. ALT. |
| | | | | | (RANGE | FIGURE | ES INC | LUDE A | LLOW | ANCES F | OR PR | ESCRIB | ED CLI | S INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | CENT TO | SEA L | EVEL) | | | | | |
| (1945) | 35 | 3 | (2330) | 19,318 | | 80 | | (2345) | <u></u> | (2295) | 35 | 81 | (2365) | | | | | 19,318 | | | | |
| (1830) | 35 | 3 | (3182) | 18,000 | (2015) | 35 | | (2219) | | (3160) | 50 | (3) | (2230) | | | - | | 18,000 | | | - | |
| 1740 | 35 | - | 3090 | 17,000 | 1915 | 80 | | 2110 | M | 3022 | 32 | 64 | 2120 | | | - | | 17,000 | | | _ | |
| 1650 | 38 | | 1990 | 16,000 | 1815 | 80 | | 2002 | = | 1950 | 500 | × | 2020 | | | - | | 16,000 | | | | |
| 1560 | 35 | | 1875 | 15,000 | 1730 | 35 | | 1890 | - | 1845 | 32 | 1 | 1905 | | 4 | - | | 15,000 | | | - | |
| | | | | | | | | 9 | | | | | | | | | | | | | | |
| | CRUISING AT 25000' | AT 25 | .000 | | | CRUISING | AT 30000' | ,000 | ╀ | CRU | CRUISING AT 35000' | T 3500 | | 5 | CRUISING AT 40000' | AT 4000 | ,0 | 1 | S. | CRUISING AT 45000' | AT 4500 | .00 |
| | APPRO | APPROXIMATE | 1 | TIVE | | APP | APPROXIMATE | TE . | | | APPROXIMATE | MATE | | | APPR | APPROXIMATE | | | | APPR | APPROXIMATE | |
| C.A.S. | RPM LBHR | 5.5 | R.F. DOWN DIST. | | C.A.S. % | LBin | 6.5. | R.F. DO | LET C.A.S. DOWN DIST. | 2 M | LB/HR G | G.S. R.F. | • DOWN DIST. | C.A.S. % | /HR | 6.S. | R.F. DOWN DIST. | AIND | C.A.S. % | /HR | G. S. R. | R.F. DOWN DIST. |
| 300 89 | 2000 | 315 | 7 07. | 120 HW | 273 90 | 4470 | 310 | . 70 | 251 | 92 4 | 170 310 | 17. 0 | 13 | | | | | 120 HW | | | | _ |
| 292 88 | 4820 | 344 | 7 67. | 80 HW | 270 90 | 4410 | 345 | .80 10 | 247 | 16 | 120 34 | . 81 | 14 | | | - | | WH 08 | | | - | + |
| 287 88 | 0999 | 376 | 89 . | 40 HW | 267 89 | 6290 | 380 | .90 | 346 | 16 | 080 38 | . 98 | 15 | | | | | 40 HW | | | 7 | |
| 279 88 | 4470 | 404 1. | 1.00 9 | 0 | 265 89 | 4220 | 416 1 | 1.00 12 | 245 | 16 | 040 431 | 1 1.00 | 11 | | | | | 0 | | | | |
| 273 87 | 1020 | 437 1. | 1.11 10 | WT 00 | 262 89 | 4180 | 453 | 1.10 13 | 245 | 10 | 000 459 | 9 1.10 | 19 | | | | _ | VT 04 | | | | |
| 265 87 | 4300 | 1. 19 | 1.20 11 | WT 08 | 257 88 | 4130 | 486 1 | 1.20 14 | 242 | 91 | 965 000 | 8 1.19 | 20 | | | H | H | WT 00 | | | h | H |
| 261 87 | 4200 | 500 1. | 1.32 11 | 120 TW | 254 88 | 1030 | 520 1 | 1.31 15 | 241 | 16 | 3950 535 | 5 1.30 | 21 | | | | _ | 120 TW | | | | |
| 1 Cli 2 Mu units 3 Re only. | limb at l'intiple N.S. ead lowe iake addit r.s. comb | oo % Fautica sr hal | SPECIAL UPM units of of cha ullowanc | SPECIAL NOTES PM Luntts by 1.15 of chart opposit of chart opposit matton flight etc | SPECIAL NOTES 1 Climb at 100, RPM 2 Multiple Naufical units by 1.15 to obtain Statute units. 3 Read lower half of chart opposite effective wind only. 4 Make additional allowances for landing, navigational errors, combat, formation flight etc. as required. | Statute re wind rational | | EXAMPLE If you are at Sea Level with 17,000 lb. of availa fuel, you can fly 945 nautical miles by holding 2 knots CAS. However, you can fly 1980 nautical by immediately climbing to 35,000 ft. at 100% At 35,000 cruise at 245 knots CAS. When duced weight allows, continue climbs to and cruis higher altitudes until 40,000 ft. is attained. At | at Sea an fly How ately c | EXAMF a Level with 1 y 945 nautica wever, you car climbing to 35 cruise at 245 lows, continue s until 40,000 | EXAMPLE with 17,0 autical m rou can fi g to 35,00 t 245 km ntinue cli | 7,000 lb. o 1 miles by h n fly 1980 n ify 1980 t s,000 ft, at knots CAS. climbs to a ft, is attain | lb. of a by hold by hold 80 nau ft. at 1 NAS. We to and ttained ttained | EXAMPLE If you are at Sea Level with 17,000 lb. of available fuel, you can fly 945 nautical miles by holding 293 knots CAS. However, you can fly 1980 nautical miles by immediately climbing to 35,000 ft. at 100% RPM. At 35,000 cruise at 245 knots CAS. When reduced weight allows, continue climbs to and cruises at higher altitudes until 40,000 ft. is attained. At | | FFECT FRa. for SGre AS-Cal | IVE WI nge fact corres corres und spe ibrated fuel co | LEGEND LEGEND R.FRange factor-Ratio of ground distance to airmiles G.SGround apped in Knots CASGround apped in Knots LEAR-Fuel consumption-Pounds per hour RANGE-Nautical miles | Headwind, 7 of ground de winds nots. d in Knots on-Pounds | W, Tail | wind-K to airm | Snots |
| BASE | BASED ON: ESTIMATE | STIM | TE | | | | 22 r wind | nautical mod, the rang | cruis il mile range | lse at 221 knots les from home. at optimum altifunautical miles. | home. | With itude v | and sta an 80 vould be | 40, 000 it, cruse at 221 knots CAS and start let down 22 nautical miles from home. With an 80 knot headwind, the range at optimum altitude would be .80 x 1980 cor 1585 nautical miles. Cruise at 221 knots | | POL | TION | POLATION PURPOSES ONLY | SONLY | NI PE | | |
| | - | OCT | 1 OCTOBER 1953 | 353 | | | CA | 1.00 | art le | t down | 10 01 | | niloc fr | don't | -04 | | | FUEL GRADE: | | 3 P-4 | | |

ADC For

| OPERATION INSTRUCTION CHART STANDARD DAY IMITS 30, 500 POUNDS OR LESS Is then fuel evailable for the contraral configuration or gress weight changes), it is necessary to observe the optimum studing activiting mone than one chart (day to external configuration or gress weight changes), it is necessary to observe the optimum studing a strinde at this prince than | | W ALTITUDE | IF YOU ARE AT 10000' IF YOU ARE AT 15000' | RANGE IN AIRMILES BY CRUISING OPT. ALT. BY CRUISING BY CRUISING OPT. ALT. BY | AT OPT. AT 15000" | 260 25 300 290 25 315 | 175 25 185 195 25 205 | 001 | CRUISING AT 10000' CRUISING AT 15000' | | RPM LBHR G.S. R.F. DOWN G RPM LBHR G.S. R.F. | | 2 92 3830 233 .70 2 258 92 3500 240 .71 | 87 3090 268 1.00 2 224 88 2910 279 1. | 7 86 2890 292 1.16 2 211 87 2720 305 1.16 | 85 2730 318 1.34 2 203 87 2610 334 | |
|--|---|------------|---|---|----------------------|-----------------------|-----------------------|------|---------------------------------------|-------------|--|--------|---|---------------------------------------|---|------------------------------------|---|
| AIRCRAFT MODEL (S) B-57B FLIGHT OPERATION STAND CHART WT. LIMITS 30, 500 POU INSTRUCTIONS FOR USHIG CHART; (A) IN FLIGHT - Select figure in fool column equal to an less than fool available for | left to section occording to present attitude and read total range available (no wind) by cruising at that altitude of maximum range. For a flight at initial offitude, operating instructions are given directly below. For a flight at higher attitude, climb immediately to desired diffude and read cruising instructions in appropriate cruising affitude section. (B) FLIGHT PLANNING. From initial fuel on board subtract. Ival for take-off and climb to desired cruising affitude and all other necessory allowences. Then use chart as for IN FLIGHT above, adding initial climb distinances to range volues. | LOW | ARE AT 5000' | ILES BY CRUISING | SIIDES INCLIDE ALLOW | 25 280 | 20 165 | 1 | CRUISING AT 5000" | APPROXIMATE | HR G.S. R.F. DOWN U | | 3700 239 83 1 250 | 258 1.00 1 | 3070 278 1.17 1 217 | | |
| AIRCRAFT MODEL (S) B-57B ENGINE(S) J65-W-5 INSTRUCTIONS FOR USING CHART: (A) IN FLIGHT - Scheer figure in fuel crutes (fine) on board minus allowence for reserve, combat, navigational error, fa | left to section occording to present altitude and road total range ovoilable (no wind) by cr ing to enother altitude of maximum range. For a Hight at initial olitivate, operating ins For a Hight at higher altitude, climb immediately to desired altitude and read erussing is altitude section. (B) FLIGHT PLANNING. From initial fuel on board subtract fuel erusing altitude and all other necessory allowences. Then use chart as for IN FLIGH eness to range volues. | | (I) IF YOU AR | BY CRUIS | AT S000' | | 155 | 80 | | | S % LBn | | 260 89 | 241 87 | 221 85 | | _ |
| AIRCRAFT MODEL (S) B-57B ENGINE(S) J65-W-5 ONS FOR USING CHART; (A) IN FLIGHT | an shitude and r inn tange. For a limb immediately LANNING - Fra cossory allowan | | | BY CRUISING POUNDS | AT OPT.ALT. | 255 3000 | 150 2000 | 1000 | EFF | TIVE | DOWN DIST. | 120 HW | WH 05 | - | 0 40 TW | WT 08 | |

Figure A-59

| F YOU ARE AT 40000' F UEL RANGE IN AIRMILES | AIRCRAF | T MODEL | AIRCRAFT MODEL (S) B-57B | | | | T | IGH | AL | HIGH ALTITUDE | E | | | EXT. LOAD | | NONE | |
|--|--------------------------|-----------------------|-------------------------------------|-------------|---|--------------------------|--|---|---|--|---|----------------------|---|--|-------------------------------------|--------------------|-----------------------------|
| FUEL RANGE RAT 35000' IF YOU ARE AT 30000' IF YOU ARE AT 35000' IF YOU ARE AT 350 | ENGINE | | W-5 | | 5 | ART WT. L | | , 500 P | OUNDS OF | LESS | | | | NO. OF | ENGINES | OPERATIN | IG:(ONE) |
| FUEL RANGE IN ARBMLES RANG | IF YC | U ARE AT | 25000' | | IF YOU | | 30000 | IF Y | OU ARE AT | 1 35000' | IF YOU | ARE AT 4 | ,0000 | | IF YOU | J ARE AT | 45000' |
| SING AT 2500' SPECIAL NOTE SPECIAL STATUS SPECIAL STANDER SPECIAL SPECIAL STANDER SPECIAL | R | INGE IN AIRM | LES | FUEL | RA | | LES | ~ | ANGE IN AIRM | ILES | RAN | SE IN AIRMIL | 83 | FUEL | RA | NGE IN AIRM | LES |
| CRUISING AT 25000 | BY CRUISING AT 25000' | OPT ALT. | BY CRUISING AT OPT. ALT. | | BY CRUISING AT 30000' | 1000 | | | G OPT ALT. | | BY CRUISING AT 40000" | OPT ALT. 1000 FT. | AT OPT. ALT. | | BY CRUISING AT 45000' | | BY CRUISING AT OPT. ALT. |
| CRUISING AT 25000 | | | | | (RANGE F | GURES II | CLUDE ALI | OWANCES | FOR PRE | CRIBED CLI | MB & DESCE | NT TO SE | LEVEL) | | | | |
| CRUISING AT 25000' | 350 | 1 | - | 3000 | | | | | | | | | | | | | |
| CRUISING AT 25000' EFFEC. APPROXIMATE APPROXIMATE | 235 | 1 | 1 | 2000 | | | | | | | | | | | | | |
| CRUISING AT 25000 | 120 | 1 | - | 1000 | | | | | | | | | | | | | |
| CRUISING AT 25000' CRUISING AT 35000' CRUISIN | | | | | | | | | | | | | | | | | |
| FFEC | 3 | UISING AT | 25000' | | | JISING AT | 30000. | 5 | RUISING AT | . 35000' | CRU | SING AT | ,0000 | 0 | CRI | JISING AT | 45000' |
| S | | APPROXIM | ATE | EFFEC. | | APPROXI | NATE | | APPROXI | MATE | | APPROXIM | ATE | TIVE | | APPROX | |
| 100 | | H | u' | | C. A. S. | /HR G.S | <u>u</u> | C.A.S. | /нв | R.F. | C.A.S. | | | | | | R.F. DOWN DIST. |
| 94 2946 291 .86 7 40 HW 92 2616 341 1.14 9 40 TW 91 2516 371 1.26 9 80 TW 91 2517 371 1.26 9 80 TW 91 2470 406 1.43 10 120 TW 92 2616 341 1.14 9 406 1.43 10 120 TW 93 2746 317 1.26 9 80 TW 94 2946 291 .86 7 40 HW 95 2616 341 1.14 9 40 TW 96 274 | 1 | 1 | - | 120 HW | | | | | | | | + | | 120 HW | | | |
| 94 2946 291 .86 7 40 HW 92 261C 341 1.14 9 40 TW 91 251C 371 1.28 9 80 TW 91 247C 406 1.45 10 120 TW 92 261C 341 1.14 9 40 TW 93 261C 341 1.14 9 40 TW 94 251C 371 1.28 9 80 TW 95 261C 341 1.14 9 40 TW 96 TW 97 261C 341 1.14 9 40 TW 98 274C 31 1.28 9 80 TW 99 2 261C 341 1.14 9 40 TW 91 247C 406 1.45 10 120 TW 91 247C 406 1.45 10 120 TW 92 261C 341 1.14 9 40 TW 93 261C 341 1.14 9 40 TW 94 294C 300 ft. with 3000 lb. of available fixed lower half of chart opposite effective wind and start let down 9 nautical miles from destination. | | 3170 | . 7B | | | | | | | | | _ | | 80 HW | | | |
| 92 2616 341 1.14 9 40 TW 91 2516 371 1.28 9 80 TW 91 2476 406 1.43 10 120 TW 92 2616 341 1.15 9 80 TW 93 2476 406 1.43 10 120 TW 94 2476 406 1.43 10 120 TW 95 2616 AND TES 95 2616 371 1.28 9 80 TW 95 2616 AND TES 96 TW 97 2476 406 1.43 10 120 TW 98 TW 99 2516 AND TES 90 TW 100 TES 11 TES 11 TES 12 TES 13 TES 14 TES 15 TES 16 TES 17 TES 18 TES 18 TES 19 TES 10 TES | | 2940 | . 86 | | | | | | | | | | | 40 HW | | | |
| 2516 371 1.28 9 80 TW 91 2516 371 1.28 9 80 TW 10 12 2476 406 1.43 10 120 TW Climb at 100% RPM Multiple Nautical units by 1.15 to obtain Statute Multiple Nautical units by 1.15 to obtain Statute Read lower half of chart opposite effective wind flag. Make additional allowances for landing, navigational rrors, combat, formation flight etc. as required. ASED ON: ESTIMATE | 9 | 2740 | 7 1.00 | | | | | | | | | - | | | | | |
| 21 2516 371 1.28 9 80 TW 21 2476 406 1.43 10 120 TW SPECIAL NOTES Climb at 199% RPM Multiple Mautical units by 1.15 to obtain Statute fuel, you can fly 290 nautical airmiles by holding airmiles by immediately climbing to 25,000 ft. using airmiles by immediately climbing to 25,000 ft. using airmiles by immediately climbing to 25,000 ft. using airmiles by material miles from home. With a 40 knot tailwind the range at 25,000 ft. would be 1.14 x 315 or 359 nautical miles. Cruise at 204 knots CAS with this wind and start let down 9 nautical miles from destination. | - | 2610 | 1.14 | | | | | | | | | _ | | 40 TW | | | |
| SPECIAL NOTES Climb at 100% RPM Multiple Nautical units by 1.15 to obtain Statute Nautical units by 1.15 to obtain Statute Then, you can fly 290 nautical airmiles by holding airmiles by immediately climbing to 25,000 ft. using airmiles by immediately climbing to 25,000 ft. using and start let down 8 nautical miles from home. With a 40 knot tailwind the range at 25,000 ft. would be 1.14 x 315 or 359 nautical miles. Cruise at 204 knots CAS with this wind and start let down 9 nautical miles from destination. | - | 2510 | 1.28 | | | | ATT. | | | | | _ | | 80 TW | | | |
| SPECIAL NOTES If you are at 15,000 ft. with 3000 lb. of available natical units by 1.15 to obtain Statute tuel, you can fly 290 nautical airmiles by holding 224 knots CAS. However, you can fly 315 nautical airmiles by immediately climbing to 25,000 ft. using airmiles by immediately climbing to 25,000 ft. using 100% RPM. At 25,000 ft. cruise at 216 knots CAS and start let down 8 nautical miles from home. With a 40 knot tailwind the range at 25,000 ft. would be 1.14 x 315 or 359 nautical miles. Cruise at 204 knots CAS with this wind and start let down 9 nautical miles from destination. | | 2470 | 1.43 | | | | | | | | | - | | | | | |
| 190% RPM Nautical units by 1.15 to obtain Statute Nautical units by 1.15 to obtain Statute rer half of chart opposite effective wind airmiles by immediately climbing to 25,000 ft. using airmiles from home. With a 40 knot tailwind the range at 25,000 ft. would be 1.14 x 315 or 359 nautical miles. Cruise at 204 knots CAS with this wind and start let down 9 nautical miles from destination. | | | SPECIAL | L NOTES | | | | | EXAMPL | mi | | | | _ | EGEND | | |
| thonal allowances for landing, navigational alramiles by immediately climbing to 25,000 ft. using airmiles by immediately climbing to 25,000 ft. using 100% RPM. At 25,000 ft. cruise at 216 knots CAS and start let down 8 nautical miles from home. With a 40 knot tailwind the range at 25,000 ft. would be 1.14 x 315 or 359 nautical miles. Cruise at 204 knots CAS with this wind and start let down 9 nautical miles from destination. | 1 CH | mb at 100 | % RPM tical units | by 1.15 | to obtain | Statute | If you are a | nt 15,000 an fly 29 | ft. with | 3000 lb. of airmiles by | available , holding | R.F. | CTIVE WI Range fact for corres | ND-HW, H or-Ratio | eadwind, T of ground di dinds | W, Tailwi | airmiles |
| ESTIMATE FUEL GRADE: | units. 3 Reconjy. 4 Ma | ke additions, combat, | half of chanal allowance, formation | art opposit | te effective ilng, naviga . as requir | e wind ational ed. | 224 knots airmiles by 100% RPM and start la 40 knot 1.14 x 3 knots CAS | As. Hornedia. At 25 of down tailwind tailwind tailwind twith this with this | wever, you ttely climb 000 ft. c. nautical he range a nautical wind and s | u can ily 3 ping to 25, ruise at 21 miles from ut 25,000 f miles. Cru | 15 nautical 300 ft. using 6 knots CAS home. With t. would be ise at 204 n 9 nautica | | Ground sportaged Calibrated Calibrated Co. RFuel co. SE Nautic IN P. C. | alrspeed alrspeed almiles ARENTHI | ots In Knots I- Pounds I SSIS FOR | per hour | |
| 1 OCTOBRE 1953 | BASE | | STIMATE | 1953 | | | miles fron | destinati | on. | | | | | FUEL GR | ADE: JI | JP-4 6.5 LB/GAL | J. |

Figure A-60

Figure A-61

| ENGINE (S): J | | | | | | 0 | HAL | HIGH ALTITUDE | | | | | EXT. LOAD | | NONE | | |
|---|---|--|--|------------------|---|---|---|--|---|--|--------------------|---|---|--|---|------------------|---------------|
| | J65-W-5 | | Ŧ | CHART WT. LIMITS | | 35,000 TC | TO 30,500 POUNDS | POUNDS | | | | | NO. 0 | NO. OF ENGINES OPERATING:(ONE) | S OPERAT | ING:(O) | NE) |
| IF YOU ARE AT 25000 | AT 25000' | | IF YOU | 1007 | ARE AT 30000' | = | IF YOU ARE AT 35000' | AT 35000' | _ | IF YOU ARE AT 40000' | ARE AT | 40000 | | IF Y(| IF YOU ARE AT 45000' | T 45000' | |
| | AIRMILES | FUEL | R. | 7 | MILES | | | RMILES | | RANG | RANGE IN AIRMILES | S 3 7 | FUEL | ~ | | IMILES | 9 |
| BY CRUISING OPT ALT. | FT. AT OPT. ALT. | | BY CRUISING AT 30000' | 1000 FT. | AT OPT. ALT. | BY CRUISING AT 35000' | SING OPT ALT. 30' 1000 FT. | T. BY CRUISING T. AT OPT. ALT. | T. AT | BY CRUISING AT 40000' | 1000 FT. | BY CRUISING AT OPT. ALT. | | AT 45000' | 1000 FT. | | AT OPT. ALT. |
| | 3 | | (RANGE F | GURES | NCLUDE AL | LOWANC | ES FOR PR | (RANGE FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | LIMB & | DESCEN | T TO SE | A LEVEL) | | | | | |
| | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | ā | | | | |
| | | | | | | | | | | | | | | | | Marine Transport | |
| CRUISING | CRUISING AT 25000' | | | CRUISING AT | NG AT 30000' | \perp | CRUISING AT 35000' | AT 35000' | - | CRUIS | CRUISING AT 40000' | 40000 | | | CRUISING AT 45000" | T 45000' | |
| APPR | APPROXIMATE | FFFEC. | | APPROXIMATE | MATE | | APPRO | APPROXIMATE | | | APPROXIMATE | | TIVE | | APPRO | APPROXIMATE | |
| C.A.S. % /HR | G.S. R.F. DOWN DIST. | | C.A.S. % | /HR G.S. | S. R.F. DOWN DIST. | C.A.S. | RPM /HR | G.S. R.F. DON | LET C.A.S. DOWN DIST. | % Q M | /HR G.S. | R.F. DOWN | | C.A.S. | /HR | G. S. R.F. | DOWN DIST. |
| | | | | | | | | | | | | | 120 HW | | | | |
| | | 80 HW 40 HW | | | | | | | | | | | 40 HW | | | | |
| | | 0 | | | | | | | - | | | | 0 | | | | |
| | | 40 TW | | | | | | | | | | | 40 TW | | | | |
| | | 80 TW | | | | I | | | - | | H | | WT 08 | | | - | |
| | | 120 TW | | | | | | | - | | - | | 120 TW | | | - | 4 |
| | SPECIAL | SPECIAL NOTES | | | | | EXAMPLE | I.E | | | | | _ | LEGEND | | | |
| 1 Climb at 100% RPM 2 Multiple Nautical ununits. 3 Read lower half of only. 4 Make additional allow errors, combat, format errors, Combat, format BASED ON: ESTIMATE DATA AS OF: 1 OCTOBI | 1 Climb at 100% RPM 2 Multiple Nautical units by 1.15to obtain Statute units. 2 Multiple Nautical units by 1.15to obtain Statute units. 3 Read lower half of chart opposite effective wind only. 4 Make additional allowances for landing, navigational errors, combat, formation flight etc. as required. BASED ON: ESTIMATE DATA AS OF: 1 OCTOBER 1953 | by 1.15 art opposit ces for land flight etc. | to obtain se effective fing, navigs as require | CN CN | If you are at 5000 ft. with 3000 you can fly 225 nautical airmiles CAS. However, you can fly 245 rimmediately climbing to 20,000 ft. cruise at 230 knot down 5 nautical miles from home tailwind, the range at 20,000 ft. 245 or 316 nautical miles. Cruis with this wind and start let down 6 destination. | 25 naver, your, itical mutical me range nauticand and s | ft. with 30 utical airm u can fly 24 ng to 20, 00 se at 230 se at 230 at 20, 000 at 20, 000 al miles. | n n n tr | ing 252 lairmil a airmil and sta and sta an 80 be 1.29 [2] knc | b. of available fuel, yy holding 252 knots autical airmiles by . using 100% RPM GAS and start let With an 80 knot vould be 1.29 x e at 212 knots CAS nautical miles from | | EFFECTIVE WIND-HW, Headwind, TW, Tallwind-Knots, R.FRange factor-Ratio of ground distance to airmiles G.SGround speed in Knots CAS-Cailbrated airspeed in Knots CAS-Cas-Cas-Cas-Cas-Cas-Cas-Cas-Cas-Cas-Cas | TND-HW, I tor-Ratio risponding seed in K d alr speed on sumptio SI miles PARENTH PURPOSI FUEL G | TD-HW, Headwind, TW, Tallwin rate Ratio of ground distance to a nonling winds ed in Knots atraspeed in Knots sumption-Pounds per hour in lies IRENTHESIS FOR INTERURPOSES ONLY FUEL GRADE: JP-4 FUEL GRADE: JP-4 | nd, TW, Tailw nd distance to lots OR INTER- 'X JP-4 : 6.5 LB/GA | o airmil | les 1 |

Figure A-62

| | NE) | ng more than sing altitude is include al- | [±2 | | ,0000; | 53 | BY CRUISING AT OPT.ALT. | | | | | | ,0000 | TE . | R.F. DOWN DIST. | | | | | | |
|-----------------------------|------------------------------------|--|------------------------|-------|----------------------|-------------------|--|--|------------------|--------------------------|-------------------|-------------------------|--------------------|-------------|--------------------|-------------|-----------|------------|---------------|---------------|--------|
| SWS | TING: (O | ghts requiri optimum cru range value cated. | TIMAT | | RE AT | RANGE IN AIRMILES | | | | | | | CRUISING AT 20000' | APPROXIMATE | /HR G.S. | | | | | | |
| EXTERNAL LOAD ITEMS NONE | NUMBER OF ENGINES OPERATING: (ONE) | NOTES: Ranges shown at optimum altitudes are maximum. In order to obtain maximum range on flights requiring more than one chart (due to external configuration or gross weight changes), it is nocessory to observe, the optimum existing altitude on each chart; i.e., when changing charts a clinib may be required to obtain a maximum range. All range values include altowances for descent distance and fuel. Climb distance and fuel are included where climbs are indicated. DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | BASED ON: ESTIMATE | | IF YOU ARE AT 20000' | RANGE | BY CRUISING OPT. ALT. AT 20000' 1000 FT | | | | | | CRUIS | | C.A.2 | | | | | _ | |
| EXTERN | R OF ENGI | innum oltitudes are maximum. In order to obtain maximum range afiguration or gross weight changes), it is necessary to observaging charts a climb may be required to obtain a maximum range and fuel. Climb distance and fuel are included where climbs are DATA BELOW CONTAIN NO FUEL RESERYE FOR LANDING | | | (1) | FUEL | POUNDS | | 12,000 | 10,000 9,000 8,000 | 7,000 6,000 5,000 | 4,000 3,000 2,000 | 0.1.1.1 | TIVE | QNIM | 120 HW | 40 HW | 0 | WT 05 | 80 TW | 120 TW |
| | NUMBE | iximum. In ordiversity the regular changes in any be required nee and fuel are | | | ,000 | | CRUISING OPT.ALT. | LEVEL ⁽¹⁾ | 1140 | 910 810 710 | 610 | 11! | .000 | | R.F. DOWN | 73 2 | | 1.00 3 | 1.14 3 | 27 4 | |
| TX. | | dijudes are me | 953 | | IF YOU ARE AT 15000' | RANGE IN AIRMILES | 0PT. ALT. B) | 100 | 15 | 15 15 15 | 1 1 1 1 2 | 111 | CRUISING AT 15000' | APPROXIMATE | 6.5 | 25.4 | 281 | 308 | 340 | 3450 373 1.27 | |
| CHA | POUNDS | n of optimum or rnal coafiguret hon changing c istance and fue DATA I | 1 OCTOBER 1953 | | IF YOU | RANGE | BY CRUISING OI AT 15000' | & DESCENT TO SEA | 1075 980 | 885 790 700 | 610 520 435 | 350 265 180 | CRUIS | | RPM LBHR | 9 95 4120 | 94 | 8 93 3640 | 0 92 3530 | 92 | |
| 2 | 35,000 P | Ranges shown ort (due to exte c chart i.e., wh | | TUDE | .00 | | BY CRUISING BY AT OPT.ALT. A | | 1125 | 895 795 695 | 600 500 410 | 111 | .0 | - | DOWN DIST. | | 1 81 | 0 2 248 | 5 2 240 | 9 2 235 | |
| STANDARD DAY | TO | 2 2 22 | DATA AS OF: | ALTI. | IF YOU ARE AT 10000' | RANGE IN AIRMILES | OPT. ALT. BY 1000 FT AT | (RANGE FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB | 15 1 | 15 15 15 | 15 15 15 | 111 | CRUISING AT 10000' | APPROXIMATE | 6.5. R.F. | 4440 247 72 | | 0 295 1.00 | 3650 324 1.15 | 3580 358 1,29 | |
| ATION | 39,500 | INSTRUCTIONS FOR USING CHART: (A) IN FLIGHT - Scloct figure in fuel column equel to or less than fuel evailable for circle (fuel on board minus allowance for reserve, comba, mavigational erro, formation flight, atc.). More horizontally right or left to section according to present elittude and road tome for any evailable (no wind) by cruising at that elittude or by climbing to another elittude of maximum range. For a flight at initial altitude, operating instructions are given directly below. For a flight or higher elittude, climb immediately to desired elittude and cruising instructions in appropriate cruising elittude, climb minus except and climb to above subtract. (B) FLIGHT PLANNING - From. initial fuel on board subtract fuel for take-off and climb to desired entitude and all other necessors allowances. Than use chart as for IN FLIGHT above, adding initial climb distructions. | | | IF YOU A | RANGE | BY CRUISING OF AT 10000' | NCES FOR | 975 885 | 800 720 635 | 550 475 395 | 320 240 165 | CRUISII | A | RPM LBHR | 9.4 | 93 | 91 3820 | 91 | 90 | |
| OPER | LIMITS | or less than furnitudes of the cities of the cities on the cities on the cities in appropriate cities in a cities of citie | | LOW | | | BY CRUISING BY AT OPT.ALT. AT | E ALLOWA | 1105 985 | 870 770 675 | 575 485 390 | 305 | | - | DOWN C.A.S | 284 | 1 270 | 1 255 | 1 246 | 240 | - |
| FLIGHT | HART WT. LIMITS | man equal to e tion flight, at ad) by cruisin wing instructi ruising instructi t fuel for | | | AT 5000' | AIRMILES | | INCLUDE | 1 | | | | AT 5000' | APPROXIMATE | S. R.F. | | 98. 85 | 1.00 | 91.16 | | |
| ш | CH | e in fuel colu- il orror, format fable (no win filiude, opera e and read er oerd subtract art as for IN | | | IF YOU ARE AT 5000' | RANGE IN A | OPT. | FIGURES | 15 | 15 15 15 | 15 15 15 | 15 1 | CRUISING A | APPRO | L.B. G.S. | | 4390, 259 | 4040 282 | 3830 30 | | |
| | | Scleet figur 1, navigatione 10 range avai 11 to 1 initial a 12 to 1 initial a 12 to 1 initial a 13 to 1 initial a 14 to 1 initial a 15 to 1 initial a 15 to 1 initial a 16 to 1 initial a 17 han use ch | | | F | | BY CRUISING AT 5000' | (RANGE | 870 790 | 715 645 570 | 495 430 355 | 285 215 145 | 5 | - | C.A.S | | 278 92 | 263 90 | 250 90 | | |
| B-57B | |) IN FLIGHT ceserve, combo le and rood to For a fligh vediately to d 3. From init | | | (1) | FUEL | POUNDS | | 12,000 11,000 | 10,000 9,000 8,000 | 7,000 6,000 5,000 | 3,000 2,000 | | TIVE | QUIM | 120 HW | 80 HW | 0 | 40 TW | WT 08 | |
| MODEL (S) | J65-W-5 | CHART: (A billowance for ra present elittud oximum range de, climb imm IT PLANNING | | | i. | 5 | BY CRUISING AT OPT.ALT. | | 1085 | 855 755 655 | 560 470 380 | 295 | | | R.F. DOWN | | .84 0 | 1.00 0 | 1.17 0 | | |
| AIRCRAFT MODEL (S) | ENGINE(S) J65-W-5 | S FOR USING the according to obtained of m higher obtains. higher obtains. h. (B) FLIGHte and all office and al | values. | | IF YOU ARE AT S.L. | RANGE IN AIRMILES | | | 15 | 15 15 | 15 15 | 15 | CRUISING AT S.L. | APPROXIMATE | G.S. | | 4770 248 | 4330 269 1 | 4080 296 1 | | |
| ₹ | E | INSTRUCTIONS FOR USING CHART; (A) IN FLIGHT - Soloct figure in fool or lettes (fuel on board minus allowance tor reserve, combat, mavigational orras, for left to section according to present elititade and road total range available (to ving to another elitiude of maximum range. For a flight at initial elititude, op. For a flight or higher elititude, climb immediately to destriad elititude and read elititude and read elititude and solutions (S. PLIGHT PLANNING - From. initial feal on board subtraction in the latest and all other necessary allowances. Then use chart as far | ances to range values. | | IF YOU | RANGE | BY CRUISING OPT. ALT. AT S.L. 1000 FT | | 765 | 635 570 510 | 440 380 315 | 250 190 130 | CRUIS | 4A | RPM LAHR | | 91 | 89 | 88 | | |
| | | 2025276 | 5 | | | | BY | | E-CITIE | | | | L | T. | C.A.S | | 288 | 269 | 256 | | |

Figure A-63

| AIRCRAFT MODEL (S) B-57B ENGINE (S): J65-W-5 | | 5 | CHART WT. I | T. LIMITS 39 | HIGH 39, 500 TO | T , 35, | ALTIT 35,000 POUNDS | HIGH ALTITUDE | DE | | | | | EXT. LOAD | 75 | NONE NES OPE | RATING | S:(ONE | ହ |
|---|-----------------|--|-------------|---|---|---|---|---|---|---|---|---|---|--|--|----------------------|-------------|-----------------------------|----------------------|
| IF YOU ARE AT 25000' | | IF YOU | AR | E AT 30000' | _ | YOU | IF YOU ARE AT 35000' | 35000 | _ | IF YOU | IF YOU ARE AT 40000' | 40000, | | | Ē | IF YOU ARE AT 45000' | E AT 4 | 2000, | |
| BY CRUISING OPT ALT. BY CRUISING AT 25000' 1000 FT. AT 0PT. ALT. | FUEL | BY CRUISING AT 30000' | 121 | DPT ALT. BY CRUISING 1000 FT. AT OPT. ALT. | | RANGE 151NG 0 | BY CRUISING OPT ALT. BY AT 35000' 1000 FT. AT | BY CRUISING AT OPT. ALT. | - | RAMGE IN AIRMI BY CRUISING OPT ALT. AT 40000' 1000 FT. | RAMGE IN AIRMILES ING OPT ALT. BY 1000 FT. AT | BY CRUISING AT OPT. ALT | ISING . ALT. | FUEL | BY CRUISING OPT ALT. AT 45000' 1000 FT. | RANGE 1 | | BY CRUISING AT OPT. ALT. | ING ALT. |
| | | (RANGE F | GURES | (RANGE FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | LOWANG | ES 70 | 2 PRESC | RIBED O | MM MB MB | DESCE | 0 1 | EALEV | EL EL | | | | IEI EI- | | |
| CRUISING AT 25000" | n n | CRU | CRUISING AT | AT 30000' | | CRUISI | CRUISING AT 35000' | ,2000; | - | CRUI | CRUISING AT 40000' | 40000, | \top | U 10 | | CRUISING AT 45000' | G AT 4 | 2000, | |
| APPROXIMATE | TIVE | | APPROXIMATE | ATE | | A | APPROXIMATE | TE | | | APPROXIMATE | IMATE | | TIVE | | AP | APPROXIMATE | ATE | |
| C.A.S. % /HR G.S. R.F. DOWN DIST. | MIND | C.A.S. % | /HR G.S. | R.F. DOWN DIST. | C.A.S. | RPM / | /нк G.S. | R.F. DO | LET C.A.S. DOWN DIST. | 8 g ¥ g | /HR G.S. | R.F. | LET DOWN DIST. | QNIA | C.A.S. | RPM /HR | 6.5 | F | LET DOWN DIST. |
| | 120 HW 80 HW | | | | | | | | | | | | | 120 HW 80 HW | | | | | |
| | 40 HW | | | | | | | | | | | | | 40 HW | | | | | |
| | 0 | | | | | | | | | | | | | 0 | | | | | |
| | 40 TW | | , | | | | | | _ | | | | | 40 TW | | 11 | | | |
| | 80 TW | | | | | _ | | | _ | | - w | | | 80 TW | | | | | |
| | 120 TW | | _ | | | _ | | | | | - | | _ | 120 TW | | | | | |
| SPECIAL NOTES Climb at 100, RPM Multiple Notifical water be 1 15 to about Statute | NOTES | 15 m | 25000 | ff you are at | 2000 | EX ft. wit | EXAMPLE with 10,0 | EXAMPLE 5000 ft. with 10,000 lb. of available | f availa | able | EFF | ECTIV | E WINI | LEGEND LEFFECTIVE WIND-HW, Headwind, TW, Tallwind-Knots | LEGEND Headwind | TW, Ta | ulwind | - Knof | R |
| units. 3 Read lower half of chart opposite effective wind only. 4 Make additional allowances for landing, navigational errors, combat, formation flight etc. as required. | t opposit | o octain or e effective ing, navigat as require | | tuel, you can My '15 nautical miles by holding '263 knots CAS. However, you can fly 870 nautical miles by immediately climbing to 15,000 ft. at 100% RPM. At 15,000 ft. cruise at 248 knots CAS. When reduced weight allows, continue climbs to and cruises at higher attitudes until 20,000 ft. is attained. At 20,000 ft. cruise at 230 knots CAS and start let down 5 nautical miles from home. With an 80 knot headwind, the range at optimum altitude would be '74 x 870 or 640 nauti- | h lly f Howeve ely clin ft, cruil ft, cruil s, cont il 20, 30 knote home. | 15 nau sr, you se at inue cl nue cl nue cl Noon K. CAS S CAS With a would | y '15 nautical miles by wever, you can fiy 870 climbing to 15,000 ft. cruise at 248 knots CA continue climbs to and continue climbs to and knots CAS and start let knots CAS and start let ie. With an 80 knot he tude would be '74 x 8 | an 119 '15 nautical miles by holding '263 However, you can fly 870 nautical miles ttely climbing to 15,000 ft. at 100% RPM. Ift. cruise at 248 knots CAS. When reduced ws, continue climbs to and cruises at higher til 20,000 ft. is attained. At 20,000 ft. 230 knots CAS and start let down 5 nautical home. With an 80 knot headwind, the range altitude would be '74 x 870 or 640 nauti- | s by holding 253 870 nautical miles 870 nautical miles CAS. When reduce nd cruises at highes nd. At 20,000 ft. I headwin 6, nautical t headwind, the raut x 870 or 640 naur | y holding 263 In natical miles at 100% RPM. S. When reduced ruises at higher At 20,000 ft. down 5 natical adwind, the range 370 or 640 natit- | | - Kange for co - Groun - Calibr HR-Fue GE-Na ANGE | ractor rrespo d speed ated al ated al cons utical IN PAF | K.FKange factor-katio of ground distance to airmiles G.SGround speed in Knois. CAS-Calbrated airspeed in Knois. LB/HR-Fuel consumption-Pounds per hour RANGE-Nautical miles () RANGE IN PARENTHESIS FOR INTER-POLATION PURPOSES ONLY | inds tis in Knots - Pounds SIS FOR | distance per ho | ce to air | rmiles | m |
| BASED ON: ESTIMATE DATA AS OF: 1 OCTOBER 1953 | 53 | | 5 | cal miles. Cruise at 250 knots C 4 nautical miles from destination. | Cruise a | at 25 | knots | Cruise at 250 knots CAS and start let down miles from destination. | start 1 | et dowr | | | ıı.u. | FUEL GRADE: JP-4 FUEL DENSITY: 6, 5 LB/GAL | NDE: JJ | P-4 5 LB/ | GAL | | |

Figure A-64

| igher (B) | Una de management alles | Etylse (fuel on beard minus allowance for rosorvo, combat, novigational cree, formation flight, asc,),Move horizontally right or for sorver. | T - Selec | ti figure in | CHA tivel colum | ENGINE(S) J65-W-5 CHART WT. LIMITS 44,000 WISTRUCTIONS FOR USING CHART: (A) IN FLIGHT - Select figure in fuel column equal to or less than fuel evallable for terutes (fuel more allowance electroserve, combot, novigational error, formation flight, etc.). Allowe hartsentelly right or | L IMIT | S an fuel o | STANDARD 44,000 TC | ₫ | TO 39, | TO 39, 500 POUI | POUNDS hown of optin | TO 39, 500 POUNDS NOTES: Renges shown or optimum elitive one chart (due to asternal configuration a | tilludes ord | NL maximum. | NDS NUMBER OF ENGINES OPERATING: (ONE) optimum obtitudes are maximum. In order to obtain maximum range on flights requiring more than configuration or gross weight changes), it is necessory to observe the optimum cruising altitude | NONE ENGINES O | NONE NONE OF ENGINES OPERATIN to obtain maximum range on Hights is necessory to observe the optim | ATING | : (ONE | core than |
|------------------------|--|--|--|--|--|--|--|--|---|-------------------|----------------------|----------------------|----------------------------|--|------------------------|----------------------------|---|-------------------------------------|---|-------------------|----------------------|-----------------------------|
| ances to range values. | ing to exerber altitude of meximum range. For a flight of initial citizate, operating so that altitude or by climb. For a flight of initial citizate, operating instructions are given directly below. For a flight of higher altitude, climb immediately to desired altitude and road errising instructions in operative training altitude section. (8) FLIGHT PLANNING. From initial fuel on board submoct fuel. for toke-off and climb to desired cruising altitude and all other necessary allowances. Then use chart as for IN FLIGHT above, adding initial climb distincts range values. | inge For a file finmediately to ING Fram ini | ght of its desired itial fue Then | altitude of the control of the contr | ude, operation wins and read eru is subtract as for IN | of by cruising of their altitude or by climb- ing instructions are given directly below, uising instructions in opporpriete cruising froit for take-off and climb to desired FLIGHT above, adding initial climb distr | g of that ions are crions in take-off ive, addir | alritude given dire oppropri- and climi | ising of that altitude or by climbi vortions are given directly below, structures in appropriate cruising for toke-off and climb to desired above, adding initial climb disti | 4 4 2 2 4 | lewances. | for descer | , when ch ni distance | anging of and fuel. DATA B | . Climb di ELOW COP | stance and t | on each chart; i.e., when changing charts a climb may be required to obtain a maximum runge. All range values include al- lowances for descent distance and fuct. Climb distance and fuel are included where climbs are indicated. DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | a maximu I where eli E FOR LA | mbs are it | All range | values in | elude of |
| | | | | | | | | | | | DATA AS | 0F: 1 (| DATA AS OF: 1 OCTOBER 1953 | ER 19 | 53 | | | BA | BASED ON: | ESTIMATE | MATE | |
| | | | | | | | L | MO | | AL | LTIT | an | ш | | | | | | | | | |
| ARE | IF YOU ARE AT S.L. | (1) | _ | IF YOU | IF YOU ARE AT 5000' | T 5000' | | = | YOU . | ARE A | IF YOU ARE AT 10000' | | 4 | YOU A | IF YOU ARE AT 15000' | 15000 | | (0) | IF YOU | ARE / | IF YOU ARE AT 20000' | .0 |
| IN AIR | RANGE IN AIRMILES | FUEL | | RAN | RANGE IN AIRMILES | MILES | | | RANGE | RANGE IN AIRMILES | ILES | T | | RANGE | RANGE IN AIRMILES | ES | FUEL | 1 | RANC | RANGE IN AIRMILES | MILES | |
| AT S.L. 1000 FT | T. BY CRUISING T AT OPT.ALT. | POUNDS | 1000 | Y CRUISING AT 5000" | BY CRUISING OPT. ALT. AT 5000' 1000 FT | T. BY CRUISING | | BY CRUISING AT 10000" | | OPT. ALT. | | BY CRUISING I | BY CRUISING AT 15000' | _ | OPT. ALT. | BY CRUISING AT OPT.ALT. | POUNDS | | BY CRUISING AT 20000" | OPT. ALT. | AT O | BY CRUISING AT OP T.ALT. |
| | | | (RA | (RANGE FIGURES | GURES | INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL(1) | ALLC | WANC | ES FOR | PRES | CRIBEL | CLIME | 3 & DES | CENT | TO SEA | LEVEL | (1) | - | | | - | |
| 15 | 1290 | 15, 158 | | 1070 | 15 | П | 1310 | 1190 | 06 | 15 | 13: | 1325 | 1305 | - | 15 | 1340 | 15,158 | 60 | | | 4 | |
| 15 | 1170 | 14,000 | | 980 | 15 | 1 | 1190 | 1090 | 90 | 15 | 1205 | 05 | 1195 | | 15 | 1220 | 14,000 | 10 | | ĺ | | |
| 12 | 975 | 12,000 | | 910 | 15 | 3 | 1090 | 1005 | 920 | 15 | 1110 | 15 | 1105 | 10 :- | 15 | 1130 | 13,000 | 0.0 | | | | |
| 15 15 | 880 795 | 11,000 | | 0890 | 15 | 3, 30 6 | 900 | 8 7 | 840 | 15 | 66 80 | 920 | 925 | | 15 | 940 | 11,000 | 0.0 | | | - | |
| 1 | 20 | 2,000 | | 000 | CT | | 07 | Ö | 080 | CT | | 745 | 760 | | 15 | 160 | 9,000 | _ | | | | |
| 15 15 15 | 620 535 455 | 8,000 7,000 6,000 | | 555 490 425 | 15 15 15 | - m 4 | 640 555 475 | 615 545 470 | 615 545 470 | 15 15 15 | 572 | 655 570 490 | 675 595 520 | | 111 | 111 | 8,000 7,000 6,000 | - | | | | |
| NG A | CRUISING AT S.L. | 0000 | | CRUI | CRUISING AT | T 5000' | | | CRUISING AT 10000' | MG AT | 100001 | 1 | 0 | RUISIN | CRUISING AT 15000' | 2000 | _ | - | CRU | SING A | CRUISING AT 20000' | |
| APPROXIMATE | | TIVE | ·s | | APPROXIMATE | IMATE | | - | A | APPROXIMATE | ATE | | 7 | AP | APPROXIMATE | 1 | EFFEC. | _ | | APPROXIMATE | MATE | |
| L.Bur G.S. | R.F. DOWN DIST. | | C.A.2 | RPM LAHR | HR G.S. | ж. г. | LET DOWN DIST. | C.A.5 | RPM LBHR | R G.S. | R.F. | LET DOWN DIST. | C.A.5 | L.B. | 6.5 | R.F. DOWN | QNIN N | .2.A.5 | % da | /HR G.S. | | DOWN |
| | | 120 HW | | | | | | | | | | - | - | | | | 120 HW | | | + | | 5 |
| | | 80 HW | | | | | | 291 9 | 96 4800 | 0 256 | . 73 | 23 | 1 | - | 1 | - | WH 08 | | | | | |
| 5020 255 | 3 .85 0 | 40 HW | 287 | 93 47 | 4770 269 | . 85 | - | 280 | 94 4500 | 0 283 | . 86 | 2 2 | 270 96 | 4280 | 293 | .86 3 | 40 HW | | | - | | |
| 4680 280 | 0 00.1 | 0 | 273 | 91 4420 | 120 293 | 1.00 | 1 2 | 265 9 | 93 4190 | 306 | 1.00 | 2 2 | 260 95 | 4030 | 322 | 1.00 3 | ۰ | | | - | | _ |
| 4480 307 | 1.15 0 | 40 TW | 267 | 91 41 | 4140 327 | 1,15 | 1 2 | 260 9 | 93 4090 | 341 | 1, 14 | 2 2 | 253 95 | 3980 | 356 | 1.12 3 | WT 07 | | | - | | _ |
| | | WT 08 | | | | | | 254 9 | 92 3990 | 374 | 1.28 | 2 | 249 94 | 3910 | 391 | 1.26 4 | WT 08 | | _ | | | _ |
| | | | | | | | | | | | | | | | | | | | | | | |

Figure A-65

| IRCRAF | AIRCRAFT MODEL (S) | (S) B-57B | m | | | I | U U U | ALI | HIGH ALTITUDE | ш | | | EXI. LOAD | NONE INONE | | |
|--|--|--|---|---|------------------------|--|--|---|--|--|----------------------|--|--|---|--|---------------------------------|
| ENGINE (S): | S): J65-W-5 | W-5 | | Ō | CHART WT. | T. LIMITS 44, | 44,000 TO | 39, 500 POUNDS | SUNDO | | | | NO. 0F | ENGINES | OPERAT | NO. OF ENGINES OPERATING: (ONE) |
| IF YC | IF YOU ARE AT 25000' | 25000' | | IF YOU | ARE | AT 30000' | IF YC | IF YOU ARE AT 35000' | 35000, | IF YOU | IF YOU ARE AT 40000' | ,0000 | | IF YOU | IF YOU ARE AT 45000' | r 45000° |
| R | RANGE IN AIRMILES | ILES | FUEL | 2 | RANGE IN AIRM | AIRMILES | RA | RANGE IN AIRMILES | LES | RAN | RANGE IN AIRMILES | ES | FUEL | RA | RANGE IN AIRMILES | MILES |
| AT 25000" | BY CRUISING OPT ALT. AT 25000" 1000 FT. | BY CRUISING AT OPT. ALT. | | BY CRUISING AT 30000' | G OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | | OPT ALT. 1000 FT. | BY CRUISING OPT ALT. BY CRUISING AT 35000' 1000 FT. AT OPT. ALT. | BY CRUISING OPT ALT. AT 40000' 1000 FT. | | BY CRUISING AT OPT. ALT. | | BY CRUISING AT 45000" | 1000 FT. | BY CRUISING AT OPT. ALT |
| | | | | (RANGE FIGURE | FIGURES | S INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | LOWANCES | FOR PRES | CRIBED CLI | AB & DESCE | NT TO SE | A LEVEL) | | | | |
| | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | |
| 110 | | 11 | | | | 100 | 31 | | | | | | | | | |
| 11 | | | | l lit | | | | | | | | | | | | |
| 2 | OUR AT 25000 | 25000 | | 80 | CRITISING AT | AT 30000' | CR | CRUISING AT 35000' | 35000' | CRU | CRUISING AT 40000' | ,00001 | | CR | CRUISING AT 45000' | T 45000' |
| 5 | APPROXIMATE | LATE | - EFFEC. | | | MATE | | APPROXIMATE | ATE | | APPROXIMATE | ATE | TIVE | | APPRO | APPROXIMATE |
| C.A.S. % | /HR G.S. | R.F. DOWN | T- | C.A.S. % | | S. R.F. DOWN | C.A.S. % | /HR G.S. | R.F. DOWN | C.A.S. RPM | /HR G.S. | R.F. DOWN DIST. | MIND | C.A.S. SRPM | /HR | G.S. R.F. DOWN |
| | | | 120 HW | | | | | | | | | | 120 HW | | | |
| - | | | 80 HW | | | | | | | | | | 80 HW | | | |
| | | | 40 HW | | | | | | | | + | | 40 HW | | | |
| | | | ۰ | | | | | | | | | | 0 | | | |
| | | | 40 TW | | | | | | | | | | 40 TW | | | 10 |
| | | | WT 08 | | | | | | | | | | WT 08 | | | |
| | | | 120 TW | | | | | | | | - | | 120 TW | | | |
| 1 Climb at 2 Multiple units. 3 Read low only. 4 Make add errors, con | tiple Nittle of lower ceaddition, comba | SPECIAL NOTES 1 Climb at 100% RDM 2 Multiple Nautical units by 1.15 to obtain Statute units. 3 Read lower half of chart opposite effective wind only. 4 Make additional allowances for landing, navigational errors, combat, formation flight etc. as required. BASED ON: ESTIMATE | SPECIAL NOTES DM al units by 1.15 i of chart oppositiowances for lan rmation flight etc | to obtain the effectifieding, navigor, as requif | | If you are at S. L. with 15,158 lb. of available fuel, you can fly 950 nautical niles by holding 280 knots CAS. However, you can fly 1290 nautical miles by immediately climbing to 15,000 ft. at 100% RPM. At 15,000 ft. cruise at 280 knots CAS. When reduced weight allows, continue climbs to and cruises at higher altitudes until 20,000 ft. is attained. At 20,000 ft. cruise at 230 knots CAS and start let down 5 nautical miles from home. With an 80knot tailwind, the range at optimum altitude would be 1,29 x 1290 or 1660 nautical miles. Cruise at 212 knots CAS and start let handles are supplied at the supplied at t | EXAMPLE Tre at S. L. with 15,158 lb. of a n fly 950 nautical miles by holding the worder, you can fly 1290 nautical miles by the nautical miles by the nautical miles by the nautical continue climbs to and cress until 20,000 ft. is attained. A at 230 knots CAS and start let do at 230 knots CAS and start let do from home. With an 80knot tailw mum altitude would be 1.29 x 12 miles. Cruise at 212 knots CAS and estimation. | th 15,158 and 19,158 and 19,159 and 19,000 to 15,000 to | EXAMPLE If you are at S. L. with 15,158 lb. of available fuel, you can fly 950 nautical miles by holding 280 knots CAS. However, you can fly 1290 nautical miles by immediately climbing to 15,000 ft. at 100% RPM. At 15,000 ft. cruise at 260 knots CAS. When reduced weight allows, continue climbs to and cruises at higher altitudes until 20,000 ft. is attained. At 20,000 ft. cruise at 230 knots CAS and start let down 5 nautical miles from home. With an 80knot tailwind, the range at optimum altitude would be 1.29 x 1290 or 1660 nautical miles. Cruise at 212 knots CAS and start let hown 5 nautical miles. Cruise at 212 knots CAS and start let hown 6 nautical miles. Cruise at 212 knots CAS and start let hown 6 nautical miles. Cruise at 212 knots CAS and start let | liable fuel, 280 knots miles by % RPM. When reduces at higher 20,000 ft. 5 hautics 14, the rang for 1660 and startle | | LEGEND LEGEND R.FRange factor-Ratio of ground distance to airmiles for corresponding winds G.SGround speed in Knots CAS-Calibrated airspeed in Knots LB/HR-Puel consumption-Dounds per hour RANGE-Nautical miles () RANGE IN PARENTHESIS FOR INTER- POLATION PURPOSES ONLY FUEL GRADE: JP-4 FUEL GRADE: JP-4 | LEGEND ND-HW, Headwind or-Ratio of ground ponding winds ed in Knots at speed in Kn ansumption-Dound huntes ARENTHESIS FO PURPOSES ONLY FUEL GRADE: FUEL GRADE: | LEGEND LEGEND Headwind, T of ground di winds Knots di in Knots on-Pounds p HESIS FOR I SES ONLY SRADE: JF | TW Tallwind- distance to ali size s per hour R INTER- JP-4 6.5 LB/GAL | oairmiles |

Figure A-66

| AIRCRAFT MODEL (S) | MODEL (S) B-57B | m. | | | | H | T | AL | HIGH ALTITUDE | DE | | | | B | EXT. LOAD | | NONE | | |
|---|--|----------------------|--|----------------------------|--|---|---|---|--|--|--|--------------------------------|--|---|---|-------------------------------|--|--------------------|----------------------------|
| ENGINE (S): | J65-W-5 | | 0 | CHART WT. LIMITS 48, 500 | LIMITS 48 | ,500 | TO 44 | TO 44,000 POUNDS | SUNDS | | | | | z | 0, 0F E | ENGINE | NO. OF ENGINES OPERATING:(ONE) | TING:(| ONE) |
| IF YOU | IF YOU ARE AT 25000' | | IF YOU | AR | E AT 30000' | - | IF YOU | IF YOU ARE AT 35000 | 35000, | _ | IF YOU | IF YOU ARE AT 40000' | 40000, | - | - | IF YC | IF YOU ARE AT 45000" | AT 450 | .00 |
| RANG | RANGE IN AIRMILES | FUEL | | RANGE IN AIR | AIRMILES | - | RAN | RANGE IN AIRMILES | ILES | - | RANG | RANGE IN AIRMILES | ILES | FUEL | EL | 000 | RANGE IN AIRMILES | IRMILES | |
| AT 25000" | OPT ALT. BY CRUISING 1000 FT. AT OPT. ALT | | BY CRUISING AT 30000' | 4G OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | | AT 35000" | AT 35000' 1000 FT. | BY CRUISING AT OPT. ALT. | | BY CRUISING AT 40000" | OPT ALT. 1000 FT. | BY CRUISING AT OPT. ALT. | ING NLT. | as 7 | BY CRUISING AT 45000" | 46 OPT ALT. 1000 FT. | | BY CRUISING AT OPT. ALT |
| | | | (RANGE | FIGURES | NCLUDE | ILLOWA | NCES F | OR PRES | FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA LEVEL) | LIMB & | DESCE | NT TO S | EA LEVE | 3 | | | | | |
| | | | | | | | | | | | | | | | | | | | |
| 8 | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | |
| CRUIS | CRUISING AT 25000' | 0 | | CRUISING AT | AT 30000' | - | CRUI | CRUISING AT 35000' | 35000' | - | CRUIS | CRUISING AT 40000 | 40000 | - | | 8 | CRUISING AT 45000" | AT 4500 | .00 |
| 4 | APPROXIMATE | TIVE | 1176 | APPROXIMATE | MATE | | | APPROXIMATE | ATE | | | APPROXIMATE | MATE | ĒĒ | TIVE | | APPR | APPROXIMATE | |
| .A.S. 75 | /HR G.S. R.F. DOWN DIST. | | C.A.S. % | /HR G.S. | R.F. | LET C.A.S. DOWN DIST. | RPM | /ня с.5. | R.F. DOWN DIST. | T. C.A.S. | R P M | /HR G.S. | R.F. | LET WIND DOWN DIST. | | C.A.S. F | HH/ | G.S. R. | R.F. DOWN DIST. |
| | | 120 HW 80 HW | | | | | | | | | | | | 120 HW 80 HW | A A | | | | |
| | | 40 HW | | Mar es | | | | | | | | 7 | | 40 HW | A | | | - | |
| | | 0 | | | | | | | | | | | | ۰ | | | | | |
| | | 40 TW | | | | | | | | _ | | | 5.4 | 40 TW | W | | | | |
| | | 80 TW | | | | | | | | | | | | 80 TW | AL. | | | - | - |
| | | 120 TW | | | | | | | | _ | | - | | 120 TW | I.W | - | | \dashv | - |
| 1 Climb 2 Multipl units. 3 Read 1 only. 4 Make ac | SPECIAL NOTES 1 Climb at 100% RPM 2 Multiple Nautical units by 1.15 to obtain Statute units. 3 Read lower half of chart opposite effective wind only. 4 Make additional allowances for landing, navigational errors, combat, formation flight etc. as required. | by 1.15 trt opposite | to obtain e effectiv ing, navig as requir | THE PERSON NAMED IN COLUMN | f you are ou can fly. AS. How nediately 0,000 ft. eight allo ltitudes ur | at 5000 950 n ever, y climbin cruise ws, cor ntil 20, | ft. w autical ou can 5 to 10 at 274 at 274 tinue c 000 ft. ts CAS | EXAMPLE vith 14,0 vith 14,0 vith 14,0 vith 108 vith 108 vith 108 vith 108 vith 108 vith is atta | EXAMPLE If you are at 5000 ft. with 14,000 lb. of available fuel, you can fly 950 nautical miles by holding 282 knots CAS. However, you can fly 1085 nautical miles by immediately climbing to 10,000 ft. at 100% RPM. At 10,000 ft. cruise at 274 knots CAS. When reduced weight allows, confinue climbs to and cruises at higher altitudes until 20,000 ft. is attained. At 20,000 ft. cruise at 230 knots CAS and start let down 5 nautical | availa 282 k 1 miles 5 RPM. en redu ses at 20,000 n 5 m | ble fuel nots by im-At ceed righer ft. | Specific Company State Company | ECTIVE -Range for cor- Ground -Calibra IR-Fuel 3E-Nauf | LEGEND EFFECTIVE WIND-HW, Headwind, TW, Tailwind-Knots R.FRange factor-Ratio of ground distance to airmiles for corresponding winds G.SGround speed in Knots. LEV/HR-Fuel consumption-Pounds per hour RANGE-Nautical miles () RANGE IN PARENTHESIS FOR INTER-POLIATION PURPOSES ONLY | LEGEND W, Headwir tio of groun mg winds Knots. Enots. tion- Poun sts. THESIS F' | END dwind, T round d ds Knots | 'W, Tailt istance per hour | wind- k to airu | Snots offes |
| BASED ON: DATA AS OF: | : ESTIMATE | 953 | | псып | miles from home. With an 40 at optimum altitude would be ,8 cal miles. Cruise at 239 knots (nautical miles from destination. | altitud Cruise les fron | With e would at 239 n desti | an 40 k d be .86 knots C. nation. | miles from home. With an 40 knot headwind, the range at optimum altitude would be .86 x 1085 or 934 nautical miles. Cruise at 239 knots CAS and start let down 4 nautical miles from destination. | vind, tl or 93 art let | e range 4 nauti- down 4 | | | FUEL | GRAD | E: JI ITY: 6. | FUEL GRADE: JP-4 FUEL DENSITY: 6.5 LB/GAL | AL | |

Figure A-67

| | ENGINE(3) | | | | | CHAI | CHART WT. LIMITS | IMITS | 48, 500 | | | 10 44, | 44,000 4 | POUNDS | ~ | | ž | NUMBER OF | ENGI | ENGINES OPERATING: (ONE) | ERATIN | 4G:(O) | (T) |
|---|--|--|--|--|--|---|--|---|--|---|----------------------|---|---|--|--|---|---|--|--|----------------------------------|--|--|----------------------------|
| STRUCTIONS Its (fuel on by Its section or Its another al Its flight of h Itude section. | FOR USI recording lititude of higher alt (B) FLI | INSTRUCTIONS FOR USING CHART: (A) IN FLIGHT - Solact figure in fuel column equal to ar less than fuel available for etulse (fuel an based minus allowance for reserve, combat, navigational error, formation flight, etc.). Move hartsandily right or test to section according to present altitude and road trains are another altitude or prosent altitude and road present altitude, or a flight or interiors are given directly below. For a flight at initial altitude, perential instructions in oppropriate crusing altitude accising instructions in oppropriate crusing altitude section. (B) PLIGHT PLANNING · From initial fuel on board subtract fuel for take off and climb to devised crusing altitude and all other necessary allowances. Then use chart as for IN FLIGHT above, adding initial climb distributed in the contract of the provential climb of site of the contract of the provential climb of site of the contract of the provential climb of site of the contract of the provential climb of site of the contract of the provential climb of site of the contract of the provential climb of site of the contract of the provential climb of site of the contract of the provential climb of site of the contract of the provential climb of site of the contract of the provential climb of the contract of the contract of the provential climb of the contract of the contra | A) IN FLIGHT reserve, comba de and read to i. For a fligh mediately to d G - Fram init allowances. | Select ot, novige stal range st at init desired al rial fuel Then us | figure in I ational orr s available Hist altitude and on board | fuel column or, formation b (no wind) de, operation d read cruits subtract | man equal to or less than fuel available for ition flight, etc.).Move horizontally right or of) by cruising at that altitude or by climb- tryising instructions are given directly below. versing instructions are appropriate cruising instructions in appropriate cruising to fuel for take-off and climb to desired t PLIGHT above, adding initial climb disti | r less that a of that a of that a income in a creations in a cake-off air | n fuel av norizontal lititude or ven direc ppropriet nd climb | to or less than fuel available for ising at their elitiude or by climb- uctions are given directly below. succinos in operprise cruising for take-off and climb to desired above, adding initial climb dist- | 2 St & 1000 77 | OTES: R no chart (n cach ch wancas fe | NOTES, Ranges shown of optimum altitudes are maximum. once chart (due to external configuration or gross weight chan each chart; i.e., when changing charts a climb may be relevances for descent distance and fuel. Climb distance and levences for Covins of Stance and DATA BELOW CONTAIN NO | wn of optional co- when che distance | imum alt riguratio nging cho and fuel. DATA BE | itudes ere n er gross arts e climb Climb dis | maximum. weight cl b may be r tance and | NOTES: Ranges shown of optimum altitudes are maximum. In order to obtain maximum range on flights requiring mane than one chart (due to external configuration or gross weight changes), it is necessary to observe, the optimum erusing altitude on each chart; i.e., when changing charts a climb may be required to obtain a maximum range. All range values include allowances for descent distance and fuel. Climb distance and fuel are included where climbs are indicated. DATA BELOW CONTAIN NO FUEL RESERVE FOR LANDING | tain maxi necessory in a max cd where | to abservent mum range climbs ar | on flight to the option 9. All rem e indicate | s requirin mum cruis ige values id. | g more the ing altitu |
| ances to range values. | olues. | | | | | | | | | | - | ATA AS | DATA AS OF: 1 OCTOBER 1953 | CTOBE | R 195 | 3 | | | | BASED ON: ESTIMATE | N. EST | IMAT | (1) |
| | | | | | | | | 2 | 3 0 | | ALTI | H | 00 | ш | | | | | | | | | |
| IF YOU ARE AT S.L. | IRE AT | S.L. | (1) | | IF YOU ARE | | AT 5000' | | F | IF YOU ARE AT 10000' | RE AT | 100001 | | F | YOU A | IF YOU ARE AT 15000' | 2000, | _ | (E) | .⊬ ∀ | IF YOU ARE AT 20000' | E AT 2 | .0000 |
| RANGE | RANGE IN AIRMILES | LES | FUEL | | RANG | | MILES | | | RANGE | RANGE IN AIRMILES | LES | T | | RANGE | RANGE IN AIRMILES | ES | FUEL | با | 2 | RANGE IN AIRMILES | AIRMILE | 2 |
| BY CRUISING OPT. ALT. AT S.L. 1000 FT | PT. ALT. | BY CRUISING AT OP T.ALT. | POUNDS | | Y CRUISING AT 5000' | BY CRUISING OPT. ALT. AT 5000' 1000 FT | BY CRUISING AT OPT.ALT. | | BY CRUISING AT 10000" | | OPT. ALT. 1000 FT | BY CRUISING AT OPT.ALT. | | BY CRUISING AT 15000' | | 0PT. ALT. 1000 FT | BY CRUISING AT OPT.ALT. | ING POUNDS | 0 | T CRUISING AT 20000" | 0 | | BY CRUISING AT OPT.ALT. |
| | | | | (RA) | IGE FIC | BURES I | (RANGE FIGURES INCLUDE ALLOWANCES FOR PRESCRIBED CLIMB & DESCENT TO SEA | ALLO | WANC | ES FOR | PRES | CRIBED | CLIMB | & DES | CENT | TO SEA | LEVEL (1) | (E) | | | | | |
| 915 | 10 | 1140 | 15, 158 | Ξ | 1120 | 10 | 11 | 1165 | 1125 | 2 | 10 | 1180 | 0 | | | | | 15, 158 | 158 | | | | |
| 850 | 10 | 1070 | 14,000 | 6 | 950 | 10 | 10 | 1085 | 1050 | 0 | 10 | 1105 | n) | | - | | | 14,000 | 000 | | | | |
| 190 | 10 | 1005 | 13,000 | .00 | 885 | 10 | 10 | 1020 | 980 | 0 | 10 | 1030 | 0 | | | | | 13,000 | 000 | | | | |
| 735 | 10 | 935 | 12,000 | 00 | 820 | 10 | 6 | 950 | 910 | 0 | 10 | 965 | 5 | | | | | 12,000 | 000 | | | | |
| 675 | 10 | 860 | 11,000 | | 092 | 10 | 80 | 875 | 840 | 0 | 10 | 890 | 0 | | | | | 11,000 | 000 | | | | |
| 615 | 10 | 785 | 10,000 | 9 | 695 | 10 | 8 | 805 | 770 | 0 | 10 | 820 | 0 | | | | | 10,000 | 000 | | | | |
| CRUISING AT S.L. | NG AT | S.L. | | | CRUI | CRUISING AT | AT 5000* | | | CRUISI | CRUISING AT 10000' | 100001 | 1 | | RUISIN | CRUISING AT 15000' | 2000, | L | - | ٥ | CRUISING AT 20000' | 3 AT 20 | ,0000 |
| API | APPROXIMATE | \TE | EFFEC. | | | APPROXIMATE | IMATE | | - | A | APPROXIMATE | ATE | | -5 | AP | APPROXIMATE | TE | | | -, | APP | APPROXIMATE | |
| RPM LBHR | R G.S. | R.F. DOWN | - | 2.A.5 | % LE | LB c.s. | R.F. | LET DOWN DIST. | 2.A.5 □ ~ ~ | RPM LBHR | R G.S. | R.F. | LET DOWN DIST. | % % % | /HR | 6.5 | R.F. D | LET WIN | | .A.D | /HR | G.S. | R.F. DOWN DIST. |
| | | | 120 HW | | | | | | | | | | | | | | | 120 HW | * | | | | |
| _ | | | WH 08 | | | | | | 5.2 | | | | | | | | | 80 HW | A. | _ | | - | |
| 302 93 5390 | 5390 262 | . 85 0 | WH 00 | 296 | 95 51 | 5140 278 | . 85 | 1 | 291 96 | 96.5 5130 | 0 298 | . 86 | 2 | | ш | | | 40 HW | M. | - | | | |
| 288 92 5030 | 0 288 | 1.00 0 | 0 | 282 | 93 47 | 4780 303 | 1.00 | 1 | 274 95 | 3 4600 | 0 317 | 1.00 | 2 | | | | | 0 | 000 | _ | | | |
| 276 91 4790 | 4790 316 | 1,15 0 | 40 TW | 276 | 93 46 | 4640 338 | 1.15 | 1 | 273 95 | 2 4600 | 0 356 | 1.13 | 62 | | | | | 40 TW | 2 | _ | | | |
| | | | 80 TW | - | | | | | 268 94 | 4 4470 | 390 | 1.26 | 2 | - | | | | 80 TW | I.W. | H | | **** | |
| | | | | | | | | | | | | | | | | | | | | | | | |

Figure, A-68

STANDARD DAY

| CONFIGU WEIGHT: | RATION. CLEA 30,5 | AN 00 POUND | S | CONFIGUR WEIGHT: | RATION: | | | |
|------------------------------|----------------------|----------------|-------|--------------------------------------|---------|-------------|--------|--------|
| APPRO | XIMATE | | | PRESSURE | | | APPROX | CIMATE |
| ERPM | MI/ LB | MACH NO. | KNOTS | ALTITUDE FEET | CAS | NO. | MI/ | 3RPM |
| 78 | .0600 | . 41 | 272 | SEA LEVEL | | | | |
| 79 | .0705 | . 43 | 261 | 5,000 | | | | |
| 79 | . 0815 | . 46 | 251 | 10,000 | | | | |
| 80 | . 0923 | . 48 | 243 | 15,000 | | | | |
| 80 | .1044 | . 52 | 239 | 20,000 | | | | |
| 81 | . 1185 | .58 | 238 | 25,000 | | | | |
| 82 | . 1358 | . 63 | 235 | 30,000 | | | | |
| 83 | , 1541 | .68 | 227 | 35,000 | | | | |
| 85 | . 1694 | . 73 | 215 | 40,000 | | | | |
| 90 | . 1767 | .74 | 194 | 45,000 | | | | |
| | | | | 50,000 | | | | |
| CONFIGUR WEIGHT: APPRO | XIMATE | 201 | | CONFIGUR WEIGHT: | | | APPRO) | (IMATE |
| %RPM | MI/ | MACH NO. | CAS | ALTITUDE FEET | CAS | MACH ND. | MI/ | %RPM |
| | | | | SEA LEVEL | | | | |
| | | | | 5,000 | | | | |
| | | | | 10,000 | | | | |
| | | | | | | | | |
| | | | | 15,000 | | | | |
| | | | | 15,000 20,000 | | | | |
| | | | | | | • 10 | | |
| | | | | 20,000 | | • | | |
| | | | | 20,000 25,000 | | · 10 | | |
| | | | | 20,000 25,000 30,000 | | • | | |
| | | | | 20,000 25,000 30,000 35,000 | | | | |

CAS - CALIBRATED AIRSPEED KNOTS
MILE- NAUT MILES PER POUNT

DATA AS OF: 1 OCTOBER 1953
DATA BASIS: ESTIMATE

 $\begin{array}{ll} \text{FUEL GRADE:} & JP\text{-}4 \\ \text{FUEL DENSITY:} & 6.5 \text{ } LB/\text{GAL} \end{array}$

STANDARD DAY

MODEL(S) B-57B

ZERO WIND

ENGINE(5): (TWO) J65-W-5

CONFIGURATION. CLEAN WEIGHT: 48,500 I

48,500 POUNDS

CONFIGURATION: CLEAN WEIGHT:

44,000 POUNDS

| APPRO | KIMATE | (deponden | | PRESSURE | | | APPROX | IMATE |
|-------|--------|-------------|-------|------------------|-------|-------------|--------|-------|
| SRPM | MI/ LB | MACH NO. | KNOTS | ALTITUDE FEET | KNOTS | MACH NO. | MI/ LB | %RPM |
| 82 | . 0539 | . 45 | 298 | SEA LEVEL | 293 | . 44 | . 0556 | 81 |
| 82 | .0611 | . 49 | 299 | 5,000 | 290 | . 48 | . 0633 | 81 |
| 83 | .0685 | .54 | 299 | 10,000 | 287 | . 52 | .0714 | 82 |
| 85 | .0767 | . 59 | 298 | 15,000 | 286 | . 56 | .0799 | 83 |
| 86 | . 0852 | .64 | 296 | 20,000 | 284 | . 62 | .0890 | 84 |
| 87 | .0960 | .68 | 283 | 25,000 | 277 | .67 | . 1010 | 85 |
| 88 | . 1057 | . 71 | 266 | 30,000 | 262 | . 70 | .1130 | 86 |
| 90 | .1116 | . 73 | 244 | 35,000 | 244 | . 73 | , 1212 | 88 |
| | | | | 40,000 | 221 | . 74 | .1250 | 93 |
| | | | | 45,000 | | | | |
| | | | | 50,000 | | | | |

CONFIGURATION. CLEAN 39,500

39,500 POUNDS

CONFIGURATION: CLEAN WEIGHT: 35,000 POUNDS

| APPROX | KIMATE | | | PRESSURE | | 4.44 | APPROX | MATE |
|--------|--------|-------------|-------|------------------|-------|------|--------|------|
| %RPM | MI/ LB | MACH NO. | KNOTS | ALTITUDE FEET | KNOTS | NO. | MVLB | %RPM |
| 80 | . 0570 | . 43 | 286 | SEA LEVEL | 279 | . 42 | . 0586 | 79 |
| 81 | .0656 | . 46 | 280 | 5,000 | 271 | . 45 | .0679 | 80 |
| 81 | .0745 | . 50 | 275 | 10,000 | 263 | . 47 | .0778 | 80 |
| 82 | . 0836 | .54 | 272 | 15,000 | 259 | .51 | .0878 | 81 |
| 83 | .0938 | .59 | 270 | 20,000 | 255 | .56 | . 0986 | 81 |
| 84 | . 1063 | . 64 | 267 | 25,000 | 254 | .61 | .1117 | 82 |
| 85 | . 1200 | .68 | 256 | 30,000 | 247 | . 66 | . 1272 | 83 |
| 86 | . 1320 | .72 | 241 | 35,000 | 235 | .70 | . 1429 | 84 |
| 90 | . 1380 | .74 | 220 | 40,000 | 220 | .74 | . 1532 | 88 |
| | | | | 45,000 | 195 | .74 | . 1550 | 93 |
| | | | | 50,000 | | | | |

REMARKS:

CAS - CALIBRATED AIRSPEEDKNOTS
MI/LB NAUT MILES PER POUNI

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

FUEL GRADE: JP-4 FUEL DENSITY:6.5 LB/GAL

STANDARD DAY

MODEL(S) B-57B

ZERO WIND

ENGINE(S): (TWO) J65-W-5

CONFIGURATION. 2 X 320 GAL WING TIP TANKS WEIGHT: 35,300 POUNDS

CONFIGURATION: 2 X 320 GAL WING TIP TANKS WEIGHT: 30,800 POUNDS

| APPRO | XIMATE | MACH | CAS | PRESSURE | | WILLIAM S | APPROX | IMATE |
|-------|--------|------|-------|------------------|-------|-------------|--------|-------|
| %RPM | MI/LB | NO. | KNOTS | ALTITUDE FEET | KNOTS | MACH NO. | MI/LB | %RPM |
| 79 | . 0569 | . 41 | 268 | SEA LEVEL | 261 | .39 | . 0583 | 78 |
| 80 | . 0653 | . 44 | 264 | 5,000 | 254 | . 42 | .0678 | 78 |
| 80 | .0743 | , 47 | 259 | 10,000 | 247 | . 45 | .0777 | 79 |
| 81 | .0842 | .51 | 254 | 15,000 | 241 | . 48 | .0882 | 79 |
| 82 | .0947 | . 55 | 251 | 20,000 | 236 | .52 | . 1003 | 80 |
| 83 | . 1068 | .60 | 246 | 25,000 | 232 | . 56 | .1135 | 81 |
| 84 | . 1210 | . 64 | 240 | 30,000 | 226 | .61 | . 1290 | 82 |
| 85 | . 1358 | . 69 | 230 | 35,000 | 222 | . 67 | . 1463 | 83 |
| 89 | .1454 | . 73 | 219 | 40,000 | 214 | . 72 | . 1605 | 87 |
| | | | | 45,000 | 193 | . 73 | . 1672 | 92 |
| | | | | 50,000 | | | | |

CONFIGURATION. WEIGHT:

CONFIGURATION: WEIGHT:

| APPRO | KIMATE | 4451 | CAS | PRESSURE | | | APPRO | KIMATE |
|-------|--------|-------------|--------|------------------|---------|-----|--------|--------|
| %RPM | MIZ | MACH NO. | CAS | ALTITUDE FEET | CAS | NO. | MI/ | %RPM |
| | | | HE | SEA LEVEL | | T. | ilias. | |
| | | | 1/12 | 5,000 | | | | |
| 111 | | | | 10,000 | | | Me. | |
| | | | 110 | 15,000 | and the | | (arri) | |
| | | | | 20,000 | | | 1881 | |
| | | | line 1 | 25,000 | | | | |
| | | | | 30,000 | | | I IMI. | |
| | | | | 35,000 | | | | |
| | | | 1.11. | 40,000 | | | | |
| | | | 7 | 45,000 | | | | |
| | | | | 50,000 | | | | |

REMARKS:

CAS - CALIBRATED AIRSPEED KNOTS
MI/L B NAUT MILES PER POUND

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

FUEL GRADE: JP-4 FUEL DENSITY: 6.5 LB/GAL

STANDARD DAY

MODEL(S) B-57B

ZERO WIND

ENGINE(S): (TWO) J65-W-5

CONFIGURATION. 2 X 320 GAL WING TIP TANKS

WEIGHT:

53,000 POUNDS

WEIGHT:

CONFIGURATION: 2 X 320 GAL WING TIP TANKS

48, 800 POUNDS

| APPRO | XIMATE | | | PRESSURE | | HACH | APPROX | IMATE |
|-------|--------|-------------|-------|------------------|-------|------|--------|-------|
| SRPM | MI/ LB | MACH NO. | KNOTS | ALTITUDE FEET | KNOTS | NO. | MI/ LB | 38RPM |
| 82 | .0511 | . 44 | 293 | SEA LEVEL | 288 | . 44 | .0521 | 82 |
| 83 | .0578 | . 49 | 297 | 5,000 | 291 | . 48 | . 0589 | 83 |
| 84 | . 0647 | .54 | 298 | 10,000 | 292 | . 53 | . 0660 | 84 |
| 86 | .0719 | . 59 | 296 | 15,000 | 291 | .58 | .0734 | 85 |
| 87 | .0804 | . 63 | 290 | 20,000 | 285 | . 62 | .0821 | 87 |
| 88 | .0904 | .67 | 279 | 25,000 | 277 | .67 | .0918 | 88 |
| 89 | .0985 | .71 | 265 | 30,000 | 265 | . 71 | . 1002 | 89 |
| 91 | . 1041 | . 73 | 245 | 35,000 | 245 | . 73 | . 1057 | 91 |
| | TO . | ETY | DIS. | 40,000 | | | | |
| | (11) | | B1 | 45,000 | | | | |
| | | | | 50,000 | | | | |

CONFIGURATION. 2 X 320 GAL WING TIP TANKS WEIGHT: 44,300 POUNDS

CONFIGURATION: 2 X 320 GAL WING TIP TANKS

WEIGHT: 39,800 POUNDS

| APPRO | KIMATE | CANADATANA | | PRESSURE | | | APPROX | IMATE |
|-------|--------|------------|-------|------------------|-------|-------------|--------|-------|
| %RPM | MI/LB | NO. | KNOTS | ALTITUDE FEET | KNOTS | MACH NO. | MI/ LB | %RPM |
| 81 | .0539 | . 43 | 282 | SEA LEVEL | 276 | . 42 | .0554 | 80 |
| 82 | .0606 | . 47 | 282 | 5,000 | 274 | . 45 | .0628 | 81 |
| 83 | .0685 | .51 | 282 | 10,000 | 270 | . 49 | .0712 | 82 |
| 84 | .0766 | . 55 | 279 | 15,000 | 267 | . 53 | .0802 | 83 |
| 85 | . 0860 | . 60 | 275 | 20,000 | 264 | .58 | .0904 | 84 |
| 86 | .0966 | . 65 | 268 | 25,000 | 259 | . 63 | .1019 | 85 |
| 88 | .1064 | . 69 | 258 | 30,000 | 250 | . 67 | . 1134 | 86 |
| 89 | .1150 | . 72 | 243 | 35,000 | 236 | . 71 | . 1252 | 87 |
| 94 | . 1199 | . 74 | 220 | 40,000 | 221 | . 74 | .1314 | 92 |
| | | | | 45,000 | | | | |
| | | | | 50,000 | | | | |

REMARKS:

CAS - CALIBRATED AIRSPEED KNOTS
MI/LB NAUT MILES PERPOUND

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

FUEL GRADE: JP-4 FUEL DENSITY:6.5 LB/GAL

STANDARD DAY

MODEL(S) B-57B

ZERO WIND

ENGINE(S): (ONE) J65-W-5

| APPRO | DXIMATE | 500 POUNI | 1 | | | | | |
|-----------------------------|---------|-------------|-------|--|---------|-------------|--|-------------|
| | ZAIMATE | MACH | CAS | PRESSURE | CAS | MACH | APPRO | DXIMATE |
| %RPM | MI/LB | NO. | KNOTS | ALTITUDE FEET | STOP S | NO. | ME/ | %RP |
| 86 | . 0675 | .37 | 248 | SEA LEVEL | | | | + |
| 87 | .0774 | . 40 | 241 | 5,000 | - | | A LED | |
| 87 | . 0868 | . 42 | 232 | 10,000 | | | | |
| 88 | . 0960 | . 45 | 224 | 15,000 | | | | |
| 90 | . 1055 | . 48 | 219 | 20,000 | | | - | - |
| 93 | . 1149 | . 53 | 216 | 25,000 | | | | |
| | - | | | 30,000 | | | | 1 |
| | | | | 35,000 | | | | |
| | | | | 40,000 | | | | |
| | | | | 45,000 | | | ST. 70 ST. 10 ST | - |
| | | | | 45,000 | | | | |
| ONFIGUR | RATION. | | | 50,000 | PATION: | | | |
| ONFIGUR EIGHT: APPRO) | | | | 50,000 CONFIGUR WEIGHT: | RATION: | 101.24 | APPRO. | XIMATE |
| EIGHT: | | MACH NO. | CAS | 50,000 CONFIGUR | RATION: | MACH NO. | APPRO: | Γ- |
| APPRO) | XIMATE | | CAS | CONFIGUR WEIGHT: PRESSURE ALTITUDE | 1 | | | XIMATE %RPM |
| APPRO) | XIMATE | | CAS | CONFIGUR WEIGHT: PRESSURE ALTITUDE FEET | 1 | | | |
| APPRO) | XIMATE | | CAS | CONFIGUR WEIGHT: PRESSURE ALTITUDE FEET | 1 | | | |
| APPRO) | XIMATE | | CAS | CONFIGUR WEIGHT: PRESSURE ALTITUDE FEET SEA LEVEL 5,000 | 1 | | | |
| APPRO) | XIMATE | | CAS | CONFIGUR WEIGHT: PRESSURE ALTITUDE FEET SEA LEVEL 5,000 10,000 | 1 | | | |
| APPRO) | XIMATE | | CAS | DRESSURE ALTITUDE FEET SEA LEVEL 5,000 10,000 15,000 | 1 | | | Γ- |
| APPRO) | XIMATE | | CAS | CONFIGUR WEIGHT: PRESSURE ALTITUDE FEET SEA LEVEL 5,000 10,000 15,000 20,000 | 1 | | | Γ- |
| APPRO) | XIMATE | | CAS | 50,000 CONFIGUR WEIGHT: PRESSURE ALTITUDE FEET SEA LEVEL 5,000 10,000 15,000 20,000 25,000 | 1 | | | Γ- |

REMARKS:

CAS - CALIBRATED AIRSPEED KNOTS
MI/LB NAUT MILES PER POUND

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

FUEL GRADE: JP-4 FUEL DENSITY: 6.5 LB/GAL

45,000 50,000

STANDARD DAY

MODEL(S) B-57B

ZERO WIND

ENGINE(S): (ONE) J65-W-5

CONFIGURATION. CLEAN 48,500 POUNDS

CONFIGURATION: CLEAN

WEIGHT:

44,000 POUNDS

| APPROXIMATE | | | | PRESSURE | 1200 | | APPROXIMATE | |
|-------------|--------|-------------|-------|------------------|-------|-------------|-------------|------|
| SRPM | MI/LB | MACH NO. | KNOTS | ALTITUDE FEET | KNOTS | MACH NO. | MVLB | %RPM |
| 92 | . 0573 | . 44 | 288 | SEA LEVEL | 280 | . 42 | .0598 | 90 |
| 93 | .0634 | . 46 | 282 | 5,000 | 273 | . 45 | . 0663 | 91 |
| 95 | .0690 | . 50 | 274 | 10,000 | 265 | . 48 | .0730 | 93 |
| | | | | 15,000 | 260 | .51 | . 0798 | 95 |
| | | | | 20,000 | | | | |
| | | | | 25,000 | | | | |
| | | | | 30,000 | | | | |
| | | | | 35,000 | | | | |
| | | | | 40,000 | | | | |
| | | | | 45,000 | | | | |
| | | | | 50,000 | | | | |

CONFIGURATION. CLEAN WEIGHT: 39,500 POUNDS

CONFIGURATION: CLEAN

35,000 POUNDS WEIGHT:


| APPROXIMATE | | IMATE | | PRESSURE | | 2000 | APPROXIMATE | |
|-------------|--------|-------------|-------|------------------|-------|-------------|-------------|------|
| SRPM | MI/ LB | MACH NO. | KNOTS | ALTITUDE FEET | KNOTS | MACH NO. | MVLB | %RPM |
| 89 | .0621 | . 41 | 269 | SEA LEVEL | 259 | .39 | .0648 | 88 |
| 90 | .0698 | . 43 | 263 | 5,000 | 252 | . 42 | .0734 | 88 |
| 91 | .0772 | . 46 | 255 | 10,000 | 244 | . 44 | .0816 | 89 |
| 93 | . 0847 | . 49 | 248 | 15,000 | 236 | . 47 | ,0900 | 91 |
| | | | | 20,000 | 230 | .51 | . 0982 | 93 |
| | | | | 25,000 | | | | |
| | | - V1 | | 30,000 | | | | |
| | | | | 35,000 | | | | |
| | | | | 40,000 | | | | |
| | | | | 45,000 | | | | |
| - | | | | 50,000 | | | | |

REMARKS:

CAS - CALIBRATED AIRSPEED KNOT'S MI/LB NAUT MILES PER POUNT

DATA AS OF: 1 OCTOBER 1953 DATA BASIS: ESTIMATE

FUEL GRADE: JP-4 FUEL DENSITY: 6.5 LB/GAL



| A | | Pag | e No. |
|--|--|--|-------|
| Pag | e No. | position indicator | 4-34 |
| IN THE SEC. S. | | switch | 4-32 |
| A-C Power System | 1-24 | Bomb Intervalometer | 4-36 |
| instrument inverter failure indicator lights | 1-25 | | 4-37 |
| instrument inverter switch | 1-25 | Bomb Indicator Lights Switch | |
| No. 1 and No. 2 inverter switches | 1-25 | Bomb Jettison Release | 4-38 |
| Acceleration Limitations | 5-7 | Bomb Loading Diagram | 4-33 |
| maximum acceleration | 5-7 | Bomb Release | 4-37 |
| Accelerometer | 1-39 | indicator lights | 4-37 |
| After Landing | 2-19 | Bomb Station Switches | 4-35 |
| After Take-off | 9-6 | Brake System | 1-38 |
| Air-conditioning and Pressurization System 4-1, | 200 | brake pressure gage | 1-38 |
| Airplane | 1-1 | failure | 3-23 |
| armament | 1-6 | parking brake lever | 1-38 |
| dimensions | 1-5 | | |
| | 2-2 | С | |
| entrance | 100 | C | |
| gross weight limitations | 5-7 | | |
| Airspeed and Altitude Calibration A-7. | | C-4A Lights | 4-19 |
| Airspeed Corrections | West Co. | controls | 4-20 |
| Airspeed Limitations | 5-4 | Cabin Pressurization and Heating | 4-1 |
| bomb door | 5-5 | air temperature rheostat | 4-4 |
| dive brake | 5-5 | control panel | 4-5 |
| in turbulent air | 9-16 | dump switch | 4-5 |
| landing gear extension speed | 5-4 | emergency operation | 4-5 |
| maximum allowable airspeeds with and without tip | | normal operation | 4-5 |
| tanks 5–5. | 5-6 | pressure-altitude indicator | 4-5 |
| wing flaps lowering speed | 5-5 | pressure schedule | 4-4 |
| Angle-of-Attack Relationship Curve 6-10, | 6-11 | | 4-4 |
| Approaching the Storm | | pressure selector switch | 4-4 |
| Armament Equipment | | temperature control switch | |
| bombing | | Canopy | 1-39 |
| control panel | | control switch 1–49, | |
| gunnery (Group A) | | jettison system | 1-39 |
| gunnery (Group B) | | lock warning lamp test switch | 1-50 |
| rocket equipment | 1-29 | release handles, emergency | 1-49 |
| Tocket equipment | 4-30 | seal | 1-49 |
| | | Cartridge Starter | 1-11 |
| В | | Center-of-Gravity Limitations 5-7, 5-9, 5-10, | 5-11 |
| | | Compartment Diagram | 1-5 |
| Bail-out | 3-12 | Chaff Dispenser | 4-16 |
| Battery | S 11.00 (S) | C-1282/ALE-1 control panels | 4-16 |
| switch | | normal operation | 4-18 |
| | | Check List of Emergency Procedures | 3-25 |
| Before Exterior Inspection | | | |
| Before Leaving Airplane | | Climb 2–14, 6–2, | |
| Before Take-off | | Climb Charts A-12 through | |
| Before Starting Engines | | Cold-Weather Landing Procedures | 9-5 |
| Before Taxiing | The state of the s | Communications and Associated Electronic Equipment | 4-8 |
| Bomb Arming Switch | 4-36 | Combat Allowance Chart | A-32 |
| Bomb and External Stores Jettison | 7// | Compartment Dome Lights | 4-20 |
| Bomb and Rocket Release Button | | | |
| Bombing Controls | 42 March 1 | Compressibility Correction Table | |
| Bomb Door | | Compressor Stall | 7-1 |
| emergency open handle | 4-34 | Control Column Stowage | 1-50 |
| ground shut-off valve | 4-34 | Control Locks | 1-31 |
| personnel safety switch | 4-34 | Control Wheel and Column | 1-32 |
| | | | |

| U | | | |
|--|----------|--|--|
| Pag | e No. | Page | e No. |
| | | | |
| Danger Areas | 2-9 | Ferry Tank Boost Pump Switch | 1-19 |
| D-C Power System | 1-20 | Ferry Tank Fill Switches | 1-18 |
| Defogging | | Fire and Overheat Detection System 1-53, | 1-54 |
| Descents 9-2 | | lamp test switch, indicator | 1-54 |
| Descent Charts | | test switch, detection | 1-54 |
| - 프라이트 전에 없었다. (1955년 1972년 1일 전 1955년 1957년 1957년 | | Fire Extinguishing System | 1-54 |
| Desert Procedures | 10 00000 | agent discharge switch | 1-55 |
| Ditching | | | 0 0 0 |
| Dive Brakes | 1-35 | pull-to-arm knobs | 1-55 |
| Dive Recovery 6-8, | 6-9 | Flap and Trim Control Panel | 1-34 |
| Dual-Engine Air Start Procedure | 3-4 | Flight Characteristics | 6-1 |
| Dual-Engine Failure | 3-4 | acceleration and deceleration | 6-6 |
| Dual-Engine Flame-out Pattern | | climb | 6-2 |
| Duar Engine Traine-out Pattern | / | cruise performance | 6-2 |
| | | dives | 6-10 |
| E | | dive brakes | 6-6 |
| All divining to the second sec | | | The state of the s |
| ng : w: 15 | | high-speed characteristics | 6-5 |
| Effective Wind Data | | landing | 6-10 |
| Ejection Procedure | | low-speed characteristics | 6-7 |
| Ejection Seats 1-50, | 1-51 | maneuvering flight | 6-3 |
| adjustment lever | 1-53 | one engine inoperative | 3-2 |
| safety pins | 2-2 | rotary bomb carrier | 6-6 |
| Electrical Fire | | spins | 6-6 |
| Electrical Power Supply System 1–20, 1–22, | | stalls | 6-7 |
| | 4 4 4 | | 100000000000000000000000000000000000000 |
| a-c power system | 1-24 | stick forces | |
| battery | 1-20 | take-off | 6–2 |
| d-c power system | 1-20 | Flight Controls System | 1-30 |
| failure 3–18, | 3-20 | Aileron control system | 1-32 |
| generator | 1-21 | Elevator control system | 1-32 |
| Elimination of Smoke or Fumes | 3-9 | Flight Operation Instruction Charts A-39 through | 70136 |
| Emergency Bomb Door Operation | | Free Air Temperature Correction Table | |
| | | Fuel-Flow Indicator | |
| Emergency Entrance | | | _ |
| Emergency Equipment 1–39, | 3-24 | Fuel Management | 7-3 |
| Emergency Fuel Control Switches | 1-9 | Fuel Panels | 1-17 |
| Emergency Fuel System Test | 2-13 | Fuel Pressure Warning Light | 1-16 |
| Emergency Procedures | 3-1 | Fuel Quantity Data | 1-16 |
| Engines 1-6, | 7-1 | Fuel Quantity Indicator | 1-18 |
| acceleration | 7-1 | Fuel Quantity Selector Switch | 1-18 |
| air start | 3-3 | Fuel Specification | |
| cooling system | | Fuel System and Controls 1-12, 1-14, | |
| | 7 2 | ruer system and controls 1-12, 1-14, | 1-13 |
| exhaust temperature variation | 7-2 | G | |
| failure | 3-2 | 9 | |
| false start | 2-11 | General Arrangement Diagram | 1-2 |
| flame-out | 3-2 | Generator: | |
| fuel control unit | 1-7 | control panel 1-21, | 1_21 |
| hot start | 2-11 | indicator lights | |
| indicators, exhaust temperature | 1-20 | | 1-24 |
| | 1-20 | loadmeters | 5 3 3 |
| limitations | 5-1 | regulator panels | 1-21 |
| noise and roughness | | voltmeter | 1-24 |
| | 7-2 | voltmeter selector switch | 1-24 |
| overheat condition | 3–9 | Glare Shade | 1-50 |
| smoke from turbine during shut-down | 7-2 | Ground Controlled Approach 9-3, | 9-13 |
| starter over-pressure protection | 1-12 | Gunnery Equipment, 50-caliber (Group A) | 4-27 |
| starting with external power | 2-10 | firing | 4-31 |
| tachometer | 1-20 | | |
| temperature and power limits | 5-4 | gun-firing trigger | 4-29 |
| Engine Failure | 3-2 | gun-heater switch | 4-29 |
| during take-off | | master guns switch | 4-29 |
| | 3-3 | pneumatic gun-charging system | 4-28 |
| fuel control system | 3–16 | Gunnery Equipment, M39, 20-millimeter (Group B) | 4-29 |
| in flight | | firing | 4-31 |
| Engine Fire | | gun firing trigger | 4-29 |
| Engine Fuel System 1-17, | | gun heater switch | 4-29 |
| Entrance | | | 75 722 |
| Exterior Inspection Diagram | 2-4 | gun limitations | 5-6 |
| External Hudeaulia Hand Dans | | gunsight 4–29, | CONCERNATION OF |
| External Hydraulic Hand Pump 1-28, | | master guns switch | 4-29 |
| External Power Receptacle 1-20, | 1-21 | 11 | |
| External Stores | 3-18 | H | |
| indicator lights | 4-37 | High-Speed Flight Characteristics | 6 - |
| switches | 1 | Holmot Dolog Phones | 0-5 |
| 3 | 4-36 | Helmet Defog Rheostat | 4-8 |

| H (Cont) | | Page | e No. |
|--|--------------|--|-------------|
| 2007A N | e No. | Left Handgrip | 1-52 |
| Horizontal stabilizer emergency switch 1-32A, | 1 22 | Lighting Equipment | 4-18 |
| Rudder control system | 1-30 | navigation lights | 4-18 |
| No. 1 fuselage tank low-level warning light | 1-13 | observer's console and instrument lights | 4-19 |
| Horizontal Stabilizer Position Indicator 1-32A, | 1-33 | observer's red and white floodlights | 4-19 |
| Horizontal Stabilizer Malfunction | | observer's spotlight | 4-19 |
| Hot-Weather Procedures | | pilot's auxiliary lighting control panel | 4-19 |
| Hydraulic System | | pilot's lighting control panel | 4-18 |
| failure ground shut-off valve | | pilot's red and white floodlights | 4-19 |
| hand pump | | standby compass light switch | 4-26 |
| pressure gage | | taxi lights | 4-20 |
| | | taxi lights switch | 4-21 |
| the manufactured by the second by | | warning lights | 4-21 |
| Ice, Snow, and Rain | 9-3 | alternate operation | 4-41 |
| IFF Radar Set AN/APX-6A | 4-13 | control panel | 4-40 |
| control panel | 4-13 | indicator | 4-40 |
| master switch | | normal operation | 4-41 |
| In-Flight Range Planning | | Low-Speed Characteristics | 6-7 |
| Inspection | | | |
| Instrument Flight Procedures | | M | |
| Instrument Loitering and Holding | | M3, 50Caliber Guns | 4-31 |
| Instrument Markings 5-2 | | M39, 20-Millimeter Guns | 4-31 |
| Instrument Panel Vibrators | | MA-2 Low Altitude Bombing System | 4-40 |
| Intercommunications Set AN/AIC-10 | 1-38 4-8 | MA-3 or MA-4 seat safety belt 1-52A, 1-53 | |
| control panel | | MA-5 or MA-6 seat safety belt 1-52B, 1-53 Machmeter | 1-38 |
| filter | | Main Differences Table | 1-4 |
| mixing switches, audio | | Main Landing Gear Emergency Extension | 3-23 |
| III EU | | Maneuvering Flight | 6-3 |
| J | | Marker Beacon AN/ARN-12 | 4-13 |
| J-2 Compass System | 4-25 | radar warning switch | 4-13 |
| emergency operation | 4-26 | Master Guns Switch | 4-29 |
| indicators | 4-26 | Maximum Allowable Airspeeds | 5-5 |
| normal operation | | with tip tanks | 5-5 |
| indicators | | without tip tanks | 5-6 |
| Jet Penetration (ADF to GCA) Pattern Jet Penetration to Radio Range | 9-12 9-11 | Maximum Continuous Power A-33 through | |
| just renetration to stands stange | | Maximum Endurance Charts A-26 through | |
| K | | Maximum Glide Maximum Range Summary | 3-5 A-5 |
| The state of the s | | Minimum Crew Requirements | |
| The contract of the state of th | | Miscellaneous Equipment | |
| Landing Distances | A-25 | District Control of the Control of t | |
| Landing Gear System | | Hali alia in to analytik Na ana-makusa ma'u | |
| control lever | 1-35 | Notice to Project | 1 25 |
| emergency down handles | 1-36 | Navigation Equipment J-2 compass system | 4-25 |
| failure lock pins | 3-23 1-37 | latitude and longitude computer set AN/ASN-6 | 4-26 |
| position indicator | 1-38 | navigation light | 4-18 |
| warning horn | 1-36 | radio compass set AN/ARN-6 | 4-11 |
| warning horn release | 1-37 | Night Flying | 9-5 |
| warning light | 1-37 | Normal External Stores Release | 4-36 |
| warning light test switch | 1-38 | Normal Procedures | 4-37 2-1 |
| Landing Light extension limitation | | No. 1 or No. 2 Fuselage Tank Boost Pump Failure | 3-16 |
| switches | 4-21 | No. 1 or No. 2 Inverter Failure | 3-21 |
| Landing Pattern 2-16, | 2-17 | No. 1 Fuselage Tank Boost Pump Light | 1-13 |
| Landing Procedures | 2-18 | No. 2 Fuselage Tank Knob | 1-16 |
| both engines inoperative | 3-6 | Nose Landing Gear Emergency Extension | 3-23 |
| cold-weather descent | 9-5 | 0 | |
| desert | 5-7 9-8 | Maria de la companya della companya | |
| flaps up | 3-15 | Observer's Check List | 8-2 |
| hot-weather | 9-7 | Observer's Left Console | |
| one engine inoperative | 3-6 | Observer's Lighting Control Panel | |
| one main gear up or unlocked | 3-6 | Observer's Responsibilities | |
| Latitude and Longitude Set AN/ASN6 | 4–26 | Observer's Right Console and Instrument Panel 4-43. | 4-44 |

| O (Cont) | | Pag | e INO. |
|--|--------|--|---------------|
| Pag | ge No. | Rotary Bomb Carrier | 6-6 |
| Observed Con Firming | 2 12 | Rudder | |
| Observer's Seat Ejection | 3-13 | pedals and adjustment knob | 1_34 |
| Oil System | 1-12 | trim switch and indicator light | 1 2/ |
| pressure indicator | 1-20 | trini switch and indicator light | 1-34 |
| quantity data | 1-12 | | |
| Oxygen Hose Hookup | 4-25 | S S | |
| Oxygen System | 4-21 | The same of the sa | |
| operation, normal and emergency | 4-24 | S-4 Shoran System | 4-16 |
| oxygen duration table | 4-22 | comparator | 4-16 |
| oxygen pressure gage and flow indicator | 4-23 | computer unit | 4-16 |
| oxygen quantity gage | 4-24 | miles-to-release indicator | 4-16 |
| oxygen regulator diluter lever | 4-22 | position deviation indicator | 4-16 |
| oxygen regulator emergency pressure lever | 4-23 | range indicator | 4-16 |
| system blow-back test | 4-24 | Seat Adjustment Lever | 1-53 |
| System Did with Back took | 1-21 | Seat Safety Pins | 2-2 |
| | | Select Armament Control Panel | 4-38 |
| P | | | |
| | | Shoran Bomb Release | 4-38 |
| Parking Brake Lever | 1-38 | Shoulder Harness | 1-50 |
| Partial Power | 3-5 | Single Engine GCA Patterns | 9-14 |
| Performance Data | A-1 | Single Engine Go-Around | 3–8 |
| Personnel Equipment Requirements | 8-2 | Smoke Release | 4-38 |
| Personnel Safety Switch | 4-34 | Stalls | 6-7 |
| Pilot's Auxiliary Lighting Control Panel | 4-20 | accelerated | 6-10 |
| Pilot's Console and Instrument Lights | 4-19 | practice | 6-10 |
| Pilot's Left Console 1-45, 1-46, 1-47, | 1-48 | with gear and flaps extended | 6-10 |
| Pilot's Lighting Control Panel | 4_18 | with gear and flaps retracted | 6-7 |
| Pilot's Red and White Floodlights | 4-19 | Stall Speed Chart | 6-7 |
| Pilot's Responsibilities | 8-1 | Standby Compass | 4-26 |
| | | Starter and Ignition System | 1-10 |
| Pilot's Right Console 1-41, 1-42, 1-43 | 1-44 | Starting Engines | 2-10 |
| Pilot's Seat Ejection | | Stick Forces | |
| Pitot Static System | | Stopping Engines | 2-19 |
| Preflight Airplane Check | 2-12 | Stopping Engines | 2-19 |
| Preflight Engine Check | 2-12 | | |
| Pressure Demand Oxygen Regulators 4-21 | | the control of the co | |
| Procedures When Encountering Engine Failure | 3-2 | | |
| Prohibited Maneuvers | 5-7 | Table of Communication and Associated Electronic | |
| | | Equipment | 48 |
| 0 | | Tachometer | 1-20 |
| φ | | Take-off | 2-13 |
| H-A deposit that | | Taxiing | 2-12 |
| | | Taxi Lights | 4-20 |
| R | | Temperature and Power Limits | 5-4 |
| | | Throttles | 1-7 |
| Radar Receiving Set AN/APS-54 4-14 | | Tip Tank Fuel System Failure | 3-17 |
| computer controls 4-27 | | Tip Tank Jettison | 3-17 |
| Radar Recovery | 9-3 | switch | Charles Shirt |
| Radar Set AN/APW-11A with AN/APA-90 4-14 | 4-15 | Torque Tube and Blowback Rod | 1-18 |
| Radio Compass AN/ARN-6 4-12 | 4-11 | | 1-31 |
| band selector knob | 4-11 | Touch-and-Go Landings | 2-18 |
| controls | 4-11 | Traffic Pattern Check | 2-15 |
| c-w voice switch | 4-12 | Turns | 9-2 |
| function control | 4-11 | | |
| indicators | 4-12 | U | |
| loop rotator switch | 4-12 | | |
| | | | |
| normal operation | 4-12 | V | |
| tuner-adf | 4-12 | | |
| tuning crank | 4-11 | Voltmeter | 1-24 |
| volume control | 4–12 | | |
| Radio Range and Jet Penetration | | W | |
| Radio Set AN/ARC-27 4-10 | , 4–11 | VV | |
| emergency operation | 4-11 | Warning Lights | 6 21 |
| normal operation | 4-10 | | 4-21 |
| Release and Jettison Airspeeds for External Stores | 5-6 | Weight and Balance | 2-2 |
| Release and Jettison Airspeeds for Internal Stores | 5-6 | Windshield: | , , |
| Right Handgrip | 1-52 | anti icing system | 4-6 |
| Rockets: | | control panel | 4-7 |
| controls | 4-38 | wiper | 4-41 |
| firing order | 4-39 | Windshield and Canopy Defogging | 4-6 |
| intervalometer | | hot air switch | 4-6 |
| jettison release | | Wing Fire | 2 0 |
| jettison release | 4-411 | WINE THE | 3-9 |

W (Cont)

| | Page |
|--------------------------|------|
| Wing Flaps | 1-34 |
| Wing-Tank—Tip-Tank Knobs | 1 10 |
| | 1-10 |

X

Υ

Z