
FAQ VITO charger for battery 18V

Explanation of symbols:



- Ready to change
- Delay charge (battery too hot or cold)
- Fast charging active
- Battery half charged
- Charging complete + melody
- Conditioning
- Battery defective
- Cooling abnormality

Malfunction/Indication	Possible cause	Remedy
Green LED flashes	• Charger is ready to charge • No battery placed • Battery placed incorrectly	• Place battery in the charger correctly
Red LED flashes	• Delay of charge due to a hot or cold battery	• Leave the battery in place • Active cooling cools/heats the battery
The red LED stays on and a melody plays	• Charging has started • Battery is charging	• Leave the battery in place
The red and green LEDs stay on	• Battery is charging	• Leave the battery in place
The green LED stays on and a melody plays	• Battery is fully charged	• Remove the battery from the charger
The red and green LEDs flash alternately	• Charger contacts are dirty • Battery contacts are dirty • Battery defective	• Clean the charger contacts • Clean the battery contacts • Replace the battery • Contact VITO Customer Service
Orange LED is lit	• Charging the battery at a high temperature	• Leave the battery plugged in • Charging takes longer than usual

FAQ VITO charger for battery 18V

	• Nachladen des Akkus bei niedriger Temperatur • Charging the battery at a low temperature • Charging a fully charged battery • Excessive discharge of a battery	
Orange LED is flashing	• Cooling malfunction • Inadequate battery cooling	• Keep the charger's ventilation openings clear • Check the operating noise of the active cooling system and contact VITO Customer Service if necessary • Clean the ventilation openings • The battery can still be charged—but the charging process will take longer than usual • If the orange light comes on frequently, contact VITO Customer Service